



1. max. supply voltage is 5 VDC
2. connect +5V (J4:2) to 3.3 VDC supply on BTT SKR 1.4 Turbo
3. MARLIN: use TEMP_SENSOR_X 20 in config.h for accurate temp reading

Sheet: /

File: SKR14_PT100_Amp.sch by Le_Bassiste, 2020

Title:

Size: A4

Date:

KiCad E.D.A. kicad (5.1.5)-3

Rev:

Id: 1/1