

## **SECTION 23 05 48 – VIBRATION CONTROLS FOR HVAC PIPING**

### **PART 1 - GENERAL**

#### **1.1 SUMMARY**

- A. This Section includes the following:
  - 1. Isolation mounts.
  - 2. Freestanding spring isolators.
  - 3. Housed spring mounts.
  - 4. Spring hangers.
  - 5. Restrained vibration isolation roof-curb rails.
  - 6. Steel vibration isolation equipment bases.

#### **1.2 DEFINITIONS**

- A. IBC: International Building Code.
- B. ICC-ES: ICC-Evaluation Service.

#### **1.3 PERFORMANCE REQUIREMENTS**

- A. Wind-Restraint Loading:
  - 1. Refer to Structural Drawings.
- B. Seismic-Restraint Loading:
  - 1. Refer to Structural Drawings.

#### **1.4 ACTION SUBMITTALS**

- A. Product Data: For the following:
  - 1. Include rated load, rated deflection, and overload capacity for each vibration isolation device.
  - 2. Illustrate and indicate style, material, strength, fastening provision, and finish for each type and size of seismic-restraint component used.
- B. Vibration Isolation Base Details: Detail overall dimensions, including anchorages and attachments to structure and to supported equipment. Include auxiliary motor slides and rails, base weights, equipment static loads, power transmission, component misalignment, and cantilever loads.

## PART 2 - PRODUCTS

### 2.1 VIBRATION ISOLATORS

- A. Manufacturers: Subject to compliance with requirements, provide products by one of the following:
  - 1. Amber/Booth Company, Inc.
  - 2. Kinetics Noise Control.
  - 3. Mason Industries.
  - 4. Vibration Mountings & Controls, Inc.
- B. Mounts: Double-deflection type, with molded, oil-resistant rubber, hermetically sealed compressed fiberglass, or neoprene isolator elements with factory-drilled, encapsulated top plate for bolting to equipment and with baseplate for bolting to structure. Color-code or otherwise identify to indicate capacity range.
  - 1. Materials: Cast-ductile-iron or welded steel housing containing two separate and opposing, oil-resistant rubber or neoprene elements that prevent central threaded element and attachment hardware from contacting the housing during normal operation.
  - 2. Neoprene: Shock-absorbing materials compounded according to the standard for bridge-bearing neoprene as defined by AASHTO.
- C. Spring Isolators: Freestanding, laterally stable, open-spring isolators.
  - 1. Outside Spring Diameter: Not less than 80 percent of the compressed height of the spring at rated load.
  - 2. Minimum Additional Travel: 50 percent of the required deflection at rated load.
  - 3. Lateral Stiffness: More than 80 percent of rated vertical stiffness.
  - 4. Overload Capacity: Support 200 percent of rated load, fully compressed, without deformation or failure.
  - 5. Baseplates: Factory drilled for bolting to structure and bonded to 1/4-inch- thick, rubber isolator pad attached to baseplate underside. Baseplates shall limit floor load to 500 psig (3447 kPa).
  - 6. Top Plate and Adjustment Bolt: Threaded top plate with adjustment bolt and cap screw to fasten and level equipment.
- D. Housed Spring Mounts: Housed spring isolator with integral seismic snubbers.
  - 1. Housing: Ductile-iron or steel housing to provide all-directional seismic restraint.
  - 2. Base: Factory drilled for bolting to structure.
  - 3. Snubbers: Vertically adjustable to allow a maximum of 1/4-inch travel up or down before contacting a resilient collar.
- E. Spring Hangers: Combination coil-spring and elastomeric-insert hanger with spring and insert in compression.

1. Frame: Steel, fabricated for connection to threaded hanger rods and to allow for a maximum of 30 degrees of angular hanger-rod misalignment without binding or reducing isolation efficiency.
2. Outside Spring Diameter: Not less than 80 percent of the compressed height of the spring at rated load.
3. Minimum Additional Travel: 50 percent of the required deflection at rated load.
4. Lateral Stiffness: More than 80 percent of rated vertical stiffness.
5. Overload Capacity: Support 200 percent of rated load, fully compressed, without deformation or failure.
6. Elastomeric Element: Molded, oil-resistant rubber or neoprene. Steel-washer-reinforced cup to support spring and bushing projecting through bottom of frame.
7. Self-centering hanger rod cap to ensure concentricity between hanger rod and support spring coil.

## **2.2 VIBRATION ISOLATION EQUIPMENT BASES**

- A. Manufacturers: Subject to compliance with requirements, provide products by one of the following:
  1. Amber/Booth Company, Inc.
  2. Kinetics Noise Control.
  3. Mason Industries.
  4. Vibration Mountings & Controls, Inc.
- B. Steel Base: Factory-fabricated, welded, structural-steel bases and rails.
  1. Design Requirements: Lowest possible mounting height with not less than 1-inch clearance above the floor. Include equipment anchor bolts and auxiliary motor slide bases or rails.
    - a. Include supports for suction and discharge elbows for pumps.
  2. Structural Steel: Steel shapes, plates, and bars complying with ASTM A 36/A 36M. Bases shall have shape to accommodate supported equipment.
  3. Support Brackets: Factory-welded steel brackets on frame for outrigger isolation mountings and to provide for anchor bolts and equipment support.

## **2.3 FACTORY FINISHES**

- A. Finish: Manufacturer's standard prime-coat finish ready for field painting.

## **PART 3 - EXECUTION**

### **3.1 EXAMINATION**

- A. Unless otherwise noted, provide vibration isolation on all mechanical equipment consistent with 2019 ASHRAE Handbook- HVAC Applications, Chapter 49, Table 47.

- B. Examine roughing-in of reinforcement and cast-in-place anchors to verify actual locations before installation.
- C. Proceed with installation only after unsatisfactory conditions have been corrected.

### **3.2 FIELD QUALITY CONTROL**

- A. Perform tests and inspections.
- B. Remove and replace malfunctioning units and retest as specified above.
- C. Prepare test and inspection reports.

### **3.3 ADJUSTING**

- A. Adjust isolators after piping system is at operating weight.
- B. Adjust limit stops on restrained spring isolators to mount equipment at normal operating height. After equipment installation is complete, adjust limit stops so they are out of contact during normal operation.
- C. Adjust active height of spring isolators.
- D. Adjust restraints to permit free movement of equipment within normal mode of operation.

### **END OF SECTION**