

# *Sparton Navigation Modules*

*Software Interface User's Manual*

*Applicable to Sparton GEDC-6 and DC-4 and AHRS-8.*



## REVISION HISTORY:

DATE	DESCRIPTION OF CHANGE	INITIALS
5/11/11	Original	CMN
9/22/11	Re-factored, NorthTek Moved to standalone document.	CMN
10/5/11	Review comments finalized.	CMN
10/25/11	Added PN, additional tuning variables documented.	CMN
9/24/12	Rev. B – Add AHRS-8 and make corrections	MJB

## Table of Contents

1	Introduction.....	9
1.1	Scope .....	9
1.2	References.....	9
1.3	Document Conventions.....	9
1.4	Applicability .....	10
2	Overview .....	10
2.1	Protocol Introduction .....	10
2.2	Interface Paradigm .....	11
2.3	Data Organization.....	11
2.3.1	Basic Data Types.....	11
2.3.2	RFS BitFields .....	12
2.4	User Accessible NavMod Variables .....	12
2.4.1	Variable Summary Table .....	13
2.5	World Magnetic Model .....	16
2.6	Low power mode.....	16
3	Protocols.....	17
3.1	RFS .....	17
3.2	NMEA.....	19
3.2.1	Raw Magnetics .....	20
3.2.2	Heading - Magnetic .....	20
3.2.3	Heading - TRUE .....	21
3.2.4	Magnetic Variation .....	21
3.2.5	Automatic Magnetic Variation .....	21
3.2.6	Magnetic Vector .....	22
3.2.7	Magnetic Field Calibration .....	23
3.2.8	Gyro Calibration .....	25
3.2.9	Magnetic Adaption Error.....	25
3.2.10	Raw Acceleration.....	26
3.2.11	Acceleration Vector .....	26
3.2.12	Raw Gyro .....	26
3.2.13	Gyro Vector .....	27

3.2.14	Pitch and Roll Output .....	27
3.2.15	Quaternion Vector.....	27
3.2.16	Temperature.....	28
3.2.17	BAUD RATE .....	28
3.2.18	Mounting Configuration .....	29
3.2.19	Read Transducers .....	29
3.2.20	NMEA RFS Access .....	30
3.2.21	NMEA/RFS RPT and GLOM .....	31
3.3	Legacy Binary .....	32
3.3.1	Raw Magnetics .....	32
3.3.2	Heading - TRUE .....	32
3.3.3	Heading - Magnetic .....	33
3.3.4	Magnetic variation .....	33
3.3.5	Automatic Magnetic Variation .....	33
3.3.6	Latitude.....	34
3.3.7	Longitude.....	34
3.3.8	Altitude .....	35
3.3.9	Day.....	35
3.3.10	Magnetic Vector .....	36
3.3.11	Magnetic calibration.....	36
3.3.12	Magnetic Adaption Error .....	36
3.3.13	Raw Acceleration.....	37
3.3.14	Pitch and Roll Output .....	37
3.3.15	Acceleration Vector.....	37
3.3.16	Temperature.....	38
3.3.17	BAUD RATE .....	38
3.3.18	Mounting Configuration .....	39
3.4	NorthTek.....	40
3.4.1	Displaying Database Elements .....	40
3.4.2	Outputting values in User Defined Format .....	42
3.4.3	Streaming Sensor Data .....	42
3.4.3.1	Accelerometer .....	43

3.4.3.2	Gyro .....	43
3.4.3.3	Magnetometer .....	43
3.4.3.4	All raw sensor data .....	44
3.4.3.5	Computed Roll, Pitch and Yaw .....	44
3.4.3.6	Computed Quaternions .....	44
3.4.3.7	Custom Combination Print Streaming (AHRS-8 only) .....	44
3.4.4	Reset .....	47
3.4.5	Setting Database Elements.....	47
3.4.6	Calibration Data Control.....	47
3.4.6.1	Restore In-field calibration data .....	47
3.4.6.2	Restore Factory calibration data .....	48
3.4.6.3	Run the Gyro Offset Calibration .....	48
3.4.7	3D Compass Calibration .....	48
A	Variable Detailed Descriptions .....	50
A.1	Variables by Name.....	50
A.1.1	vidCount .....	50
A.1.2	name .....	50
A.1.3	quiet .....	50
A.1.4	VERSION .....	50
A.1.5	REVISION .....	50
A.1.6	serialnumber .....	51
A.1.7	orientation.....	51
A.1.8	baud.....	51
A.1.9	pitch.....	52
A.1.10	roll.....	52
A.1.11	yaw .....	52
A.1.12	yawt.....	52
A.1.13	quaternion .....	52
A.1.14	lat.....	53
A.1.15	lonG .....	53
A.1.16	alt.....	53
A.1.17	day.....	53

A.1.18	restorefactorycal .....	53
A.1.19	set_wmm .....	54
A.1.20	magvar .....	54
A.1.21	wmmGD.....	54
A.1.22	wmmHasRun .....	54
A.1.23	magr.....	54
A.1.24	magp .....	55
A.1.25	accelr .....	55
A.1.26	accelp.....	55
A.1.27	gyror .....	55
A.1.28	gyrop.....	55
A.1.29	gyroSampleRate .....	56
A.1.30	positionrate .....	56
A.1.31	position.....	56
A.1.32	composite2.....	56
A.1.33	composite3.....	57
A.1.34	calmode .....	57
A.1.35	calCommand.....	57
A.1.36	calNumPoints .....	57
A.1.37	magErr .....	58
1.1.38	wlim .....	58
1.1.39	alim .....	58
1.1.40	mlim.....	58
1.1.41	km0.....	59
1.1.42	ka0 .....	59
1.1.43	emlim.....	59
1.1.44	ealim .....	59
1.1.45	kgyrooffset .....	60
A.1.46	magOffset .....	60
A.1.47	tempCalOffset .....	60
A.1.48	magCalTemperature.....	60

A.1.49	magOffsetCorrectionXPlus ,magOffsetCorrectionYPlus, magOffsetCorrectionZPlus, magOffsetCorrectionXNeg, magOffsetCorrectionYNeg, magOffsetCorrectionZNeg .....	61
A.1.50	magOffsetTCX, magOffsetTCY, magOffsetTCZ .....	61
A.1.51	magLinearityXPlus ,magLinearityYPlus, magLinearityZPlus, magLinearityXNeg, magLinearityYNeg, magLinearityZNeg .....	61
A.1.52	magLinearityXTC0 ,magLinearityXTC1, magLinearityXTC2, magLinearityYTC0, magLinearityYTC1, magLinearityYTC2, magLinearityZTC0, magLinearityZTC1, magLinearityZTC2 .....	61
A.1.53	magLinearityX ,magLinearityY, magLinearityZ .....	62
A.1.54	magCrossAxisCorrectionX, magCrossAxisCorrectionY, magCrossAxisCorrectionZ .....	62
A.1.55	magFieldCalX, magFieldCalY, magFieldCalZ .....	62
A.1.56	accelrange .....	62
A.1.57	accelOffset.....	63
A.1.58	accelGyroCalTemperature.....	63
A.1.59	accelOffsetTCX, accelOffsetTCY, accelOffsetTCZ.....	63
A.1.60	accelLinearityXPlus ,accelLinearityYPlus, accelLinearityZPlus, accelLinearityXNeg, accelLinearityXPlus, accelLinearityYPlus , accelLinearityZPlus, accelLinearityXNeg , accelLinearityYNeg, accelLinearityZNeg.....	63
A.1.61	accelLinearityXTC0, accelLinearityXTC1 , accelLinearityXTC2, accelLinearityYTC0, accelLinearityYTC1, accelLinearityYTC2, accelLinearityZTC0, accelLinearityZTC1, accelLinearityZTC2.....	64
A.1.62	accelLinearityX ,accelLinearityY, accelLinearityZ.....	64
A.1.63	accelCrossAxisCorrectionX, accelCrossAxisCorrectionY , accelCrossAxisCorrectionZ.....	64
A.1.64	gyroOffset.....	65
1.1.65	gyroMaxRate .....	65
1.1.66	gyroMaxReturnCnt .....	65
A.1.67	gyroOffsetTCX, gyroOffsetTCY, gyroOffsetTCZ.....	65
A.1.68	gyroLinearityXPlus, gyroLinearityYPlus , gyroLinearityZPlus, gyroLinearityXNeg , gyroLinearityYNeg, gyroLinearityZNeg.....	65
A.1.69	gyroLinearityXTC0, gyroLinearityXTC1 , gyroLinearityXTC2, gyroLinearityYTC0 , gyroLinearityYTC1, gyroLinearityYTC2, gyroLinearityZTC0, gyroLinearityZTC1, gyroLinearityZTC2 .....	66
A.1.70	gyroLinearityX, gyroLinearityY, gyroLinearityZ.....	66
A.1.71	gyroFieldCalX, gyroFieldCalY , gyroFieldCalZ.....	66
A.1.72	gyroCrossAxisCorrectionX, gyroCrossAxisCorrectionY, gyroCrossAxisCorrectionZ.....	66
A.1.73	InvokeGyroOffsetCal .....	67

A.1.74	boresightMatrixX, boresightMatrixY , boresightMatrixZ .....	67
A.1.75	lowpower.....	67
A.1.76	temperature .....	67
A.1.77	temperatureOffset .....	67
A.1.78	temperatureSlope .....	68
A.1.79	temperatureWrapDivider.....	68
A.1.80	kgyroOffsetCalFactor.....	68
A.1.81	nmeaecho.....	68
A.1.82	nmeaignorechecksum .....	68
A.1.83	restoreFieldCal .....	69
A.1.84	pMatrix0, pMatrix1, pMatrix2.....	69
A.1.85	printmask.....	69
A.1.86	printtrigger .....	69
A.1.87	printmodulus .....	69
B	Troubleshooting .....	70
B.1	NMEA commands are not echoed. ....	70
B.2	NMEA commands don't respond to "enter" key. ....	70
B.3	Repeating output is not appearing.....	70
B.4	Repeating output is making typing a new command difficult. ....	70
B.5	The compass is providing an inaccurate heading:.....	70
B.6	The compass does not output any response. ....	70



## 1 Introduction

This is an interface document. It describes how to communicate with, control and obtain sensor, status and configuration data from the Sparton family of Attitude and Heading Reference (AHRS) products. This document is intended for system engineers, systems integrators or software developers that need to know how to communicate with, utilize and obtain measurements from a Sparton AHRS product. This document applies to the AHRS-8, GEDC-6 and DC-4 devices. In this document, these devices will be referred to as Navigational Modules (NavMods) and all references shall apply to all devices except where noted.

### 1.1 Scope

This document covers the following topics:

- Low level communications interfaces at the software level
- Packet level communications protocol
- Applications layer functions and the relevance to the function of the NavMod
- Examples of commands for user purposes

This document is not a hardware or mechanical data sheet.

### 1.2 References

This document is an umbrella document in that some of the interface descriptions for the NavMods are described in external documentation. This document describes the relationship of these documents. The additional documentation needed to complete the entire interface description for the NavMod family is listed below.

- *NorthTek System, Programming Manual*
- *Remote Function Select (RFS) Protocol Suite, Interface Design Description*

### 1.3 Document Conventions

Descriptive text in this document appears in this font (Calibri 11).

Data sent transmitted to the NavMod appears in *this font (Courier 11, Bold Italic)*.

Data sent from the NavMod appears in **this font (Courier 11, Bold, grey background)**.

Information that must be supplied in this spot is enclosed in <> pairs. The <contents> brace pair should be replaced with the user supplied data or will be filled in by the NavMod according to the description contained in the <>'s.

- A carriage return character is shown as <CR> or <cr>.
- A line feed character is shown as <LF> or <lf>.
- Control sequences are indicated as <CTRL-S>.

Non printable characters are spelled out in <> pairs, for example <ESCAPE> is equal to the escape character (0x1b). Additional text will included when non-printable characters might not be clear to the reader.

## 1.4 Applicability

This document applies to the Sparton AHRS-8, GEDC-6 and DC-4 Digital Compasses. All portions of this document that refer to gyro functionality only apply to the AHRS-8 and GEDC-6.

# 2 Overview

## 2.1 Protocol Introduction

The interface to the NavMod is a serial communication link (User Port). The link is an asynchronous character oriented interface that operates in a bidirectional mode. This serial link transmits and receives asynchronous characters using nominal "UART" type framing with 8 data bits, no parity and a single stop bit, with a default baud rate of 115200. The baud rate may be changed by software command. No error detection is used with the individual characters.

The serial link is full-duplex; however in practice the information flow is largely half-duplex in nature. Essentially the client and the server operate in a poll-response fashion. For example, in the above situation, the device that desires to use the NavMod would be the master (client) and the NavMod would be the slave (server).

The NavMod provides the following protocols on the User Port:

- RFS -- A binary protocol called Remote Function Select (RFS). This protocol provides a robust, error checked method of communicating with the NavMod
- NMEA --- A printable ASCII protocol that conforms to the general message formatting used by the National Marine Equipment Manufacturers (NMEA) association guidelines.
- Legacy Binary – An efficient binary protocol that has no error checking support (i.e. no checksum).
- NorthTek -- A free form command line interpreter suitable for human operator usage or custom output requirements.

These protocols are able to operate simultaneously by virtue of the framing used for each protocol type. After the frame for one protocol is complete, another protocol may be used for the next frame. The RFS protocol packets begin with an **<SOH>** character and ends with an **<ETX>** character. The NMEA protocol begins with a **\$** character and ends with a **<LF>** character. The Legacy Binary protocol begins with a **0xA4** character and ends with a **0xA0** character. Once the first character for a new frame identifies one of these three protocols, all subsequent characters, up to the terminator for that protocol, are considered only for that protocol. All characters that are received outside one of the packet types are passed to the NorthTek interpreter. Each of the three packet oriented protocols expects packets to be completed in a timely manner. If the next character is not entered in a specific time interval (1 second RFS, 5 seconds NMEA, 0.5 seconds for Legacy), the packet is discarded and the receive parser resets to be ready to accept any packet type.

The Legacy and NMEA protocols provide a degree of backwards compatibility with the SP300x product family. The RFS protocol provides some advantages over the other protocols, namely 1) Robust error checking via a 16 bit CRC as part of each packet, 2) User definable messages such that the user can generally put all required data into a single message and 3) A self-descriptive command structure such that new NavMod features are automatically accessible to hosts. The NMEA protocol can utilize some (but not all) of the features of the RFS command set. The Legacy Binary interface is appropriate for systems that need to minimize communications with the device. The NorthTek interface is an advanced user interface that allows the user to enter and perform small command scripts within the compass in addition to a standard set of interface commands.

## 2.2 Interface Paradigm

The previously described protocols differ in the formatting of the actual “packets” or “commands” that are sent to or received from the NavMod. The protocols are similar in that they all conform to the same basic paradigm. The host sends a command, the NavMod then responds. All protocols follow this basic rule. Some protocols provide for the NavMod to respond automatically once commanded. As the purpose of the NavMod is, ostensibly, to provide a constant stream of navigation information most of the protocols (excepting the Legacy Binary) provide a method of automatically outputting information without an additional query from the host. The exception to this paradigm is NorthTek. NorthTek, being a programming environment, allows customization of the user interface in an algorithmic way.

## 2.3 Data Organization

The NavMods incorporate an internal database. The database contains primitive elements. The primitive elements provide the storage for information that is accessed externally. The elements can be settings, status or values. Regardless of the type of the element, the method of access to the value of the element is similar across all protocols. The internal data storage method is isolated from the data presented to the external interfaces. This resolves issues of bit/byte ordering (“endian-ness”). The specific format of multi-byte values is specified on each interface. Regardless of the method of transmission there are several basic data types as described in the following section.

### 2.3.1 Basic Data Types

The internal database elements are one of the following types:

- Int16 – A 16 bit signed integer.
- Int32 – A 32 bit signed integer.
- Float32 – An IEEE format 32 bit floating point value.
- String – A counted string. Byte 0 is the length of the string that follows ***including*** the terminating null.
- Ordinal -- An 8 bit value that represents a selection from a discrete set of 0 based values (0..N).
- ArrayInt32 – An array of Int32 values
- ArrayFloat32 – An array of Float32 values.

- BitField – RFS only. A combined variable that includes multiple other data types in the same object.

### 2.3.2 RFS BitFields

BitFields are user programmable as to content thus allowing the user to configure a single message that contains multiple useful values into a single report (similar to packed structures) BitFields minimize communications required to obtain the necessary data for the application. An overview of BitFields is provided here to frame the context of the variable table which describes the list of variables that follows in a later section. Full details of the BitFields and their usage can be found in the *RFS Protocol Suite* document.

A BitField is a variable type that contains meta-data instead of data. A BitField, for example, may contain a reference to an Int32 variable, an Ordinal Variable and a Float32 Variable. When setting or getting the variable, the application program would be able set or read all three values in the same message. The BitField variable contains the information to describe what three other variables would be set or read in a message to/from the BitField variable. The BitField thus contains not the actual data to be transmitted, but information describing what information will be transmitted. RFS messages may be used to manipulate the BitField meta-data or operate on the actual data referred to by the BitField. Some RFS messages are modal in that they automatically determine if the intended message is for the meta-data or the data itself. Full details are described in the *RFS Protocol Suite* document. BitFields are only used with the RFS protocol. (RFS protocol technical support is available from the manufacturer).

## 2.4 User Accessible NavMod Variables

The NavMod contains variables that are accessible by the user. In the NorthTek and NMEA protocols, the variables are identifiable by name. In the RFS protocols variables are identified by name but retrieved and manipulated by number. It is important to note that the number associated with a specific variable name may change in the future, however the RFS protocol was designed to accommodate this behavior and resolves the name/number matchups when the NavMod is first interrogated at power up. This strategy allows future NavMod software releases to add additional features while not obsoleting existing interface software.

The variable definitions for the NavMod are available as an XML file. This XML file describes each variable type, the dimensions of array variables, minimum and maximum values, and default values. Contact the manufacturer for availability.

The NavMod variables are listed in the table below. The variable names are the same names that would be entered in NMEA and NorthTek commands. This is a shorthand table to remind the user of the variable names. Detailed descriptions of each variable are found in Appendix A.1, Variable Detailed Descriptions, Variables by Name. In general, all variables are available via the RFS protocol;

variables that are available via NorthTek are marked as shown. The Legacy Binary protocol can only access variables that are predefined in its protocol.

### 2.4.1 Variable Summary Table

See Appendix A “Variable Detailed Descriptions” for the details on the variables in this table.

Name	Type	Notes	N M E A	N o r t h T e k	DC-4	GED C-6	AHRS-8
vidCount	Int32	Variable Count	●	●	●	●	●
name	String	Device Name		●	●	●	●
quiet	Ordinal	Debug Suppress	●	●	●	●	●
VERSION	String	Software version release identifier		●	●	●	●
REVISION	String	Subversion revision number of this software		●	●	●	●
serialnumber	String	Factory set serial number		●	●	●	●
orientation	Ordinal	Physical orientation of compass	●	●	●	●	●
baud	Ordinal	User Port Baud rate	●	●	●	●	●
pitch	Float32	Pitch angle in degrees, positive up	●	●	●	●	●
roll	Float32	Roll angle in degrees, positive rightside down	●	●	●	●	●
yaw	Float32	Magnetic heading in degrees	●	●	●	●	●
yawt	Float32	True heading in degrees	●	●	●	●	●
quaternion	ArrayFloat32	4 element array representing w, x, y and z	●	●	●	●	●
lat	Float32	Latitude (user supplied for WMM, see set_wmm)	●	●	●	●	●
lonG	Float32	Longitude (user supplied for WMM, see set_wmm)	●	●	●	●	●
alt	Float32	Altitude (user supplied for WMM, see set_wmm)	●	●	●	●	●
day	Float32	Estimated date expressed to the tenth of a year (user supplied for WMM, see set_wmm)	●	●	●	●	●
restorefactorycal	Command	Restores calibration data to factory settings	●	●	●	●	●
set_wmm	Ordinal	Command to update the World Magnetic Model data (uses lat, lonG, alt day)	●	●	●	●	●
magvar	Float32	Magnetic Variation - difference between true and magnetic	●	●	●	●	●
wmmGD	ArrayFloat32	World Magnetic Model geodetic magnetic field X Y Z at Lat/Long	●	●	●	●	●
wmmHasRun	Ordinal	Indicates whether the World Magnetic Model has been run (implies wmmGD and magvar are valid)	●	●	●	●	●
magr	ArrayFloat32	Raw Magnetometer X Y Z Total array	●	●	●	●	●
magp	ArrayFloat32	Processed Magnetometer X Y Z array	●	●	●	●	●
accelr	ArrayFloat32	Raw Accelerometer X Y Z array	●	●	●	●	●
accelp	ArrayFloat32	Processed Accelerometer X Y Z array	●	●	●	●	●
gyror	ArrayFloat32	Raw gyro X Y Z array	●	●		●	●
gyrop	ArrayFloat32	Processed gyro X Y Z array	●	●		●	●
gyroSampleRate	Float32	Actual sample rate for the gyro (samples/second)	●	●		●	●
positionrate	Int32	Report rate for the data described in the RFS “position” variable (see next row)	●	●	●	●	●
position	BitField	Composite object descriptor with pitch, roll, yawt, magErr, temperature, magp X/Y/Z, accelp X/Y/Z, gyrop X/Y/Z,1			●	●	●

composite2	BitField	User defined RFS composite object (packed structure) descriptor			•	•	•
composite3	BitField	User defined RFS composite object (packed structure) descriptor			•	•	•
calmode	Ordinal	Calibration Mode	•	•	•	•	•
calCommand	Ordinal	Commands the next step for “in field” calibration	•	•	•	•	•
calNumPoints	Int32	Number of points collected for 3D Calibration Mode	•	•	•	•	•
magErr	Float32	Magnetic error term resulting from calibration calcs	•	•	•	•	•
wlim	Float32	Algorithm constant - threshold limit	•	•	•	•	•
alim	Float32	Algorithm constant - threshold limit for accel	•	•	•	•	•
mlim	Float32	Algorithm constant – threshold limit for mag	•	•	•	•	•
km0	Float32	Algorithm constant - magnetic gain	•	•	•	•	•
ka0	Float32	Algorithm constant - acceleration gain	•	•	•	•	•
emlim	Float32	Algorithm constant - magnetic error threshold limit	•	•	•	•	•
ealim	Float32	Algorithm constant - accel error threshold limit	•	•	•	•	•
kgyrooffset	Float32	Algorithm constant - gyro offset	•	•		•	•
magOffset	ArrayFloat32	Calibration offset for the magnetometer	•	•	•	•	•
tempCalOffset	Int32	Temperature (degrees C) at which the magnetometers were calibrated	•	•	•	•	
magCalTemperature	Float32	Base temperature (degrees C) for the magnetometer calibration parameters	•	•			•
magOffsetCorrectionXPlus magOffsetCorrectionYPlus magOffsetCorrectionZPlus magOffsetCorrectionXNeg magOffsetCorrectionYNeg magOffsetCorrectionZNeg	ArrayFloat32	Factory calibration temperature correction coefficients for the magnetometer	•	•	•	•	
magOffsetTCX magOffsetTCY magOffsetTCZ	ArrayFloat32	Factory temperature compensated calibration offsets for the magnetometer	•	•			•
magLinearityXPlus magLinearityYPlus magLinearityZPlus magLinearityXNeg magLinearityYNeg magLinearityZNeg	ArrayFloat32	Factory temperature compensated calibration offsets for the magnetometer	•	•	•	•	
magLinearityXTC0 magLinearityXTC1 magLinearityXTC2 magLinearityYTC0 magLinearityYTC1 magLinearityYTC2 magLinearityZTC0 magLinearityZTC1 magLinearityZTC2	ArrayFloat32	Factory temperature compensated calibration scalars for the magnetometer	•	•			•
magLinearityX magLinearityY magLinearityZ	ArrayFloat32	Computed calibration scalars for the magnetometer - is used to “linearize” the magnetic vector after the offset has been applied	•	•			•
magCrossAxisCorrectionX magCrossAxisCorrectionY magCrossAxisCorrectionZ	ArrayFloat32	Adjusts for any unorthogonal mounting of the magnetometers	•	•	•	•	•
magFieldCalX magFieldCalY magFieldCalZ	ArrayFloat32	In field calibration offset and scalars for the magnetometers	•	•	•	•	•
accelrange	Ordinal	Accelerometer full scale range setting (4g vs. 8g)	•	•			•

accelOffset	ArrayFloat32	Calibration offset for the accelerometer	•	•	•	•	•
accelGyroCalTemperature	ArrayFloat32	Temperature (deg C) at which the Rate Table temperature compensation parameters for both accelerometer and gyro are computed.	•	•			•
accelOffsetTCX accelOffsetTCY accelOffsetTCZ	ArrayFloat32	Temperature compensated calibration offsets for the accelerometer	•	•			•
accelLinearityXPlus accelLinearityYPlus accelLinearityZPlus accelLinearityXNeg accelLinearityYNeg accelLinearityZNeg	ArrayFloat32	Calibration scalars for the accelerometer	•	•	•	•	
accelLinearityXTC0 accelLinearityXTC1 accelLinearityXTC2 accelLinearityYTC0 accelLinearityYTC1 accelLinearityYTC2 accelLinearityZTC0 accelLinearityZTC1 accelLinearityZTC2	ArrayFloat32	temperature compensated calibration scalars for the accelerometer	•	•			•
accelLinearityX accelLinearityY accelLinearityZ	ArrayFloat32	Temperature compensated linearity coefficients for the accelerometer, these are computed from the accelLinearityXTC0, etc. variables and temperature.	•	•			•
accelCrossAxisCorrectionX accelCrossAxisCorrectionY accelCrossAxisCorrectionZ	ArrayFloat32	Corrections to compensate for any unorthogonal mounting of the accelerometerS	•	•	•	•	•
gyroOffset	ArrayFloat32	Calibration offset for the gyro	•	•		•	•
gyroMaxRate	Float32	The NavMod switches to using just the magnetometer and accelerometer above this rate.	•	•			•
gyroMaxReturnCnt	Int32	After the gyro has exceeded the gyroMaxRate, this variable defines the number of in-range gyro values that must occur before switching back to using the gyro data	•	•			•
gyroOffsetTCX gyroOffsetTCY gyroOffsetTCZ	ArrayFloat32	Temperature compensated calibration offsets for the magnetometer	•	•			•
gyroLinearityXPlus gyroLinearityYPlus gyroLinearityZPlus gyroLinearityXNeg gyroLinearityYNeg gyroLinearityZNeg	ArrayFloat32	Calibration scalars for the gyro	•	•		•	
gyroLinearityXTC0 gyroLinearityXTC1 gyroLinearityXTC2 gyroLinearityYTC0 gyroLinearityYTC1 gyroLinearityYTC2 gyroLinearityZTC0 gyroLinearityZTC1 gyroLinearityZTC2	ArrayFloat32	Temperature compensated calibration scalars for the gyro	•	•			•
gyroLinearityX gyroLinearityY gyroLinearityZ	ArrayFloat32	Computed calibration scalars for the gyro based on the temperature compensated calibration scalars (e.g. gyroLinearityXTC0, etc.)	•	•			•
gyroFieldCalX gyroFieldCalY	ArrayFloat32	In field calibration offset and scalar for the gyro	•	•		•	•



gyroFieldCalZ							
gyroCrossAxisCorrectionX gyroCrossAxisCorrectionY gyroCrossAxisCorrectionZ	ArrayFloat32	Calibration cross axis correction for the gyro	•	•		•	•
InvokeGyroOffsetCal	Command	Command the gyro offset calibration to start	•	•		•	•
boresightMatrixX boresightMatrixY boresightMatrixZ	ArrayFloat32	Rotation matrix that will be applied to transform from the NavMod's reference frame to the host reference frame	•	•	•	•	•
lowpower	Command	Command to enter Low Power Mode	•	•	•	•	•
temperature	Int32	Temperature in Celsius	•	•	•	•	•
temperatureOffset	Float32	Factory calibration temperature offset	•	•	•	•	
temperatureSlope	Float32	Factory calibration temperature slope	•	•	•	•	
temperatureWrapDivider	Int32	Used to determine if raw temperature wrapped around	•	•	•	•	
kgyroOffsetCalFactor	Float32	Gyro offset field cal factor	•	•		•	•
nmeaecho	Ordinal	Command to turn on echoes of NMEA characters	•	•	•	•	•
nmeaignorechecksum	Ordinal	Command to ignore received NMEA checksum	•	•	•	•	•
restoreFieldCal	Ordinal	Command to set magnetic field calibration data back to factory default	•	•	•	•	•
pMatrix0 pMatrix1 pMatrix2	ArrayFloat32	Platform matrix (rotation matrix) – provides 3D orientation	•	•			•
printmask	Int32	Used to select items for printing	•	•			•
printtrigger	Int32	Used to select triggers (data updates) that will cause the printmask selected items to print.	•	•			•
printmodulus	Int32	Print when x number of trigger events occur as defined by printtrigger	•	•			•

## 2.5 World Magnetic Model

The NavMods contain a world magnetic model. This model allows the user to input a physical location and time (lat, lonG, alt and day<sup>1</sup>) and have the compass compute the magnetic declination and thus be able to output a true heading instead of a magnetic heading. The world magnetic model is valid for 5 years at which point it must be updated. The world magnetic model data is updated via RFS. Users who have a product lifetime expectation that exceeds 5 years, that need true heading output, and wish to field update the world magnetic model data, must implement, at a minimum, the file transfer portion of the RFS protocol. Hardware designers should refer to the reference design to ensure that the proper software interface is available to the compass for performing this update.

## 2.6 Low power mode

The NavMod has a low power mode. When in lowpower the only thing operating is the serial port. Activity on the serial port will cause the NavMod to exit low power mode. Upon exiting low power mode, the NavMod resets itself to the power on state. Any temporary settings prior to low power mode will be lost, but permanent settings will be retained. The low power command is detailed in the NorthTek section of the document and also in the detailed variable descriptions section in the appendix.

<sup>1</sup> These are NorthTek variable names, hence the odd capitalization.



### 3 Protocols

All the serial port protocols co-exist on the same serial port at all times. The user may use whichever protocol is most desirable. The suggested protocols for future growth are the RFS protocol for automated binary interfaces and NorthTek for human controlled interactive interfaces. The NMEA protocol will continue to be supported but cannot by its nature support some of the RFS/NorthTek current and future capabilities. Note that NMEA or Legacy protocols can be implemented in NorthTek for custom applications.

The factory default baud rate is 115200 baud but may be changed to any of the allowable baud rates. Note that the same baud rate applies to all protocols simultaneously. Once changed, the NavMod will maintain the baud rate setting through a power cycle. To change the baud rate to 9600 for example, using NMEA enter the following string (see variable description A.1.8 for allowable values, <LF> is ctrl-j on the keyboard):

***\$PSPA,BAUD=4<LF>***

To change the baud rate using NorthTek enter:

***baud 4 set drop<cr>***

Note that NMEA does not echo characters by default. NMEA echo can be turned on (setting is lost with a power cycle or lowpower cycle) with the following command:

***nmeaecho 1 set drop<cr>***

This command can be sent in NMEA format as follows:

***\$PSRFS,nmeaecho,set,1<LF>***

The NMEA processor ignores the checksum's absence by default, however for users that desire to have an additional level of error protection in sending commands to the NavMod, the checksum may be enabled (ignore disabled) for receive. The following command (effect is for the current power on cycle) enables (disables the ignoring of) the NMEA checksum. Commands which fail the checksum test are not performed.

***nmeaignorechecksum 0 set drop<cr>***

Note that this command can be entered in NMEA format as follows:

***\$PSRFS,nmeaignorechecksum,set,0<LF>***

#### 3.1 RFS

The RFS protocol suite is described in a separate document titled Remote Function Select (RFS) Protocol Suite.

RFS assigns a unique Variable Identifier (VID) for each database element (see Appendix A for the list of available database elements). Other than the reserved VID<sup>2</sup> the user application should not depend on a particular numeric for a particular VID for the database elements from one release of the

---

<sup>2</sup> VID 0 is always the count of the number of VIDs in the device. VID 1 is always the name of the device. Vid 2 is always the major version number. Vid 3 is always the minor version number.

NavMod software to another. The names should remain the same from release to release and can be used to resolve the same variable to a VID number.

To be software revision independent, the user application should use VID 0 to obtain the number of elements, and then obtain the names of all of the database elements by looping through all of the VIDS and using the “Get\_Next” commands. The user application can then obtain the current VID for the desired named element listed in Appendix A. From then on, with that VID, the user application may use the “Set” command or the “Get\_Value” command and the NavMod will respond with “Value\_Is”.

The NavMod interfaces the RFS protocol layered on top of a packet transfer mechanism called Sparton Asynchronous Packet Protocol (SAPP). SAPP is also described in the Remote Function Select (RFS) Protocol Suite’s Appendix E. Please refer to the referenced document for more information.

Below is a NavMod specific example for which the user will need to have the RFS Protocol Suite document open for reference. In this example, the user application is obtaining the serial number of the NavMod unit. All figure numbers in parenthesis below refer to those found in the [RFS Protocol Suite document](#).

Application creates a command to get information about the variable with Variable ID (VID) = 4:

RFS Command: **get** VID = 4, payload size = 0, message sequence = 216 (0xD8)  
which translates to RFS payload (Figure 4-15 RFS Outer Layer Protocol Diagram):  
01 00 00 00 00 01 D8 04

then the application must add the SAPP layer for error protection (Figures 4-34 – Packet Frame and 4-35 – Packet Body), note that “10 81” is substituted for “01” in 2 places to prevent “01” from being confused with the start character (SOH) (reference E.3.4 Packet Frame):

01 0B 40 10 81 00 00 00 00 10 81 D8 04 EB 42 03

The NavMod creates the response message:

RFS Response: **getResponse** VID = 4, payload size=23, seq=216,  
(see Figure 4-16 Data Description Object) Scalar 0x1X,  
(see Figure 4-17 Scalar Description Field) Type 2=String, Field Size = 20 (0x14),  
Name=“serialnumber”, String Length Max = 20,  
(see Figure 4-8 String Data Format) String Length=4, String Value=“S10”  
01 00 00 00 17 00 D8 04 10 02 14 0D 73 65 72 69 61 6C 6E 75 6D 62 65 72 00 14 04 53 31 30  
00

The NavMod then adds the SAPP layer for framing and error detection resulting in the following output (RFS Protocol Suite Figures 4-34 – Packet Frame and 4-35 – Packet Body):

01 22 60 10 81 00 00 00 17 00 D8 04 10 90 02 14 0D 73 65 72 69 61 6C 6E 75 6D 62 65 72 00  
14 04 53 31 30 00 87 4F 03

## 3.2 NMEA

NMEA commands use ASCII text strings to communicate with the digital compass through the User Port. All commands should follow the command syntax exactly. No white space should be included in NMEA command strings. Data is formatted with the first character being “\$” to signify the start of a NMEA command and include a “\*” to signify the start of the checksum.

It is not necessary to include any checksum characters in commands sent to the digital compass. Strictly speaking, this is not standard NMEA protocol but manually entering checksums is not practical. However an option exists to enable NMEA checksums if additional error protection is desired. This option is off by default and may be enabled via a NorthTek or a NMEA command string (see the *nmeaignorechecksum* explanation in the Protocols section). All NMEA responses from the compass will contain a checksum followed by a carriage return and line feed.

The NavMod by default at power up does not echo the NMEA character strings, however a NorthTek command exists that will enable echo of NMEA command strings as they are typed (*nmeaecho 1 set drop<cr>*). This mode is provided for evaluators that wish to use a serial terminal to hand type NavMod commands. Each command sent must be terminated with a carriage return <CR> and line feed <LF> (entered as <CTRL-J> in some terminal programs such as Tera Term). To turn off the character echo, use the command: *nmeaecho 0 set drop<cr>*

The checksum value is the result of XORing the ASCII bytes between, but not including, the “\$” and “\*” characters. This one byte value is reported in the output word by two ASCII characters representing two hex digits, with the most significant nibble first.

NMEA commands must be completed in a timely manner. The terminating character must be received within 5 seconds after the reception of the last character. If the command is not received in the time allotted all characters received will be discarded and the command ignored. This is to prevent the NavMod from getting stuck in the NMEA protocol.

Example:

**\$HCHDM,300.4,M\*2E<CR><LF>**

“\$”	= Start of NMEA text message
“HCHDM”	= Response header from compass. (HC=Magnetic Compass, HDM = Magnetic Heading)
“300.4”	= Heading in degrees
“M”	= Magnetic Heading
“*”	= Start of checksum field
“2E”	= Hexadecimal checksum value

Any NMEA command can be repeated continuously by adding the repeat (RPT) instruction to the end of the command string (before the checksum). The repetition rate is given in seconds and should be in the range 0.1 to 500.0 seconds. For example, to request magnetic heading continuously at a 0.5second (2Hz) rate, the following command should be issued:

**\$xxHDM,RPT=0.5<CR><LF>**

The compass will respond by continuously sending magnetic heading information every 0.5 seconds. To discontinue RPT function, simply send another NMEA command. Repeat commands are not maintained through a power cycle or low power mode.

In the following command descriptions, <int#> represents an integer number (the <> will not be in the response). The symbols such as ###.# with decimal points represent floating point numbers with a fixed format. The symbol float# represents floating numbers without a fixed format.

### 3.2.1 Raw Magnetics

Description: Reads current magnetics directly from magnetometers (Mx, My, and Mz). These are raw sensor readings and do not yet have any calibration parameters applied.

Send: **\$PSPA,MR<cr><lf>**

Response: **\$PSPA,MRx=<int#>,MRy=<int#>,MRz=<int#>\*<checksum in hex>**

Response Example:

**\$PSPA,MRx=1553,MRy=-1669,MRz=-1419\*60**

### 3.2.2 Heading - Magnetic

Description: Reads the current magnetic heading. The heading is compensated for platform tilt. The xx in xxHDM represent “don’t care” characters and so are not used.

Send: **\$xxHDM<cr><lf>**

Response: **\$HCHDM,<###.#>,M\*<checksum in hex>**

<###.#> = Heading in range 000.0 to 359.9

Response Example:

```
$HCHDM,300.4,M*2E
```

### 3.2.3 Heading - TRUE

Description: Reads the current true heading. The heading is compensated for platform tilt. True heading is the magnetic heading corrected for magnetic variation.

Send: `$xxHDT<cr><lf>`

Response: `$HCHDT,<###.#>,T*<checksum in hex>`

<###.#> = Heading in range 000.0 to 359.9

Response Example:

```
$HCHDT,295.9,T*2B
```

### 3.2.4 Magnetic Variation

Description: Set the magnetic variation angle. The variation angle is used in adjusting magnetic heading to true heading. This will override any previous internally computed World Magnetic value.

Send: `$xxVAR,<###.#>,<E or W><cr><lf>`

Response: `$HCVAR,<###.#>,<E or W>*<checksum in hex>`

<###.#> = Variation in range 000.0 to 180.0

<E or W> = Direction of variation East(+) or West(-)

Send Example:

```
$xxVAR,4.2,W<cr><lf>
```

Response Example:

```
$HCVAR,004.2,W*31
```

### 3.2.5 Automatic Magnetic Variation

Description: Computes the local magnetic variation based on the device's current geographical location (geodetic coordinate system referenced to the WGS 84 ellipsoid). Latitude and longitude are entered in degrees with + being north

and east respectively. Altitude is entered in meters above sea level. The day is entered as a fractional year based on the current day of the year (i.e. February 15 is the 46<sup>th</sup> day of the 2008. In fractional terms, this would be  $46/365 = 0.126$ . The Day value for February 15, 2008 would then be entered as 2008.1 (resolution beyond a tenth causes negligible change in variation). Once the computation is complete, the magnetic variation will be updated in the compass. *NOTE: TO RETAIN MAGNETIC VARIATION ACCURACY, THE MAGNETIC MODEL MUST BE UPDATED EVERY FIVE YEARS ON THE NOAA SCHEDULE (see <http://www.ngdc.noaa.gov/geomag/WMM/DoDWMM.shtml>). A SEPARATE PROGRAM IS AVAILABLE ON THE SUPPLIED CD WHICH WILL ASSIST IN DOWNLOADING NEW COEFFICIENTS INTO THE DIGITAL COMPASS. THIS ONLY AFFECTS THE CALCULATION OF TRUE HEADING AND DOES NOT AFFECT MAGNETIC HEADING ACCURACY.* NOTE: Resetting the magnetic parameters to the factory default does not affect the magnetic variation information. To clear out the magnetic variation, manually set the magnetic variation to zero.

Send:

```
$PSPA,AUTOVAR,<#Latitude>,<#Longitude>,<#Altitude>,<#Day><cr><lf>
```

Response:

```
$PSPA,AutoVar=<###.##>,<checksum in hex>
```

#Latitude = Geodetic latitude in degrees. North(+) or South(-).

#Longitude = Geodetic longitude in degrees. East(+) or West(-).

#Altitude = Geodetic altitude in meters from sea-level

#Day = Approximate date in terms of 1/10<sup>th</sup> of a year

Send Example:

```
$PSPA,AUTOVAR,29.12,-81.35,100,2011.6<cr><lf>
```

Response Example:

```
$PSPA,AutoVar=-005.9*66
```

### 3.2.6 Magnetic Vector

Description: Measures the magnetic field strength along each axis (X, Y, and Z) and total absolute field strength (MAtotal) in milligauss.

Send:

```
$PSPA,M<cr><lf>
```

Response:

```
$PSPA,Mx=<int#>,My=<int#>,Mz=<int#>,Mt=<int#>*<checksum in hex>
```

Response Example:

```
$PSPA,Mx=63,My=-261,Mz=-262,Mt=376*29
```

### 3.2.7 Magnetic Field Calibration

Description: Controls the compass in field calibration process. Field calibration involves multiple steps:

- 1) Select which mode, 3D, 2D, or User mode.
- 2) Start the calibration
- 3) Capture Points
- 4) End point capture
- 5) Allow the calibration algorithm to converge.
- 6) Terminate calibration, causing values to be stored.

The compass is already factory calibrated in an environment free from magnetic distortions. When the compass is first used in the application, it must learn the local magnetic distortions.

#### 3-D Field Calibration

The 3-D calibration procedure is used for applications that move outside of a plane. It does **not** require full 360 deg pitch and roll capability for this calibration. The positions should be chosen to represent the extremes expected for the application.

The results are stored in magFieldCalX, magFieldCalY and magFieldCalZ with the first value being offset and the second being a divisor.

Send:

```
$PSPA,CAL=3D<cr><lf>
```

```
$PSPA,CAL_CMD=START_CAL<cr><lf>
```

Change position and repeat CAPTURE\_POINT totaling 4 to 12 points

```
$PSPA,CAL_CMD=CAPTURE<cr><lf>
```

```
.  
.   
.
```

```
$PSPA,CAL_CMD=CAPTURE<cr><lf>
```

Stop the capture after a minimum of 4 points .

```
$PSPA,CAL_CMD=END_CAPTURE<cr><lf>
```

```
$PSPA,MAGERR,RPT=0.5<cr><lf>
```

Watch for the magnetic error quality indicator to settle to a minimum value

```
$PSPA,CAL_CMD=END_CAL<cr><lf>
```

**\$PSPA,CAL=OFF<cr><lf>**

Response:

```
$PSPA,CAL=3D*<checksum in hex>
$PSPA,CAL_CMD=START_CAL *<checksum in hex>
$PSPA,CAL_CMD=CAPTURE,POINTS=<#>*<checksum in hex>
.
.
.
$PSPA,CAL_CMD=CAPTURE,POINTS=<#>*<checksum in hex>
$PSPA,CAL_CMD=END_CAPTURE<#>*<checksum in hex>
$PSPA,MagErr=<int#>*<checksum in hex>
$PSPA,MagErr=<int#>*<checksum in hex>
.
.
.
$PSPA,MagErr=<int#>*<checksum in hex>
$PSPA,MagErr=<int#>*<checksum in hex>
$PSPA,END_CAL=<int#>*<checksum in hex>
$PSPA,CAL=OFF*<checksum in hex>
```

## 2-D Field Calibration

The 2-D calibration procedure is used for applications that stay within a plane. The positions should be chosen to represent the extremes expected for the application.

The results are stored in magFieldCalX, magFieldCalY and magFieldCalZ with the first value being offset and the second being a divisor.

Send:

```
$PSPA,CAL=2D<cr><lf>
$PSPA,CAL_CMD=START_CAL<cr><lf>
Change position and repeat CAPTURE_POINT totaling 4 to 12 points
$PSPA,CAL_CMD=CAPTURE<cr><lf>
.
.
.
$PSPA,CAL_CMD=CAPTURE<cr><lf>
Stop the capture after a minimum of 4 points.
$PSPA,CAL_CMD=END_CAPTURE<cr><lf>
$PSPA,MAGERR,RPT=0.5<cr><lf>
Watch for the magnetic error quality indicator to settle to a minimum value
$PSPA,CAL_CMD=END_CAL<cr><lf>
```



**\$PSPA,CAL=OFF<cr><lf>**

Response:

```
$PSPA,CAL=3D*<checksum in hex>
$PSPA,CAL_CMD=START_CAL *<checksum in hex>
$PSPA,CAL_CMD=CAPTURE,POINTS=<#>*<checksum in hex>
.
.
.
$PSPA,CAL_CMD=CAPTURE,POINTS=<#>*<checksum in hex>
$PSPA,CAL_CMD=END_CAPTURE<#>*<checksum in hex>
$PSPA,MagErr=<int#>*<checksum in hex>
$PSPA,MagErr=<int#>*<checksum in hex>
.
.
.
$PSPA,MagErr=<int#>*<checksum in hex>
$PSPA,MagErr=<int#>*<checksum in hex>
$PSPA,END_CAL=<int#>*<checksum in hex>
$PSPA,CAL=OFF*<checksum in hex>
```

### 3.2.8 Gyro<sup>3</sup> Calibration

For this procedure, the navigation unit must be in a static position. The gyro calibration procedure will complete automatically. The results are stored in gyroFieldCalX, gyroFieldCalY and gyroFieldCalZ with the first value being offset and the next value being a divisor.

Send: **\$PSPA,GYROCAL<cr><lf>**

Response:

**\$PSPA,GYROCAL\*<checksum in hex>**

### 3.2.9 Magnetic Adaption Error

---

<sup>3</sup> GEDC-6 Only

**Description:** Indicates quality of the adaptive magnetic calibration process. Smaller values represent lower error corresponding to better magnetic calibration. Adaption error is limited to the range 0 to 10,000.

**Send:** `$PSPA,MAGERR<cr><lf>`

**Response:** `$PSPA,MagErr=<int#>*<checksum in hex>`

**Response Example:**

`$PSPA,MagErr=16*0A`

### 3.2.10 Raw Acceleration

**Description:** Reads current acceleration directly from accelerometers (AccelX, AccelY, AccelZ). These are raw sensor readings and do not yet have any calibration parameters applied.

**Send:** `$PSPA,AR<cr><lf>`

**Response:** `$PSPA,ARx=<int#>,ARy=<int#>,ARz=<int#>*<checksum in hex>`

**Response Example:**

`$PSPA,ARx=2052,ARy=1991,ARz=1284*61`

### 3.2.11 Acceleration Vector

**Description:** Measures the acceleration along each axis (X, Y, and Z) and total magnitude (At = Atotal) in milli-g.

**Send:** `$PSPA,A<cr><lf>`

**Response:** `$PSPA,Ax=<int#>,Ay=<int#>,Az=<int#>,At=<int#>*<checksum in hex>`

**Example Response:**

`$PSPA,Ax=-70,Ay=76,Az=995,At=1000*02`

### 3.2.12 Raw Gyro

Description: Reads current gyro directly from gyrometers (GyroX, GyroY, GyroZ). These are raw sensor readings and do not yet have any calibration parameters applied.

Send: `$PSPA,GR<cr><lf>`

Response: `$PSPA,GRx=<int#>,GRy=<int#>,GRz=<int#>*<checksum in hex>`

Response Example:

`$PSPA,GRx=133,GRy=93,GRz=80*5E`

### 3.2.13 Gyro Vector

Description: Provides the calibrated gyro values along each axis (X, Y, and Z) in milliDegrees per second.

Send: `$PSPA,G<cr><lf>`

Response: `$PSPA,Gx=<float#>,Gy=<float#>,GRz=<float#>*<checksum in hex>`

Response Example:

`$PSPA,Gx=165.974,Gy=285.613,Gz=-168.670*31`

### 3.2.14 Pitch and Roll Output

Description: Reads the current platform orientation (Pitch and Roll).

Send: `$PSPA,PR<cr><lf>`

Response: `$PSPA,Pitch=<##.#>,Roll=<###.#>*<checksum in hex>`

Pitch range (degrees): -90.0 to +90.0

Roll range (degrees): -180.0 to +180.0

Example Response:

`$PSPA,Pitch=+18.2,Roll=-042.4*56`

### 3.2.15 Quaternion Vector

Description: Provides the attitude in the form of a quaternion. The x, y, z define the axis of rotation and the w provides the angle (theta) of rotation about that axis where  $\theta = \arccos(w) * 2$

Send: `$PSPA,QUAT<cr><lf>`

Response:

```
$PSPA,QUATw=<#.#####>,x=<#.#####>,  
y=<#.#####>,z=<#.#####>*<checksum in hex>
```

Example Response:

```
$PSPA,QUATw=0.314214,x=0.007481,y=-0.034541,z=-  
0.948694*0D
```

### 3.2.16 Temperature

Description: Reads the internal temperature channel of the on-board microcontroller and converts to degrees C. This measurement is calibrated at the factory for general use even though it is not required by the compass in determining an accurate heading.

Send: `$PSPA,TEMP<cr><lf>`

Response: `$PSPA,Temp=<##.#>,C*<checksum in hex>`

<##.#> = Variation in range -20.0 to +70.0C

Response Example:

```
$PSPA,Temp=+24.1,C*72
```

### 3.2.17 BAUD RATE

Description: The factory default BAUD setting is 115200 Baud (Baud value = 8). When the baud rate command is issued, the compass will echo back the command once at the current baud rate and then again at the new baud rate. The baud rate will be stored in EEPROM and will become the new operating communication rate for the UART. The baud rate will apply to both Legacy, RFS, NorthTek and NMEA commands issued on the UART.

Send: `$PSPA,BAUD=<# Baud value><cr><lf>`

Response: `$PSPA,Baud=<# Baud value>*<checksum in hex>`

Send Example:

**\$PSPA,BAUD=4<cr><lf>**

Response Example:

**\$PSPA,BAUD=4\*25**

Acceptable Baud Rate Values:

0= 300 Baud

1 = 1200 Baud

2 = 2400 Baud

3 = 4800 Baud

4 = 9600 Baud

5 = 19.2 kBaud

6 = 38.4 kBaud

7 = 57.6 kBaud

8 = 115.2 kBaud

### 3.2.18 Mounting Configuration

**Description:** Sets the mounting orientation of the compass platform. The default orientation is horizontal (see Figure 4 in the Navigation Sensors Product Guide). To determine the orientation setting, read the acceleration vector. When in a static level condition, Az should be approximately +1000mg and Ax and Ay should be close to zero.

**Send:** **\$PSPA,MOUNT=<'H' for horizontal or 'V' for vertical><cr><lf>**

**Response:** **\$PSPA,Mount=<'H or V'>\*<checksum in hex>**

Send Example:

**\$PSPA,MOUNT=V<cr><lf>**

Response Example:

**\$PSPA,Mount=V\*18**

### 3.2.19 Read Transducers

**Description:** Reads current magnetic heading, true heading, pitch, roll, temperature, and magnetic error. This command provides the most frequently used information in one command string.

Send: **\$xxXDR<cr><lf>**

Response: **\$HCXDR, <Transducer string as described below>\*<checksum in hex>**

<Transducer String> =

A,	- Angular Displacement Measurement
###.#,	- Magnetic Heading
D,	- Units of Degrees for Magnetic Heading
A,	- Second Angular Displacement Measurement
###.#,	- True Heading
D,	- Units of Degrees for True Heading
A,	- Third Angular Displacement Measurement
+###.#,	- Pitch
D,	- Units of Degrees for Pitch
A,	- Fourth Angular Displacement Measurement
+###.#	- Roll
D,	- Units of Degrees for Roll
C,	- Temperature Measurement
+###.#,	Temperature
C,	- Units of Degrees C for Temperature
G,	- Generic Measurement
###	- Magnetic Error (measurement is unitless)

Send Example:

**\$xxXDR<cr><lf>**

Response Example:

**\$HCXDR,A,281.3,D,A,281.3,D,A,+07.9,D,A,-000.8,D,C,+21.1,C,G,0216\*2C**

### 3.2.20 NMEA RFS Access

Most of the RFS variables are accessible via the NMEA protocol. This section describes the method used to set or get these variables. Note: NMEA and RFS variable names are case sensitive and must be matched exactly.

NMEA access to RFS variables (see Variable Summary Table, 2.4.1 for variable availability) is with one of two commands, with options. The first command is to “get” or read a variable. The syntax is:

**\$PSRFS,<rfs variable name>,get<cr><lf>**

The NavMod will respond in kind with the variable name and the values of the variable. For Example the following command produces:

```
$PSRFS,yaw,get<cr><lf>  
$PSRFS,yaw,286.672424*38<cr><lf>
```

Variables that may be set, are “settable” by a similar mechanism except by replacing the get command with a set command and providing the new values separated by commas. For example, the sequence below indicates how to use the NMEA/RFS protocol to get the NavMod orientation and then set it to another value:

```
$PSRFS,orientation,get<cr><lf>  
$PSRFS,orientation,0*02<cr><lf>  
$PSRFS,orientation,set,1<cr><lf>  
$PSRFS,orientation,1*03<cr><lf>
```

### 3.2.21 NMEA/RFS RPT and GLOM

NMEA/RFS commands may have the RPT=# option applied to make an output repeat at the specified rate. In addition that NMEA/RFS commands allow additional (up to 8) NMEA/RFS commands to be “GLOM”d onto the current repeating output. This is best described by the following example that shows how to output the magnetic heading (yaw) at a 5 second rate and to GLOM on the true heading (yawt) at the same rate.

```
$PSRFS,yaw,get,RPT=5.0<cr><lf>  
$PSRFS,yaw,287.384308*3C    << immediate response to get command  
$PSRFS,yaw,287.273376*3C    << occurring at 5 second rate  
$PSRFS,yaw,287.244049*37    << occurring at 5 second rate  
$PSRFS,yawt,get,GLOM<cr><lf>  
$PSRFS,yawt,287.167603*49   << immediate response to get command  
$PSRFS,yaw,287.301758*30    << occurring at 5 second rate  
$PSRFS,yawt,287.301758*44   << output at same time as line above  
$PSRFS,yaw,287.294495*3F    << occurring at 5 second rate  
$PSRFS,yawt,287.294495*4B   << output at same time as line above  
$PSRFS,yaw,287.294983*35    << occurring at 5 second rate  
$PSRFS,yawt,287.294983*41   << output at same time as line above
```

### 3.3 Legacy Binary

Legacy Binary is intended to be only used by users of the older Sparton compasses such as the SP3002, SP3003, and SP3004. As a result, it does not have access to any of the newer data such as the gyro data and so is not recommended for new designs.

Legacy Binary commands allow for compact and efficient communication with the digital compass using the serial interface. Data is formatted on a hexadecimal byte level requiring minimal communication time to transfer commands to and from the compass. Processing of data received from the compass also becomes easier as parsing of text strings is not required. All legacy commands sent to the compass begin with a header byte (0xA4) and end with a termination byte (0xA0).

If the compass does not recognize a sequence of bytes as being a legacy command, no response is produced. If the compass recognizes the command but, for some reason, cannot execute it, it will respond with an error code. All error codes begin with a header byte (0xAE) and end with a termination byte (0xA0). Commands which commence and do not conclude within a timely manner will be rejected. All multi-byte values are sent most significant byte (MSByte) first.

Error Code Format:      3 Bytes (**0xAE**, **<8-bit error code>**, **0xA0**)

8-bit Error Codes:

0xFF = Improper command termination (i.e. no 0xA0 found)  
0xFE = Receive buffer overflow  
0xFD = Invalid parameter associated with given command

#### 3.3.1 Raw Magnetics

Description:              Reads current magnetics directly from magnetometers (Mx, My, and Mz). These are raw sensor readings and do not yet have any calibration parameters applied.

Send:                      3 Byte (**0xA4**, **0x01**, **0xA0**)

Response:                9 Bytes  
(**0xA4**, **0x01**, **<Mx>**, **<My>**, **<Mz as 16-bit integers MS byte first>**, **0xA0**)

#### 3.3.2 Heading - TRUE

Description:              Reads the current true heading. The heading is compensated for platform tilt. True heading is the magnetic heading corrected for magnetic variation.



Send: 3 Byte (**0xA4, 0x02, 0xA0**)  
 Response: 5 Bytes  
**(0xA4, 0x02, <Heading as a 16-bit signed integer>, 0xA0)**

Heading (degrees) = (16-bit Heading value)\*360/4096  
 Heading Range = 0.0 to +359.9

### 3.3.3 Heading - Magnetic

Description: Reads the current magnetic heading. The heading is compensated for platform tilt.

Send: 3 Bytes (**0xA4, 0x09, 0xA0**)  
 Response: 5 Bytes  
**(0xA4, 0x09, <Heading as a 16-bit signed integer>, 0xA0)**

Heading (degrees) = (16-bit Heading value)\*360/4096  
 Heading Range = 0.0 to +359.9

### 3.3.4 Magnetic variation

Description: Set the magnetic variation angle. The heading will be adjusted to indicate true north instead of magnetic north. Magnetic variation angles >+180 and <-180 will be limited to +180 and -180 respectively.

Send: 5 Bytes (**0xA4, 0x83, <16-bit signed integer value MSB first>, 0xA0**)  
 Response: 5 Bytes  
**(0xA4, 0x83, <16-bit signed Variation>, 0xA0)**

16-bit signed integer = (Magnetic Variation)\*10.0

### 3.3.5 Automatic Magnetic Variation

Description: Latitude, Longitude, Altitude, and Day should be programmed separately using their respective commands before issuing this command. Automatic variation will compute the local magnetic variation based on the device's

current geographical location (geodetic coordinate system referenced to the WGS 84 ellipsoid). Once the computation is complete, the magnetic variation will be updated in the compass. **NOTE: TO RETAIN MAGNETIC VARIATION ACCURACY, THE MAGNETIC MODEL MUST BE UPDATED EVERY FIVE YEARS. A SEPARATE PROGRAM IS AVAILABLE ON THE SUPPLIED CD WHICH WILL ASSIST IN DOWNLOADING NEW COEFFICIENTS INTO THE DIGITAL COMPASS. THIS ONLY AFFECTS THE CALCULATION OF TRUE HEADING AND DOES NOT AFFECT MAGNETIC HEADING ACCURACY.** NOTE: Resetting the magnetic parameters to the factory default does not affect the magnetic variation information. To clear out the magnetic variation, manually set the magnetic variation to zero

Send: 3 Byte (**0xA4, 0x0F, 0xA0**)

Response: 5 Bytes

**(0xA4, 0x0F, <Variation as a 16-bit signed integer>, 0xA0)**

16-bit signed integer = (Magnetic Variation)\*10.0

### 3.3.6 Latitude

Description: Set the geodetic latitude angle in degrees (geodetic coordinate system referenced to the WGS 84 ellipsoid). The magnetic variation will not change until latitude, longitude, altitude, and day have been programmed and the Automatic Variation command is issued. Latitude >+90 or <-90 will be limited to +90 and -90 respectively.

Send: 5 Bytes

**(0xA4, 0x8B, <16-bit signed integer value MSB first>, 0xA0)**

Response: 5 Bytes

**(0xA4, 0x8B, <16-bit Latitude>, 0xA0)**

16-bit signed integer = (North(+) or South(-) Latitude in degrees)\*100.0

### 3.3.7 Longitude

Description: Set the geodetic longitude angle in degrees (geodetic coordinate system referenced to the WGS 84 ellipsoid). The magnetic variation will not change until latitude, longitude, altitude, and day have been programmed and the

Automatic Variation command is issued. . Latitude >+180 or <-180 will be limited to +180 and -180 respectively.

Send: 5 Bytes  
(0xA4, 0x8C, 16-bit signed integer value MSB first, 0xA0)

Response: 5 Bytes  
(0xA4, 0x8C, 16-bit signed Longitude, 0xA0)

16-bit signed integer = (East(+) or West(-) Longitude in degrees)\*100.0

### 3.3.8 Altitude

Description: Set the geodetic altitude in meters above sea level (geodetic coordinate system referenced to the WGS 84 ellipsoid). The magnetic variation will not change until latitude, longitude, altitude, and day have been programmed and the Automatic Variation command is issued. Altitude >+32767 or <-32767 will be limited to +32767 and -32767 respectively.

Send: 5 Bytes  
(0xA4, 0x8D, 16-bit signed integer value MSB first, 0xA0)

Response: 5 Bytes  
(0xA4, 0x8D, 16-bit signed Altitude, 0xA0)

16-bit signed integer = +/- Altitude in meters

### 3.3.9 Day

Description: The day is entered as a fractional year based on the current day of the year (i.e. February 15 is the 46<sup>th</sup> day of the 2008. In fractional terms, this would be  $46/365 = 0.126$ . The Fractional Day value for February 15, 2008 would then be 2008.1 (resolution beyond a tenth causes negligible change in variation). The magnetic variation will not change until latitude, longitude, altitude, and day have been programmed and the Automatic Variation command is issued. Day < 2005 will be limited to 2005.

Send: 5 Bytes  
(0xA4, 0x8E, 16-bit unsigned integer value MSB first, 0xA0)

Response: 5 Bytes  
(0xA4, 0x8E, 16-bit unsigned Day, 0xA0)

16-bit unsigned integer = (Fractional Day)\*10.0

### 3.3.10 Magnetic Vector

Description: Measures the magnetic field strength along each axis (X, Y, and Z) and total absolute field strength (MAtotal) in milligauss.

Send: 3 Bytes  
(0xA4, 0x04, 0xA0)

Response: 11 Bytes  
(0xA4, 0x04, MAx, MAy, MAz, MAtotal as 16-bit integers, 0xA0)

### 3.3.11 Magnetic calibration

Description: The method for calibration matches the description in the NMEA section of this document.

Send: 4 Bytes  
(0xA4, 0x56, 8-bit configuration {0x00=OFF, 0x01=3D, 0x02=2D, 0x03 = User, 0xFF = RESET}, 0xA0)

Response: 4 Bytes (0xA4, 0x56, 8-bit configuration, 0xA0)

### 3.3.12 Magnetic Adaption Error

Description: Indicates quality of the adaptive magnetic calibration process. Smaller values represent better magnetic calibration. Adaption error is limited to the range 0 to 10,000.

Send: 3 Byte  
(0xA4, 0x08, 0xA0)

Response: 5 Bytes  
(0xA4, 0x08, Error as a 16-bit unsigned integer, 0xA0)

### 3.3.13 Raw Acceleration

Description: Reads current acceleration directly from accelerometers (AccelX, AccelY, AccelZ). These are raw sensor readings and do not yet have any calibration parameters applied.

Send: 3 Bytes  
(0xA4, 0x05, 0xA0)

Response: 9 Bytes  
(0xA4, 0x05, AccelX, AccelY, AccelZ as 16-bit integers, 0xA0)

### 3.3.14 Pitch and Roll Output

Description: Reads the current platform orientation (Pitch and Roll).

Send: 3 Byte  
(0xA4, 0x06, 0xA0)

Response: 7 Bytes  
(0xA4, 0x06, Pitch, Roll as 16-bit signed integers, 0xA0)

Pitch (in degrees) = (Response Value)\*90/4096

Pitch Range = -90 to +90

Roll (in degrees) = (Response Value)\*180/4096

Acceleration Vector Roll Range = -180 to +180

### 3.3.15 Acceleration Vector

Description: Measures the acceleration along each axis (X, Y, and Z) and total absolute strength (Atotal) in milli-g.

Send: 3 Byte  
(0xA4, 0x07, 0xA0)

Response: 11 Bytes  
(0xA4, 0x07, Ax, Ay, Az, Atotal as 16-bit integers, 0xA0)

### 3.3.16 Temperature

Description: Reads the internal temperature channel of the on-board microcontroller. This measurement is calibrated at the factory, though not required by the compass in determining an accurate heading.

Send: 3 Bytes  
(0xA4, 0x11, 0xA0)

Response: 5 Bytes  
(0xA4, 0x11, Temperature as 16-bit signed integer MSB first, 0xA0)

$\text{Temperature\_C} = (\text{Temperature\_MSB} * 256 + \text{Temperature\_LSB}) / 10.0$

### 3.3.17 BAUD RATE

Description: The factory default BAUD setting is 115200 Baud (0x08). When the baud rate command is issued on the UART, the compass will echo back the command once at the current baud rate and then again at the new baud rate. The baud rate will be stored in EEPROM and will become the new operating communication rate for the UART. The baud rate will apply to Legacy, RFS, NorthTek and NMEA commands issued on the UART.

Send: 4 Bytes  
(0xA4, 0x57, 8-bit BAUD value MSB first, 0xA0)

Response: 4 Bytes  
(0xA4, 0x57, 8-bit BAUD value, 0xA0)

Acceptable Baud Rate Values:

0x01 = 1200 Baud  
0x02 = 2400 Baud  
0x03 = 4800 Baud  
0x04 = 9600 Baud  
0x05 = 19.2 kBaud  
0x06 = 38.4 kBaud

0x07 = 57.6 kBaud  
0x08 = 115.2 kBaud

### 3.3.18 Mounting Configuration

**Description:** Sets the mounting orientation of the compass platform. The default orientation is horizontal. For vertical orientations consult the particular device's data sheet. To determine the orientation setting, read the acceleration vector. When in a static level condition, Az should be approximately +1000mg and Ax and Ay should be close to zero.

**Send:** 4 Bytes  
(0xA4, 0x4A, 8-bit orientation  
{0x00=Horizontal, 0x01=Vertical}, 0xA0)

**Response:** 4 Bytes  
(0xA4, 0x4A, 8-bit orientation, 0xA0)

### 3.4 NorthTek

NorthTek is not a protocol per se. NorthTek is a programming language, a command interpreter, and an execution environment. NorthTek is described in detail in a separate manual. NorthTek provides the user with a command line interface that allows direct interaction with the NavMod. NorthTek also allows the user to load custom programs into the NavMod that will execute a custom user application. The user may create programs that cause some of the standard protocol outputs but at user defined points, or may create custom output depending on the specific need. The user specific algorithms may be used to filter the output data, control the reporting rate, create unusual mounting configurations, or select multiple calibration sets, for example.

Because NorthTek is an environment unto itself, an entire manual is dedicated to the NorthTek System as listed in the references. The user should refer to that manual for detailed descriptions of the commands being used in this manual.

NorthTek provides a command line access to the internal database variables. NorthTek also provides raw and processed sensor data streamed at the acquisition rate. The sections that follow illustrate some of the NorthTek functionality that can be used on the NavMod. The reader should refer to the *NorthTek System Programming Manual* for detailed descriptions on syntax and semantics of the commands used in the examples that follow.

#### 3.4.1 Displaying Database Elements

The internal database is available to the NorthTek command line. See Appendix A for a list of the database elements. All database elements may be printed to the output using the NorthTek command "di.". This command expects a reference to a data element on the stack, and then prints out the current value in a human readable form. The syntax is the name of the data element (case sensitive) followed by a space followed by "di." (also case sensitive). Some specific values are typically more interesting than others to the user. Some of the common values are:

Compass Heading (magnetic)

```
yaw di.<CR>
```

NorthTek prints:

```
yaw = 4.433077e+01
```

```
OK
```

```
pitch di.
```

```
pitch = 1.655078
```

```
OK
```

```
roll di.
```

```
roll = -5.246325e-01
```

```
OK
```

```
yaw di.
```

```
yaw = 12.752021
```

```
OK
```

```
yawt di.
```

```
yawt = 12.639648
```

```
OK
```



```
help pitch
Pitch angle in degrees, positive up
OK
help roll
Roll angle in degrees, positive rightside down
OK
orientation di.
orientation = Horizontal
OK
help magr
Raw Magnetometer X,Y,Z,Total array
OK
help magp
Processed Magnetometer X,Y,Z array
OK
help accelr
Raw Accelerometer X,Y,Z array
OK
help accelp
Processed Accelerometer X,Y,Z array
OK
magr di. magp di. accelr di. accelp di.
magr = 00-- 5424.000000
01-- 1232.000000
02-- 6600.000000
03-- 8651.347656

magp = 00-- 290.135895
01-- -40.983604
02-- 338.315552

accelr = 00-- 0.000000e+00
01-- 0.000000e+00
02-- 0.000000e+00

accelp = 00-- -26.452639
01-- -7.922364
02-- 999.194458
```

This example also shows that multiple commands can be entered on a single input line (up to 80).

Note that help is available for the database variables. The NorthTekSystem (NTS) outputs a longer, more informative string for the variable when

**help <variable>**

is entered.

### 3.4.2 Outputting values in User Defined Format

The user can control the output formatting if desired. The example below shows how to first print the default formatted output for a variable, then print the output in a fixed format (equivalent to %8.3f in "C").

```
pitch di.  
pitch = 1.509415  
OK  
roll di.  
roll = -4.413672e-01  
OK  
yaw di.  
yaw = 6.415520  
OK  
8 3 pitch di@ ff. 1.510OK  
8 3 roll di@ ff. -0.444OK  
8 3 yaw di@ ff. 6.514OK
```

### 3.4.3 Streaming Sensor Data

The NTS allows the user to stream the raw sensor data, the processed sensor data and the computed heading information. Note that once the command is entered the data streams continuously. The user can suspend the output of all streaming data temporarily by using the <CTRL-S> keystroke. Data can be resumed with the <CTRL-Q> keystroke. Various output streams are demonstrated in the example below:

```
1 magp.pOK  
MP: 954362, 5473, 1193, 6571, 293.256195, -38.316196, 336.443970, 7.061350  
MP: 954462, 5505, 1198, 6608, 295.269257, -38.649624, 338.835449, 6.935188  
MP: 954561, 5472, 1216, 6609, 293.155518, -39.872185, 338.939423, 6.863805  
MP: 954661, 5494, 1235, 6625, 294.564667, -41.205887, 339.979187, 6.923146  
MP: 954761, 5460, 1192, 6555, 292.450928, -38.205055, 335.404205, 7.046950 <<< ctrl-s hit here  
0 magp.pOK  
OK  
OK  
1 accelp.pOK <<< ctrl-q hit here  
AP: 1140739, -19, 8, 2027, -26.391603, -8.007813, 999.548462, 1.498477, -0.441541  
AP: 1140839, -19, 8, 2025, -26.367191, -7.925182, 998.910889, 1.504051, -0.448529  
AP: 1140938, -19, 8, 2024, -26.513676, -7.824708, 998.474243, 1.507221, -0.450943  
AP: 1141038, -19, 8, 2027, -26.428226, -7.995606, 999.524048, 1.512748, -0.450165  
AP: 1141138, -18, 8, 2026, -25.966551, -7.837541, 999.211365, 1.513467, -0.453428  
AP: 1141236, -18, 8, 2026, -26.171877, -7.971193, 999.133423, 1.503507, -0.451818 <<< ctrl-s hit here  
0 accelp.p  
1 accelp.p 1 magp.pOK <<< ctrl-q hit here  
AP: 1211835, -19, 8, 2027, -26.513676, -7.983399, 999.755981, 1.500116, -0.440688  
MP: 1211854, 5480, 1220, 6580, 293.658783, -40.205616, 337.067810, 7.080771  
AP: 1211935, -19, 7, 2028, -26.562504, -7.641603, 1000.036743, 1.507705, -0.447420
```

```
MP:1211953,5456,1222,6628,292.148987,-40.316753,340.187134,7.076100
AP:1212034,-19,8,2027,-26.467350,-8.025342,999.837341,1.513208,-0.443575
MP:1212054,5448,1232,6580,291.645721,-40.983604,337.067810,7.101585
AP:1212135,-18,7,2026,-26.159672,-7.739259,999.353149,1.514449,-0.450098
MP:1212154,5464,1220,6611,292.652252,-40.205616,339.043396,7.164870 <<< ctrl-s hit here
0 magp.p 0 accelp.pOK
```

The format of the XXX.p commands is shown below.

#### 3.4.3.1 Accelerometer

**1 accel.p // enables print of raw accelerometer readings**

// Output format is

// A:%6d,%6d,%6d,%6d

// printing timestamp(ms), x, y and z accelerometer values, 2048 = 1g for the 4g accelrange setting (default) and 1024=1g for the 8g accelrange setting

**0 accel.p // disables**

**1 accelp.p // enables print of raw/processed accelometer readings**

// Output format is

// AP:%d,%d,%d,%d,%f,%f,%f

// printing timestamp(ms), x, y and z accelerometer raw values and x,y and z linearized values, the raw values are scaled such that 2048 = 1g for the 4g accelrange setting (default) and 1024=1g for the 8g accelrange setting and the linearized values are in the units of milli-gs.

**0 accelp.p // disables**

#### 3.4.3.2 Gyro

**1 gyro.p // enables print of raw gyroscope readings**

// Output format is

// G:%6d,%6d,%6d,%6d

// printing timestamp(ms), x, y, z values

**0 gyro.p // disables**

**1 gyrop.p // enables print of raw and processed gyro readings**

// Output format is

// GP:%d,%d,%d,%d,%f,%f,%f

// printing timestamp(ms), x, y and z gyro raw values and x,y and z linearized values

// with units of radians/sample, use the value of gyroSampleRate to convert

**0 gyrop.p // disables**

#### 3.4.3.3 Magnetometer

**1 mag.p // enables print of raw magnetometer readings**

// Output format is

// M:%6d,%6d,%6d,%6d

// printing timestamp(ms), x, y and z magnetometer values

```
0 mag.p // disables
```

```
1 magp.p // enables print of raw and processed magnetometer readings
```

```
// Output format is
```

```
// MP:%d,%d,%d,%d,%f,%f,%f
```

```
// printing timestamp(ms), x, y and z magnetometer raw values and x,y and z linearized values
```

```
0 magp.p // disables
```

#### **3.4.3.4 All raw sensor data**

```
1 s.p // enables print of all raw sensor data
```

```
// Output format is
```

```
// %d,%d,%d,%d,%d,%d,%d,%d,%d,%d,%d,%d
```

```
// mag x,y,z, accel x,y,z, gyro x,y,z and raw temp (1/10 deg C) respectively
```

```
0 s.p // disables
```

#### **3.4.3.5 Computed Roll, Pitch and Yaw**

```
1 compass.p // enables print of computed attitude and heading
```

```
// Output format is
```

```
// C,%d,%7.2f,%7.2f,%7.2f
```

```
// timestamp(ms), pitch, roll and yaw respectively
```

```
0 compass.p // disables
```

#### **3.4.3.6 Computed Quaternions**

```
1 quat.p // enables print of computed quaternions
```

```
// Output format is
```

```
// QUAT:%f,%f,%f,%f
```

```
// quaternion vector (w,x,y,z) respectively
```

```
0 quat.p // disables
```

#### **3.4.3.7 Custom Combination Print Streaming (AHRS-8 User Port only)**

The customizable print streaming commands allows selection of the data to be streamed and provides control of when the data is streamed.

For this capability, there are three configuration variables: printmodulus, printtrigger and printmask plus the following set of constants:

magr\_trigger

magp\_trigger

accelr\_trigger

```
accelp_trigger  
gyror_trigger  
gyrop_trigger  
yaw_trigger  
yawt_trigger  
quat_trigger  
temp_trigger  
time_trigger
```

Each of the above trigger definitions is a single bit. If a bit is set in the printmask, then when a print trigger event occurs, the data that is associated with that bit will print in the output. Note that, although the triggers occur in interrupt handlers or high priority tasks, the actual printing occurs in a low priority task. This may cause a small delay in the print from the point of the trigger but is necessary to avoid interfering with the data acquisition and computations.

The printmodulus indicates how many trigger events must take place before the printing occurs.

For example, suppose we want to print the raw and processed magnetometer data and the temperature and we want to print on every 100th processed magnetometer calculation. To accomplish this, we would set the print mask using this sequence of NorthTek:

```
>>> printmask  
>>> magr_trigger magp_trigger or temp_trigger or set drop
```

The “drop” is needed because the “set” operator puts a status result on the top of the stack. If the “drop” is not used, then eventually, the stack may overflow.

To cause it to print on every 100<sup>th</sup> trigger event :

```
>>> printmodulus 100 set drop
```

The trigger condition is set

```
>>> printtrigger magp_trigger set drop
```

Note that this kind of printing is on by default, but can be disabled with printer\_mask d.off or suspended with CTRL-S, or by setting the printtrigger to 0

```
>>> printtrigger 0 set drop
```

Note that we can cause the print to be output with the word “p.”. With the “p.” command, we can write our own trigger condition in NorthTek and then evoke this printout.

Given the above configuration, the output is:

```
P:,659539,mr,5890,-712,7323,mp,327.566681,94.818001,385.820099,T,33.06
P:,660481,mr,5968,-695,7342,mp,314.355835,93.428726,386.015045,T,33.06
P:,661423,mr,5850,-661,7316,mp,330.460510,93.706581,385.495178,T,33.06
P:,662365,mr,5995,-742,7337,mp,314.104187,93.914970,386.534943,T,33.00
P:,663306,mr,5965,-699,7328,mp,324.169617,93.150871,385.625153,T,33.00
P:,664248,mr,5902,-694,7337,mp,320.206360,92.803551,386.210022,T,33.00
P:,665190,mr,5900,-677,7326,mp,320.080536,91.622673,385.495178,T,33.00
```

The interpretation of this output is P:,TIME,mr(indicates mag raw),x,y,z,mp(indicates mag proc),x,y,z,T(temp),value.

The printmodulus for accelr and gyror is applied to the RAW sample rates, i.e. 400 hz on gyro/accel, NOT on the divided down values.

This is what we get when we set printmask to all of the trigger constants:

```
P:,878979,mr,6174,-751,7403,mp,337.317566,96.762985,390.499084,ar,22,38,2052,ap,-
6.347656,-22.460938,1011.718750,gr,-8,-4,26,gp,0.000010,0.000039,-
0.000102,y,342.53,yt,342.53,q,0.988351,-0.009816,0.004613,-0.151807,T,32.19
P:,879920,mr,5985,-763,7416,mp,327.126343,95.165321,389.914185,ar,21,34,2049,ap,-
6.591797,-20.874023,1010.375977,gr,-3,-16,9,gp,-0.000003,0.000004,-
0.000050,y,342.53,yt,342.53,q,0.988343,-0.009981,0.004853,-0.151841,T,32.19
P:,880862,mr,6045,-735,7397,mp,334.172119,97.874405,391.148926,ar,21,35,2046,ap,-
6.835938,-21.118164,1009.033203,gr,6,-25,6,gp,-0.000035,-0.000023,-
0.000042,y,342.54,yt,342.54,q,0.988360,-0.010000,0.004931,-0.151726,T,32.19
```

The time\_trigger is triggered by the 1msec clock tick, so a time based output can be created if necessary.

Note that if too much data is specified to print for the baud rate, the NavMod will drop whole lines of output. The algorithm will not let another trigger occur until the previous output has completed. Dropping whole lines avoids the problem of erroneous data due to dropped digits.

Here is a sample script which is similar to gyrop.p but with temperature added:

```
printmodulus 4 set drop // every 4th raw gyro
printmask // variable that gets set in the next line
gyror_trigger gyrop_trigger or temp_trigger or set drop
printtrigger printmask set drop
```

### 3.4.4 Reset

The NorthTek “reset” command will invoke a reset of the processor. Allow a few seconds for the processor to come back up. All variables will be reset to their default value or read from non-volatile memory if the variable is marked “permanent”. Any NorthTek script which has been loaded will be lost unless the script has been loaded into EEPROM using the userOpen and userClose commands (see NorthTek Application Note AN-1002 as an example). Note that if a EEPROM update is in progress, then the reset will be delayed until the update completes. Also consider that the power up sequence takes time to reload configuration from EEPROM, so the reset command has a variable delay.

### 3.4.5 Setting Database Elements

Integers and Ordinals can be set using the following syntax. Note that ordinals are set with an integer but display with the ordinal name.

**<variableName> <integerValue> set**

Example:

```
orientation 2 set drop  
orientation di.  
orientation = Left Edge
```

Floating point values can be set using the following syntax:

**<variableName> F<floatValue> set**

Example:

```
magvar F5.9 set drop
```

Arrays can be set using the following syntax:

**<variableName> array[ <startIndex> <endIndex> <sequence of numbers> ]array set**

Example:

```
boresightMatrixX array[ 0 2 F1.0 F0.0 F0.0 ]array set drop
```

### 3.4.6 Calibration Data Control

The commands in this section can be set using RFS as well as NorthTek.

#### 3.4.6.1 Restore In-field calibration data

The NavMod comes with a nominal field calibration setup. The user may perform an in-field calibration as described elsewhere in this document. Performing the in-field calibration stores internal coefficients. If in-field calibration has been performed and the magnetic environment has changed, the in-field calibration may be in error. The in-field calibration can be re-performed or the in-field

calibration data can be reset to the factory values. To reset the in-field calibration to the factory values:

***restoreFieldCal 1 set drop***

#### **3.4.6.2 Restore Factory calibration data**

Each NavMod is individually internally calibrated at the factory. Because of the unique ability to configure the NavMod, the user may choose to modify the internal calibration (for example magOffset). If at some time the user wishes to return the NavMod to the factory calibration, it can be restored with the following command:

***restoreFactoryCal 1 set drop***

#### **3.4.6.3 Run the Gyro Offset Calibration**

The GEDC-6 uses an advanced algorithm to continuously track the gyro offsets during normal use. Therefore, calibration of the gyro offsets should not be necessary. If offsets exist in the gyros when the GEDC-6 is stationary, the user would encounter a slow, constant change in orientation (i.e. drifting) over time. The following steps describe how to successfully execute an in-field calibration of the gyros:

- 1) Insure that the GEDC-6 is stationary. Orientation of the compass does not matter.
- 2) Invoke the Gyro Offset Calibration option using the command:  
***InvokeGyroOffsetCal 1 set drop***
- 3) Once activated, keep the GEDC-6 stationary for 30 seconds to insure that the offsets measurements are complete.
- 4) The gyro calibration will end automatically and return to normal gyro offset tracking after about 20 seconds. The new gyro offset will be saved to internal non-volatile memory.
- 5) After 30 seconds from the start of calibration, the GEDC-6 can be used.

Note: Gyro offset calibration is not applicable to the Sparton DC-4 Digital Compass.

#### **3.4.7 3D Compass Calibration**

This script performs 3D compass calibration. To perform calibration use a dumb terminal to send this to the NavMod (if huh? is seen flying by, add some delay to each line transmitted or reduce the baud to 38400). Once the script has been loaded, send the command "cal3D". The script will then prompt the user to capture calibration points. The user should move the compass around and select between 4 and 12 points, then hit ESC. The script will then print the magnetic error at a 0.5 Hz rate. Observe the magnetic error until it converges sufficiently then hit the spacebar or any other key. The compass will now be field calibrated. The cal3D command may be re-entered as many times as desired without re-loading the macro. The macro needs to be loaded only once while the NavMod remains powered up. There is enough information in the basic programming section and the appendix to analyze this macro sufficiently should the user desire to extend this functionality to other custom user scripts.

```
: cal3D // start compiling a new word, called cal3D
calmode 1 set drop // set the calibration mode to 3D
." Calibration starting" cr // tell the user we are starting then <CR>
```



```

calCommand cal_start set drop          // issue the cal_start command

." Press any key to take next point, ESC to finish" cr // Tell the user what to do

// The code now grabs a point, the user changes the
// compass position and repeats the cal3DState
// from 4-12 times total.

begin                                  // begin a begin-while-repeat loop
    key 27 = 0=                        // wait for key input compare with ESC
                                        // invert the logic (0=)
    while                             // only continue if the TOS has a true,
                                        // i.e. user hit a key != ESC
        calCommand cal_capture set drop // take another point
        250 delay                      // wait 250 msec to allow point to be counted
        calNumPoints di.               // print out point number
repeat                                // end of begin-while-repeat

// Now the points are captured,
// command the SW to compute the cal values:

calCommand cal_end_capture set drop // issue command to end the capture of points

." Starting error settling" cr          // tell user what's going on
." Press any key to terminate" cr      // issue instructions

// The user observes magErr to watch it settle
// at a minimum value (EKit can display every sec or so):

begin                                  // keep printing magErr at .250 sec intervals
    ?key 0=                            // ?key returns false hit a key is hit
                                        // 0= inverts so then...
    while                             // while tests for no key pressed
        magErr di.                    // print the mag error
        250 delay                     // wait 250 msec to print again
repeat                                // end of begin-while-repeat
." Calibration done!" cr                // celllll-e-braaaate good times, come on!
calCommand cal_end set drop             // cal computation
calmode 0 set drop                     // terminate but "I'll be back"
;                                       // end of compilation
// To execute the calibration simply type
// cal3D
// Or uncomment the line above and the script will run when it is loaded.

```

# Appendices

## A Variable Detailed Descriptions

### A.1 Variables by Name

In the tables below, “Permanent” indicates that the value is stored in non-volatile memory.

#### A.1.1 vidCount

Type:	Int32
Detailed Description:	Describes how many RFS variables exist in the database.
Range:	3..total number of variables.
Default:	n/a
Persistence:	Permanent
Access	Read Only

#### A.1.2 name

Type:	String
Detailed Description:	Gives the name of the device such as “AHRS-8 (Attitude Heading and Reference System)”
Range:	n/a
Default:	n/a
Persistence:	Constant
Access:	Read Only

#### A.1.3 quiet

Type:	Constant
Detailed Description:	Allows the user to suppress some debug output at runtime.
Range:	0..1, 0= Off 1 = On
Default:	0
Persistence:	Temporary
Access:	read/write

#### A.1.4 VERSION

Type:	String
Detailed Description:	Contains the code version. Format is \$ Version: x.x.x
Range:	n/a
Default:	n/a
Persistence:	Constant
Access:	Read Only

#### A.1.5 REVISION

Type:	String
-------	--------

Detailed Description:	Contains the code's configuration revision number. Format is \$Revision: DDD \$, where DDD is a decimal number.
Range:	n/a
Default:	n/a
Persistence:	Constant
Access:	Read Only

#### A.1.6 serialnumber

Type:	String
Detailed Description:	Contains the factory set value for this unit's serial number.
Range:	n/a
Default:	n/a
Persistence:	Constant
Access:	Read Only

#### A.1.7 orientation

Type:	Ordinal
Detailed Description:	Physical orientation of compass relative to the host application. Heading, pitch and roll will be translated from that of the NavMod to that of the application according to the given setting. See the Sparton Digital Compass Product Guide for details
Range:	0..4 0 = horizontal 1 = vertical 2 = left edge 3 = right edge 4 = inverted
Default:	0
Persistence:	Permanent
Access:	Read/Write

#### A.1.8 baud

Type:	Ordinal
Detailed Description:	Selects the user port baud rate using an index.
Range:	0..8 0 = 300 1 = 1200 2 = 2400 3 = 4800 4 = 9600 5 = 19200 6 = 38400 7 = 57600 8 = 115200
Default:	0
Persistence:	Permanent
Access:	Read/Write

### A.1.9 pitch

Type:	Float32
Detailed Description:	Gives the computed pitch angle, positive is nose up, units are degrees
Range:	-180.0 .. 180.0
Default:	n/a
Persistence:	Temporary
Access:	Read Only

### A.1.10 roll

Type:	Float32
Detailed Description:	Gives the computed roll angle, positive direction is right wing down, units are degrees
Range:	-180.0 .. 180.0
Default:	n/a
Persistence:	Temporary
Access:	Read Only

### A.1.11 yaw

Type:	Float32
Detailed Description:	Gives the computed magnetic heading angle, positive value starting at 0.0 = magnetic North, units are degrees
Range:	0.00 .. 360.0
Default:	n/a
Persistence:	Temporary
Access:	Read Only

### A.1.12 yawt

Type:	Float32
Detailed Description:	Gives the computed true heading angle in degrees, positive value starting at 0.0 = true North. Only valid if a declination has been set manually or by execution of the world magnetic model with a valid position and time.
Range:	0.00 .. 360.0
Default:	n/a
Persistence:	Temporary
Access:	Read Only

### A.1.13 quaternion

Type:	ArrayFloat32
Detailed Description:	4 element quaternion array representing w, x, y, and z respectively. Quaternions represent the NavMod's attitude similar to pitch/roll/heading but without the problem of Gimbal lock. Thus quaternions are recommended over pitch/roll/heading for any device that has full 3D range of rotation. Note that this quaternion is relative to magnetic North rather than true North.
Range:	n/a
Default:	n/a
Persistence:	Temporary
Access:	Read Only

#### A.1.14 lat

Type:	Float32
Detailed Description:	This variable needs to be set by the user prior to executing the world magnetic model. Value is latitude in degrees and fractions of a degree.
Range:	+/- 90 degrees.
Default:	0.0
Persistence:	Permanent
Access:	Read/Write

#### A.1.15 lonG

Type:	Float32
Detailed Description:	This variable needs to be set by the user prior to executing the world magnetic model. Value is longitude in degrees and fractions of a degree.
Range:	+/- 180.0 degrees
Default:	0.0
Persistence:	Permanent
Access:	Read/Write

#### A.1.16 alt

Type:	Float32
Detailed Description:	The altitude needs to be set by the user prior to executing the World Magnetic Model to compute magnetic variation. Units are in meters.
Range:	+/- 10000 meters
Default:	0.0
Persistence:	Permanent
Access:	Read/Write

#### A.1.17 day

Type:	Float32
Detailed Description:	The date which needs to be set by the user prior to executing the World Magnetic Model. Units are in years. Precision is to 0.1 of a year. Accuracy beyond 0.1 year does not improve the World Magnetic Model estimate.
Range:	2010.0 to 3000.0
Default:	2010.0
Persistence:	Permanent
Access:	Read/Write

#### A.1.18 restorefactorycal

Type:	Ordinal
Detailed Description:	The user can command the calibration data to be reset to the factory settings by setting this variable to one (will automatically be reset to 0).
Range:	0..1
Default:	0
Persistence:	Temporary
Access:	Read/Write

#### A.1.19 set\_wmm

Type:	Ordinal
Detailed Description:	Command to update the World Magnetic Model offset (magvar) in accordance with the current location in the world, uses the variables lat, lonG, alt and day which must be previously provided by the user. Set this variable to 1 to invoke the World Magnetic Model. Reading this variable has no meaning. The result is stored in magvar and as seen in the difference between yawt and yaw
Range:	0..1 (automatically resets to 0 when set to 1)
Default:	0
Persistence:	Temporary
Access:	Read/Write

#### A.1.20 magvar

Type:	Float32
Detailed Description:	Contains the difference between the magnetic heading and the true heading. This value can be computed indirectly using set_wmm or can be directly written to the NavMod by the user.
Range:	+/- 360.0 degrees
Default:	0.0
Persistence:	Permanent
Access:	Read/Write

#### A.1.21 wmmGD

Type:	ArrayFloat32
Detailed Description:	World Magnetic Model geodetic magnetic field X Y Z at Lat/Long
Range:	N/A
Default:	<value>0.521215</value> <value>0.0</value> <value>0.853426</value> <value>1.0
Persistence:	Permanent
Access:	Read Only

#### A.1.22 wmmHasRun

Type:	Ordinal
Detailed Description:	Indicates whether the World Magnetic Model (WMM) has been run (implies wmmGD and magvar are valid), a value of 1 means the WMM has been run.
Range:	0..1
Default:	0
Persistence:	Permanent
Access:	Read Only

#### A.1.23 magr

Type:	ArrayFloat32
Detailed Description:	Raw Magnetometer X Y Z array
Range:	n/a
Default:	n/a

Persistence:	Temporary
Access:	Read Only

#### A.1.24 magp

Type:	ArrayFloat32
Detailed Description:	Processed Magnetometer X Y Z array, this value takes magr and applies the factory calibration, the field calibration data and the cross axis correction (magCrossAxisCorrection)
Range:	n/a
Default:	n/a
Persistence:	Temporary
Access:	Read Only
Units	milli-gauss

#### A.1.25 accelr

Type:	ArrayFloat32
Detailed Description:	Raw Magnetometer X Y Z array, 2048=1g when accelrange=4g, 1024=1g when accelrange=8g
Range:	n/a
Default:	n/a
Persistence:	Temporary
Access:	Read Only

#### A.1.26 accelp

Type:	ArrayFloat32
Detailed Description:	Processed Accelerometer X Y Z array, this value takes accelr and applies the factory calibration and the cross axis correction (accelCrossAxisCorrection). Units are in milli-gs.
Range:	n/a
Default:	n/a
Persistence:	Temporary
Access:	Read Only
Units	milli-g

#### A.1.27 gyror

Type:	ArrayFloat32
Detailed Description:	Applies to GEDC-6 and AHRS-8 only. Raw gyro X Y Z array
Range:	n/a
Default:	n/a
Persistence:	Temporary
Access:	Read Only

#### A.1.28 gyrop

Type:	ArrayFloat32
Detailed Description:	Applies to GEDC-6 and AHRS-8 only. Processed gyro X Y Z array, this value takes gyror and applies the factory calibration. Units are radians/sample. To convert gyrop vector to millidegrees per second, get the sample rate using the command "gyroSampleRate di." (note the dot at the end), then multiply each

	vector element with $\text{gyroSampleRate} * (180.0/\text{PI}) * 1000.0$ .
Range:	n/a
Default:	n/a
Persistence:	Temporary
Access:	Read Only
Units	degrees/second

#### A.1.29 gyroSampleRate

Type:	Float32
Detailed Description:	Applies to GEDC-6 and AHRS-8 only. Actual sample rate for the gyro (samples/second) as measured once per second.
Range:	n/a
Default:	100.0
Persistence:	Temporary
Access:	Read Only
Units	samples/second

#### A.1.30 positionrate

Type:	Int32
Detailed Description:	This variable determines the interval of the automatic output of the RFS variable "position". It may be 0 indicating that there is no automatic output, or up to 180000 msecs indicating 180 seconds (every 3 minutes).
Range:	0..180000 (0 = off) (msecs)
Default:	0
Persistence:	Temporary
Access:	Read/Write

#### A.1.31 position

Type:	Bit Field
Detailed Description:	RFS only. This is an aggregate bit field (packed structure) descriptor that by default contains pitch, roll, yawt, magErr, temperature, magp X/Y/Z, accelp X/Y/Z, gyrop X/Y/Z, respectively (32-bits each). It may be redefined to contain up to 16 variables. The user may define which variables are carried in this bit field and the format is stored permanently (survives a power cycle). This variable can be output at a repeating rate using the positionrate variable.
Range:	n/a
Default:	n/a
Persistence:	Permanent
Access:	Read/Write

#### A.1.32 composite2

Type:	Bit Field
Detailed Description:	RFS only. A user defined composite variable (packed structure), similar to "position". The user may define up to 16 fields in this variable and query it with RFS.
Range:	n/a
Default:	n/a



Persistence:	Permanent
Access:	Read/Write

### A.1.33 composite3

Type:	Bit Field
Detailed Description:	RFS only. A user defined composite variable (packed structure), similar to “position”. The user may define up to 16 fields in this variable and query it with RFS.
Range:	n/a
Default:	n/a
Persistence:	Permanent
Access:	Read/Write

### A.1.34 calmode

Type:	Ordinal
Detailed Description:	Calibration Mode – see the Magnetic Field Calibration section in which it is set by NorthTek as “ <b>calmode v set</b> ”, or the NMEA command \$PSPA,CAL=, or by RFS set command. See also the 3D Compass Calibration subsection in the NorthTek section for a script that uses these variables, or the NMEA calibration section.
Range:	0..3 0 = CalModeOff 1 = CalMode3D 2 = CalMode2D 3 = User
Default:	0
Persistence:	Temporary
Access:	Read/Write

### A.1.35 calCommand

Type:	Ordinal
Detailed Description:	Commands the next step in the “in field” calibration procedure - see the Magnetic Field Calibration section in the NMEA calibration section. The commands are ignored unless calmode is not off. See also the 3D Compass Calibration subsection in the NorthTek section for a script that uses these variables.
Range:	0..4 0 = CALIBRATION_COMMAND_START 1 = CALIBRATION_COMMAND_CAPTURE_POINT 2 = CALIBRATION_COMMAND_END_CAPTURE 3 = CALIBRATION_COMMAND_END_CALIBRATION 4 = CALIBRATION_RESET
Default:	n/a
Persistence:	Temporary
Access:	Read/Write

### A.1.36 calNumPoints

Type:	Int32
-------	-------

Detailed Description:	Number of points collected for the magnetic calibration procedure - see the Magnetic Field Calibration section in which it is reported by the \$PSPA,CAL_CMD=CAPTURE,POINTS= response, but can also be read directly via RFS or NorthTek, see the NorthTek section for the display command (di.), see also the 3D Compass Calibration subsection in the NorthTek section for a script that uses these variables.
Range:	0..12
Default:	0
Persistence:	Temporary
Access:	Read/Write

### A.1.37 magErr

Type:	Float32
Detailed Description:	Magnetic error term resulting from the magnetic calibration procedure – this is not the actual error but is a quality factor that is a function of the points collected in the “in field” calibration procedure, see the Magnetic Field Calibration section in which it is reported by the \$PSPA,MAGERR,RPT=0.5 command, but can also be viewed directly using RFS or NorthTek, see the NorthTek section for the display command (di.), see also the 3D Compass Calibration subsection in the NorthTek section for a script that uses these variables
Range:	N/A
Default:	0
Persistence:	Temporary
Access:	Read Only

### 1.1.38 wlim

Type:	Float32
Detailed Description:	Algorithm constant – Controls the reliance on gyros that is motion dependent. Rotations that exceed wlim will tend to favor the gyro estimates.
Range:	N/A
Default:	N/A
Persistence:	Permanent
Access:	Read/Write

### 1.1.39 alim

Type:	Float32
Detailed Description:	Algorithm constant – Controls estimator sensitivity to transient acceleration anomalies
Range:	N/A
Default:	N/A
Persistence:	Permanent
Access:	Read/Write

### 1.1.40 mlim

Type:	Float32
Detailed Description:	Algorithm constant – Controls estimator sensitivity to transient magnetic anomalies

Range:	N/A
Default:	2.0
Persistence:	Permanent
Access:	Read/Write

#### 1.1.41 km0

Type:	Float32
Detailed Description:	Algorithm constant - magnetic gain. This variable sets an overall reliance on the magnetoemters versus the gyros that are independent of motion. Lower values will force the compass to rely more heavily on the gyro estimates rather than the absolute magnetometer values. CAUTION: Setting this value too low may cause the heading orientation to drift due to accumulated errors in the estimation process.
Range:	N/A
Default:	N/A
Persistence:	Permanent
Access:	Read/Write

#### 1.1.42 ka0

Type:	Float32
Detailed Description:	Algorithm constant - acceleration gain. This variable sets an overall reliance on the accelerometers versus the gyros that are independent of motion. Lower values will force the compass to rely more heavily on the gyro estimates rather than the absolute accelerometer values. CAUTION: Setting this value too low may cause the heading orientation to drift due to accumulated errors in the estimation process.
Range:	N/A
Default:	N/A
Persistence:	Permanent
Access:	Read/Write

#### 1.1.43 emlim

Type:	Float32
Detailed Description:	Algorithm constant – Controls the convergence between actual magnetometer sensor orientation and the internal estimator during periods of excessive magnetic disturbances.
Range:	N/A
Default:	0.1
Persistence:	Permanent
Access:	Read/Write

#### 1.1.44 ealim

Type:	Float32
Detailed Description:	Algorithm constant – Controls the convergence between actual accelerometer

	sensor orientation and the internal estimator during periods of excessive acceleration disturbances.
Range:	N/A
Default:	0.1
Persistence:	Permanent
Access:	Read/Write

#### 1.1.45 kgyrooffset

Type:	Float32
Detailed Description:	Applies to GEDC-6 and AHRS-8 only. Algorithm constant – Controls the sensitivity of the gyro offset tracking.
Range:	0 .. 1000.0
Default:	1.0
Persistence:	Permanent
Access:	Read/Write

#### A.1.46 magOffset

Type:	ArrayFloat32
Detailed Description:	Calibration offset for the magnetometer – is subtracted from magr as part of computing magp, for AHRS-8, this is a computed value based on the magOffsetTC variables
Range:	n/a
Default:	n/a
Persistence:	Permanent (DC-4 and GEDC-6) Temporary (AHRS-8)
Access:	Read/Write (DC-4, GEDC-6) Read Only (AHRS-8)

#### A.1.47 tempCalOffset

Type:	Int32
Detailed Description:	Applies to DC-4 and GEDC-6 only. Temperature at which the magnetometer calibration parameters were determined.
Range:	n/a
Default:	n/a
Persistence:	Permanent
Access:	Read/Write

#### A.1.48 magCalTemperature

Type:	Float32
Detailed Description:	Applies to AHRS-8 only. Base temperature for the magnetometer temperature compensations.
Range:	-45 .. 90
Default:	n/a
Persistence:	Permanent
Access:	Read/Write

#### A.1.49 **magOffsetCorrectionXPlus ,magOffsetCorrectionYPlus, magOffsetCorrectionZPlus, magOffsetCorrectionXNeg, magOffsetCorrectionYNeg, magOffsetCorrectionZNeg**

Type:	ArrayFloat32
Detailed Description:	Applies to DC-4 and GEDC-6 only. Factory calibration temperature correction coefficients for the magnetometer - is used to compute the offset for the magnetic vector. The “Plus” arrays are used when the corresponding component is positive and the “Neg” arrays are used when the corresponding component is negative.
Range:	n/a
Default:	n/a
Persistence:	Permanent
Access:	Read/Write

#### A.1.50 **magOffsetTCX, magOffsetTCY, magOffsetTCZ**

Type:	ArrayFloat32
Detailed Description:	Applies to AHRS-8 only. Factory temperature compensated calibration offsets for the magnetometer - is used to compute the offset compensation based on current temperature (magOffset).
Range:	n/a
Default:	n/a
Persistence:	Permanent
Access:	Read/Write

#### A.1.51 **magLinearityXPlus ,magLinearityYPlus, magLinearityZPlus, magLinearityXNeg, magLinearityYNeg, magLinearityZNeg**

Type:	ArrayFloat32
Detailed Description:	Applies to DC-4 and GEDC-6 only. Factory calibration scalars for the magnetometer - is used to “linearize” the magnetic vector after the offset has been applied. The “Plus” arrays are used when the corresponding component is positive and the “Neg” arrays are used when the corresponding component is negative. In each array, the first component is the scalar that multiplies the X (or Y or Z), then the second multiplies the X (or Y or Z) squared and the third multiplies the X (or Y or Z) cubed and then they are summed to yield the processed mag X (or Y or Z).
Range:	n/a
Default:	n/a
Persistence:	Permanent
Access:	Read/Write

#### A.1.52 **magLinearityXTC0 ,magLinearityXTC1, magLinearityXTC2, magLinearityYTC0, magLinearityYTC1, magLinearityYTC2, magLinearityZTC0, magLinearityZTC1, magLinearityZTC2**

Type:	ArrayFloat32
Detailed Description:	Applies to AHRS-8 only. Factory temperature compensated calibration scalars for the magnetometer - is used to compute the linearity compensation factors based on current temperature (magLinearityX, magLinearityY, magLinearityZ).

Range:	n/a
Default:	n/a
Persistence:	Permanent
Access:	Read/Write

#### A.1.53 magLinearityX, magLinearityY, magLinearityZ

Type:	ArrayFloat32
Detailed Description:	Applies to AHRS-8 only. Computed calibration scalars for the magnetometer - is used to “linearize” the magnetic vector after the offset has been applied. Computation is based on the current temperature and the factory temperature compensated calibration scalars for each axis (e.g. magLinearityXTC0). In each array, the first component is the scalar that multiplies the X (or Y or Z), then the second multiplies the X (or Y or Z) squared and the third multiplies the X (or Y or Z) cubed and then they are summed to yield the processed mag X (or Y or Z).
Range:	n/a
Default:	n/a
Persistence:	Temporary
Access:	Read Only

#### A.1.54 magCrossAxisCorrectionX, magCrossAxisCorrectionY, magCrossAxisCorrectionZ

Type:	ArrayFloat32
Detailed Description:	Factory calibration cross axis correction – these are the 3 rows of a matrix that is multiplied (dot product) by the calibrated magnetometer vector to get the final (magp) vector
Range:	n/a
Default:	n/a
Persistence:	Permanent
Access:	Read Only

#### A.1.55 magFieldCalX, magFieldCalY, magFieldCalZ

Type:	ArrayFloat32
Detailed Description:	In field calibration offset and scalars. This is computed by the 2D or 3D calibration procedure (see Magnetic Field Calibration section). The first component is subtracted from the factory calibrated mag X/Y/Z and the second component divides into the difference.
Range:	n/a
Default:	n/a
Persistence:	Permanent
Access:	Read/Write

#### A.1.56 accelrange

Type:	Ordinal
Detailed Description:	Applies to AHRS-8 only. Accelerometer full scale range setting. The higher

	range is a trade-off with less resolution. A reset or power cycle must be performed for this change to take effect in the accelerometer.
Range:	0..1 0 = 4g (default) 1 = 8g
Default:	0
Persistence:	Permanent
Access:	Read/Write

#### A.1.57 accelOffset

Type:	ArrayFloat32
Detailed Description:	Calibration offset for the accelerometer - is subtracted from accelr as part of computing accelp, for AHRS-8, this is computed based on the accelOffsetTC variables.
Range:	n/a
Default:	n/a
Persistence:	Permanent (DC-4 and GEDC-6) Temporary (AHRS-8)
Access:	Read/Write (DC-4, GEDC-6) Read Only (AHRS-8)

#### A.1.58 accelGyroCalTemperature

Type:	ArrayFloat32
Detailed Description:	Applies to AHRS-8 only. Temperature (deg C) at which the Rate Table temperature compensation parameters for both accelerometer and gyro are computed.
Range:	-45 .. 90
Default:	n/a
Persistence:	Permanent
Access:	Read/Write

#### A.1.59 accelOffsetTCX, accelOffsetTCY, accelOffsetTCZ

Type:	ArrayFloat32
Detailed Description:	Applies to AHRS-8 only. Temperature compensated calibration offsets for the accelerometer which are used to compute the offset compensation based on current temperature (accelOffset).
Range:	n/a
Default:	n/a
Persistence:	Permanent
Access:	Read/Write

#### A.1.60 accelLinearityXPlus, accelLinearityYPlus, accelLinearityZPlus, accelLinearityXNeg, accelLinearityXPlus, accelLinearityYPlus, accelLinearityZPlus, accelLinearityXNeg, accelLinearityYNeg, accelLinearityZNeg

Type:	ArrayFloat32
Detailed Description:	Applies to DC-4 and GEDC-6 only. Factory calibration scalars for the accelerometer - is used to "linearize" the accelerometer vector after the offset has been applied. The "Plus" arrays are used when the corresponding component is positive and the "Neg" arrays are used when the corresponding

	component is negative. In each array, the first component is the scalar that multiplies the X (or Y or Z), then the second multiplies the X (or Y or Z) squared and the third multiplies the X (or Y or Z) cubed and then they are summed to yield the processed accel X (or Y or Z).
Range:	n/a
Default:	n/a
Persistence:	Permanent
Access:	Read/Write

#### A.1.61 accelLinearityXTC0, accelLinearityXTC1 , accelLinearityXTC2, accelLinearityYTC0, accelLinearityYTC1, accelLinearityYTC2, accelLinearityZTC0, accelLinearityZTC1, accelLinearityZTC2

Type:	ArrayFloat32
Detailed Description:	Applies to AHRS-8 only. Factory temperature compensated calibration scalars for the accelerometer -used to compute the linearity compensation factors based on current temperature (accelLinearityX, accelLinearityY, accelLinearityZ).
Range:	n/a
Default:	n/a
Persistence:	Permanent
Access:	Read/Write

#### A.1.62 accelLinearityX ,accelLinearityY, accelLinearityZ

Type:	ArrayFloat32
Detailed Description:	Applies to AHRS-8 only. Computed calibration scalars for the accelerometer - used to “linearize” the accelerometer vector after the offset has been applied. Computation is based on the current temperature and the factory temperature compensated calibration scalars for each axis (e.g. accelLinearityXTC0). In each array, the first component is the scalar that multiplies the X (or Y or Z), then the second multiplies the X (or Y or Z) squared and the third multiplies the X (or Y or Z) cubed and then they are summed to yield the processed accel X (or Y or Z).
Range:	n/a
Default:	n/a
Persistence:	Temporary
Access:	Read Only

#### A.1.63 accelCrossAxisCorrectionX, accelCrossAxisCorrectionY , accelCrossAxisCorrectionZ

Type:	ArrayFloat32
Detailed Description:	Factory calibration cross axis correction – these are the 3 rows of a matrix that is multiplied (dot product) by the calibrated accelerometer vector to get the final (accelp) vector
Range:	n/a
Default:	n/a
Persistence:	Permanent
Access:	Read Only



#### A.1.64 gyroOffset

Type:	ArrayFloat32
Detailed Description:	Applies to GEDC-6 and AHRS-8 only. Calibration offset for the gyro is subtracted from gyror as part of computing gyrop. For AHRS-8, this value is computed from the accelOffsetTC variables.
Range:	n/a
Default:	n/a
Persistence:	Permanent (GEDC-6) Temporary (AHRS-8)
Access:	Read/Write (GEDC-6) Read Only (AHRS-8)

#### 1.1.65 gyroMaxRate

Type:	Float32
Detailed Description:	Applies to AHRS-8 only. The gyro full scale range is fixed at 500 degrees per second. This variable defines the point at which the NavMod switches to using just the magnetometer and accelerometer and ignores the gyro value.
Range:	0 .. 50000.0
Default:	450
Persistence:	Permanent
Access:	Read/Write

#### 1.1.66 gyroMaxReturnCnt

Type:	Int32
Detailed Description:	Applies to AHRS-8 only. After the gyro has exceeded the gyroMaxRate, this variable defines the number of in-range gyro values that must occur before switching back to using the gyro data.
Range:	0 .. 10,000
Default:	25
Persistence:	Permanent
Access:	Read/Write

#### A.1.67 gyroOffsetTCX, gyroOffsetTCY, gyroOffsetTCZ

Type:	ArrayFloat32
Detailed Description:	Applies to AHRS-8 only. Factory temperature compensated calibration offsets for the gyro - is used to compute the offset compensation based on current temperature (gyroOffset).
Range:	n/a
Default:	n/a
Persistence:	Permanent
Access:	Read/Write

#### A.1.68 gyroLinearityXPlus, gyroLinearityYPlus, gyroLinearityZPlus, gyroLinearityXNeg, gyroLinearityYNeg, gyroLinearityZNeg

Type:	ArrayFloat32
Detailed Description:	Applies to GEDC-6 only. Factory calibration scalars for the gyro - used to "linearize" the gyro vector after the offset has been applied. The "Plus" arrays are used when the corresponding component is positive and the "Neg" arrays are used when the corresponding component is negative. In each array, the

	first component is the scalar that multiplies the X (or Y or Z), then the second multiplies the X (or Y or Z) squared and the third multiplies the X (or Y or Z) cubed and then they are summed to yield the processed accel X (or Y or Z).
Range:	n/a
Default:	n/a
Persistence:	Permanent
Access:	Read/Write

#### A.1.69 gyroLinearityXTC0, gyroLinearityXTC1 , gyroLinearityXTC2, gyroLinearityYTC0 , gyroLinearityYTC1, gyroLinearityYTC2, gyroLinearityZTC0, gyroLinearityZTC1, gyroLinearityZTC2

Type:	ArrayFloat32
Detailed Description:	Applies to AHRS-8 only. Factory temperature compensated calibration scalars for the gyro -used to compute the linearity compensation factors based on current temperature (gyroLinearityX, gyroLinearityY, gyroLinearityZ).
Range:	n/a
Default:	n/a
Persistence:	Permanent
Access:	Read/Write

#### A.1.70 gyroLinearityX, gyroLinearityY, gyroLinearityZ

Type:	ArrayFloat32
Detailed Description:	Applies to AHRS-8 only. Temperature compensated linearity coefficients for the gyro, these are computed from the gyroLinearityXTC0, etc. variables and temperature.
Range:	n/a
Default:	n/a
Persistence:	Temporary
Access:	Read Only

#### A.1.71 gyroFieldCalX, gyroFieldCalY , gyroFieldCalZ

Type:	ArrayFloat32
Detailed Description:	Applies to GEDC-6 and AHRS-8 only. In field calibration offset and scalars. This is computed by the Gyro calibration command (set InvokeGyroOffsetCal to 1). The first component is subtracted from the factory calibrated gyro X/Y/Z and the second component divides into the difference.
Range:	n/a
Default:	n/a
Persistence:	Permanent
Access:	Read Only

#### A.1.72 gyroCrossAxisCorrectionX, gyroCrossAxisCorrectionY, gyroCrossAxisCorrectionZ

Type:	ArrayFloat32
Detailed Description:	Applies to GEDC-6 and AHRS-8 only. Calibration cross axis correction for the gyro
Range:	n/a
Default:	n/a

Persistence:	Permanent
Access:	Read/Write

#### A.1.73 InvokeGyroOffsetCal

Type:	Ordinal
Detailed Description:	Applies to GEDC-6 and AHRS-8 only. Command the gyro offset calibration to start by setting this to 1
Range:	0..1
Default:	0
Persistence:	Temporary
Access:	Read/Write

#### A.1.74 boresightMatrixX, boresightMatrixY, boresightMatrixZ

Type:	ArrayFloat32
Detailed Description:	Boresight orientation – these arrays make up the rows of the boresight matrix, this rotation matrix is used to transform from the NavMod reference frame to the host reference frame. This affects yaw, yawT, pitch, roll, quat, pMatrix
Range:	N/A
Default:	Identity matrix
Persistence:	Permanent
Access:	Read/Write

#### A.1.75 lowpower

Type:	Ordinal
Detailed Description:	Setting this variable to 1 makes the NavMod enter low power mode. All functions stop and the NavMod enters the lowest power state. The NavMod is restarted with any serial port activity. The reset is identical to a power up reset.
Range:	0..1
Default:	0
Persistence:	Temporary
Access:	Read/Write

#### A.1.76 temperature

Type:	Float32
Detailed Description:	Internal temperature in degrees Celsius
Range:	-1000 .. 1000
Default:	0
Persistence:	Temporary
Access:	Read Only

#### A.1.77 temperatureOffset

Type:	Float32
Detailed Description:	Applies to DC-4 and GEDC-6 only. Temperature calibration offset (counts). The AHRS-8 temperature sensor is calibrated by its manufacturer.
Range:	-1000 .. 1000
Default:	

Persistence:	Permanent
Access:	Read/Write

#### A.1.78 temperatureSlope

Type:	Float32
Detailed Description:	Applies to DC-4 and GEDC-6 only. Temperature calibration slope.
Range:	-1000 .. 1000
Default:	
Persistence:	Permanent
Access:	Read/Write

#### A.1.79 temperatureWrapDivider

Type:	Int32
Detailed Description:	Applies to DC-4 and GEDC-6 only. Value used to determine if raw temperature wrapped from 0 to 256.
Range:	0 .. 256
Default:	
Persistence:	Permanent
Access:	Read/Write

#### A.1.80 kgyroOffsetCalFactor

Type:	Float32
Detailed Description:	Applies to GEDC-6 and AHRS-8 only. Gyro offset field cal factor
Range:	N/A
Default:	0.996
Persistence:	Permanent
Access:	Read/Write

#### A.1.81 nmeaecho

Type:	Ordinal
Detailed Description:	Setting this variable to 1 makes the NMEA protocol parser echo input characters and properly handle backspace characters. For human interactive use, set this variable to 1.
Range:	0..1
Default:	0
Persistence:	Temporary
Access:	Read/Write

#### A.1.82 nmeaignorechecksum

Type:	Ordinal
Detailed Description:	Setting this variable to 1 causes the NMEA input parser to ignore incoming checksums. For human interactive use, set this variable to 1(default).
Range:	0..1
Default:	1
Persistence:	Temporary
Access:	Read/Write

#### A.1.83 restoreFieldCal

Type:	Ordinal
Detailed Description:	Command to set magnetic field calibration data back to factory default
Range:	N/A
Default:	0
Persistence:	Temporary
Access:	Read/Write

#### A.1.84 pMatrix0, pMatrix1, pMatrix2

Type:	ArrayFloat32
Detailed Description:	Platform matrix (rotation matrix) – provides 3D orientation, each array is a row in the platform matrix, the transform from the NavMod reference to the host reference is included as defined by the boresightMatrix
Range:	N/A
Default:	0
Persistence:	Temporary
Access:	Read/Write

#### A.1.85 printmask

Type:	Int32
Detailed Description:	Setting this variable selects items which are to be printed out
Range:	N/A
Default:	0
Persistence:	Temporary
Access:	Read/Write

#### A.1.86 printtrigger

Type:	Int32
Detailed Description:	Used to select triggers (data updates) that will cause the printmask selected items to print.
Range:	N/A
Default:	0
Persistence:	Temporary
Access:	Read/Write

#### A.1.87 printmodulus

Type:	Int32
Detailed Description:	Setting this variable defines when to print out based on this many triggers as defined by printtriggers
Range:	0..10000
Default:	4
Persistence:	Temporary
Access:	Read/Write

## B Troubleshooting

### B.1 NMEA commands are not echoed.

Choose one of the following options:

- turn on echos using the command “nmeaecho 1 set”
- turn on local echo on your terminal emulator. For example, using HyperTerminal: File->Properties->Settings tab->ASCII Setup->“Echo typed characters locally”. Note that the disadvantage of this option is that you have to turn it back off for mForth commands.

### B.2 NMEA commands don't respond to “enter” key.

Choose one of:

- type <ctrl-J>
- set your terminal emulator to send line ends for the “enter” key. For example, using HyperTerminal: File->Properties->Settings tab->ASCII Setup->“Send line ends with line feeds”

### B.3 Repeating output is not appearing.

- type <ctrl-Q> since you may have previously typed a <ctrl-S>

### B.4 Repeating output is making typing a new command difficult.

- enter <ctrl-S> to pause the repeat display and type in your new command, restart any repeat displays with <ctrl-Q>

### B.5 The compass is providing an inaccurate heading:

- check for magnetic interference in the area, electric motors, chairs, door, cables, cell phone
- in-field calibration may need to be reset (restoreFieldCal 1 set) or rerun (eliminates interference of items that are fixed in location relative to the compass)
- gyro calibration may need to be rerun (InvokeGyroOffsetCal 1 set)
- if you have modified the calibration data, use the restorefactorycal command (restorefactorycal 1 set)

### B.6 The compass does not output any response.

Check the following:

- that there is a TTL logic level connection to compass pins USER\_RXD (P2-2) and USER\_TXD (P2-3) (reference GEDC-6 Data Sheet)
- that the baud rate matches the baud rate setting on the compass (initial factory setting is 115200), note that the NDS-1 GUI has an option to try all baud rates if the baud rate is unknown
- that the other serial interface properties are 8 bit, no parity, 1 stop bit, no flow control
- compass is seated properly (we recommend that it be keyed by blocking the socket for P1-4) (reference GEDC-1 Data Sheet)
- compass has power on P2-1 (+4V – +10V DC) and ground on P1-7, P2-6, P2-7 (reference GEDC-6 Data Sheet)

- Factory use pins (P2-4 and P2-5) are high (reference the Data Sheet for your product), or open