


Document	Revision	Status	Authors	Changelog
Current Version				
103230	A	Released	Gepperth Jürgen	Added Protective Foil to the assembly process
Document History				
102964	B	Released	Johannes Schwarz	Removed the foil wrapping step as this is now part of the kitting instructions
102964	A	Released	Jonas Huber Matthias Bösl Johannes Schwarz	Initial version

Step	Description	Picture	Comments
1	<p>Picking the Mounting Bracket</p> <p>Take MOUNTING_BRACKET_ASSEMBLY.</p>		

2

Inserting Reset Button Extension

Insert the BUTTON_EXTENSION for the reset button into the MAIN_BODY.






3 Inserting Motor and Flexible PCBA into Housing



Insert MOTOR_FPBCA_ASSEMBLY into the MAIN_BODY.



The motor is kept in position by 2 screws coming from of the main body.




- 1. Insert Motor with flexible PCBA halfway into the main body.
- 2. Insert button extension half way into the Main body.
- 3. Afterwards the motor can be pushed down to his final position as well as the button extension.
- 4. Attach the motor and FPCBA to the housing by inserting the two MOTOR_SCREWS





Attention: MOTOR_FPBCA_ASSEMBLY differs depending on target SKU.

4	<p>Inserting Mounting Button Extension</p> <p>Insert MOUNTING_BUTTON_EXTENSION for the mounting button into MAIN_BODY.</p>		
5	<p>Assembling the Gear</p> <p>Put GEAR into the opening of the rotary encoder on PPCBA.</p>		

6	<p>Placing the PPCBA in Main Body</p> <p>Make sure that the PPCBA is positioned in the MAIN_BODY such that the gear sits in the opening of the main body and that the plastic domes sit in the corresponding openings of the rigid PCB.</p>		
7	<p>Insert PCB_SCREWS</p> <p>Attach the rigid PCB to the housing by inserting the two PCB_SCREWS.</p>		




<p>7A</p>	<p>Checking Mounting Quality</p> <p>Make sure the PCB cannot move at all after the insertion of the screws.</p>		
<p>8</p>	<p>Connecting Flexible PCB to PPCBA</p> <ol style="list-style-type: none">1. Put the flex PCB into the connector2. Flip the fastener to lock the PCB		
<p>9</p>	<p>Positioning the White Sticker</p> <p>Place the WHITE_STICKER on the back of the flexible PCB.</p>		<p>Max. 1,5mm over PCBA:</p>



10

Scanning of PCBA Serial
Scan EMS assigned PCBA serial number (sticker or engraved).



11	<p>Printing of Device Labels</p> <p>Print the DEVICE_LABEL in accordance with the label printing instructions DEVICE_LABEL_LPI.</p>		
12	<p>Attaching the Device Label</p> <p>Attach the printed DEVICE_LABEL into the back of the main body.</p>		
13	<p>Positioning Flexible PCB</p> <p>Position the flexible PCBA in display area using the yellow marked 2 locators.</p> <p>Make sure the FPCBA slides under the green marked edge</p>		



14



Positioning the Light Blocker




Position the LIGHT_BLOCKER in display area using the 2 locators.



Attention: LIGHT_BLOCKER differs depending on target SKU.

15	<p>Pushing Display Ring onto Main Body</p> <p>Push DISPLAY_RING onto MAIN_BODY.</p> <p>Make sure the display engraving (can be seen on the inside of the display ring) sits on the same side as the flex pcb.</p>		<p>Attention: DISPLAY_RING differs depending on target SKU.</p>
16	<p>Attaching Battery Cover</p> <p>Attach BATTERY_COVER to MAIN_BODY.</p>		

17	<p>Inserting Hinge</p> <p>Put HINGE into hole to hold the BATTERY_COVER.</p>		
18	<p>Pushing the Display Ring Down</p> <p>Push the DISPLAY_RING completely down.</p>		

19	<p>Attaching the Wheel</p> <p>Push the WHEEL onto the main body.</p>		
20	<p>Snapping on the Front Cap</p> <p>Snap the FRONT_CAP onto the MAIN_BODY.</p>		<p>Attention: The opening must be placed over the infrared temperature sensor.</p>
23	<p>Printing of Setup Labels</p> <p>Print the SETUP_LABEL in accordance with the label printing instructions SETUP_LABEL_LPI.</p>		

24

Attaching the Setup Label

Place the SETUP_LABEL on the WHEEL.




Attention: SETUP differs depending on target SKU.




Orientation	Orientation
Horizontal	
Vertical	

25	<p>Remove the Mounting Bracket</p>		
26	<p>Scan the Rear Serial Number</p> <p>The station starts the EOL procedure</p>		



27	<p>Scan the Front Serial Number</p>		
28	<p>Insert Batteries</p> <p>Open the battery compartment cover.</p> <p>Insert the AA_BATTERIES.</p> <p>Close the battery compartment cover.</p>		

29	<p>Wait for EOL on display.</p> <p>1) If DUT shows FAI, don't proceed, station should show FAIL.</p>		
30	<p>Press the pairing button</p> <p>1) DUT shows 00</p>		

31	<p>Turn the wheel to the right until all LEDs turn on</p> <ul style="list-style-type: none">1) DUT counts up2) DUT turns on all LEDs above maximum		
32	<p>Turn wheel to the left until all LEDs turn off</p> <ul style="list-style-type: none">1) DUT counts down2) DUT turns off all LEDs below minimum		

33	<p>Attach the Mounting Bracket</p>		
34	<p>Mount DUT using its adapter on the stand</p> <ul style="list-style-type: none">1) DUT shows CAL2) DUT performs calibration	<div></div>	

35	<div>Wait for PA or FAI on DUT</div> <div>1) The station should show PASS or FAIL</div>	<div></div> <div></div>	
36	<div>Remove DUT from stand</div>	<div></div>	



37	Remove the Mounting Bracket from the device main body.		
38	Open & Close the battery cover to interrupt the power supply		

<p>39</p>	<p>Checking for Customer Mode</p> <p>Check that the display shows the temperature when turning the wheel.</p> <p>Attention: If the device shows “EOL”, the EOL test has not been completed.</p>		
<p>40</p>	<p>Placing the Battery Tab</p> <p>Open the battery compartment again.</p> <p>Place the BATTERY_TAB as shown.</p> <p>Close the battery compartment cover back.</p> <p>Attention: The battery tab must break the electric contact.</p>		

41	Close battery door		
42	Check Wheel on Torque Meter - Max allowed: 40mNm		

43	<p>Wrapping the Device(s) in Protective Foil</p> <p>Wrap the Device(s) in PROTECTIVE_FOIL.</p>		
----	---	---	--

Instructions for Opening DVA02 for Rework:

1	<p>Get between the Front Cap and the Wheel with a plastic tool at the red marked area.</p> <p>Note: DO NOT USE METAL. It will damage the wheel</p>		
2	<p>Push the Front Cap up with the plastic tool until the lift side is fully lift.</p>		
3	<p>Now you can pull up the Front cap with your hands. Throw the Front Cap away.</p>	