


MCR Series Client Mode Network Configuration



Reader is in TCP mode and DHCP is activated
Local PC configures the reader using UDP broadcast
Reader is addressed by its unique Id (e.g. MCR04-0A1800)
Configuration tools:
- miFinder
- miConnect