

GAMESHARK LITE

For use with all PlayStation® game consoles, including the 9000 series and higher units, the PS one™, and PS2™ in PS1 mode.

INTRODUCTION

So you Wanna Beat The Game? Now that you have purchased GameShark® Lite, let us show you how to get the most out of your game play and achieve your ultimate goal. The GameShark® Lite is completely menu-driven. You don't need to add codes letter-by-letter or number-by-number every time you turn on your machine. All you need to do is highlight the enhancement you want to use and start playing games like never before!

The GameShark® Lite is more technologically advanced than any other game enhancer on the market today. It will revolutionize your gameplay, arming you with the power to load the most devastating codes available and show you how to create your own havoc-wreaking codes of destruction.

INSTRUCTIONS FOR START-UP

1. With your PlayStation OFF, place the GameShark® Lite CD-ROM in your PlayStation and close the lid.
2. Insert a game controller into Controller Port #1.
3. Turn your PlayStation® ON.

The Main Menu is composed of four items:

1. Start GS Lite
2. How to use
3. Go Big Win Big
4. about gameshark.com

Press up and down on the directional pad (D-Pad) to highlight one of these items, then press the X button to select it.

Selecting How to Use, Go Big Win Big or about gameshark.com will activate an FMV sequence. The option to Start GS Lite will launch the GameShark application.

START GS LITE

Selecting Start GS Lite option will bring you to the GameShark® Main Menu which contains the following choices:

1. Start Game
2. Select Cheat Codes
3. Explorer
4. Options

Press up and down on the directional pad (D-Pad) to highlight one of these items, then press the X button to select it.

START GAME

This selection takes you to the Start Game Options menu. You will then be presented with three options. Press up or down on the D-Pad to highlight an option and press the X button to select it.

Option 1: Start Game With Selected Codes

This option starts the game using the enhancement codes chosen from the Select Cheat Codes menu. You will be prompted to remove your GameShark Lite CD-ROM and insert the game CD.

Option 2: Start Game Without Codes

This option starts the game without any enhancement codes. The game will play as normal.

Option 3: Cancel

This option takes you back to the Main Menu.

SELECT CHEAT CODES

This option takes you to the built-in list of PlayStation® titles supported by the GameShark® Lite. All titles are listed alphabetically. Press up or down on the directional pad to highlight the desired game and press the X button to select it. The Circle button will return you to the previous menu. L1 will scroll the list up and R1 will scroll the list down. The bottom of the Select Cheat Codes screen will display the highlighted game, the number of enhancement codes that are active for that specific game, and the percentage of storage space available within the GameShark Lite's memory for codes. Once you've selected a game, a full list of enhancement codes will appear on the screen for that game. These descriptions represent a code. Press up or down on the direction pad to highlight an individual code. The X button will toggle the codes on and off. You can activate almost any combination of enhancements. Active codes will be highlighted in yellow. To delete a code, press the Triangle button. When you are finished selecting the desired cheats, press the Circle button to return to the previous menu or the Start button to go to the Start Game menu.

NOTE: Some games require an access code labeled as (M), meaning this code "ALWAYS MUST BE ON." This code must be highlighted in green at all times or the GameShark® LITE will not be able to load the game properly. There may be future titles that require this access code. If this code is required on new games, it will be made available with codes for that game.

WHERE TO FIND NEW ENHANCEMENT CODES

As new games are released, you will want to add new codes for those games to your GameShark® Lite. You can find new codes at:

- Gameshark.com, the Official GameShark® Website
- Various videogame magazines
- GameShark® Magazine, the Official GameShark® Newsletter, call 410-785-4064 to subscribe.

- The Official Code Hotline: 1-900-773-SHARK. This call costs \$1.29 per minute, and you must be over 18 years old or have a parent's permission to call.

We're making sure that the newest codes to the hottest games are easy to find.

ADDING NEW GAMES TO THE GAMESHARK LITE

To add new codes to your GameShark® Lite, you must first add the title of the game to the GameShark® Lite, if it does not already exist in the built-in list of games. To add a new game title, go to the Select Cheat Codes menu and select "New Game". The New Game Edit screen will appear, here you can enter the title of a new game. You will be presented with four options:

Option 1: Edit Name

Highlight this option and press the X button on your controller. You will be presented with a box filled with letters, numbers and symbols. Use the directional pad to highlight letters in the box to spell the name of the game. Use the X button to select a character. Use the Select button to change between upper and lower case characters. To go back one character, press the Square button and to delete the entire name, press the Triangle button. When you have finished entering the name of the new game, press the O button.

Option 2: Detect Game CD

Make sure your game CD is in your PlayStation® and the lid is closed. Highlight this option and press the X button on your controller. The GameShark® Lite will initialize your CD and search for the name of the game. When prompted, press the X button. Sometimes your GameShark® Lite will not find the name of your game. If this occurs, go to the New Game Edit screen, select Edit Name, and enter the title.

Option 3: Exit and Save

Saves the title to the built-in list of games found in the Select Game list and returns you to that list. This option will only appear after you have created a name for a game.

Option 4: Exit and Discard

Deletes the name you have entered and returns you to the Select Game list. Once you have added the title of your game to the Select Game list, find the title you created by using the L1 and R1 buttons to scroll up and down the list. Highlight the new name and press the X button. The Select Cheat Codes screen will appear. It is now time for you to add your codes to the GameShark® Lite.(see below)

DELETING GAMES FROM THE GAMESHARK LITE

If you want to remove a game from the Select Cheat Codes menu, simply highlight the game title that you want to delete and press the Triangle button. You will be given a choice to delete or cancel. Highlight Delete and press the X button. The game will disappear from the list. To cancel, simply highlight cancel and press the X button. Note: Preloaded games may not be deleted because they are loaded from the CD.

ADDING NEW CODES TO THE GAMESHARK LITE

To add a new code to your GameShark code list, you first need to insert a regular memory card into one of the Memory Card slots on your PlayStation®. We recommend you keep a spare memory card specifically for saving all of your GameShark® codes. In the Select Cheat Codes menu, highlight New Code and press the X button. This will take you to the New Code Description screen. In this screen, you will be presented with a new text entry box. This is where you will enter descriptions of your new codes. You will probably want to name your new enhancement codes according to their functions. For example, if a code gives you a large number of lives, you may want to name the new code "Infinite Lives." Enter the description of the code the same way you entered the title of the new game earlier. Press the Circle button when you are finished. If you exit without entering a new code description, "No Cheat Name" will appear and become the default description of that code. To change this, simply highlight that title and press the X.

ENTERING CODES INTO THE GAMESHARK LITE

After you have entered a description and pressed the Circle button, two more boxes will appear onscreen. The box on the left, with the dots, is the Code Entry box. The box on the right is the Options box. Use the D-Pad to navigate between the boxes. A yellow border will appear around the box that you are currently using. Select the Code Entry box and press the X button. This is where you will input your new code(s) for the game you selected from the GameShark® Lite's list of games. A small text entry box will appear. Use this box to choose the letters and numbers of the actual cheat code. Most codes will be a one line combination of 12 numbers and letters, but some codes may be 2 lines or longer. Use the D-pad to highlight a letter or number, pressing the X button to select that letter or number.

Continue until the entire code is entered. Individual codes can sometimes be quite long, so a bit of concentration may be required. If you make a mistake while entering a code, don't panic! You can use the L1 or R1 buttons to move backward and forward to re-enter a number or letter. Simply move the cursor to the letter or number that you entered incorrectly, and select the correct letter or number to replace it. The new letter or number will overwrite the old one. After you have entered the new code for this game, press the O button to return to the Options menu. The following are the options you can select:

Option 1: Default On

Allows you to keep the code on at all times. Every time you start the GameShark® Lite, the selected code will ALWAYS be "ON". Use the X button to toggle between ON and OFF status.

Option 2: Exit and Save

Saves your new code to the specific game listed at the top of this menu, then exits you to the Select Cheat Codes menu. From there, you can activate your new code or enter more enhancement codes for your game by selecting New Code.

Option 3: Exit and Discard

This will delete the code that you just entered and then exit you to the Select Cheat Codes menu. From there, you can enter more enhancement codes for your game by selecting New Code. Once you have entered and saved your new codes, you can start to use them. If you chose Option 2, your new codes will be saved to your memory card and will appear in your games list whenever you use GameShark with your memory card inserted. Remember to activate your codes before you start the game if their defaults are OFF. All activated codes are highlighted in Yellow. You can add additional codes to any game simply by selecting the game, highlighting the New Code line and pressing the X button. Follow the entry steps from above. **NOTE:** Each code is usually only one line and should have only one description. Do not enter all of a title's GameShark® Lite codes into one description. Make a description for each code you add.

DELETING A CODE

If you want to delete a code, simply highlight the description of the code and press the Triangle button. A message will appear asking if you are sure you want to delete the code. Use the D-pad to highlight Delete and press the X button. To cancel, simply highlight cancel and press the X button.

Note: Preloaded codes may not be deleted because they are loaded from the CD.

Loading and Saving the Code List.

To copy code lists from one card to another or save the code list from another memory card simply:

1. Start the GameShark® Lite
2. Go to the Select Cheat Codes option and press the X button.
3. Press the Select button on the controller.
4. Remove your memory card from the PlayStation® and insert the card that you want to copy.
5. Select the Load Codes to Memory Card option. The codes from the second memory card will now appear on the screen.
6. Put the first memory card back into the memory card slot and select the Save Codes to memory Card option. The codes should now appear on the first memory card.

EXPLORER

The Explorer menu is composed of five items:

1. Play CD Music
2. Exit

To select an option, highlight that option and press the X button. Pressing the O button while in any of the above options will bring you back to the Explorer menu.

NOTE: Make sure that you insert the game CD into the PlayStation before you choose one of these options

PLAY CD MUSIC

This option allows you to play either music tracks stored on a PlayStation game CD or a normal audio CD. Use the directional pad to highlight which button on the CD Player you want to activate, then press the X button on your controller.

EXIT

This exits the Explorer options and returns you to the Main Menu.

OPTIONS

Choosing Options from the Main Menu allows you to perform the following tasks:

Task 1: Change Background

Lets you choose from a number of different background settings and patterns. Use the directional pad to scroll through the different patterns and colors. When you find the desired background, press the X button.

Task 2: Scroll Background On/Off

The background can either scroll or remain stationary. Press the X button to toggle ON and OFF.

Task 3: Menu Scrolling On

Makes each menu either quickly scroll or flash off the screen when you move to a new menu. Press the X button to toggle ON and OFF.

Task 4: Sound Enabled/Disabled

Press the X button to toggle four different sounds ON and OFF.

Task 5: Poly Map

Press the X button to toggle between Off, Wires, Shades and Flats. Wires displays the game in Wire Frames, as opposed to fully textured and colored. Shades displays the game in different shades. Flats displays the games in 2D images instead of 3D.

Task 6: Exit

Exits the menu.

TROUBLE SHOOTING

If you are having problems with your GameShark® Lite, make sure the card is plugged in properly. If you are having problems with codes, make sure you have entered the code or codes properly. Some games require an access code labeled as "ALWAYS MUST BE ON." This code should be highlighted in green at all times or the GameShark® Lite will not be able to load the game properly. There may be future titles that require this access code. If this code is required on new games it will be made available with codes for that game. If you are still having problems, you can call our Technical Support at (410) 785-4064. Please DO NOT call this number for codes, as they are not available through Tech Support.

You can reach InterAct through at:

Phone: (410) 785-4064

E-Mail: support@gameshark.com

World Wide Web: <http://www.gameshark.com>

Mailing Address:

InterAct Accessories, Inc.

ATTN: CUSTOMER SERVICE -VG

335 Clubhouse Lane

Hunt Valley, MD 21031

WARRANTY INFORMATION

InterAct Accessories, Inc. warrants to the original purchaser of this product that it will be free from defects in materials and/or workmanship for a period of ninety (90) days from the date of purchase. If a defect covered by this warranty is discovered within the 90-day warranty period, InterAct Accessories, Inc. will repair or replace, at its option, free of charge, any part that InterAct Accessories, Inc. determines to be defective, provided that a copy of the original sales receipt is included with the product return.

This warranty is limited to the internal works of this product and the external housing. It will not apply if your InterAct product has been damaged by abuse, misuse, negligence, accident, modification, tampering, or by any other causes unrelated to defective materials and/or workmanship.

Repair or replacement as provided under this warranty is the exclusive prerogative of InterAct Accessories, Inc. Any applicable implied warranties, including warranties of merchantability and fitness for a particular purpose, are hereby limited to 90 days from the date of purchase and are subject to the conditions set forth in this limited warranty. In no event shall InterAct Accessories, Inc. or its affiliates be liable for consequential or incidental damages resulting from the breach of any express or implied warranties.

Some states do not allow limitations on how long an implied warranty lasts or exclusion or limitation of incidental/consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other legal rights, which vary from state to state.

To obtain warranty service within the warranty period: Send the defective item postage prepaid with a copy of the sales receipt, return address and a brief description of the problems you are experiencing to the address below.

For questions, trouble-shooting assistance or to obtain service after the warranty period has expired, contact InterAct's consumer service support team by:

You can reach InterAct by the following means:

Phone: (410) 785-4064

E-Mail: support@gameshark.com

World Wide Web: <http://www.gameshark.com>

Mailing Address:

InterAct Accessories, Inc.

ATTN: CUSTOMER SERVICE -VG

335 Clubhouse Lane

Hunt Valley, MD 21031

©2000 InterAct Accessories, Inc. A RECOTON® COMPANY. InterAct is a registered trademark of STD Manufacturing, Ltd.

Printed in England.