


Mc-Label3 Printer



Card No. PS237

Detail Clean

Frequency

Model

Estimated Time to Complete

Monthly

Mc-Label 3

5-10 Minutes

Health & Safety Hazards

- Power off equipment when cleaning
- Do not use sprays or damp cloths near electrical power supplies

Food Safety



Wash & Dry hands after performing tasks













Remove or cover all food & packaging



Ensure nuts, bolts and screws are tight



Inspect equipment, do not use if damaged



The amber LED to prompt cleaning has been disabled. Cleaning must be completed monthly as part of your planned and daily maintenance tasks.

For new or swapped out units:

Should the amber light show, the steps below can be followed to remove the light.

To get this disabled log a call with the Help Desk and they will remotely update your printers to prevent this from reoccurring.

1. Turn off printer
2. Remove paper and close cover
3. Turn on the printer, the printer should flash a red LED indicating the paper is missing
4. Press and hold down the multi-function button on the front of the printer for 5 seconds / until the Amber LED disappears
5. Re load paper
6. Contact help desk to update printer to prevent from reoccurring