

Trend Graph Display Window

■ Trend graph display

This window plots measurement values of each OUT in chronological order.

■ Basic operations on the display window

Check the OUT numbers to display. (1)

Click the area of (2) to switch to the OUT to operate.

(A white bar is displayed next to the selected OUT.)

The icons of (3) allow such operations as expansion/reduction of the horizontal axis/vertical axis and movement of the display area.

Use the cursor function (4) to display the analysis results on (5).

Click the icon of (6) to clear display data.

* When batch measurement is ON, start batch measurement to update the trend graph by clicking the [Batch start] button or executing another operation.

