

? Measurement Value Display Window

■ How to view the measurement value display window

Measurement values judged as GO are displayed in green and those judged as HI or LO are displayed in red.

The “HI”, “GO”, or “LO” are lit according to the judgment result. (1)

In addition, “TIM” lights when TIMING is ON and “ZERO” lights when ZERO is ON.

The display window size can be changed arbitrarily.

The display of each OUT is automatically adjusted according to the number of OUTs to display and the window size.

* When batch measurement is ON, start batch measurement to update measurement values by clicking the [Batch start] button or executing another operation.

■ Measurement value display setting

Click the icon of (2) to open the measurement value display setting window (3).
Check the OUT numbers to display and determine the display order for them by using (4).

