

Master Profile Registration

■ How to register a master profile

Register a measured profile as a master profile.

Use the master profile as a reference profile for setting the position correction and OUT measurement.

There are two methods for registration as follows:

<Register on the profile display window>

Press the [Register] button to register the currently displayed profile (yellow line) as a master profile (red line).

<Register on the profile selection window>

Select one of the height image displayed profiles to register. First, click the [Select profile] button (2) to open the profile selection window.

When a profile is formed to some extent and displayed, click the [Update hgt. img.] button.

Next, place the green cursor (3) on the desired profile position and click the [OK] button.

Finally, press the [Register] button to register the selected profile as a master profile.

* When batch measurement is ON, clicking the [Batch start] button (1) starts the profile measurement.

Clicking the [Update profile] or [Update hgt. img.] button updates the display data.

