



## ANTI-THEFT ALARM SYSTEM



- Refer to Spec (Specific) Service Manual for transmitter registration procedure.

### INSPECTION

Before performing the system inspection, check the following:

- Battery condition, Burned back-up fuse,
- Loose connector, other electrical system normal operation
- ALARM OPERATION IS NORMAL BUT ALARM INDICATOR DOES NOT COME ON
  - Faulty speedometer panel
- ALARM OPERATION IS NORMAL BUT BUZZER DOES NOT SOUND
  - Faulty speedometer panel
- ALARM OPERATION IS NORMAL BUT TURN SIGNAL LIGHT DOES NOT BLINK
  - Faulty answer back relay
  - Open circuit in wire between the answer back relay and back-up fuse
  - Open circuit in wire between the answer back relay and speedometer
  - Open circuit in wire between the answer back relay and diode
  - Faulty diode
- ALARM CANNOT BE SET WITH MODE SWITCH
  - Open circuit in wire between the speedometer and back-up fuse
  - Faulty speedometer panel
- ALARM CANNOT BE UNSET WITH IGNITION SWITCH
  - Open circuit in wire between the speedometer and back-up fuse
  - Faulty speedometer panel
- ALARM CANNOT BE SET/ALARM CANNOT BE UNSET WITH REMOTE TRANSMITTER
  - Open circuit in wire between the speedometer and back-up fuse
  - Remote transmitter not registered
  - Faulty remote transmitter
  - Faulty speedometer panel
- ALARM OPERATION IS NORMAL BUT REMOTE TRANSMITTER CANNOT BE REGISTERED
  - Faulty speedometer panel