



FINAL REDUCTION (SCOOTER TYPE)

GENERAL

- When installing the driveshaft, be sure to use the special tools; position the special tools on the bearing inner race and pull the driveshaft into the bearing until it is fully seated.

TROUBLESHOOTING

Engine starts but vehicle won't move

- Damaged final reduction
- Seized final reduction
- Faulty drive pulley
- Faulty driven pulley/clutch

Abnormal noise

- Worn, seized or chipped gears
- Worn or damaged final reduction bearing

Oil leak

- Oil level too high
- Worn or damaged oil seal
- Cracked crankcase and/or final reduction case

