



















GENERAL INFORMATION








SYMBOLS

The symbols used throughout this manual show specific service procedures. If supplementary information is required pertaining to these symbols, it would be explained specifically in the text without the use of the symbols.

INSTRUCTION SYMBOL

	Removal or Disassembly procedure. Disconnect the connector.		Installation or Assembly procedure. Connect the connector.
	Order of removal/disassembly with a point of note.		Order of installation/assembly with a point of note.
	Tighten to the specified torque.		Replace with a new one before assembly.
	Check the part for an inspection.		Measure the part for an inspection.
	Turn ignition switch to OFF.		Turn ignition switch to ON.
	Start the engine.		Measure a resistance or check continuity.
	Measure a voltage.		Measure an ampere.
	Use the Honda special tool.		Refer to Spec (Specific) Service Manual for the instruction.


LUBRICATION AND SEAL SYMBOL

	Use the recommended engine oil.		Apply molybdenum oil solution (mixture of an engine oil and molybdenum grease in a ratio of 1:1).
	Apply a specified grease.		Apply a liquid sealant.
	Apply a locking agent. Use a medium strength one unless otherwise specified.		Use specified brake fluid.
	Use a specified fork oil or suspension fluid.		




SERVICE RULES

Use genuine Honda or Honda-recommended parts and lubricants or their equivalents. Parts that don't meet Honda's design specifications may cause damage to the vehicle.




Use the special tools designed for this product to avoid damage and incorrect assembly.




Do not bend or twist control cables. Damaged control cables will not operate smoothly and may stick or bend.




In removal and disassembly, record the location of each part for installation and assembly.




After cleaning, check the bearing by slowly rotating the inner race. If any radial play, axial play or roughness is felt, it must be replaced.




Snap rings are always installed with the chamfered (rolled) edge facing away from the thrust of the mating part.



Oil seals are always installed with grease packed into the seal cavity and the manufacturer's name facing the outside (dry side).




Rubber hoses should be installed so the end is bottomed onto its fitting. Rubber or plastic dust/dirt boots should be replaced securely in the exact positions.






GENERAL INFORMATION

Install new gaskets, O-rings, cotter pins, and lock plates when reassembling.




When tightening bolts or nuts, begin with the larger diameter or inner bolt first. Then tighten to the specified torque diagonally in incremental steps.



Clean parts in cleaning solvent upon disassembly. Lubricate any sliding surfaces before reassembly.




After reassembly, check all parts for proper installation and operation.



Cylinder head bolt removal order:

1. Loosen the smaller bolt first.
2. Loosen the bolts in a crisscross pattern from the outside inward.

Tighten the bolts in a crisscross pattern from the center outward.





ABBREVIATION



Throughout this manual, the following abbreviations are used to identify the respective parts or systems.

Abbrev. term	Full term
ABS	Anti-lock Brake System
CBS	Combined brake system
CKP sensor	Crankshaft Position sensor
CMP sensor	Camshaft Position sensor
DLC	Data Link Connector
DTC	Diagnostic Trouble Code
ECM	Engine Control Module
ECT sensor	Engine Coolant Temperature sensor
EEPROM	Electrically Erasable Programmable Read Only Memory
EOT sensor	Engine Oil Temperature sensor
EVAP	Evaporative Emission
IACV	Idle Air Control Valve
IAT sensor	Intake Air Temperature sensor
ICM	Ignition Control Module
MAP sensor	Manifold Absolute Pressure sensor
MCS	Motorcycle Communication System
MIL	Malfunction Indicator Lamp
PAIR	Pulse Secondary Air Injection
PGM-FI	Programmed Fuel Injection
SCS short connector	Service Check Signal short connector
TP sensor	Throttle Position sensor
VS sensor	Vehicle Speed sensor



FASTENERS

TIGHTENING TORQUE




Torque values are determined according to fastener size and strength, and the strength of the parts that are fastened together.

Example; A torque of 1 kg-m refers to the moment of force obtained when a 1-meter long wrench is loaded with 1 kilogram. At the same moment, a heavier load is needed as the effective wrench length is shorter. 1 kg-m = 10 N·m, 1 kg-m = 7 ft.-lb.

The tightening torque when the torque wrench is attached to the special tool is greater than indicated.

Therefore, when tightening, the torque less than the indicated torque should be applied.

STANDARD TORQUE VALUES




For the nuts and bolts other than ones for specific locations should be tightened with the correct torque according to the torque chart below.

Thread dia.	FASTENER	N·m (kgf·m, lbf·ft)
5 mm	Hex bolt/nut	5 (0.5, 3.6)
6 mm	Hex bolt/nut	10 (1.0, 7)
8 mm	Hex bolt/nut	22 (2.2, 16)
10 mm	Hex bolt/nut	34 (3.5, 25)
12 mm	Hex bolt/nut	54 (5.5, 40)
5 mm	Screw	4 (0.4, 2.9)
6 mm	Screw	9 (0.9, 6.5)

Thread dia.	FASTENER	N·m (kgf·m, lbf·ft)
6 mm	8 mm head, small flange bolt	10 (1.0, 7)
6 mm	8 mm head, large flange bolt	12 (1.2, 9)
6 mm	10 mm head bolt/nut	12 (1.2, 9)
8 mm	Flange bolt/nut	27 (2.8, 20)
10 mm	Flange bolt/nut	39 (4.0, 29)




LOCKING/SPECIAL BOLT/NUT




Lock Washer

- When the washer is compressed under the bearing surface pressure, the elasticity of the spring and the edges of the ring ends prevent loosening.
- Do not use the lock washer which have lost its elasticity or is deformed or eccentric.




Cone Spring Lock Washer

- The bearing surface presses on the cone spring washer and the spring reaction presses against the nut to prevent it from loosening.
- Application:
 - Clutch lock nut
 - Primary gear lock nut
- Installing in the opposite direction prevents effective locking. Always install cone washers with their "OUTSIDE" mark facing out. If unmarked, install cone spring washers as shown in the column at left.



Self-lock Nut

- This is a nut with a spring plate on top. This spring plate presses against the thread, making it difficult for the nut to loosen. After removal, this type of nut can be used again.
- Application:
 - PRO-Link pivot point nuts
 - Axle nuts




Stake-type Lock Nut

- Stake (or indent) the collar of the nut to make it match the groove in the shaft.
- Application:
 - Clutch center lock nut
 - Wheel bearing retainer
 - Shift drum stopper plate
- Replace with a new one after removal.




GENERAL INFORMATION




UBS Bolt

- The threads are pressed by the reaction on the inclined bolt flange.
- Application:
 - Cylinder
 - Cylinder head
 - Foot peg
 - Bracket




Pre-coated Bolt (ALOC Bolt)

- The pre-coated bolt has a special coating or sealant on its threads, to add locking and sealing function.
- Application:
 - Brake disc bolt
 - Brake caliper mounting bolt
- Replace with a new one after removal.




Locking Agent

- Apply a thread locking agent to the thread to prevent loosening.
- Application:
 - Stator coil bolt
 - Bearing retainer bolts
 - Shift drum stopper plate bolt
 - Fork socket bolts
 - Brake disc bolts
- Applying a small amount of adhesive to the end of the bolt threads distributes the adhesive throughout when the bolt is threaded in.



CT Bolt

- A CT bolt creates female threads when it screws into the unthreaded pilot hole.
- The lower half of the CT bolt features the combination of the standard threads [A] and the low threads [B].




Special Bolt

- Certain areas of a vehicle are subject to repeated and severe external forces. Special bolts with a high percentage of elastic deformation capability are used in these areas.
- Application:
 - Connecting rod bolt
 - Crankshaft journal bolt




BEARING REPLACEMENT



Ball bearings are always installed with the manufacturer's name and size code [A] facing out. This is true for open, single-sealed and double-sealed bearings. Apply the proper grease to open and single-sealed bearings before reassembly.


"U" or "Z" indicates a bearing with a rubber seal or metal shield respectively.

- U: Single rubber sealed type
- Z: Single metal sealed type
- UU: Double rubber sealed type
- ZZ: Double metal sealed type



Ball bearings are removed using tools which apply force against one or both (inner [A] and outer [B]) races. If the force is applied against only one race (either inner or outer), the bearing will be damaged during removal and must be replaced.

If the bearing is in a blind hole in the crankcase and cannot be removed by hammering on the opposite side, remove it with a bearing remover. For recommended bearing removers, refer to the Tool Compatibility Table.




If the use of a bearing remover is not possible, remove the bearing by thermally expanding the case; slowly and uniformly heating the case with a heat gun (industrial dryer), or a hot plate.

To avoid burns, wear insulated gloves when handling the heated case.



GENERAL INFORMATION



Caution should be taken regarding the direction in which the bearing is installed. Apply the proper grease to the bearing before reassembly. The outer race [A] should be installed with a driver [B], attachment [C] and pilot [D]. The bearing must be installed in a parallel manner.

BEARING REMOVER COMPATIBILITY TABLE

BEARING NUMBER	I.D. (mm)	O.D. (mm)	TOOL NUMBER				
			BEARING REMOVER	SHAFT	HANDLE	WEIGHT	REMOVER SET
6000 6200 6300	10	26 30 35	07936-GE00200	07936-GE00100	Included with shaft	07741-0010201	-
6001 6201 6301	12	28 32 37	09936-1660110	07936-1660120	Included with shaft	07741-0010201	07936-1660001
6002 6202 6302	15	32 35 42	07936-KC10200	07936-KC10100	Included with shaft	07741-0010201	-
6003 6203 6303	17	35 40 47	07936-3710300	Included with remover	07936-3710100	07741-0010201	-
6004 6204 6304	20	42 47 52	07936-3710600	Included with remover	07936-3710100	07741-0010201	07936-3710001
6005 6205 6305	25	47 52 62	07936-ZV10100	Included with remover	07936-3710100	07741-0010201	-
6006 6206 6306	30	55 62 72	07936-8890300	Included with remover	07936-3710100	07741-0010201	-
6007 6207 6307	35	62 72 80	07936-3710400	Included with remover	07936-3710100	07741-0010201	-
60/22 62/22 63/22	22	44 50 56	070MC-MFR0100	Included with remover	07936-3710100	07741-0010201	-



TOOL COMPATIBILITY CHART

FITTING POINT <div>TOOL NAME</div> <div>TOOL NUMBER</div> <div>BEARING O.D. (mm) I.D. (mm) NUMBER</div> <div>SIZE (mm)</div>			OUTER RACE																INNER RACE																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																							
			ATTACHMENT								PILOT								DRIVER HANDLE	ATTACH- MENT	INNER DRIVER	ATTACH- MENT	INNER DRIVER HANDLE																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																			
			07746-0010700	07946-1870100	07746-0010100	07746-0010200	07746-0010300	07746-0010400	07746-0010500	07746-0010600	07GAD-SD40101	10	12	15	17	20	22	25	30	35	40	07746-0040100	07746-0040200	07746-0040300	07746-0040400	07746-0040500	07746-0040600	07746-0040700	07746-0040800	07746-0040900	07746-0041000	07746-0041100	07746-0041200	07746-0041300	07746-0041400	07746-0041500	07746-0041600	07746-0041700	07746-0041800	07746-0041900	07746-0042000	07746-0042100	07746-0042200	07746-0042300	07746-0042400	07746-0042500	07746-0042600	07746-0042700	07746-0042800	07746-0042900	07746-0043000	07746-0043100	07746-0043200	07746-0043300	07746-0043400	07746-0043500	07746-0043600	07746-0043700	07746-0043800	07746-0043900	07746-0044000	07746-0044100	07746-0044200	07746-0044300	07746-0044400	07746-0044500	07746-0044600	07746-0044700	07746-0044800	07746-0044900	07746-0045000	07746-0045100	07746-0045200	07746-0045300	07746-0045400	07746-0045500	07746-0045600	07746-0045700	07746-0045800	07746-0045900	07746-0046000	07746-0046100	07746-0046200	07746-0046300	07746-0046400	07746-0046500	07746-0046600	07746-0046700	07746-0046800	07746-0046900	07746-0047000	07746-0047100	07746-0047200	07746-0047300	07746-0047400	07746-0047500	07746-0047600	07746-0047700	07746-0047800	07746-0047900	07746-0048000	07746-0048100	07746-0048200	07746-0048300	07746-0048400	07746-0048500	07746-0048600	07746-0048700	07746-0048800	07746-0048900	07746-0049000	07746-0049100	07746-0049200	07746-0049300	07746-0049400	07746-0049500	07746-0049600	07746-0049700	07746-0049800	07746-0049900	07746-0050000	07746-0050100	07746-0050200	07746-0050300	07746-0050400	07746-0050500	07746-0050600	07746-0050700	07746-0050800	07746-0050900	07746-0051000	07746-0051100	07746-0051200	07746-0051300	07746-0051400	07746-0051500	07746-0051600	07746-0051700	07746-0051800	07746-0051900	07746-0052000	07746-0052100	07746-0052200	07746-0052300	07746-0052400	07746-0052500	07746-0052600	07746-0052700	07746-0052800	07746-0052900	07746-0053000	07746-0053100	07746-0053200	07746-0053300	07746-0053400	07746-0053500	07746-0053600	07746-0053700	07746-0053800	07746-0053900	07746-0054000	07746-0054100	07746-0054200	07746-0054300	07746-0054400	07746-0054500	07746-0054600	07746-0054700	07746-0054800	07746-0054900	07746-0055000	07746-0055100	07746-0055200	07746-0055300	07746-0055400	07746-0055500	07746-0055600	07746-0055700	07746-0055800	07746-0055900	07746-0056000	07746-0056100	07746-0056200	07746-0056300	07746-0056400	07746-0056500	07746-0056600	07746-0056700	07746-0056800	07746-0056900	07746-0057000	07746-0057100	07746-0057200	07746-0057300	07746-0057400	07746-0057500	07746-0057600	07746-0057700	07746-0057800	07746-0057900	07746-0058000	07746-0058100	07746-0058200	07746-0058300	07746-0058400	07746-0058500	07746-0058600	07746-0058700	07746-0058800	07746-0058900	07746-0059000	07746-0059100	07746-0059200	07746-0059300	07746-0059400	07746-0059500	07746-0059600	07746-0059700	07746-0059800	07746-0059900	07746-0060000	07746-0060100	07746-0060200	07746-0060300	07746-0060400	07746-0060500	07746-0060600	07746-0060700	07746-0060800	07746-0060900	07746-0061000	07746-0061100	07746-0061200	07746-0061300	07746-0061400	07746-0061500	07746-0061600	07746-0061700	07746-0061800	07746-0061900	07746-0062000	07746-0062100	07746-0062200	07746-0062300	07746-0062400	07746-0062500	07746-0062600	07746-0062700	07746-0062800	07746-0062900	07746-0063000	07746-0063100	07746-0063200	07746-0063300	07746-0063400	07746-0063500	07746-0063600	07746-0063700	07746-0063800	07746-0063900	07746-0064000	07746-0064100	07746-0064200	07746-0064300	07746-0064400	07746-0064500	07746-0064600	07746-0064700	07746-0064800	07746-0064900	07746-0065000	07746-0065100	07746-0065200	07746-0065300	07746-0065400	07746-0065500	07746-0065600	07746-0065700	07746-0065800	07746-0065900	07746-0066000	07746-0066100	07746-0066200	07746-0066300	07746-0066400	07746-0066500	07746-0066600	07746-0066700	07746-0066800	07746-0066900	07746-0067000	07746-0067100	07746-0067200	07746-0067300	07746-0067400	07746-0067500	07746-0067600	07746-0067700	07746-0067800	07746-0067900	07746-0068000	07746-0068100	07746-0068200	07746-0068300	07746-0068400	07746-0068500	07746-0068600	07746-0068700	07746-0068800	07746-0068900	07746-0069000	07746-0069100	07746-0069200	07746-0069300	07746-0069400	07746-0069500	07746-0069600	07746-0069700	07746-0069800	07746-0069900	07746-0070000	07746-0070100	07746-0070200	07746-0070300	07746-0070400	07746-0070500	07746-0070600	07746-0070700	07746-0070800	07746-0070900	07746-0071000	07746-0071100	07746-0071200	07746-0071300	07746-0071400	07746-0071500	07746-0071600	07746-0071700	07746-0071800	07746-0071900	07746-0072000	07746-0072100	07746-0072200	07746-0072300	07746-0072400	07746-0072500	07746-0072600	07746-0072700	07746-0072800	07746-0072900	07746-0073000	07746-0073100	07746-0073200	07746-0073300	07746-0073400	07746-0073500	07746-0073600	07746-0073700	07746-0073800	07746-0073900	07746-0074000	07746-0074100	07746-0074200	07746-0074300	07746-0074400	07746-0074500	07746-0074600	07746-0074700	07746-0074800	07746-0074900	07746-0075000	07746-0075100	07746-0075200	07746-0075300	07746-0075400	07746-0075500	07746-0075600	07746-0075700	07746-0075800	07746-0075900	07746-0076000	07746-0076100	07746-0076200	07746-0076300	07746-0076400	07746-0076500	07746-0076600	07746-0076700	07746-0076800	07746-0076900	07746-0077000	07746-0077100	07746-0077200	07746-0077300	07746-0077400	07746-0077500	07746-0077600	07746-0077700	07746-0077800	07746-0077900	07746-0078000	07746-0078100	07746-0078200	07746-0078300	07746-0078400	07746-0078500	07746-0078600	07746-0078700	07746-0078800	07746-0078900	07746-0079000	07746-0079100	07746-0079200	07746-0079300	07746-0079400	07746-0079500	07746-0079600	07746-0079700	07746-0079800	07746-0079900	07746-0080000	07746-0080100	07746-0080200	07746-0080300	07746-0080400	07746-0080500	07746-0080600	07746-0080700	07746-0080800	07746-0080900	07746-0081000	07746-0081100	07746-0081200	07746-0081300	07746-0081400	07746-0081500	07746-0081600	07746-0081700	07746-0081800	07746-0081900	07746-0082000	07746-0082100	07746-0082200	07746-0082300	07746-0082400	07746-0082500	07746-0082600	07746-0082700	07746-0082800	07746-0082900	07746-0083000	07746-0083100	07746-0083200	07746-0083300	07746-0083400	07746-0083500	07746-0083600	07746-0083700	07746-0083800	07746-0083900	07746-0084000	07746-0084100	07746-0084200	07746-0084300	07746-0084400	07746-0084500	07746-0084600	07746-0084700	07746-0084800	07746-0084900	07746-0085000	07746-0085100	07746-0085200	07746-0085300	07746-0085400	07746-0085500	07746-0085600	07746-0085700	07746-0085800	07746-0085900	07746-0086000	07746-0086100	07746-0086200	07746-0086300	07746-0086400	07746-0086500	07746-0086600	07746-0086700	07746-0086800	07746-0086900	07746-0087000	07746-0087100	07746-0087200	07746-0087300	07746-0087400	07746-0087500	07746-0087600	07746-0087700	07746-0087800	07746-0087900	07746-0088000	07746-0088100	07746-0088200	07746-0088300	07746-0088400	07746-0088500	07746-0088600	07746-0088700	07746-0088800	07746-0088900	07746-0089000	07746-0089100	07746-0089200	07746-0089300	07746-0089400	07746-0089500	07746-0089600	07746-0089700	07746-0089800	07746-0089900	07746-0090000	07746-0090100	07746-0090200	07746-0090300	07746-0090400	07746-0090500	07746-0090600	07746-0090700	07746-0090800	07746-0090900	07746-0091000	07746-0091100	07746-0091200	07746-0091300	07746-0091400	07746-0091500	07746-0091600	07746-0091700	07746-0091800	07746-0091900	07746-0092000	07746-0092100	07746-0092200	07746-0092300	07746-0092400	07746-0092500	07746-0092600	07746-0092700	07746-0092800	07746-0092900	07746-0093000	07746-0093100	07746-0093200	07746-0093300	07746-0093400	07746-0093500	07746-0093600	07746-0093700	07746-0093800	07746-0093900	07746-0094000	07746-0094100	07746-0094200	07746-0094300	07746-0094400	07746-0094500	07746-0094600	07746-0094700	07746-0094800	07746-0094900	07746-0095000	07746-0095100	07746-0095200	07746-0095300	07746-0095400	07746-0095500	07746-0095600	07746-0095700	07746-0095800	07746-0095900	07746-0096000	07746-0096100	07746-0096200	07746-0096300	07746-0096400	07746-0096500	07746-0096600	07746-0096700	07746-0096800	07746-0096900	07746-0097000	07746-0097100	07746-0097200	07746-0097300	07746-0097400	07746-0097500	07746-0097600	07746-0097700	07746-0097800	07746-0097900	07746-0098000	07746-0098100	07746-0098200	07746-0098300	07746-0098400	07746-0098500	07746-0098600	07746-0098700	07746-0098800	07746-0098900	07746-0099000	07746-0099100	07746-0099200	07746-0099300	07746-0099400	07746-0099500	07746-0099600	07746-0099700	07746-0099800	07746-0099900	07746-0100000	07746-0100100	07746-0100200	07746-0100300	07746-0100400	07746-0100500	07746-0100600	07746-0100700	07746-0100800	07746-0100900	07746-0101000	07746-0101100	07746-0101200	07746-0101300	07746-0101400	07746-0101500	07746-0101600	07746-0101700	07746-0101800	07746-0101900	07746-0102000	07746-0102100	07746-0102200	07746-0102300	07746-0102400	07746-0102500	07746-0102600	07746-0102700	07746-0102800	07746-0102900	07746-0103000	07746-0103100	07746-0103200	07746-0103300	07746-0103400	07746-0103500	07746-0103600	07746-0103700	07746-0103800	07746-0103900	07746-0104000	07746-0104100	07746-0104200	07746-0104300	07746-0104400	07746-0104500	07746-0104600	07746-0104700	07746-0104800	07746-0104900	07746-0105000	07746-0105100	07746-0105200	07746-0105300	07746-0105400	07746-0105500	07746-0105600	07746-0105700	07746-0105800	07746-0105900	07746-0106000	07746-0106100