

### PowerSDR keyboard shortcuts.

PowerSDR must be in **FOCUS** (Mouse Click somewhere on the PowerSDR console screen) for the PowerSDR to respond to keyboard input.

Function	Key	ALT	CTRL	ALT + CTRL	CTRL + SHIFT	Shift + ALT
<b>Ke9ns:</b> Mouse over a PowerSDR button usually brings you to its SETUP page OR <b>Ke9ns:</b> Mouse over a DX spot on Pan, opens QRZ page OR <b>Ke9ns:</b> Mouse over a SWL spot on Pan, opens Google page OR <b>Ke9ns:</b> Mouse over ID timer, toggles between voiceID, waterID, and Pop-Up	Right mouse Click					
<b>Ke9ns:</b> Show DX Spotters on Pan and Lat/Long on Pan (instead of DX Spots) Or With Mouse over Band Button causes dec in the BandStack. Or Resets Database to Factory Defaults if Held at Power UP.	SHIFT					
<b>Ke9ns:</b> When mouse over a DX spot, sets VFOA, Mode, Split, and RX Filter to that DX Spot	CTRL					
Change VFO Freq (by the current Tune Step amount)	Mouse Wheel					
Change VFO Freq (by the current Alt Tune Step amount)	PowerMate Knob					
-1 MHz	A					
+ RX FILTER (F1-F10,VAR1/2)	B					
	C					
-10 KHz	D					
+10 KHz	E					
-1 KHz	F					
-100 Hz	G					
-10 Hz	H					

- RIT	I					
-1 Hz	J					
Filter width inc (50hz)	K					
Filter width dec (50hz)	L					
+ BAND	M					
- BAND	N					
+ RIT	O					
- XIT	P					
+1 MHz	Q					
+1 KHz	R					
-100 KHz	S					
+100 Hz	T					
+1 Hz	U					
- RX FILTER (F1-F10,VAR1/2)	V					
+100 KHz	W					
+ MODE	X					
+10 Hz	Y					
- MODE	Z					
Automatically finishes an “Accept” button operation(if the control features an Accept button) Or Whatever windows object has the current Focus	ENTER Enter Key					
Cancel button (if the control features a Cancel button)	ESC					
(LEFT) Mouse Click over the last selected control (current Focused object)	Space Bar Space					
Allows direct VFOA frequency Entry	0-9 and . or ,					
+ XIT	[					
	]					
CW DOT	.					
CW DASH	?					
Toggle MUT button	*					
AF level inc	+					
AF level dec	-					
Ke9ns: Help screen (mouse must be over item requesting help)	F1					
	F2					
	F3					

	F4					
	F5					
	F6					
	F7					
	F8					
	F9					
	F10					
	F11					
	F12					
Flex-3000: ATU form					CTRL SHIFT A	
<b>Hidden:</b> EEPROM calibration form					CTRL SHIFT C	
<b>Hidden:</b> Debug form					CTRL SHIFT D	
<b>Hidden:</b> Flex-3000/5000: PA Calibration form. Use to reCal your transmitter					CTRL SHIFT F	
Hidden: Flex-3000/5000: Volts & Temp					CTRL SHIFT I	
<b>Hidden:</b> Flex-5000: Relays menu item add (TX1,TX2,TX3)					CTRL SHIFT O	
<b>Hidden:</b> TRX I/O Test and Calibration form. Use to reCal your receiver. (general, RX, TX image & carrier & filter, I/O calibration and tests)					CTRL SHIFT P	
<b>Hidden:</b> Flex-5000: TRX2 I/O Test and Calibration form. Use to reCal RX2					CTRL SHIFT R	
Hero's Preselector (3 <sup>rd</sup> party option) screen					CTRL SHIFT S	
Hidden: SDR-1000 PA Qualify form					CTRL SHIFT T	
<b>Hidden:</b> Flex-5000: VU5K option Calibration form					CTRL SHIFT V	
About form				CTRL ALT A		
<b>Hidden:</b> Flex-5000: LPF (low pass filter) manual override form (RX1 and RX2)				CTRL ALT 4		
<b>Hidden:</b> DSP test form (WBIQ, Manual Notch, NR, ANF, DC Block)				CTRL ALT D		
<b>Hidden:</b> Flex-1500: TX				CTRL ALT G		

image calibration form						
Flex-5000 (RX2 only) ESC (Enhanced Signal Clarity)				CTRL ALT R		
FlexWire UCB config and setup form (I <sup>2</sup> C bus)				CTRL ALT U		
Hidden: Toggles <b>Full Duplex</b> button on/off (button located just to left of words "Tune Step:")				CTRL ALT F		
Change AGC-T level inc ( see CTRL R)			CTRL +			
Change AGC-T level dec ( see CTRL E)			CTRL -			
Change Tune Step Up (larger step)			CTRL (left arrow)			
Change Tune Step Dwn (smaller step)			CTRL (right arrow)			
Mouse Wheel: Freq inc (by Tune Step amount)			CTRL (up arrow)			
Mouse Wheel: Freq dec (by Tune Step amount)			CTRL (dwn arrow)			
QuickSave current Freq (just below VFO LOCK button)			CTRL C			
Toggle between: Spectrum, and Panadapter modes			CTRL D			
Change AGC-T level dec			CTRL E			
Narrow current RX filter by 5hz (see ALT F)			CTRL F			
Toggle VFO LOCK button			CTRL L			
Toggle MOX button			CTRL M			
Toggle ANF button			CTRL N			
Toggle PreAmp mode			CTRL P			
Change AGC-T level inc			CTRL R			
Toggle SPLIT button			CTRL S			
Toggle RESTORE button (QuickSave restore)			CTRL V			
CW speed value dec (see ALT Q)			CTRL W			
Mic level inc		ALT (up arrow)				
Mic level dec		ALT (dwn arrow)				
Vox level inc		ALT (left arrow)				
Vox level dec		ALT (right arrow)				

[illegible]
