

## Introduction

This guide covers the basic installation and configuration of your IOLAN. It is intended for systems administrators.

The following are the steps needed to setup the IOLAN.

1. Verify that you have all the required parts
2. Setup the hardware
3. Power on the IOLAN
4. Configure the IOLAN

For detailed information, please refer to the IOLAN User’s Guide for your model.

## Components

### What’s In the Box

- The IOLAN
- External power supply\*
- A Quick Start Guide (this document)
- Warranty Card
- RJ45 - DB9 adapter (RJ45 models only excluding TS2 model)
- A CD-ROM containing documentation and firmware required to configure and operate the IOLAN

\*Not included when purchasing Power over Ethernet models and HL models

### What You Need to Supply

- Serial cable(s) to connect your serial devices to the IOLAN
- An Ethernet 10/100BASE-T cable to connect the IOLAN to the network

## Hardware Setup

### Connecting Serial Devices

Please refer to the pin-out table and ensure you have the appropriate cable for connecting your serial device to one of the RJ45 serial ports on the IOLAN.

**NOTE:** The STS8-D unit uses the 8 pin connector and only supports EIA-232.

| Pinout  | EIA-232   | EIA-422   | EIA-485 Full Duplex | EIA-485 Half Duplex |
|---------|-----------|-----------|---------------------|---------------------|
| 1       | Power In  | Power In  | Power In            | Power In            |
| 2 (in)  | DCD       |           |                     |                     |
| 3 (out) | RTS       | TxD+      | TxD                 | TxD+/RxD+           |
| 4 (in)  | DSR       |           |                     |                     |
| 5 (out) | TxD       | TxD-      | TxD-                | TxD-/RxD-           |
| 6 (in)  | RxD       | RxD+      | RxD+                |                     |
| 7       | GND       | GND       | GND                 | GND                 |
| 8 (in)  | CTS       | RxD-      | RxD-                |                     |
| 9 (out) | DTR       |           |                     |                     |
| 10      | Power Out | Power Out | Power Out           | Power Out           |

### Connecting the LAN

- Connect the IOLAN to the HUB or Switch that will provide the network connectivity.

### Setting the Dip Switch

- The dip switch on the IOLAN is set in the factory to serial. Unless you plan to attach a console to the IOLAN, leave the dip switch in the serial position.

## Connectiing the Power

### Models with barrel connectors

- Plug the power adapter into a power socket and connect the barrel connector end into the IOLAN. The IOLAN will power up.

### Models with screw terminal blocks

- Enusre power is NOT applied to the wires prior to connection
- Connect wires to screw terminal. Refer to polarity markings on top of unit.
- Turn on power at source

## Powering On Cycle

When the power is connected to the IOLAN, the Power/Ready LED will cycle through several sequences and will end in a solid green once the unit is fully booted and ready to be configured.

If the LED is not solid green after two minutes, refer to the User’s Guide for help identifying the reason.

### LED Guide

**Power/Ready**—(Green/Yellow/Red)

- **Green**—
  - Solid = System Ready
  - Flashing = System is booting or dip switch is in console mode
- **Yellow**—
  - Flashing = Booting
- **Red**—Error condition (refer to the User’s Guide for details)

**Link/10/100**

- **Green**—10 Mbits
  - **Yellow**—100 Mbits
  - **Off**—No LAN connection
- Activity**—Flashes for LAN RX/TX activity  
**Tx**—Flashes with transmit serial activity  
**Rx**—Flashes with receive serial activity

## Configuring the Unit

The CD\_ROM provided with your IOLAN includes software for configuring the unit. This software is designed for use on a Windows Operating System. For other Operating Systems, please refer to the IOLAN User’s Guide for methods of configuring the IOLAN.

1. Insert the CD-ROM into the PC.
  - It should launch automatically. If it does not launch, open Windows Explorer and point to the CD-ROM Drive. Double click on the index file to launch the main page.

2. From the main page, select the Easy Config Wizard to launch the configuration wizard or alternatively, install the DeviceManager software and use it to configure the IOLAN.

### Default admin Password

You will be prompted by the software for the **admin** user password before being allowed to configure the IOLAN.

The factory default password for the admin user is:

**superuser** (case sensitive)

You should change the admin password to restrict unauthorized access to the IOLAN.

For additional methods of configuring your IOLAN (i.e., HTTP, Telnet, SNMP), please refer to the IOLAN User’s Guide.

Registering the IOLAN

You should register IOLAN online at:

http://www.perle.com/support\_services/warranty\_reg.asp

WARNINGS

The SDS4 HL is suitable for use in Class I, Division 2 groups A,B,C,D or unclassified locations.

WARNING - EXPLOSION HAZARD - DO NOT DISCONNECT EQUIPMENT UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NON-HARAZDOUS

AVERTISSEMENT - RISQUE D’EXPLOSION - AVANT DE DÉCONNECTER L’EQUIPEMENT, COUPER LE COURANT OU S’ASSURER QUE L’EMPLACEMENT EST DÉSIGNÉ NON DANGEREUX



|                                                                                                                                                                                                                                                                                                                              |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                                                                                                                                                                                                                                                              |
| <b>Perle offers free technical support to Perle Authorised Distributors and Registered Perle Resellers.</b>                                                                                                                                                                                                                  |
| <b>To access technical support, please visit the Perle website at <a href="http://www.perle.com/support">www.perle.com/support</a>.</b>                                                                                                                                                                                      |
| <b>Here you will find:</b>                                                                                                                                                                                                                                                                                                   |
| <ul style="list-style-type: none"><li>• latest drivers and firmware updates for download</li><li>• technical tips</li><li>• frequently asked questions</li><li>• documentation</li><li>• configuration support</li><li>• cabling information</li><li>• maintenance contract information</li><li>• and much more...</li></ul> |
| <b>If you are unable to find the information you require, please feel free to contact our technical support teams by email at:</b>                                                                                                                                                                                           |
| <b>USA</b>                                                                                                                                                                                                                                                                                                                   |
| <b>Email: <a href="mailto:ptac@perle.com">ptac@perle.com</a></b>                                                                                                                                                                                                                                                             |
| <b>Europe</b>                                                                                                                                                                                                                                                                                                                |
| <b>Email: <a href="mailto:ptacemea@perle.com">ptacemea@perle.com</a></b>                                                                                                                                                                                                                                                     |
| <b>Asia</b>                                                                                                                                                                                                                                                                                                                  |
| <b>Email: <a href="mailto:ptacasia@perle.com">ptacasia@perle.com</a></b>                                                                                                                                                                                                                                                     |
| <b>Internet</b>                                                                                                                                                                                                                                                                                                              |
| <b><a href="http://www.perle.com/support_services">www.perle.com/support_services</a></b>                                                                                                                                                                                                                                    |

|                                              |
|----------------------------------------------|
| IOLAN                                        |
| 2/4/8-Port Quick Start Guide                 |
| Part No: 5500171-16                          |
| Copyright © Perle Systems Limited, 2005-2010 |



IOLAN  
Desktop  
2/4/8-Port  
Quick Start Guide



- Advanced serial to Ethernet connectivity
- Universal, software selectable EIA-232/422/485 interface (on some models)
- 15 KV ESD protection
- Next Generation IP support (IPV6)