



Notes:

1. When STM32F405RTELQFP144 is mounted, J1 and J2 must be populated! C6 and C47 should be populated!
2. When STM32F405RTELQFP144 is mounted, J1 and J2 must be populated! C48 and C47 should be not populated!
3. U1 is a symbol refers to STM32F405RTELQFP144.

For the STM32F405RTELQFP144, please see the corresponding datasheet

**HAVA STASYONU
HG-2S MURAT
IRKAN**