


HITACHI
Inspire the Next

WIRED REMOTE CONTROLLER

MODEL

SPX-RCK3




















РУССКИЙ
Ελληνικά
PORTUGUÊS
ESPAÑOL
ITALIANO
FRANÇAIS
DEUTSCH
ENGLISH



PRECAUTIONS FOR USE

- In case of power failure happen, Wired Remote Controller may not show current operating mode when power comes back. However unit will continue to operate at previous setting mode.
- It is not recommended to use both Wireless Remote Controller and Wired Remote Controller at the same time.
- Some features of Wireless Remote Controller are not available when use Wired Remote Controller as mentioned below:

Standard Wireless Remote Controller	Features not available on Wired Remote Controller
RAR-3U1  	<ul style="list-style-type: none">● Auto Swing Control 
RAR-3U2  	<ul style="list-style-type: none">● Auto Swing Control ● Extended Airflow 
RAR-3U3  	<ul style="list-style-type: none">● Auto Swing Control ● Parallel Swing Control ● Symmetry Swing Control 
RAR-3U4  	<ul style="list-style-type: none">● Auto Swing Control ● Extended Airflow ● Plasma Ion Control 

NAMES AND FUNCTIONS OF REMOTE CONTROL UNIT

■ This controls the operation function and timer setting of the room air conditioner.

ENGLISH

START/STOP Button

Press this button to start operation.
Press it again to stop operation.

FUNCTION Button

Use this button to select the operating mode. Every time you press it, the mode will change from (AUTO) to (HEAT) to (DEHUMIDIFY) and to (COOL) cyclically.

SLEEP Button

Use this button to set the sleep timer. (→ next page)

Reserve Button

Timer setting reservation.

OFF TIMER Button

Select the turn OFF time.

ON TIMER Button

Select the turn ON time.

Transmission Sign

The transmission sign blinks when a signal has been send.

TEMPERATURE Button

Room temperature setting.
Value will change quicker when keep pressing.

FAN SPEED Button

This determines the fan speed. Every time you press this button, the intensity of circulation will change from (AUTO) to (HI) to (MED) to (LOW) to (SILENT) (This button allows selecting the optimal or preferred fan speed for each operation mode).

CANCEL Button

Cancel timer reservation.

Precautions for Use

- Do not put the remote controller in the following places.
 - Under direct sunlight.
 - In the vicinity of a heater.
- Handle the remote controller carefully. Do not drop it on the floor, and protect it from water.
- Once the outdoor unit stops, it will not restart for about 3 minutes (unless you turn the power switch off and on or unplug the power cord and plug it in again).
This is to protect the device and does not indicate a failure.
- If you press the FUNCTION selector button during operation, the device may stop for about 3 minutes for protection.


VARIOUS FUNCTIONS

■ Auto Restart Control


- If there is a power failure, operation will be automatically restarted when the power is resumed with previous operation mode. (As the operation is not stopped by remote controller.)
 - If you intend not to continue the operation when the power is resumed, switch off the power supply. When you switch on the circuit breaker, the operation will be automatically restarted with previous operation mode.
- Note: 1. If you do not require Auto Restart Control, please consult your sales agent or OFF by remote control.
2. Auto Restart Control is not available when Timer or Sleep Timer mode is set.

AUTOMATIC OPERATION

The device will automatically determine the mode of operation, HEAT, COOL or DEHUMIDIFY depending on the current room temperature. The selected mode of operation will change when the room temperature varies.





1


Press the FUNCTION selector so that the display indicates the  (AUTO) mode of operation.

- When AUTO has been selected, the device will automatically determine the mode of operation, HEAT, COOL or DEHUMIDIFY depending on the current room temperature. However the mode of operation will not change when indoor unit connected to multi type outdoor unit.
- If the mode automatically selected by the unit is not satisfactory, manually change the mode setting (heat, dehumidify, cool or fan).

START STOP

Press the  (START/STOP) button. Operation starts with a beep. Press the button again to stop operation.

■ As the settings are stored in memory in the remote controller, you only have to press the  (START/STOP) button next time.



FAN SPEED (AUTO) When the AUTO fan speed mode is set in the cooling/heating operation:

For the heating operation	<ul style="list-style-type: none">• The fan speed will automatically change according to the temperature of discharged air.• When the difference of room temperature and setting temperature is large, fan starts to run at HI speed.• When the room temperature reaches setting temperature, fan speed changes to LOW automatically.
For the cooling operation	<ul style="list-style-type: none">• When the difference of room temperature and setting temperature is large, fan starts to run at HI speed.• After room temperature reaches the preset temperature, the cooling operation, which changes the fan speed and room temperature to obtain optimum conditions for natural healthful cooling will be performed.

HEATING OPERATION

ENGLISH

- Use the device for heating when the outdoor temperature is under 21°C.
When it is too warm (over 21°C), the heating function may not work in order to protect the device.
- In order to keep reliability of the device, please use this device above -15°C of the outdoor temperature.

1 Press the FUNCTION selector so that the display indicates (HEAT).

Set the desired FAN SPEED with the (FAN SPEED) button (the display indicates the setting).

- (AUTO) : The fan speed is HI at first and varies to MED automatically when the preset temperature has been reached.
- (HI) : Economical as the room will become warm quickly.
But you may feel a chill at the beginning.
- (MED) : Fan speed slow.
- (LOW) : Fan speed slower.
- (SILENT) : Fan speed ultra slower.

2

Set the desired room temperature with the TEMPERATURE buttons (the display indicates the setting).

3 The temperature setting and the actual room temperature may vary somewhat depending on conditions.

START STOP Press the (START/STOP) button. Heating operation starts with a beep. Press the button again to stop operation.

■ As the settings are stored in memory in the remote controller, you only have to press the (START/STOP) button next time.

DEHUMIDIFYING OPERATION

Use the device for dehumidifying when the room temperature is over 16°C.
When it is under 15°C, the dehumidifying function will not work.

1 Press the FUNCTION selector so that the display indicates (DEHUMIDIFY). The FAN SPEED is set at LOW or SILENT.

2 Set the desired room temperature with the TEMPERATURE button (the display indicates the setting). The range of 20-26°C is recommended as the room temperature for dehumidifying.

START STOP Press the ① (START/STOP) button. Dehumidifying operation starts with a beep. Press the button again to stop operation.

■ As the settings are stored in memory in the remote controller, you only have to press the ① (START/STOP) button next time.


■ Dehumidifying Function







When the room temperature is higher than the temperature setting: The device will dehumidify the room, reducing the room temperature to the preset level.
When the room temperature is lower than the temperature setting: Dehumidifying will be performed at the temperature setting slightly lower than the current room temperature, regardless of the temperature setting. The function will stop (the indoor unit will stop emitting air) as soon as the room temperature becomes lower than the setting temperature.



COOLING OPERATION


Use the device for cooling when the outdoor temperature is $-10 \sim 43^{\circ}\text{C}$.
If indoor humidity is very high (80%), some dew may form on the air outlet grille of the indoor unit.

ENGLISH



- 1** Press the FUNCTION selector so that the display indicates * (COOL).
- 2** Set the desired FAN SPEED with the  (FAN SPEED) button (the display indicates the setting).
 -  (AUTO) : The FAN SPEED is HI at first and varies to MED automatically when the preset temperature has been reached.
 -  (HI) : Economical as the room will become cool quickly.
 -  (MED) : Fan speed slow.
 -  (LOW) : Fan speed slower.
 -  (SILENT) : Fan speed ultra slower.
- 3** Set the desired room temperature with the TEMPERATURE button (the display indicates the setting).
The temperature setting and the actual room temperature may vary some how depending on conditions.

START/STOP Press the  (START/STOP) button. Cooling operation starts with a beep. Press the button again to stop operation. The cooling function does not start if the temperature setting is higher than the current room temperature (even though the  (OPERATION) lamp lights). The cooling function will start as soon as you set the temperature below the current room temperature.

■ As the settings are stored in memory in the remote controller, you only have to press the  (START/STOP) button next time.


TIMER RESERVATION

■ ON Timer and OFF Timer are available.

OFF Timer Reservation

1 (OFF) OFF TIME setting

- Select the OFF TIME by pressing the (OFF) Button.
- Setting time will change according to the below sequence when you press the button.



- The value change quicker if you keep pressing the button.


2 Press the (Reserve) button

- OFF TIMER reserved with a signal received sound "beep".
- The (OFF) Mark starts lighting instead of blinking.

ON Timer Reservation

1 (ON) ON TIME setting

- Select the ON TIMER by pressing the (ON) Button.
- At the beginning of setting, time 6 hours was set.
- Setting time will change according to the below sequence.



- The value change quicker if you keep pressing the button.

2 Press the (Reserve) button



- ON TIMER reserved with a signal received sound "beep".
- The (ON) Mark starts lighting instead of blinking.

CANCELLATION of Timer Reservation



1 Press the (Cancel) button

- As the time settings are stored in remote controller memory, you only have to press the (Reserve) button in order to use the same setting next time.


■ Operation stop at setting time



■ Operation will start for setting temperature at setting time (The starting time may different depend on the room temperature and set temperature).



HOW TO SET THE SLEEP TIMER



Example: Setting 3 hours sleep time.

Mode	Indication
Sleep timer	1 hour → 2 hours → 3 hours → 7 hours → Sleep timer off

Sleep Timer: The device will continue working for the designated number of hours and then turn off.
Press the SLEEP button, indoor unit will produce a beep.
The timer information will be displayed on the remote controller.

ENGLISH

How to Cancel Reservation

Press the ○ (CANCEL) button. The ① (RESERVED) sign goes out with a beep.

Explanation of the sleep timer


The device will control the FAN SPEED and room temperature automatically so as to be quiet and good for people's health.

NOTE

- If you set the sleep timer after the off or on-timer has been set, the sleep timer becomes effective instead of the off or on-timer set earlier.
- You can not set other timer during sleep timer operation.
- After sleep timer time is up and when press sleep button again, the sleep timer will be set as last setting.
- Sleep timer effective only once.

INSTALLATION OF WIRED REMOTE CONTROLLER

- (a) Connection to the electrical box;
 - Remove the cover of electric box
 - Connect the connector of wired remote controller to CN1102 of electrical board.
 - Assemble back the cover of electrical box
- (b) Wiring installation for wired remote controller (2 methods);
 - Wired remote controller casing can be opened by pressing the slots with minus screw driver (see below diagram)



- Decide the fixing location of remote controller so that the length of wire shall be within 15 meters.




- Do not cut the provided wire. Excess wire should be properly wound and fitted at safe place.
- Do not join the wire with additional wire.

Wiring installation illustrations

Wall recessed wiring installation (Supplied)

1. When connecting the wires via the wall's recessed slot;
 - Fix the bottom casing to the wall by provided screw.
 - Assemble the top casing to the fixed bottom casing.
 (Refer to the illustration below for detail installation)



Inside top wiring installation (Alternative)

2. When the wires to be connected from the inside top portion of top casing;
 - Break off a perforated aperture located at the top portion of the bottom casing by nipper. Smoothen the aperture by cutter.
 - Fix the bottom casing to the wall by provided screw.
 - Connect the wires to the lead wires connector.
 - Mount the wires through the provided slot on top casing.
 - Assemble the top casing to the fixed bottom casing
 (Refer to the illustration below for detail installation)

