



## **Global report**

## Table of content

1. [Properties](#)
2. [System Events](#)
3. [Blocks](#)
  - 3.1. [CaseLinkingInUse1](#)
  - 3.2. [CaseLinkingNotInUse1](#)
  - 3.3. [Receive\\_TrackSide\\_Msg](#)
  - 3.4. [InformationFilter](#)
  - 3.5. [validateDataDirection](#)
  - 3.6. [CheckEuroRadioMessage](#)
  - 3.7. [changeLevelByDiver1](#)
  - 3.8. [doDriverRequests1](#)
  - 3.9. [receiveRequestsModesAndLevel1](#)
  - 3.10. [triggerForMA1](#)
  - 3.11. [updateDMIStatus1](#)
  - 3.12. [getTIUStatusFromData](#)
  - 3.13. [mergeTIU\\_Info](#)
  - 3.14. [selectTrainData](#)
  - 3.15. [SoM\\_NTC\\_SN](#)
  - 3.16. [SoM\\_SR\\_FS\\_OS\\_LS\\_SH\\_SN\\_UN](#)
  - 3.17. [processHandingOver](#)
  - 3.18. [MoRC\\_Main\\_v21](#)
  - 3.19. [MoRC\\_Main\\_v22](#)
  - 3.20. [mobileDataRouter\\_out](#)
  - 3.21. [InputWrapper](#)
  - 3.22. [ABrakeFactory](#)
  - 3.23. [TargetManagement](#)
  - 3.24. [CalcBrakingCurves](#)
  - 3.25. [LimitLocations](#)
  - 3.26. [Commands](#)
  - 3.27. [AGradient](#)
  - 3.28. [addGradient1](#)
  - 3.29. [addGradient2](#)
  - 3.30. [AddBGToFIFO](#)
  - 3.31. [AggregatePackets](#)
  - 3.32. [Build\\_Packets0\\_1](#)
  - 3.33. [Build\\_SinglePosReport](#)
  - 3.34. [PosReport\\_Supervision](#)
  - 3.35. [ReceiveReportParameters](#)
  - 3.36. [ErrorManager](#)
  - 3.37. [bothBrakesActive](#)
  - 3.38. [getTIUStatusFromCommand](#)
  - 3.39. [handleTraction](#)
  - 3.40. [mapModeToTractionCutOff](#)

- 3.41. [TIU\\_OutputIntegration](#)
- 3.42. [calcDistances1](#)
- 3.43. [collectDMIPackets1](#)
- 3.44. [convert\\_cm\\_s\\_km\\_h1](#)
- 3.45. [copyGradientElement1](#)
- 3.46. [copySpeedProfileElement1](#)
- 3.47. [copyTrackDescription1](#)
- 3.48. [cyclicReportToDMI1](#)
- 3.49. [doEntryRequest1](#)
- 3.50. [doldentifierRequest1](#)
- 3.51. [isSendingNeeded1](#)
- 3.52. [mapEntryForLevel1](#)
- 3.53. [mapMoRCtoRadio\\_CS1](#)
- 3.54. [sendBrakesToDMI1](#)
- 3.55. [sendDynamic1](#)
- 3.56. [sendLevelListPkg1](#)
- 3.57. [sendTrainData1](#)
- 3.58. [sendVersion1](#)
- 3.59. [synchWithDMI1](#)
- 3.60. [trainDataStorage](#)
- 3.61. [sendAcknowledgementRBC](#)
- 3.62. [checkRadioMessages](#)
- 3.63. [sendValidTrainDataRBC](#)
- 3.64. [linkedBG\\_missed](#)
- 3.65. [twoConsecutiveLinkedBGs\\_missed](#)
- 3.66. [addAnnouncedBGs](#)
- 3.67. [calculateBGLocations](#)
- 3.68. [calculateTrainpositionAttributes](#)
- 3.69. [calculateTrainPositionInfo](#)
- 3.70. [delDispensableBGs](#)
- 3.71. [msg\\_2\\_passedBG](#)
- 3.72. [Input](#)
- 3.73. [ManageLevels](#)
- 3.74. [CheckLevelAndMode](#)
- 3.75. [ManageModes](#)
- 3.76. [Output](#)
- 3.77. [TrackAtlasETCS](#)
- 3.78. [F2.9 MoRC Main](#)
- 3.79. [F1 Receive Information from Trackside](#)
- 3.80. [Driver](#)

- 3.81. [Configuration1](#)
- 3.82. [F3 Measure Train Movement](#)
- 3.83. [F4 Radio Communication Controller](#)
- 3.84. [F5 Manage JRU](#)
- 3.85. [F6 DMI Controller](#)
- 3.86. [F7 TIU Controller](#)
- 3.87. [F8 Persistent Data](#)
- 3.88. [CaseLinkingInUse1](#)
- 3.89. [CaseLinkingNotInUse1](#)
- 3.90. [Receive\\_TrackSide\\_Msg](#)
- 3.91. [InformationFilter](#)
- 3.92. [validateDataDirection](#)
- 3.93. [CheckEuroRadioMessage](#)
- 3.94. [changeLevelByDiver1](#)
- 3.95. [doDriverRequests1](#)
- 3.96. [receiveRequestsModesAndLevel1](#)
- 3.97. [triggerForMA1](#)
- 3.98. [updateDMIStatus1](#)
- 3.99. [getTIUStatusFromData](#)
- 3.100. [mergeTIU\\_Info](#)
- 3.101. [selectTrainData](#)
- 3.102. [SoM\\_NTC\\_SN](#)
- 3.103. [SoM\\_SR\\_FS\\_OS\\_LS\\_SH\\_SN\\_UN](#)
- 3.104. [processHandingOver](#)
- 3.105. [MoRC\\_Main\\_v21](#)
- 3.106. [MoRC\\_Main\\_v22](#)
- 3.107. [mobileDataRouter\\_out](#)
- 3.108. [InputWrapper](#)
- 3.109. [ABrakeFactory](#)
- 3.110. [TargetManagement](#)
- 3.111. [CalcBrakingCurves](#)
- 3.112. [LimitLocations](#)
- 3.113. [Commands](#)
- 3.114. [AGradient](#)
- 3.115. [addGradient1](#)
- 3.116. [addGradient2](#)
- 3.117. [AddBGToFIFO](#)
- 3.118. [AggregatePackets](#)
- 3.119. [Build\\_Packets0\\_1](#)
- 3.120. [Build\\_SinglePosReport](#)

3.121. [PosReport Supervision](#)  
3.122. [ReceiveReportParameters](#)  
3.123. [ErrorManager](#)  
3.124. [bothBrakesActive](#)  
3.125. [getTIUStatusFromCommand](#)  
3.126. [handleTraction](#)  
3.127. [mapModeToTractionCutOff](#)  
3.128. [TIU OutputIntegration](#)  
3.129. [calcDistances1](#)  
3.130. [collectDMIPackets1](#)  
3.131. [convert\\_cm\\_s\\_km\\_h1](#)  
3.132. [copyGradientElement1](#)  
3.133. [copySpeedProfileElement1](#)  
3.134. [copyTrackDescription1](#)  
3.135. [cyclicReportToDMI1](#)  
3.136. [doEntryRequest1](#)  
3.137. [doldentifierRequest1](#)  
3.138. [isSendingNeeded1](#)  
3.139. [mapEntryForLevel1](#)  
3.140. [mapMoRCtoRadio\\_CS1](#)  
3.141. [sendBrakesToDMI1](#)  
3.142. [sendDynamic1](#)  
3.143. [sendLevelListPkg1](#)  
3.144. [sendTrainData1](#)  
3.145. [sendVersion1](#)  
3.146. [synchWithDMI1](#)  
3.147. [trainDataStorage](#)  
3.148. [sendAcknowledgementRBC](#)  
3.149. [checkRadioMessages](#)  
3.150. [sendValidTrainDataRBC](#)  
3.151. [linkedBG missed](#)  
3.152. [twoConsecutiveLinkedBGs missed](#)  
3.153. [addAnnouncedBGs](#)  
3.154. [calculateBGLocations](#)  
3.155. [calculateTrainpositionAttributes](#)  
3.156. [calculateTrainPositionInfo](#)  
3.157. [delDispensableBGs](#)  
3.158. [msg\\_2\\_passedBG](#)  
3.159. [Input](#)  
3.160. [ManageLevels](#)

3.161. [CheckLevelAndMode](#)  
3.162. [ManageModes](#)  
3.163. [Output](#)  
3.164. [TrackAtlasETCS](#)  
3.165. [F2.9 MoRC Main](#)  
3.166. [F1 Receive Information from Trackside](#)  
3.167. [Driver](#)  
3.168. [Configuration1](#)  
3.169. [F3 Measure Train Movement](#)  
3.170. [F4 Radio Communication Controller](#)  
3.171. [F5 Manage JRU](#)  
3.172. [F6 DMI Controller](#)  
3.173. [F7 TIU Controller](#)  
3.174. [F8 Persistent Data](#)  
3.175. [Driver](#)  
3.176. [Configuration](#)  
3.177. [ERTMS Track](#)  
3.178. [Eurobalise](#)  
3.179. [Interlocking](#)  
3.180. [RBC](#)  
3.181. [Train](#)  
3.182. [Train Movement](#)  
3.183. [Input](#)  
3.184. [ManageLevels](#)  
3.185. [CheckLevelAndMode](#)  
3.186. [ManageModes](#)  
3.187. [Output](#)  
3.188. [CaseLinkingInUse1](#)  
3.189. [CaseLinkingNotInUse1](#)  
3.190. [Receive TrackSide Msg](#)  
3.191. [InformationFilter](#)  
3.192. [validateDataDirection](#)  
3.193. [CheckEuroRadioMessage](#)  
3.194. [changeLevelByDiver1](#)  
3.195. [doDriverRequests1](#)  
3.196. [receiveRequestsModesAndLevel1](#)  
3.197. [triggerForMA1](#)  
3.198. [updateDMIStatus1](#)  
3.199. [getTIUStatusFromData](#)  
3.200. [mergeTIU Info](#)

3.201. [selectTrainData](#)  
3.202. [SoM NTC SN](#)  
3.203. [SoM SR FS OS LS SH SN UN](#)  
3.204. [processHandingOver](#)  
3.205. [MoRC Main v21](#)  
3.206. [MoRC Main v22](#)  
3.207. [mobileDataRouter\\_out](#)  
3.208. [InputWrapper](#)  
3.209. [ABrakeFactory](#)  
3.210. [TargetManagement](#)  
3.211. [CalcBrakingCurves](#)  
3.212. [LimitLocations](#)  
3.213. [Commands](#)  
3.214. [AGradient](#)  
3.215. [addGradient1](#)  
3.216. [addGradient2](#)  
3.217. [AddBGToFIFO](#)  
3.218. [AggregatePackets](#)  
3.219. [Build Packets0 1](#)  
3.220. [Build SinglePosReport](#)  
3.221. [PosReport Supervision](#)  
3.222. [ReceiveReportParameters](#)  
3.223. [ErrorManager](#)  
3.224. [bothBrakesActive](#)  
3.225. [getTIUStatusFromCommand](#)  
3.226. [handleTraction](#)  
3.227. [mapModeToTractionCutOff](#)  
3.228. [TIU OutputIntegration](#)  
3.229. [calcDistances1](#)  
3.230. [collectDMIPackets1](#)  
3.231. [convert cm s km h1](#)  
3.232. [copyGradientElement1](#)  
3.233. [copySpeedProfileElement1](#)  
3.234. [copyTrackDescription1](#)  
3.235. [cyclicReportToDMI1](#)  
3.236. [doEntryRequest1](#)  
3.237. [doldentifierRequest1](#)  
3.238. [isSendingNeeded1](#)  
3.239. [mapEntryForLevel1](#)  
3.240. [mapMoRCtoRadio\\_CS1](#)

3.241. [sendBrakesToDMI1](#)  
3.242. [sendDynamic1](#)  
3.243. [sendLevelListPkg1](#)  
3.244. [sendTrainData1](#)  
3.245. [sendVersion1](#)  
3.246. [synchWithDMI1](#)  
3.247. [trainDataStorage](#)  
3.248. [sendAcknowledgementRBC](#)  
3.249. [checkRadioMessages](#)  
3.250. [sendValidTrainDataRBC](#)  
3.251. [linkedBG\\_missed](#)  
3.252. [twoConsecutiveLinkedBGs\\_missed](#)  
3.253. [addAnnouncedBGs](#)  
3.254. [calculateBGLocations](#)  
3.255. [calculateTrainpositionAttributes](#)  
3.256. [calculateTrainPositionInfo](#)  
3.257. [delDispensableBGs](#)  
3.258. [msg\\_2\\_passedBG](#)  
3.259. [Input](#)  
3.260. [ManageLevels](#)  
3.261. [CheckLevelAndMode](#)  
3.262. [ManageModes](#)  
3.263. [Output](#)  
3.264. [TrackAtlasETCS](#)  
3.265. [F2.9 MoRC Main](#)  
3.266. [F1 Receive Information from Trackside](#)  
3.267. [Driver](#)  
3.268. [Configuration1](#)  
3.269. [F3 Measure Train Movement](#)  
3.270. [F4 Radio Communication Controller](#)  
3.271. [F5 Manage JRU](#)  
3.272. [F6 DMI Controller](#)  
3.273. [F7 TIU Controller](#)  
3.274. [F8 Persistent Data](#)  
3.275. [processHandingOver](#)  
3.276. [MoRC Main v21](#)  
3.277. [MoRC Main v22](#)  
3.278. [mobileDataRouter\\_out](#)  
3.279. [CaseLinkingInUse1](#)  
3.280. [CaseLinkingNotInUse1](#)



3.281. [AddBGToFIFO](#)  
3.282. [AggregatePackets](#)  
3.283. [Build\\_Packets0\\_1](#)  
3.284. [Build\\_SinglePosReport](#)  
3.285. [PosReport\\_Supervision](#)  
3.286. [ReceiveReportParameters](#)  
3.287. [ErrorManager](#)  
3.288. [calcDistances1](#)  
3.289. [collectDMIPackets1](#)  
3.290. [convert\\_cm\\_s\\_km\\_h1](#)  
3.291. [copyGradientElement1](#)  
3.292. [copySpeedProfileElement1](#)  
3.293. [copyTrackDescription1](#)  
3.294. [cyclicReportToDMI1](#)  
3.295. [doEntryRequest1](#)  
3.296. [doldentifierRequest1](#)  
3.297. [isSendingNeeded1](#)  
3.298. [mapEntryForLevel1](#)  
3.299. [mapMoRCtoRadio\\_CS1](#)  
3.300. [sendBrakesToDMI1](#)  
3.301. [sendDynamic1](#)  
3.302. [sendLevelListPkg1](#)  
3.303. [sendTrainData1](#)  
3.304. [sendVersion1](#)  
3.305. [synchWithDMI1](#)  
3.306. [CaseLinkingInUse1](#)  
3.307. [CaseLinkingNotInUse1](#)  
3.308. [Receive\\_TrackSide\\_Msg](#)  
3.309. [InformationFilter](#)  
3.310. [validateDataDirection](#)  
3.311. [CheckEuroRadioMessage](#)  
3.312. [changeLevelByDiver1](#)  
3.313. [doDriverRequests1](#)  
3.314. [receiveRequestsModesAndLevel1](#)  
3.315. [triggerForMA1](#)  
3.316. [updateDMIStatus1](#)  
3.317. [getTIUStatusFromData](#)  
3.318. [mergeTIU\\_Info](#)  
3.319. [selectTrainData](#)  
3.320. [SoM\\_NTC\\_SN](#)

3.321. [SoM SR FS OS LS SH SN UN](#)  
3.322. [processHandingOver](#)  
3.323. [MoRC Main v21](#)  
3.324. [MoRC Main v22](#)  
3.325. [mobileDataRouter\\_out](#)  
3.326. [InputWrapper](#)  
3.327. [ABrakeFactory](#)  
3.328. [TargetManagement](#)  
3.329. [CalcBrakingCurves](#)  
3.330. [LimitLocations](#)  
3.331. [Commands](#)  
3.332. [AGradient](#)  
3.333. [addGradient1](#)  
3.334. [addGradient2](#)  
3.335. [AddBGToFIFO](#)  
3.336. [AggregatePackets](#)  
3.337. [Build\\_Packets0\\_1](#)  
3.338. [Build\\_SinglePosReport](#)  
3.339. [PosReport\\_Supervision](#)  
3.340. [ReceiveReportParameters](#)  
3.341. [ErrorManager](#)  
3.342. [bothBrakesActive](#)  
3.343. [getTIUStatusFromCommand](#)  
3.344. [handleTraction](#)  
3.345. [mapModeToTractionCutOff](#)  
3.346. [TIU\\_OutputIntegration](#)  
3.347. [calcDistances1](#)  
3.348. [collectDMIPackets1](#)  
3.349. [convert\\_cm\\_s\\_km\\_h1](#)  
3.350. [copyGradientElement1](#)  
3.351. [copySpeedProfileElement1](#)  
3.352. [copyTrackDescription1](#)  
3.353. [cyclicReportToDMI1](#)  
3.354. [doEntryRequest1](#)  
3.355. [doldentifierRequest1](#)  
3.356. [isSendingNeeded1](#)  
3.357. [mapEntryForLevel1](#)  
3.358. [mapMoRCtoRadio\\_CS1](#)  
3.359. [sendBrakesToDMI1](#)  
3.360. [sendDynamic1](#)

3.361. [sendLevelListPkg1](#)  
3.362. [sendTrainData1](#)  
3.363. [sendVersion1](#)  
3.364. [synchWithDMI1](#)  
3.365. [trainDataStorage](#)  
3.366. [sendAcknowledgementRBC](#)  
3.367. [checkRadioMessages](#)  
3.368. [sendValidTrainDataRBC](#)  
3.369. [linkedBG\\_missed](#)  
3.370. [twoConsecutiveLinkedBGs\\_missed](#)  
3.371. [addAnnouncedBGs](#)  
3.372. [calculateBGLocations](#)  
3.373. [calculateTrainpositionAttributes](#)  
3.374. [calculateTrainPositionInfo](#)  
3.375. [delDispensableBGs](#)  
3.376. [msg\\_2\\_passedBG](#)  
3.377. [Input](#)  
3.378. [ManageLevels](#)  
3.379. [CheckLevelAndMode](#)  
3.380. [ManageModes](#)  
3.381. [Output](#)  
3.382. [TrackAtlasETCS](#)  
3.383. [F2.9 MoRC\\_Main](#)  
3.384. [processHandingOver](#)  
3.385. [MoRC\\_Main\\_v21](#)  
3.386. [MoRC\\_Main\\_v22](#)  
3.387. [mobileDataRouter\\_out](#)  
3.388. [InputWrapper](#)  
3.389. [ABrakeFactory](#)  
3.390. [TargetManagement](#)  
3.391. [CalcBrakingCurves](#)  
3.392. [LimitLocations](#)  
3.393. [Commands](#)  
3.394. [AGradient](#)  
3.395. [addGradient1](#)  
3.396. [addGradient2](#)  
3.397. [getTIUStatusFromData](#)  
3.398. [mergeTIU\\_Info](#)  
3.399. [selectTrainData](#)  
3.400. [SoM\\_NTC\\_SN](#)

3.401. [SoM SR FS OS LS SH SN UN](#)  
3.402. [changeLevelByDiver1](#)  
3.403. [doDriverRequests1](#)  
3.404. [receiveRequestsModesAndLevel1](#)  
3.405. [triggerForMA1](#)  
3.406. [updateDMIStatus1](#)  
3.407. [Abstract](#)  
3.408. [CaseLinkingInUse1](#)  
3.409. [CaseLinkingNotInUse1](#)  
3.410. [calcDistances1](#)  
3.411. [collectDMIPackets1](#)  
3.412. [convert\\_cm\\_s\\_km\\_h1](#)  
3.413. [copyGradientElement1](#)  
3.414. [copySpeedProfileElement1](#)  
3.415. [copyTrackDescription1](#)  
3.416. [cyclicReportToDMI1](#)  
3.417. [doEntryRequest1](#)  
3.418. [doIdentifierRequest1](#)  
3.419. [isSendingNeeded1](#)  
3.420. [mapEntryForLevel1](#)  
3.421. [mapMoRCtoRadio\\_CS1](#)  
3.422. [sendBrakesToDMI1](#)  
3.423. [sendDynamic1](#)  
3.424. [sendLevelListPkg1](#)  
3.425. [sendTrainData1](#)  
3.426. [sendVersion1](#)  
3.427. [synchWithDMI1](#)  
3.428. [Abstract](#)  
3.429. [Input](#)  
3.430. [ManageLevels](#)  
3.431. [CheckLevelAndMode](#)  
3.432. [ManageModes](#)  
3.433. [Output](#)  
3.434. [getTIUStatusFromData](#)  
3.435. [mergeTIU\\_Info](#)  
3.436. [selectTrainData](#)  
3.437. [TrackAtlasETCS](#)  
3.438. [SoM NTC SN](#)  
3.439. [SoM SR FS OS LS SH SN UN](#)  
3.440. [bothBrakesActive](#)

3.441. [getTIUStatusFromCommand](#)  
3.442. [handleTraction](#)  
3.443. [mapModeToTractionCutOff](#)  
3.444. [TIU\\_OutputIntegration](#)  
3.445. [InputWrapper](#)  
3.446. [ABrakeFactory](#)  
3.447. [TargetManagement](#)  
3.448. [CalcBrakingCurves](#)  
3.449. [LimitLocations](#)  
3.450. [Commands](#)  
3.451. [AGradient](#)  
3.452. [addGradient1](#)  
3.453. [addGradient2](#)  
3.454. [bothBrakesActive](#)  
3.455. [getTIUStatusFromCommand](#)  
3.456. [handleTraction](#)  
3.457. [mapModeToTractionCutOff](#)  
3.458. [TIU\\_OutputIntegration](#)  
3.459. [CaseLinkingInUse1](#)  
3.460. [CaseLinkingNotInUse1](#)  
3.461. [Receive\\_TrackSide\\_Msg](#)  
3.462. [InformationFilter](#)  
3.463. [validateDataDirection](#)  
3.464. [CheckEuroRadioMessage](#)  
3.465. [trainDataStorage](#)  
3.466. [sendAcknowledgementRBC](#)  
3.467. [checkRadioMessages](#)  
3.468. [sendValidTrainDataRBC](#)  
3.469. [TrackAtlasETCS](#)  
3.470. [linkedBG\\_missed](#)  
3.471. [twoConsecutiveLinkedBGs\\_missed](#)  
3.472. [addAnnouncedBGs](#)  
3.473. [calculateBGLocations](#)  
3.474. [calculateTrainpositionAttributes](#)  
3.475. [calculateTrainPositionInfo](#)  
3.476. [delDispensableBGs](#)  
3.477. [msg\\_2\\_passedBG](#)  
3.478. [Abstract definition](#)  
3.479. [AddBGToFIFO](#)  
3.480. [AggregatePackets](#)

- 3.481. [Build\\_Packets0\\_1](#)
- 3.482. [Build\\_SinglePosReport](#)
- 3.483. [PosReport\\_Supervision](#)
- 3.484. [ReceiveReportParameters](#)
- 3.485. [ErrorManager](#)
- 4. [Data Links](#)
- 5. [System Inputs](#)
- 6. [System Outputs](#)

## 1. Model properties

**Name :** ETCS System

**Version :** 0.1

**Description :**

**Date :** Dec 9, 2015, 1:55 PM

**Available modes :** Standard mode

**Current system mode :** Standard mode

## 2. Sytem events

Name	Description
System Failure	Default system event corresponding to a system failure

## 3. Blocks

### 3.1. CaseLinkingInUse1

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - In Ports

storedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trackSideForCheck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

q\_nvlocacc

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

errorLinkedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.2. CaseLinkingNotInUse1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

trackSideForCheck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

q\_nvlocacc

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



**- Out Ports**

applyServiceBrake

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

badBaliseMessageToDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errorUnlinkedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.3. Receive\_TrackSide\_Msg**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

API\_TrackSide\_Msg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inActualOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outTrackMessage\_for\_check

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.4. InformationFilter**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inSupervisingDevice

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingL1Transition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingL2L3Transition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingAckOfTrainDataFromRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inEmergencyStopAccepted

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inLastAckTextMessageId

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingNTCTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inActiveCab

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainDataValid

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inFilterEvents

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outAcceptedMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outPacketsForML

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.5. validateDataDirection**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

inMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inLRBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPositionedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.6. CheckEuroRadioMessage

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

activateCheck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rtmMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

tNvContact

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastRelevantEventTimestamp

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

connectionStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

radioSequenceError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

tNvContactError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

otherTimingError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

radioMessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

checkedMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.7. changeLevelByDiver1

**Description :**

**Hypothesis :**

**Scope :** Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



### - In Ports

levelData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lasttNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

ML\_levelTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

updatedNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.8. doDriverRequests1

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

inDriverRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outDriverRequestToLevels

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outDriverRequestToModes

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.9. receiveRequestsModesAndLevel1

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

fromDMI\_driverRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDMI\_Icon\_Ack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDMI\_TextMsg\_Ack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outDriverRequestToLevels

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

forModesAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.10. triggerForMA1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

fromDMI\_driverRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outForMA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.11. updateDMIStatus1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

sndValidationRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

oldStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

newStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.12. getTIUStatusFromData**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inTIUActualData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.13. mergeTIU\_Info**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

newInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

storedInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EVC\_trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

updatedInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.14. selectTrainData**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

newTIUTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_train\_commands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EVC\_trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.15. SoM\_NTC\_SN**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



### - In Ports

Status\_Mode\_Change\_from\_Level\_and\_Mode\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

start\_ack\_to\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.16. SoM\_SR\_FS\_OS\_LS\_SH\_SN\_UN

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

Status\_MA\_FS\_SR\_OS\_LS\_SH\_from\_MA\_L2\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Status\_Mode\_Change\_from\_Level\_and\_Mode\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

request\_MA\_FS\_SR\_OS\_LS\_SH\_to\_MA\_L2\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

request\_Mode\_Change\_SB\_to\_FS\_to\_Level\_and\_Mode\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

start\_ack\_to\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.17. processHandingOver

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

sessionManagementAbility

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcStatus\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcStatus\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dataFromTrack\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

sendPositionReport\_2\_handingOverRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendTrainData\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

bufferInformationFromAcceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

supervisingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

useInformationFromAcceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

handingOverMobile\_is\_mobile\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPassesA\_RBC\_RBC\_border\_WithItsFrontEnd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

notReady

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionCmds\_2\_MoRC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionCmds\_2\_MoRC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.18. MoRC\_Main\_v21

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

eventsAndPhases

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msg\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

atPowerUpRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

newRadioNetworkIDFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

configData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



**- Out Ports**

sendAPositionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rejectOrderToContactRBC\_or\_RIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

informDriverNoCompatibleVersionSupported

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

memorizeTheLastRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

notReady

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msgToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

safeRadioIndication

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastReceivedRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.19. MoRC\_Main\_v22

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

eventsAndPhases

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msg\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

atPowerUpRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

newRadioNetworkIDFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

configData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

sendAPositionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rejectOrderToContactRBC\_or\_RIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

informDriverNoCompatibleVersionSupported

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

memorizeTheLastRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

notReady

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msgToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

safeRadioIndication

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastReceivedRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.20. mobileDataRouter\_out

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

## - In Ports

useInformationFromAcceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

handingOverRBC\_is\_RBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_handingOverRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_RBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_RBC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendTrainData\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionManagementAbility

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dataToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

positionReport\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcMsgToRBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcMsgToRBC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



**- Out Ports**

data\_2\_RBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

data\_2\_RBC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.21. InputWrapper**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

TrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dataFromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

mrsp\_update\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ma\_update\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mrsp\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ma\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

gp\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

gp\_update\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.22. ABrakeFactory

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

T\_b

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aBrakeSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aBrakeService

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.23. TargetManagement**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

MRSP\_updated

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA\_updated

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MRSP

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.24. CalcBrakingCurves

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

TrainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

A\_Expected

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

A\_Safe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

curveCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.25. LimitLocations

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

MRSP\_Profile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

curveCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

T\_b



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData\_int

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

FLOlisSBI1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

locations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MostRestrictiveDisplayedTarget

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

speeds

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.26. Commands

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

floilsSB1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

allTargets

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

speeds

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

locations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mrdt

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MLrequestEB

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MLrequestSB

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TrainData\_int

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

targetSpeedReached

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

eoOverpassed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sdmCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sdmToDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

brakeCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.27. AGradient

**Description :**

**Hypothesis :**

**Scope :** Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

TrainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

GradientProfile\_updated

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

GradientProfile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

A\_gradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.28. addGradient1**

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

aBrakeSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aGradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

aSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.29. addGradient2

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

aBrakeSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aGradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

aSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.30. AddBGToFIFO**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



### - In Ports

reportsSent

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

out\_reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.31. AggregatePackets

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inPacket0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPacket1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPacket4

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPacket5

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outPackets

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.32. Build\_Packets0\_1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

modeLevelStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPos

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

train2trackStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

prvDirTrain

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.33. Build\_SinglePosReport

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

errorMsg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

posRepHeader

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet4

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet5

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.34. PosReport\_Supervision**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

systemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rbcComm

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

modeLevelStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posRepParam

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

train2trackStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

present

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trackInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPos

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

prvDirTrain

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



**- Out Ports**

trigger

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

out\_reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posRep

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.35. ReceiveReportParameters**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

out\_reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

present

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posRep

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posRepParam

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.36. ErrorManager**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

BG\_LinkingConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

LinkedBG\_MessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

UnlinkedBG\_MessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RadioMessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RadioSequenceError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RadioSafeRadioConnectionError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SafetyCriticalFailure

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### DoubleLinkingError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### DoubleRepositioningError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

#### errorVector

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.37. bothBrakesActive

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

speedSupbrakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelBrakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

brakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.38. getTIUStatusFromCommand

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

in\_IsolationStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_brake\_command

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.39. handleTraction

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

in\_train\_commands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outTrainCommands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.40. mapModeToTractionCutOff**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inModeLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

tractionCutOff

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



3.41. TIU\_OutputIntegration

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

in\_IsolationStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SpeedSup\_brakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_brake\_inhibition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_train\_commands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_change\_traction\_system

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_passenger\_door\_control\_info

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_change\_of\_allowed\_current\_consumption

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

outTIU\_to\_API

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outCommandStatusforEVC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.42. calcDistances1

**Description :**

**Hypothesis :**

**Scope :** Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

## - In Ports

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outLocationKP\_Balise\_Track

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ouDistanceKP\_Balise

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outDistance\_ToTSA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.43. collectDMIPackets1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

## - In Ports

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_dynamic

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_menuRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_evc\_coded\_train\_data

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_text\_message

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trackDescription

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_systemVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_displayControl

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_EVC\_levelData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_EVC\_radioNet

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_driverIdentifier

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trainRunningNumber

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_adhesionFactor

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_iconRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

systemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

to\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.44. convert\_cm\_s\_km\_h1

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

cm\_s

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

km\_h

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.45. copyGradientElement1

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



- In Ports

dmiUpdateLevelsDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_fromBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inCurrentDMIStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inBrakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSpeedSupervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMovementAuthority

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inRadioConnectionStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDataFromEVC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_evc\_coded\_train\_data

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trackDescription

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_displayControl

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_EVC\_levelList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_EVC\_radioNet

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_driverIdentifier

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trainRunningNumber

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_adhesionFactor

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_fromModesAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

index

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

to\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

continue

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

toDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.46. copySpeedProfileElement1

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

index

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

fromDMI\_TrainDataAck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

continue

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

toDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.47. copyTrackDescription1

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

fromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

toDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.48. cyclicReportToDMI1

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inCurrentDMIStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSpeedSupervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNationalValues



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMovementAuthority

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMoRC\_status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

packetDynamic

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.49. doEntryRequest1

**Description :**

**Hypothesis :**

**Scope :** Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

sendTrainDataToDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

new\_menuRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

new\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outLevelsNeeded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.50. doldentifierRequest1

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ownVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.51. isSendingNeeded1

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inCurrentDMIStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

sendingNeeded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.52. mapEntryForLevel1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

new\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.53. mapMoRCtoRadio\_CS1

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - In Ports

inMoRC\_status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

outBMI\_CS

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.54. sendBrakesToDMI1

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

brakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

dmi\_iconRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.55. sendDynamic1

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSpeedSupervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeLevel\_Ack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMoRC\_status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMovementAuthority

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

packetDynamic

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.56. sendLevelListPkg1

**Description :**

**Hypothesis :**

**Scope :** Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



**- In Ports**

UpdateLevelsRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

levelDataPkg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.57. sendTrainData1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDataFromEVC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

trainData\_ForDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.58. sendVersion1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

ownVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmiStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

VersionPkg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.59. synchWithDMI1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

outputStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

systemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

updatedOutputStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

send\_dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.60. trainDataStorage**

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

eventsForTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDatafromTIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDatafromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDataAckfromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

updatedStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

actualTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.61. sendAcknowledgementRBC**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EVC\_t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

nidEngine

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RBC\_timeStamp

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



**- Out Ports**

updatedStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outMessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.62. checkRadioMessages**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trackMessages

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

ackReceived

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ackRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.63. sendValidTrainDataRBC**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

evc\_t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

nidEngine

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

p0\_positionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

p1\_positionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

updatedStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outMessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.64. linkedBG\_missed

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

enable

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

position

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

missed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

indexOfBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.65. twoConsecutiveLinkedBGs\_missed**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msgFromTrack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

missed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

missedLinkedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

secondConsecutiveBG\_missed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.66. addAnnouncedBGs**

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

overrun

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.67. calculateBGLocations



Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

BGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errors

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedPositionedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.68. calculateTrainpositionAttributes

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

trainPositionInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.69. calculateTrainPositionInfo**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

recalculateBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

positionCalculationNotConsistent

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPositionInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.70. delDispensableBGs**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

deleteBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

BGs\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.71. msg\_2\_passedBG**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

msgFromTrack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

BG\_passed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

onlyBGsAnnouncedViaRadio

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.72. Input

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Data\_From\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_Messages

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_Packets

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_STM

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Localisation

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Speed\_and\_Supervision



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_F2\_Functions

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Cab\_In

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

driver\_level\_transition\_In

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ERTMS\_capabilities\_In

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

startOfMissionEnded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_MASSPGradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

train\_standstill

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelAck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outStartOfMissionEnded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

driver\_level\_transition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ERTMS\_capabilities

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_to\_Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Cab

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_DMI\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_F2\_Functions\_to\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Localisation\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Speed\_and\_Supervision\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_STM\_to\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_TIU\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.73. ManageLevels

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

trainStandstill

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelAck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

driverLevelTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ERTMScapabilities

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

DataFromTrackToLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MemorizedLevelIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

TripTrainRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

needsAckFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

serviceBrakeRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

nextLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

announced\_level\_transition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

positionReportNeeded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelsNew

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

isAvailableForUse

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

announcedLevelTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

connectionToRBCRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.74. CheckLevelAndMode

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



**- In Ports**

Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

Level\_Mode\_Compatible

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.75. ManageModes**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Current\_Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Cab

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_F2\_Functions

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Localisation

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Speed\_and\_Supervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_STM

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TripModeFromLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

EB\_Requested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Service\_Brake\_Command

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentMode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_BG\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.76. Output**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

needsAckFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

service\_brake\_from\_level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

LevelsTransitionPositionPassed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EB\_Requested\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Service\_Brake\_Command\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Level\_Mode-Compatible

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

next\_level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TripTrain

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

previous\_level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MemorizedLevelIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

announce\_driver\_selection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentMode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_DMI\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_BG\_Management\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

Service\_Brake\_Command

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EB\_Requested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

transitionPositionPassed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Compatible\_Mode\_And\_Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_BG\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.77. TrackAtlasETCS

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



- In Ports

TrainData\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDriverToMA\_R

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MessageIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ModeAndLevel\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TrainPositionIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

train\_length

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

preindicationLocation

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

P203V1\_onboard

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

PermanentDataP003

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

bus\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

To\_ModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

to\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

to\_Supervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA\_onboard\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ces\_accepted

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ces\_revoked

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trip\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NV\_raw\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA\_request\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

message147

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SSP\_available

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

bus\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.78. F2.9 MoRC\_Main

**Description :**

**Hypothesis :**

**Scope :** Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

obuEventsAndPhases

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

radioNetworkIDs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

statusOfMobile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

connectionStatusTimerInterval

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMessage\_new

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train\_global

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msgBus\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

nid\_engine

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

onboardPhoneNumbers

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

onboardPhoneNumbers\_b



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

m\_version

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

ignoreMessagesFromRBC\_except\_m39\_AckOfTerminationOfCommunicationSession

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendAPositionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

cmdsToMobile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

memorizeTheLastRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

orderTheRegistrationOfItsConnectedMobiles

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rejectOrderToContactRBC\_or\_RIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

InformTheDriverThatNoConnectionWasSetup

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

safeRadioConnectionStatus\_toDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileSWStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

requestTheSetupOfASafeRadioConnection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

requestReleaseOfSafeRadioConnectionWithTrackside

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionSuccessfullyEstablished

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ready

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MessageToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msgBus\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.79. F1 Receive Information from Trackside

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - In Ports

RBCBTMIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

TracksideOut

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.80. Driver**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Input1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

Output1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.81. Configuration1

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- Out Ports

Output1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.82. F3 Measure Train Movement

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

OdometryIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

OdometryOut

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.83. F4 Radio Communication Controller

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

RadioIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

RadioOut

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.84. F5 Manage JRU

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### 3.85. F6 DMI Controller

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

DMIIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

DMIOut

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.86. F7 TIU Controller**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

TIUIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

TIUOut

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.87. F8 Persistent Data**



Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

PersistentDataIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

PersistentDataOut

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.88. CaseLinkingInUse1

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

storedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trackSideForCheck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

q\_nvlocacc

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

passedBG\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errorLinkedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.89. CaseLinkingNotInUse1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

trackSideForCheck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

q\_nvlocacc

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

applyServiceBrake

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

badBaliseMessageToDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errorUnlinkedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.90. Receive\_TrackSide\_Msg

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

API\_TrackSide\_Msg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inActualOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

outTrackMessage\_for\_check

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.91. InformationFilter

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSupervisingDevice

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingL1Transition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingL2L3Transition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingAckOfTrainDataFromRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inEmergencyStopAccepted

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inLastAckTextMessageld

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingNTCTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inActiveCab

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainDataValid

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inFilterEvents

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outAcceptedMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outPacketsForML

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.92. validateDataDirection**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

inMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inLRBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPositionedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.93. CheckEuroRadioMessage

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



- In Ports

rtmMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

tNvContact

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastRelevantEventTimestamp

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

connectionStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

activateCheck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

checkedMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

radioSequenceError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

tNvContactError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

otherTimingError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

radioMessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.94. changeLevelByDiver1

Description :

Hypothesis :

Scope : Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

levelData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lasttNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

ML\_levelTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

updatedNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.95. doDriverRequests1

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

inDriverRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outDriverRequestToModes

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outDriverRequestToLevels

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.96. receiveRequestsModesAndLevel1

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

fromDMI\_driverRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDMI\_Icon\_Ack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDMI\_TextMsg\_Ack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

forModesAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outDriverRequestToLevels

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.97. triggerForMA1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

fromDMI\_driverRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outForMA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.98. updateDMIStatus1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

oldStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sndValidationRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

newStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.99. getTIUStatusFromData**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inTIUActualData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.100. mergeTIU\_Info**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



**- In Ports**

newInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

storedInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EVC\_trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

updatedInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.101. selectTrainData**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

newTIUTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EVC\_trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.102. SoM\_NTC\_SN**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Status\_Mode\_Change\_from\_Level\_and\_Mode\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

start\_ack\_to\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.103. SoM\_SR\_FS\_OS\_LS\_SH\_SN\_UN**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Status\_MA\_FS\_SR\_OS\_LS\_SH\_from\_MA\_L2\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Status\_Mode\_Change\_from\_Level\_and\_Mode\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

request\_MA\_FS\_SR\_OS\_LS\_SH\_to\_MA\_L2\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

request\_Mode\_Change\_SB\_to\_FS\_to\_Level\_and\_Mode\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

start\_ack\_to\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.104. processHandingOver

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcStatus\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcStatus\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dataFromTrack\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionManagementAbility

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

sessionCmds\_2\_MoRC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionCmds\_2\_MoRC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_handingOverRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendTrainData\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

bufferInformationFromAcceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

supervisingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

useInformationFromAcceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

handingOverMobile\_is\_mobile\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPassesA\_RBC\_RBC\_border\_WithItsFrontEnd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

notReady

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.105. MoRC\_Main\_v21

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



- In Ports

msg\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

eventsAndPhases

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

atPowerUpRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

newRadioNetworkIDFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

configData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

msgToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendAPositionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rejectOrderToContactRBC\_or\_RIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

infomDriverNoCompatibleVersionSupported

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

safeRadiolIndication

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

memorizeTheLastRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastReceivedRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

notReady

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.106. MoRC\_Main\_v22

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

msg\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

eventsAndPhases

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

atPowerUpRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

newRadioNetworkIDFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

configData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

msgToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendAPositionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rejectOrderToContactRBC\_or\_RIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

infomDriverNoCompatibleVersionSupported

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

safeRadioIndication

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

memorizeTheLastRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastReceivedRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

notReady

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.107. mobileDataRouter\_out

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



**- In Ports**

dataToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

positionReport\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcMsgToRBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcMsgToRBC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

useInformationFromAcceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

handingOverRBC\_is\_RBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_handingOverRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_RBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_RBC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendTrainData\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionManagementAbility

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

data\_2\_RBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

data\_2\_RBC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.108. InputWrapper**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

TrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dataFromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

mrsp\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mrsp\_update\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ma\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ma\_update\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

gp\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

gp\_update\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.109. ABrakeFactory

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

T\_b

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aBrakeSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aBrakeService

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.110. TargetManagement

Description :

Hypothesis :

Scope : Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

MRSP

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MRSP\_updated

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA\_updated

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.111. CalcBrakingCurves**

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

TrainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

A\_Safe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

A\_Expected

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

curveCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.112. LimitLocations



Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

MRSP\_Profile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

curveCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

T\_b

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData\_int

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

speeds

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

locations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MostRestrictiveDisplayedTarget

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

FLOlisSBI1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.113. Commands

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

allTargets

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

speeds

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

locations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mrdt

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

floilsSB1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MLrequestSB

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MLrequestEB

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TrainData\_int

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

sdmToDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sdmCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetSpeedReached

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

eoOverpassed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

brakeCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.114. AGradient

Description :

Hypothesis :

Scope : Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

TrainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

GradientProfile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

GradientProfile\_updated

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

A\_gradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.115. addGradient1



Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

aBrakeSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aGradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

aSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.116. addGradient2

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

aBrakeSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aGradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

aSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.117. AddBGToFIFO

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reportsSent

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

out\_reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.118. AggregatePackets

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inPacket0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPacket1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPacket4

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPacket5

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outPackets

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.119. Build\_Packets0\_1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

modeLevelStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPos

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

train2trackStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

prvDirTrain

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.120. Build\_SinglePosReport

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errorMsg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

posRepHeader

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet4

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet5

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



3.121. PosReport\_Supervision

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

present

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posRepParam

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

systemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rbcComm

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trackInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

train2trackStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPos

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

modeLevelStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

prvDirTrain

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

trigger

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.122. ReceiveReportParameters**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

out\_reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

present

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posRepParam

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.123. ErrorManager**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

BG\_LinkingConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

LinkedBG\_MessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

UnlinkedBG\_MessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RadioMessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RadioSequenceError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RadioSafeRadioConnectionError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SafetyCriticalFailure

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### DoubleLinkingError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### DoubleRepositioningError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

#### errorVector

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.124. bothBrakesActive

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

speedSupbrakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelBrakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

brakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.125. getTIUStatusFromCommand

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



### - In Ports

in\_IsolationStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_brake\_command

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.126. handleTraction

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

in\_train\_commands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outTrainCommands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.127. mapModeToTractionCutOff

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

inModeLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

tractionCutOff

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.128. TIU\_OutputIntegration**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

in\_IsolationStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SpeedSup\_brakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_brake\_inhibition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_train\_commands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_change\_traction\_system

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_passenger\_door\_control\_info

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_change\_of\_allowed\_current\_consumption

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outTIU\_to\_API

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outCommandStatusforEVC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.129. calcDistances1

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outLocationKP\_Balise\_Track

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ouDistanceKP\_Balise

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outDistance\_ToTSA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.130. collectDMIPackets1

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

## - In Ports

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_dynamic

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_menuRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_evc\_coded\_train\_data

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_text\_message

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trackDescription

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_systemVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_displayControl

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_EVC\_levelData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_EVC\_radioNet

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_driverIdentifier

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trainRunningNumber



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_adhesionFactor

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_iconRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

systemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

to\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.131. convert\_cm\_s\_km\_h1

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

cm\_s

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

km\_h

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.132. copyGradientElement1

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

index

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

continue

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

toDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.133. copySpeedProfileElement1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

index

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

continue

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

toDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.134. copyTrackDescription1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

fromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

toDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.135. cyclicReportToDMI1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

inCurrentDMIStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSpeedSupervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMovementAuthority

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMoRC\_status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

packetDynamic

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.136. doEntryRequest1

**Description :**

**Hypothesis :**

**Scope :** Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

new\_menuRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

new\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendTrainDataToDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outLevelsNeeded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.137. dolidentifierRequest1



Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ownVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.138. isSendingNeeded1

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inCurrentDMIStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

sendingNeeded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.139. mapEntryForLevel1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

new\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.140. mapMoRCtoRadio\_CS1

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - In Ports

inMoRC\_status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

outBMI\_CS

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.141. sendBrakesToDMI1

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

brakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

dmi\_iconRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.142. sendDynamic1

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSpeedSupervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMoRC\_status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMovementAuthority

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

packetDynamic

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.143. sendLevelListPkg1

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

levelList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

UpdateLevelsRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

levelDataPkg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.144. sendTrainData1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDataFromEVC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

trainData\_ForDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.145. sendVersion1

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



### - In Ports

ownVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmiStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

VersionPkg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.146. synchWithDMI1

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outputStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

systemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

send\_dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

updatedOutputStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.147. trainDataStorage

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDatafromTIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDatafromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDataAckfromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

eventsForTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

actualTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

updatedStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.148. sendAcknowledgementRBC**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

EVC\_t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

nidEngine

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RBC\_timeStamp

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

updatedStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outMessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.149. checkRadioMessages**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

trackMessages

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

ackReceived

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ackRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.150. sendValidTrainDataRBC**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



- In Ports

trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

evc\_t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

nidEngine

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

p0\_positionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

p1\_positionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outMessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

updatedAtStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.151. linkedBG\_missed

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

position

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

enable

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

missed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

indexOfBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.152. twoConsecutiveLinkedBGs\_missed**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

missed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

missedLinkedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

secondConsecutiveBG\_missed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.153. addAnnouncedBGs

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

BGs\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

overrun

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.154. calculateBGLocations**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

BGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errors

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedPositionedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.155. calculateTrainpositionAttributes

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



**- In Ports**

trainPositionInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.156. calculateTrainPositionInfo**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

currentOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

recalculateBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

trainPositionInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

positionCalculationNotConsistent

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.157. delDispensableBGs**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

BGs\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

deleteBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

BGs\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.158. msg\_2\_passedBG**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

msgFromTrack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BG\_passed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

onlyBGsAnnouncedViaRadio

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.159. Input

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Data\_From\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_Messages

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_Packets

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_STM

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Localisation

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Speed\_and\_Supervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_F2\_Functions

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Cab\_In

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

driver\_level\_transition\_In

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ERTMS\_capabilities\_In

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

startOfMissionEnded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_MASSPGradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

train\_standstill

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

driver\_level\_transition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelAck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ERTMS\_capabilities

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outStartOfMissionEnded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_to\_Level



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Cab

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_DMI\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_F2\_Functions\_to\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Localisation\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Speed\_and\_Supervision\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_STM\_to\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_TIU\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.160. ManageLevels

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

trainStandstill

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

driverLevelTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelAck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ERTMScapabilities

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

DataFromTrackToLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MemorizedLevelIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

nextLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TripTrainRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

needsAckFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

announcedLevelTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

serviceBrakeRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

connectionToRBCRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

positionReportNeeded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelsNew

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

isAvailableForUse

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.161. CheckLevelAndMode

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

Level\_Mode-Compatible

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.162. ManageModes

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Current\_Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Cab

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_F2\_Functions

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Localisation

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Speed\_and\_Supervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_STM



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TripModeFromLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

currentMode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EB\_Requested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Service\_Brake\_Command

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_BG\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.163. Output

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

next\_level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TripTrain

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

previous\_level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

needsAckFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

announce\_driver\_selection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

service\_brake\_from\_level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

LevelsTransitionPositionPassed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentMode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EB\_Requested\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Service\_Brake\_Command\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_DMI\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_BG\_Management\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Level\_Mode\_Compatible

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

Compatible\_Mode\_And\_Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_BG\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Service\_Brake\_Command

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EB\_Requested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

transitionPositionPassed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.164. TrackAtlasETCS

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

MessageIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ModeAndLevel\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TrainData\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TrainPositionIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

train\_length

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

preindicationLocation

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDriverToMA\_R

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

bus\_in



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

P203V1\_onboard

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

PermanentDataP003

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

SSP\_available

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NV\_raw\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

To\_ModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

to\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

to\_Supervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA\_onboard\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA\_request\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

bus\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

message147

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ces\_accepted

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ces\_revoked

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trip\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.165. F2.9 MoRC\_Main

**Description :**

**Hypothesis :**

**Scope :** Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

currentTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

obuEventsAndPhases

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

radioNetworkIDs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

statusOfMobile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMessage\_new

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train\_global

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msgBus\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

connectionStatusTimerInterval

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

nid\_engine

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

onboardPhoneNumbers

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

onboardPhoneNumbers\_b

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

m\_version

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

ignoreMessagesFromRBC\_except\_m39\_AckOfTerminationOfCommunicationSession

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendAPositionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

cmdsToMobile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

memorizeTheLastRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

orderTheRegistrationOfItsConnectedMobiles

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rejectOrderToContactRBC\_or\_RIU



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

InformTheDriverThatNoConnectionWasSetup

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

safeRadioConnectionStatus\_toDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileSWStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

requestTheSetupOfASafeRadioConnection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

requestReleaseOfSafeRadioConnectionWithTrackside

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionSuccessfullyEstablished

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MessageToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msgBus\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ready

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.166. F1 Receive Information from Trackside

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - In Ports

RBCBTMIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

TracksideOut

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.167. Driver**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Input1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

Output1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.168. Configuration1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - Out Ports

Output1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.169. F3 Measure Train Movement

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - In Ports

OdometryIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

OdometryOut

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.170. F4 Radio Communication Controller

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

RadioIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

RadioOut

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.171. F5 Manage JRU**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**3.172. F6 DMI Controller**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

DMIIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

DMIOut

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.173. F7 TIU Controller**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

TIUIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

TIUOut

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.174. F8 Persistent Data**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

PersistentDataIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

PersistentDataOut

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.175. Driver**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Input1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

Output1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.176. Configuration**

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- Out Ports

Output1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.177. ERTMS Track

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

Input1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Input2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



#### - Out Ports

Output1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.178. Eurobalise

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - In Ports

Input1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

Output1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Output2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.179. Interlocking

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - In Ports

Input1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Input2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

Output1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Output2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.180. RBC

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Input1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Input2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

Output1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Output2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Output3

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.181. Train**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Input1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

Output1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.182. Train Movement**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- Out Ports**

Output1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.183. Input**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Data\_From\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_Messages

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_Packets

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_STM

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Localisation

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Speed\_and\_Supervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_F2\_Functions

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Cab\_In

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

driver\_level\_transition\_In

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ERTMS\_capabilities\_In

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

startOfMissionEnded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_MASSPGradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

train\_standstill

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelAck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outStartOfMissionEnded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

driver\_level\_transition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ERTMS\_capabilities

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_to\_Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Cab

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_DMI\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_F2\_Functions\_to\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Localisation\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Speed\_and\_Supervision\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_STM\_to\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_TIU\_To\_Mode



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.184. ManageLevels

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

trainStandstill

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelAck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

driverLevelTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ERTMScapabilities

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

DataFromTrackToLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MemorizedLevelIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

TripTrainRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

needsAckFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

serviceBrakeRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

nextLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

announced\_level\_transition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

positionReportNeeded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelsNew

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

isAvailableForUse

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

announcedLevelTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

connectionToRBCRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.185. CheckLevelAndMode

**Description :**

**Hypothesis :**

**Scope :** Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

Level\_Mode\_Compatible

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.186. ManageModes**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Current\_Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Cab

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_F2\_Functions

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Localisation

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Speed\_and\_Supervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_STM

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TripModeFromLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



### - Out Ports

EB\_Requested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Service\_Brake\_Command

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentMode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_BG\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.187. Output

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

needsAckFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

service\_brake\_from\_level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

LevelsTransitionPositionPassed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EB\_Requested\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Service\_Brake\_Command\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Level\_Mode-Compatible

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

next\_level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TripTrain

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

previous\_level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MemorizedLevelIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

announce\_driver\_selection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentMode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_DMI\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_BG\_Management\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

Service\_Brake\_Command

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EB\_Requested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

transitionPositionPassed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Compatible\_Mode\_And\_Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_BG\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.188. CaseLinkingInUse1

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

storedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trackSideForCheck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

q\_nvlocacc

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

passedBG\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errorLinkedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.189. CaseLinkingNotInUse1

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

trackSideForCheck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

q\_nvlocacc

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

applyServiceBrake

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

badBaliseMessageToDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errorUnlinkedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.190. Receive\_TrackSide\_Msg

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

API\_TrackSide\_Msg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inActualOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outTrackMessage\_for\_check

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.191. InformationFilter

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



**- In Ports**

inMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSupervisingDevice

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingL1Transition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingL2L3Transition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingAckOfTrainDataFromRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inEmergencyStopAccepted

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inLastAckTextMessageld

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingNTCTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inActiveCab

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainDataValid

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inFilterEvents

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outAcceptedMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outPacketsForML

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.192. validateDataDirection

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

inMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inLRBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPositionedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.193. CheckEuroRadioMessage

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

rtmMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

tNvContact

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastRelevantEventTimestamp

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

connectionStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

activateCheck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

checkedMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

radioSequenceError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

tNvContactError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

otherTimingError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

radioMessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.194. changeLevelByDiver1

Description :

Hypothesis :

Scope : Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

levelData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lasttNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

ML\_levelTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

updatedNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.195. doDriverRequests1

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

inDriverRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outDriverRequestToModes

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outDriverRequestToLevels

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.196. receiveRequestsModesAndLevel1

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



**- In Ports**

fromDMI\_driverRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDMI\_Icon\_Ack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDMI\_TextMsg\_Ack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

forModesAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outDriverRequestToLevels

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.197. triggerForMA1

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

fromDMI\_driverRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outForMA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.198. updateDMIStatus1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

oldStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sndValidationRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

newStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.199. getTIUStatusFromData

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - In Ports

inTIUActualData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

outStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.200. mergeTIU\_Info

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

newInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

storedInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EVC\_trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

updatedInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.201. selectTrainData

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

newTIUTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EVC\_trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

outTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.202. SoM\_NTC\_SN

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Status\_Mode\_Change\_from\_Level\_and\_Mode\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

start\_ack\_to\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.203. SoM\_SR\_FS\_OS\_LS\_SH\_SN\_UN**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Status\_MA\_FS\_SR\_OS\_LS\_SH\_from\_MA\_L2\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Status\_Mode\_Change\_from\_Level\_and\_Mode\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

request\_MA\_FS\_SR\_OS\_LS\_SH\_to\_MA\_L2\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

request\_Mode\_Change\_SB\_to\_FS\_to\_Level\_and\_Mode\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

start\_ack\_to\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.204. processHandingOver

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



- In Ports

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcStatus\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcStatus\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dataFromTrack\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionManagementAbility

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

sessionCmds\_2\_MoRC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionCmds\_2\_MoRC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_handingOverRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendTrainData\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

bufferInformationFromAcceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

supervisingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

useInformationFromAcceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

handingOverMobile\_is\_mobile\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPassesA\_RBC\_RBC\_border\_WithItsFrontEnd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

notReady

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.205. MoRC\_Main\_v21

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

msg\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

eventsAndPhases

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

atPowerUpRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

newRadioNetworkIDFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

configData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

msgToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendAPositionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rejectOrderToContactRBC\_or\_RIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

infomDriverNoCompatibleVersionSupported

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

safeRadioIndication

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

memorizeTheLastRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastReceivedRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

notReady

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.206. MoRC\_Main\_v22

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



- In Ports

msg\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

eventsAndPhases

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

atPowerUpRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

newRadioNetworkIDFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

configData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

msgToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendAPositionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rejectOrderToContactRBC\_or\_RIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

infomDriverNoCompatibleVersionSupported

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

safeRadioIndication

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

memorizeTheLastRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastReceivedRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

notReady

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.207. mobileDataRouter\_out

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

dataToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

positionReport\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcMsgToRBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcMsgToRBC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

useInformationFromAcceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

handingOverRBC\_is\_RBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_handingOverRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_RBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_RBC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendTrainData\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionManagementAbility

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

data\_2\_RBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

data\_2\_RBC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.208. InputWrapper**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

TrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dataFromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

mrsp\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mrsp\_update\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ma\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ma\_update\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

gp\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

gp\_update\_out



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.209. ABrakeFactory

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

T\_b

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aBrakeSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aBrakeService

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.210. TargetManagement**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

MRSP

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MRSP\_updated

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA\_updated

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.211. CalcBrakingCurves**

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

TrainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

A\_Safe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

A\_Expected

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

curveCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.212. LimitLocations

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

MRSP\_Profile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

curveCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

T\_b

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData\_int

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

speeds

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

locations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MostRestrictiveDisplayedTarget

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

FLOlisSBI1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.213. Commands

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



- In Ports

allTargets

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

speeds

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

locations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mrdt

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

floilsSB1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MLrequestSB

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MLrequestEB

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TrainData\_int

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

sdmToDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sdmCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetSpeedReached

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

eoOverpassed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

brakeCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.214. AGradient

Description :

Hypothesis :

Scope : Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

TrainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

GradientProfile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

GradientProfile\_updated

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

A\_gradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.215. addGradient1**

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

aBrakeSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aGradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

aSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.216. addGradient2

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

aBrakeSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aGradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

aSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.217. AddBGToFIFO**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reportsSent

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

out\_reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.218. AggregatePackets

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inPacket0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPacket1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPacket4

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPacket5

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outPackets

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.219. Build\_Packets0\_1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



- In Ports

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

modeLevelStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPos

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

train2trackStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

prvDirTrain

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.220. Build\_SinglePosReport

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errorMsg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

posRepHeader

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet4

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet5

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.221. PosReport\_Supervision**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

present

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posRepParam

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

systemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rbcComm

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trackInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

train2trackStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPos

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

modeLevelStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

prvDirTrain

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

trigger

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.222. ReceiveReportParameters**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

out\_reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

present

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posRepParam

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.223. ErrorManager

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



**- In Ports**

BG\_LinkingConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

LinkedBG\_MessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

UnlinkedBG\_MessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RadioMessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RadioSequenceError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RadioSafeRadioConnectionError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SafetyCriticalFailure

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### DoubleLinkingError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### DoubleRepositioningError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

#### errorVector

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.224. bothBrakesActive

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

speedSupbrakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelBrakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

brakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.225. getTIUStatusFromCommand

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

in\_IsolationStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_brake\_command

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.226. handleTraction

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

in\_train\_commands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outTrainCommands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.227. mapModeToTractionCutOff

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

inModeLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

tractionCutOff

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.228. TIU\_OutputIntegration**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

in\_IsolationStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SpeedSup\_brakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_brake\_inhibition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_train\_commands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_change\_traction\_system

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_passenger\_door\_control\_info

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_change\_of\_allowed\_current\_consumption

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outTIU\_to\_API

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outCommandStatusforEVC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.229. calcDistances1

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



## - Out Ports

outLocationKP\_Balise\_Track

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ouDistanceKP\_Balise

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outDistance\_ToTSA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.230. collectDMIPackets1

**Description :**

**Hypothesis :**

**Scope :** Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

## - In Ports

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_dynamic

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_menuRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_evc\_coded\_train\_data

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_text\_message

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trackDescription

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_systemVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_displayControl

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_EVC\_levelData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_EVC\_radioNet

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_driverIdentifier

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trainRunningNumber

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_adhesionFactor

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_iconRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

systemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

to\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.231. convert\_cm\_s\_km\_h1

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

cm\_s

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

km\_h

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.232. copyGradientElement1

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

index

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

continue

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

toDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.233. copySpeedProfileElement1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

index

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

continue

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

toDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.234. copyTrackDescription1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

fromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

toDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.235. cyclicReportToDMI1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



- In Ports

inCurrentDMIStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSpeedSupervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMovementAuthority

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMoRC\_status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

packetDynamic

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.236. doEntryRequest1

**Description :**

**Hypothesis :**

**Scope :** Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

new\_menuRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

new\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendTrainDataToDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outLevelsNeeded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.237. doidentifierRequest1

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ownVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.238. isSendingNeeded1

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inCurrentDMIStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

sendingNeeded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.239. mapEntryForLevel1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

new\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.240. mapMoRCtoRadio\_CS1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inMoRC\_status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outBMI\_CS

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.241. sendBrakesToDMI1

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

brakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

dmi\_iconRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.242. sendDynamic1

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSpeedSupervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMoRC\_status



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMovementAuthority

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

packetDynamic

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.243. sendLevelListPkg1

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

levelList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

UpdateLevelsRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

levelDataPkg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.244. sendTrainData1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDataFromEVC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

trainData\_ForDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.245. sendVersion1

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

ownVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmiStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

VersionPkg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.246. synchWithDMI1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

## - In Ports

dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outputStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

systemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

send\_dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

updatedOutputStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.247. trainDataStorage

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDatafromTIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDatafromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDataAckfromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

eventsForTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

actualTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

updatedStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.248. sendAcknowledgementRBC**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



- In Ports

EVC\_t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

nidEngine

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RBC\_timeStamp

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

updatedStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outMessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.249. checkRadioMessages**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

trackMessages

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

ackReceived

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ackRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.250. sendValidTrainDataRBC**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

evc\_t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

nidEngine

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

p0\_positionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

p1\_positionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

outMessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

updatedAtStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.251. linkedBG\_missed

Description :

Hypothesis :

Scope : Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

position

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

enable

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

missed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

indexOfBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.252. twoConsecutiveLinkedBGs\_missed**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

missed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

missedLinkedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

secondConsecutiveBG\_missed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.253. addAnnouncedBGs**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



**- In Ports**

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

BGs\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

overrun

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.254. calculateBGLocations**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

BGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errors

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedPositionedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.255. calculateTrainpositionAttributes

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

trainPositionInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.256. calculateTrainPositionInfo

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

currentOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

recalculateBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

trainPositionInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

positionCalculationNotConsistent

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.257. delIDispensableBGs**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

BGs\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

deleteBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

BGs\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.258. msg\_2\_passedBG**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

msgFromTrack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BG\_passed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

onlyBGsAnnouncedViaRadio

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.259. Input

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



**- In Ports**

Data\_From\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_Messages

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_Packets

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_STM

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Localisation

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Speed\_and\_Supervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_F2\_Functions

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Cab\_In

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

driver\_level\_transition\_In

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ERTMS\_capabilities\_In

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

startOfMissionEnded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_MASSPGradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

train\_standstill

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

driver\_level\_transition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelAck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ERTMS\_capabilities

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outStartOfMissionEnded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_to\_Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Cab

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_DMI\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_F2\_Functions\_to\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Localisation\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Speed\_and\_Supervision\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_STM\_to\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_TIU\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.260. ManageLevels

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

trainStandstill

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

driverLevelTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelAck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ERTMScapabilities

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

DataFromTrackToLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MemorizedLevelIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

nextLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TripTrainRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

needsAckFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

announcedLevelTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

serviceBrakeRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

connectionToRBCRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

positionReportNeeded



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelsNew

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

isAvailableForUse

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.261. CheckLevelAndMode

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - In Ports

Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

Level\_Mode\_Compatible

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.262. ManageModes**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Current\_Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Cab

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_F2\_Functions

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Localisation

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Speed\_and\_Supervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_STM

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TripModeFromLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

currentMode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EB\_Requested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Service\_Brake\_Command

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_BG\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.263. Output

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

next\_level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TripTrain

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

previous\_level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

needsAckFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

announce\_driver\_selection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

service\_brake\_from\_level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

LevelsTransitionPositionPassed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentMode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EB\_Requested\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Service\_Brake\_Command\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_DMI\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_BG\_Management\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Level\_Mode\_Compatible

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

Compatible\_Mode\_And\_Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_BG\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Service\_Brake\_Command

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EB\_Requested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

transitionPositionPassed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.264. TrackAtlasETCS

Description :

Hypothesis :

Scope : Internal



- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

MessageIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ModeAndLevel\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TrainData\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TrainPositionIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

train\_length

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

preindicationLocation

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDriverToMA\_R

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

bus\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

P203V1\_onboard

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

PermanentDataP003

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

SSP\_available

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NV\_raw\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

To\_ModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

to\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

to\_Supervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA\_onboard\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA\_request\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

bus\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

message147

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ces\_accepted

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ces\_revoked

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trip\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.265. F2.9 MoRC\_Main

**Description :**

**Hypothesis :**

**Scope :** Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

currentTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

obuEventsAndPhases

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

radioNetworkIDs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

statusOfMobile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMessage\_new



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train\_global

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msgBus\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

connectionStatusTimerInterval

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

nid\_engine

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

onboardPhoneNumbers

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

onboardPhoneNumbers\_b

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

m\_version

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

ignoreMessagesFromRBC\_except\_m39\_AckOfTerminationOfCommunicationSession

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendAPositionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

cmdsToMobile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

memorizeTheLastRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

orderTheRegistrationOfItsConnectedMobiles

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rejectOrderToContactRBC\_or\_RIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

InformTheDriverThatNoConnectionWasSetup

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

safeRadioConnectionStatus\_toDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileSWStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

requestTheSetupOfASafeRadioConnection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

requestReleaseOfSafeRadioConnectionWithTrackside

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionSuccessfullyEstablished

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MessageToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msgBus\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ready

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.266. F1 Receive Information from Trackside

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - In Ports

RBCBTMIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

TracksideOut

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.267. Driver**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Input1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

Output1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.268. Configuration1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - Out Ports

Output1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.269. F3 Measure Train Movement

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - In Ports

OdometryIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

OdometryOut

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.270. F4 Radio Communication Controller

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

RadioIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

RadioOut

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.271. F5 Manage JRU**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**3.272. F6 DMI Controller**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

DMIIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



**- Out Ports**

DMIOut

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.273. F7 TIU Controller**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

TIUIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

TIUOut

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.274. F8 Persistent Data**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

PersistentDataIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

PersistentDataOut

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.275. processHandingOver**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcStatus\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcStatus\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dataFromTrack\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionManagementAbility

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

sessionCmds\_2\_MoRC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionCmds\_2\_MoRC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_handingOverRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendTrainData\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

bufferInformationFromAcceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

supervisingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

useInformationFromAcceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

handingOverMobile\_is\_mobile\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPassesA\_RBC\_RBC\_border\_WithItsFrontEnd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

notReady

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.276. MoRC\_Main\_v21

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

msg\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

eventsAndPhases

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

atPowerUpRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

newRadioNetworkIDFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

configData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



**- Out Ports**

msgToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendAPositionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rejectOrderToContactRBC\_or\_RIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

infomDriverNoCompatibleVersionSupported

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

safeRadioIndication

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

memorizeTheLastRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastReceivedRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

notReady

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.277. MoRC\_Main\_v22

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

msg\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

eventsAndPhases

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

atPowerUpRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

newRadioNetworkIDFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

configData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

msgToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendAPositionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rejectOrderToContactRBC\_or\_RIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

infomDriverNoCompatibleVersionSupported

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

safeRadiolIndication

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

memorizeTheLastRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastReceivedRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

notReady

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.278. mobileDataRouter\_out

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

dataToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

positionReport\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcMsgToRBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcMsgToRBC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

useInformationFromAcceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

handingOverRBC\_is\_RBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_handingOverRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_RBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_RBC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendTrainData\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionManagementAbility

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



**- Out Ports**

data\_2\_RBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

data\_2\_RBC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.279. CaseLinkingInUse1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

storedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trackSideForCheck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

q\_nvlocacc

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

passedBG\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errorLinkedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.280. CaseLinkingNotInUse1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

trackSideForCheck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

q\_nvlocacc

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

applyServiceBrake

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

badBaliseMessageToDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errorUnlinkedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.281. AddBGToFIFO

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reportsSent

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

out\_reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.282. AggregatePackets

Description :  
Hypothesis :  
Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inPacket0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPacket1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPacket4

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPacket5

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outPackets

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.283. Build\_Packets0\_1**

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

modeLevelStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPos

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

train2trackStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

prvDirTrain

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.284. Build\_SinglePosReport

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



- In Ports

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errorMsg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

posRepHeader

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet4

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet5

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.285. PosReport\_Supervision**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

present

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posRepParam

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

systemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rbcComm

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trackInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

train2trackStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPos

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

modeLevelStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

prvDirTrain

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

trigger

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.286. ReceiveReportParameters**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

out\_reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

present

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posRepParam

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.287. ErrorManager**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

BG\_LinkingConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

LinkedBG\_MessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

UnlinkedBG\_MessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RadioMessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RadioSequenceError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RadioSafeRadioConnectionError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SafetyCriticalFailure

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

DoubleLinkingError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

DoubleRepositioningError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

errorVector

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.288. calcDistances1

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - In Ports

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



### - Out Ports

outLocationKP\_Balise\_Track

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ouDistanceKP\_Balise

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outDistance\_ToTSA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.289. collectDMIPackets1

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_dynamic

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_menuRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_evc\_coded\_train\_data

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_text\_message

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trackDescription

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_systemVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_displayControl

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_EVC\_levelData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_EVC\_radioNet

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_driverIdentifier

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trainRunningNumber

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_adhesionFactor

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_iconRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

systemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

to\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.290. convert\_cm\_s\_km\_h1

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

cm\_s

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

km\_h

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.291. copyGradientElement1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

index

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

continue

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

toDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.292. copySpeedProfileElement1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

index

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

continue

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

toDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.293. copyTrackDescription1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

fromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

toDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.294. cyclicReportToDMI1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



- In Ports

inCurrentDMIStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSpeedSupervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMovementAuthority

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMoRC\_status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

packetDynamic

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.295. doEntryRequest1

**Description :**

**Hypothesis :**

**Scope :** Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

new\_menuRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

new\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendTrainDataToDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outLevelsNeeded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.296. dolidentifierRequest1

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ownVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.297. isSendingNeeded1

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inCurrentDMIStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

sendingNeeded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.298. mapEntryForLevel1**

**Description :**

**Hypothesis :**

**Scope :** Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

new\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.299. mapMoRCtoRadio\_CS1

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - In Ports

inMoRC\_status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

outBMI\_CS

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.300. sendBrakesToDMI1

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

brakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

dmi\_iconRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.301. sendDynamic1

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSpeedSupervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMoRC\_status



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMovementAuthority

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

packetDynamic

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.302. sendLevelListPkg1

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

levelList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

UpdateLevelsRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

levelDataPkg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.303. sendTrainData1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDataFromEVC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

trainData\_ForDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.304. sendVersion1

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

ownVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmiStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

VersionPkg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.305. synchWithDMI1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

## - In Ports

dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outputStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

systemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

send\_dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

updatedOutputStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.306. CaseLinkingInUse1

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

storedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trackSideForCheck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

q\_nvlocacc

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

errorLinkedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

trackSideForCheck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

q\_nvlocacc

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

applyServiceBrake

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

badBaliseMessageToDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errorUnlinkedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.308. Receive\_TrackSide\_Msg**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



### - In Ports

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

API\_TrackSide\_Msg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inActualOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outTrackMessage\_for\_check

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.309. InformationFilter

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

## - In Ports

inSupervisingDevice

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingL1Transition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingL2L3Transition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingAckOfTrainDataFromRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inEmergencyStopAccepted

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inLastAckTextMessageId

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingNTCTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inActiveCab

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainDataValid

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inFilterEvents

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outAcceptedMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outPacketsForML

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.310. validateDataDirection

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

inMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inLRBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPositionedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.311. CheckEuroRadioMessage

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

activateCheck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rtmMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

tNvContact

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastRelevantEventTimestamp

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

connectionStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

radioSequenceError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

tNvContactError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

otherTimingError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

radioMessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

checkedMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.312. changeLevelByDiver1

**Description :**

**Hypothesis :**

**Scope :** Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

levelData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lasttNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

ML\_levelTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

updatedNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.313. doDriverRequests1

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



### - In Ports

inDriverRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outDriverRequestToLevels

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outDriverRequestToModes

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.314. receiveRequestsModesAndLevel1

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

fromDMI\_driverRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDMI\_Icon\_Ack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDMI\_TextMsg\_Ack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outDriverRequestToLevels

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

forModesAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.315. triggerForMA1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

fromDMI\_driverRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outForMA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.316. updateDMIStatus1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

sndValidationRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

oldStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

newStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.317. getTIUStatusFromData**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inTIUActualData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.318. mergeTIU\_Info**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

newInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

storedInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EVC\_trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

updatedInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.319. selectTrainData**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

newTIUTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_train\_commands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EVC\_trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.320. SoM\_NTC\_SN**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Status\_Mode\_Change\_from\_Level\_and\_Mode\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

start\_ack\_to\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



3.321. SoM\_SR\_FS\_OS\_LS\_SH\_SN\_UN

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

Status\_MA\_FS\_SR\_OS\_LS\_SH\_from\_MA\_L2\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Status\_Mode\_Change\_from\_Level\_and\_Mode\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

request\_MA\_FS\_SR\_OS\_LS\_SH\_to\_MA\_L2\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

request\_Mode\_Change\_SB\_to\_FS\_to\_Level\_and\_Mode\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

start\_ack\_to\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.322. processHandingOver

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

sessionManagementAbility

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcStatus\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcStatus\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dataFromTrack\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

sendPositionReport\_2\_handingOverRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendTrainData\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

bufferInformationFromAcceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

supervisingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

useInformationFromAcceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

handingOverMobile\_is\_mobile\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPassesA\_RBC\_RBC\_border\_WithItsFrontEnd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

notReady

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionCmds\_2\_MoRC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionCmds\_2\_MoRC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.323. MoRC\_Main\_v21

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

eventsAndPhases

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msg\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

atPowerUpRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

newRadioNetworkIDFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

configData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



- Out Ports

sendAPositionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rejectOrderToContactRBC\_or\_RIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

informDriverNoCompatibleVersionSupported

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

memorizeTheLastRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

notReady

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msgToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

safeRadioIndication

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastReceivedRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.324. MoRC\_Main\_v22

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

eventsAndPhases

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msg\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

atPowerUpRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

newRadioNetworkIDFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

configData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

sendAPositionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rejectOrderToContactRBC\_or\_RIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

informDriverNoCompatibleVersionSupported

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

memorizeTheLastRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

notReady

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msgToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### safeRadioIndication

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### mobileConnectionCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### mobileRegistrationCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### lastReceivedRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.325. mobileDataRouter\_out

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

## - In Ports

useInformationFromAcceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

handingOverRBC\_is\_RBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_handingOverRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_RBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_RBC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendTrainData\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionManagementAbility

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dataToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

positionReport\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcMsgToRBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcMsgToRBC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



**- Out Ports**

data\_2\_RBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

data\_2\_RBC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.326. InputWrapper**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

TrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dataFromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

mrsp\_update\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ma\_update\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mrsp\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ma\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

gp\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

gp\_update\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.327. ABrakeFactory

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

T\_b

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aBrakeSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aBrakeService

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.328. TargetManagement

Description :

Hypothesis :

Scope : Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

MRSP\_updated

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA\_updated

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MRSP

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

TrainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

A\_Expected

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

A\_Safe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

curveCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.330. LimitLocations

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

MRSP\_Profile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

curveCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

T\_b



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData\_int

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

FLOlisSBI1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

locations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MostRestrictiveDisplayedTarget

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

speeds

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.331. Commands

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

floilsSB1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

allTargets

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

speeds

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

locations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mrdt

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MLrequestEB

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MLrequestSB

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TrainData\_int

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

targetSpeedReached

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

eoOverpassed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sdmCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sdmToDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

brakeCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.332. AGradient

Description :

Hypothesis :

Scope : Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

TrainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

GradientProfile\_updated

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

GradientProfile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

A\_gradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.333. addGradient1**

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

aBrakeSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aGradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

aSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.334. addGradient2

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

aBrakeSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aGradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

aSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.335. AddBGToFIFO**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



### - In Ports

reportIsSent

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

out\_reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.336. AggregatePackets

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inPacket0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPacket1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPacket4

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPacket5

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outPackets

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.337. Build\_Packets0\_1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

modeLevelStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPos

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

train2trackStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

prvDirTrain

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.338. Build\_SinglePosReport

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

errorMsg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

posRepHeader

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet4

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet5

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.339. PosReport\_Supervision

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

systemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rbcComm

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

modeLevelStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posRepParam

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

train2trackStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

present

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trackInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPos

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

prvDirTrain

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



**- Out Ports**

trigger

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

out\_reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posRep

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.340. ReceiveReportParameters**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

out\_reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

present

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posRep

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posRepParam

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.341. ErrorManager**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

BG\_LinkingConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

LinkedBG\_MessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

UnlinkedBG\_MessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RadioMessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RadioSequenceError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RadioSafeRadioConnectionError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SafetyCriticalFailure

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### DoubleLinkingError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### DoubleRepositioningError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

#### errorVector

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.342. bothBrakesActive

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

speedSupbrakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelBrakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

brakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.343. getTIUStatusFromCommand

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

in\_IsolationStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_brake\_command

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.344. handleTraction

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

in\_train\_commands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outTrainCommands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.345. mapModeToTractionCutOff**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inModeLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

tractionCutOff

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.346. TIU\_OutputIntegration**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



**- In Ports**

in\_IsolationStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SpeedSup\_brakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_brake\_inhibition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_train\_commands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_change\_traction\_system

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_passenger\_door\_control\_info

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_change\_of\_allowed\_current\_consumption

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

outTIU\_to\_API

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outCommandStatusforEVC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.347. calcDistances1

**Description :**

**Hypothesis :**

**Scope :** Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

## - In Ports

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outLocationKP\_Balise\_Track

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ouDistanceKP\_Balise

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outDistance\_ToTSA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.348. collectDMIPackets1

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_dynamic

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_menuRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_evc\_coded\_train\_data

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_text\_message

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trackDescription

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_systemVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_displayControl

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_EVC\_levelData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_EVC\_radioNet

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_driverIdentifier

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trainRunningNumber

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_adhesionFactor

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_iconRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

systemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

to\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.349. convert\_cm\_s\_km\_h1

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

cm\_s

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

km\_h

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.350. copyGradientElement1

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

dmiUpdateLevelsDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_fromBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inCurrentDMIStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainPosition



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inBrakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSpeedSupervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMovementAuthority

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inRadioConnectionStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDataFromEVC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_evc\_coded\_train\_data

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trackDescription

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_displayControl

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_EVC\_levelList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_EVC\_radioNet

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_driverIdentifier

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trainRunningNumber

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_adhesionFactor

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_fromModesAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

index

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

to\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

continue

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

toDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.351. copySpeedProfileElement1

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

index

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

fromDMI\_TrainDataAck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

continue

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

toDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.352. copyTrackDescription1

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

fromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

toDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.353. cyclicReportToDMI1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inCurrentDMIStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSpeedSupervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMovementAuthority

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMoRC\_status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

packetDynamic

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.354. doEntryRequest1

**Description :**

**Hypothesis :**

**Scope :** Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



### - In Ports

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

sendTrainDataToDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

new\_menuRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

new\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outLevelsNeeded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.355. dolidentifierRequest1

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ownVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.356. isSendingNeeded1

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

incurrentDMIStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

sendingNeeded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.357. mapEntryForLevel1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

new\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.358. mapMoRCtoRadio\_CS1

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - In Ports

inMoRC\_status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

outBMI\_CS

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.359. sendBrakesToDMI1

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

brakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

dmi\_iconRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.360. sendDynamic1

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSpeedSupervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeLevel\_Ack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMoRC\_status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMovementAuthority

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

packetDynamic

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.361. sendLevelListPkg1

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

UpdateLevelsRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

levelDataPkg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.362. sendTrainData1

Description :  
Hypothesis :  
Scope : Internal



**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDataFromEVC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

trainData\_ForDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.363. sendVersion1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

ownVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmiStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

VersionPkg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.364. synchWithDMI1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

outputStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

systemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

updatedOutputStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

send\_dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.365. trainDataStorage

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

eventsForTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDatafromTIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDatafromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDataAckfromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

updatedStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

actualTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.366. sendAcknowledgementRBC**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EVC\_t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

nidEngine

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RBC\_timeStamp

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

updatedStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outMessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.367. checkRadioMessages**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trackMessages

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



**- Out Ports**

ackReceived

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ackRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.368. sendValidTrainDataRBC**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

evc\_t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

nidEngine

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

p0\_positionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

p1\_positionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

updatedAtStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outMessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.369. linkedBG\_missed

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

enable

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

position

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

missed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

indexOfBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.370. twoConsecutiveLinkedBGs\_missed**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msgFromTrack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

missed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

missedLinkedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

secondConsecutiveBG\_missed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.371. addAnnouncedBGs**

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

overrun

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.372. calculateBGLocations

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



- Out Ports

BGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errors

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedPositionedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.373. calculateTrainpositionAttributes

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

trainPositionInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.374. calculateTrainPositionInfo

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

recalculateBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

positionCalculationNotConsistent

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPositionInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.375. delDispensableBGs**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

deleteBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

BGs\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.376. msg\_2\_passedBG**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

msgFromTrack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

BG\_passed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

onlyBGsAnnouncedViaRadio

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.377. Input**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Data\_From\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_Messages

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_Packets

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_STM

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Localisation

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Speed\_and\_Supervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_F2\_Functions

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Cab\_In

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

driver\_level\_transition\_In

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ERTMS\_capabilities\_In

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

startOfMissionEnded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_MASSPGradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



- Out Ports

train\_standstill

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelAck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outStartOfMissionEnded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

driver\_level\_transition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ERTMS\_capabilities

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_to\_Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Cab

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_DMI\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_F2\_Functions\_to\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Localisation\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Speed\_and\_Supervision\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_STM\_to\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_TIU\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.378. ManageLevels

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

trainStandstill

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelAck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

driverLevelTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ERTMScapabilities

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

DataFromTrackToLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MemorizedLevelIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

TripTrainRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

needsAckFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

serviceBrakeRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

nextLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

announced\_level\_transition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

positionReportNeeded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelsNew

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

isAvailableForUse

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

announcedLevelTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

connectionToRBCRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.379. CheckLevelAndMode

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

Level\_Mode\_Compatible

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.380. ManageModes**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



**- In Ports**

Current\_Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Cab

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_F2\_Functions

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Localisation

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Speed\_and\_Supervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_STM

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TripModeFromLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

EB\_Requested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Service\_Brake\_Command

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentMode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_BG\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.381. Output

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

needsAckFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

service\_brake\_from\_level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

LevelsTransitionPositionPassed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EB\_Requested\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Service\_Brake\_Command\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Level\_Mode-Compatible

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

next\_level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TripTrain

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

previous\_level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MemorizedLevelIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

announce\_driver\_selection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentMode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_DMI\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_BG\_Management\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

Service\_Brake\_Command

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EB\_Requested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

transitionPositionPassed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Compatible\_Mode\_And\_Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_BG\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.382. TrackAtlasETCS

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

TrainData\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDriverToMA\_R

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MessageIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ModeAndLevel\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TrainPositionIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

train\_length

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SystemTime



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

preindicationLocation

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

P203V1\_onboard

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

PermanentDataP003

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

bus\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

To\_ModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

to\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

to\_Supervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA\_onboard\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ces\_accepted

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ces\_revoked

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trip\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NV\_raw\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA\_request\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

message147

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SSP\_available

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

bus\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.383. F2.9 MoRC\_Main

**Description :**

**Hypothesis :**

**Scope :** Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

obuEventsAndPhases

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

radioNetworkIDs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

statusOfMobile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

connectionStatusTimerInterval

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMessage\_new

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train\_global

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msgBus\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

nid\_engine

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

onboardPhoneNumbers

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

onboardPhoneNumbers\_b

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

m\_version

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



**- Out Ports**

ignoreMessagesFromRBC\_except\_m39\_AckOfTerminationOfCommunicationSession

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendAPositionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

cmdsToMobile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

memorizeTheLastRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

orderTheRegistrationOfItsConnectedMobiles

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rejectOrderToContactRBC\_or\_RIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

InformTheDriverThatNoConnectionWasSetup

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

safeRadioConnectionStatus\_toDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileSWStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

requestTheSetupOfASafeRadioConnection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

requestReleaseOfSafeRadioConnectionWithTrackside

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionSuccessfullyEstablished

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ready

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MessageToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msgBus\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.384. processHandingOver

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

sessionManagementAbility

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcStatus\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcStatus\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dataFromTrack\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

sendPositionReport\_2\_handingOverRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendTrainData\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

bufferInformationFromAcceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

supervisingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

useInformationFromAcceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

handingOverMobile\_is\_mobile\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPassesA\_RBC\_RBC\_border\_WithItsFrontEnd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

notReady

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionCmds\_2\_MoRC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionCmds\_2\_MoRC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.385. MoRC\_Main\_v21

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

eventsAndPhases

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msg\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

atPowerUpRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

newRadioNetworkIDFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

level



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

configData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

sendAPositionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rejectOrderToContactRBC\_or\_RIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

informDriverNoCompatibleVersionSupported

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

memorizeTheLastRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

notReady

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msgToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

safeRadioIndication

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastReceivedRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.386. MoRC\_Main\_v22

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

eventsAndPhases

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msg\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

atPowerUpRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

newRadioNetworkIDFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionContext

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

configData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

sendAPositionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rejectOrderToContactRBC\_or\_RIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

informDriverNoCompatibleVersionSupported

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

memorizeTheLastRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

notReady

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msgToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

safeRadioIndication

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileConnectionCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mobileRegistrationCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastReceivedRadioNetworkID

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.387. mobileDataRouter\_out

**Description :**

**Hypothesis :**

**Scope :** Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

## - In Ports

useInformationFromAcceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

handingOverRBC\_is\_RBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_acceptingRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_handingOverRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_RBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendPositionReport\_2\_RBC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sendTrainData\_2\_acceptingRBC



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sessionManagementAbility

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dataToRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

positionReport\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcMsgToRBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

morcMsgToRBC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

data\_2\_RBC\_1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

data\_2\_RBC\_2

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.388. InputWrapper**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

TrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dataFromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

mrsp\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mrsp\_update\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ma\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ma\_update\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

gp\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

gp\_update\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.389. ABrakeFactory

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

T\_b

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aBrakeSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aBrakeService

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.390. TargetManagement

Description :

Hypothesis :

Scope : Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

MRSP

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MRSP\_updated

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA\_updated

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

TrainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

A\_Safe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

A\_Expected

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

curveCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.392. LimitLocations

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



- In Ports

MRSP\_Profile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

curveCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

T\_b

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData\_int

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

speeds

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

locations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MostRestrictiveDisplayedTarget

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

FLOlisSBI1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.393. Commands

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

allTargets

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

speeds

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

locations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mrdt

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

floilsSB1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MLrequestSB

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MLrequestEB

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TrainData\_int

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

sdmToDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sdmCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetSpeedReached

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

eoOverpassed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

brakeCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.394. AGradient

Description :

Hypothesis :

Scope : Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

TrainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

GradientProfile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

GradientProfile\_updated

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

A\_gradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

aBrakeSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aGradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

aSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.396. addGradient2

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



### - In Ports

aBrakeSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aGradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

aSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.397. getTIUStatusFromData

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

inTIUActualData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.398. mergeTIU\_Info**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

newInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

storedInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EVC\_trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

updatedInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.399. selectTrainData**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

newTIUTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EVC\_trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.400. SoM\_NTC\_SN**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Status\_Mode\_Change\_from\_Level\_and\_Mode\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

start\_ack\_to\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.401. SoM\_SR\_FS\_OS\_LS\_SH\_SN\_UN

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

Status\_MA\_FS\_SR\_OS\_LS\_SH\_from\_MA\_L2\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Status\_Mode\_Change\_from\_Level\_and\_Mode\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

request\_MA\_FS\_SR\_OS\_LS\_SH\_to\_MA\_L2\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

request\_Mode\_Change\_SB\_to\_FS\_to\_Level\_and\_Mode\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

start\_ack\_to\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.402. changeLevelByDiver1

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

levelData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lasttNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

ML\_levelTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

updatedNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.403. doDriverRequests1

Description :  
Hypothesis :  
Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inDriverRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outDriverRequestToLevels

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outDriverRequestToModes

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.404. receiveRequestsModesAndLevel1

**Description :**

**Hypothesis :**

**Scope :** Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

fromDMI\_driverRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDMI\_Icon\_Ack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDMI\_TextMsg\_Ack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



### - Out Ports

outDriverRequestToLevels

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

forModesAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.405. triggerForMA1

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

fromDMI\_driverRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outForMA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.406. updateDMIStatus1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

sndValidationRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

oldStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

newStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.407. Abstract**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

API\_fromAPI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmiStatusReset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

InSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

fromDMI\_TrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDMI\_TrainDataAck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outUpdateLevelsDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

CurrentDMIStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

updatedNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDMI\_TrainRunningNumber

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Local Analysis

[InSystemTime](A) | [inStatusList](A) | [API\_fromAPI](A) | [dmiStatusReset](A) = [fromDMI\_TrainData](A)  
 [inStatusList](U) | [API\_fromAPI](U) | [dmiStatusReset](U) | [InSystemTime](U) = [fromDMI\_TrainData](U)  
 [inStatusList](E) | [API\_fromAPI](E) | [dmiStatusReset](E) | [InSystemTime](E) = [fromDMI\_TrainData](E)  
 [InSystemTime](A) | [inStatusList](A) | [API\_fromAPI](A) | [dmiStatusReset](A) = [fromDMI\_TrainDataAck](A)  
 [inStatusList](U) | [API\_fromAPI](U) | [dmiStatusReset](U) | [InSystemTime](U) = [fromDMI\_TrainDataAck](U)  
 [inStatusList](E) | [API\_fromAPI](E) | [dmiStatusReset](E) | [InSystemTime](E) = [fromDMI\_TrainDataAck](E)  
 [InSystemTime](A) | [inStatusList](A) | [API\_fromAPI](A) | [dmiStatusReset](A) = [outUpdateLevelsDMI](A)  
 [inStatusList](U) | [API\_fromAPI](U) | [dmiStatusReset](U) | [InSystemTime](U) = [outUpdateLevelsDMI](U)  
 [inStatusList](E) | [API\_fromAPI](E) | [dmiStatusReset](E) | [InSystemTime](E) = [outUpdateLevelsDMI](E)  
 [InSystemTime](A) | [inStatusList](A) | [API\_fromAPI](A) | [dmiStatusReset](A) = [outStatusList](A)  
 [inStatusList](U) | [API\_fromAPI](U) | [dmiStatusReset](U) | [InSystemTime](U) = [outStatusList](U)  
 [inStatusList](E) | [API\_fromAPI](E) | [dmiStatusReset](E) | [InSystemTime](E) = [outStatusList](E)  
 [InSystemTime](A) | [inStatusList](A) | [API\_fromAPI](A) | [dmiStatusReset](A) = [CurrentDMIStatus](A)  
 [inStatusList](U) | [API\_fromAPI](U) | [dmiStatusReset](U) | [InSystemTime](U) = [CurrentDMIStatus](U)  
 [InSystemTime](A) | [inStatusList](A) | [API\_fromAPI](A) | [dmiStatusReset](A) = [updatedNTC](A)  
 [inStatusList](U) | [API\_fromAPI](U) | [dmiStatusReset](U) | [InSystemTime](U) = [updatedNTC](U)  
 [inStatusList](E) | [API\_fromAPI](E) | [dmiStatusReset](E) | [InSystemTime](E) = [updatedNTC](E)  
 [InSystemTime](A) | [inStatusList](A) | [API\_fromAPI](A) | [dmiStatusReset](A) = [fromDMI\_TrainRunningNumber](A)  
 [inStatusList](U) | [API\_fromAPI](U) | [dmiStatusReset](U) | [InSystemTime](U) = [fromDMI\_TrainRunningNumber](U)  
 [inStatusList](E) | [API\_fromAPI](E) | [dmiStatusReset](E) | [InSystemTime](E) = [fromDMI\_TrainRunningNumber](E)

3.408. CaseLinkingInUse1

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

storedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trackSideForCheck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

q\_nvlocacc

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

errorLinkedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.409. CaseLinkingNotInUse1

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

trackSideForCheck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

q\_nvlocacc

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

applyServiceBrake

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

badBaliseMessageToDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errorUnlinkedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.410. calcDistances1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



### - Out Ports

outLocationKP\_Balise\_Track

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ouDistanceKP\_Balise

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outDistance\_ToTSA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.411. collectDMIPackets1

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

## - In Ports

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_dynamic

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_menuRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_evc\_coded\_train\_data

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_text\_message

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trackDescription

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_systemVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_displayControl

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_EVC\_levelData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_EVC\_radioNet

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_driverIdentifier

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trainRunningNumber

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_adhesionFactor

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_iconRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

systemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

to\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.412. convert\_cm\_s\_km\_h1

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

cm\_s

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

km\_h

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.413. copyGradientElement1

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

dmiUpdateLevelsDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_fromBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inCurrentDMIStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inBrakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSpeedSupervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMovementAuthority

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inRadioConnectionStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDataFromEVC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_evc\_coded\_train\_data

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trackDescription

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_displayControl

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_EVC\_levelList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_EVC\_radioNet



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_driverIdentifier

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_trainRunningNumber

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_adhesionFactor

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_fromModesAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

index

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

to\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

continue

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

toDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.414. copySpeedProfileElement1

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

index

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

fromDMI\_TrainDataAck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

continue

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

toDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.415. copyTrackDescription1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

fromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

toDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.416. cyclicReportToDMI1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

inCurrentDMIStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSpeedSupervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMovementAuthority

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMoRC\_status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

packetDynamic

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.417. doEntryRequest1

**Description :**

**Hypothesis :**

**Scope :** Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

sendTrainDataToDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

new\_menuRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

new\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outLevelsNeeded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.418. dolidentifierRequest1

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ownVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.419. isSendingNeeded1

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



**- In Ports**

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

incurrentDMIStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

sendingNeeded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.420. mapEntryForLevel1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

dmi\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

new\_entryRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.421. mapMoRCtoRadio\_CS1

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - In Ports

inMoRC\_status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

outBMI\_CS

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.422. sendBrakesToDMI1

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

brakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

dmi\_iconRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.423. sendDynamic1

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSpeedSupervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeLevel\_Ack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMoRC\_status

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMovementAuthority

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

packetDynamic

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.424. sendLevelListPkg1

**Description :**

**Hypothesis :**

**Scope :** Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

UpdateLevelsRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

levelDataPkg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.425. sendTrainData1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDataFromEVC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

trainData\_ForDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.426. sendVersion1

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

ownVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmiStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

VersionPkg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.427. synchWithDMI1**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



**- In Ports**

outputStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TIU\_TrainStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

systemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

updatedOutputStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

send\_dmi\_identifierRequest

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

dmiUpdateLevelsDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inCurrentDMIStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inNTC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

outStatusList

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Local Analysis

$[dmiUpdateLevelsDMI](A) \mid [inStatusList](A) \mid [inCurrentDMIStatus](A) \mid [inNTC](A) = [outStatusList](A)$   
 $[inCurrentDMIStatus](U) \mid [inNTC](U) \mid [dmiUpdateLevelsDMI](U) \mid [inStatusList](U) = [outStatusList](U)$   
 $[dmiUpdateLevelsDMI](E) \mid [inStatusList](E) \mid [inCurrentDMIStatus](E) \mid [inNTC](E) = [outStatusList](E)$

3.429. Input

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Data\_From\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_Messages

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_Packets

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_STM

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Localisation

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Speed\_and\_Supervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_F2\_Functions

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Cab\_In

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

driver\_level\_transition\_In

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ERTMS\_capabilities\_In

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

startOfMissionEnded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_MASSPGradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

train\_standstill

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

driver\_level\_transition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelAck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ERTMS\_capabilities

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outStartOfMissionEnded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_to\_Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Cab

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_DMI\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_F2\_Functions\_to\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Localisation\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Speed\_and\_Supervision\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_STM\_to\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_TIU\_To\_Mode



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track\_To\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.430. ManageLevels

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

trainStandstill

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

driverLevelTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelAck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ERTMScapabilities

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

DataFromTrackToLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MemorizedLevelIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

nextLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TripTrainRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

needsAckFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

announcedLevelTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

serviceBrakeRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

connectionToRBCRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

positionReportNeeded

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelsNew

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

isAvailableForUse

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.431. CheckLevelAndMode

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - In Ports

Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

Level\_Mode\_Compatible

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.432. ManageModes**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

Current\_Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Cab

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_F2\_Functions

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Localisation

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Speed\_and\_Supervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_STM

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_From\_Track

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TripModeFromLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



### - Out Ports

currentMode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EB\_Requested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Service\_Brake\_Command

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_BG\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.433. Output

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

next\_level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TripTrain

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

previous\_level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

needsAckFromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

announce\_driver\_selection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

service\_brake\_from\_level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

LevelsTransitionPositionPassed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentMode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EB\_Requested\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Service\_Brake\_Command\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_DMI\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_BG\_Management\_From\_Mode

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Level\_Mode\_Compatible

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

Compatible\_Mode\_And\_Level

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Data\_To\_BG\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Service\_Brake\_Command

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EB\_Requested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

transitionPositionPassed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.434. getTIUStatusFromData

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

inTIUActualData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

outStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.435. mergeTIU\_Info

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

newInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

storedInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EVC\_trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

updatedInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.436. selectTrainData**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

newTIUTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_train\_commands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EVC\_trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.437. TrackAtlasETCS

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

MessageIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ModeAndLevel\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TrainData\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TrainPositionIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

train\_length

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

preindicationLocation



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDriverToMA\_R

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

bus\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

P203V1\_onboard

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

PermanentDataP003

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

SSP\_available

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NV\_raw\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

To\_ModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

to\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

to\_Supervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA\_onboard\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA\_request\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

bus\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

message147

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ces\_accepted

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ces\_revoked

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trip\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.438. SoM\_NTC\_SN

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Status\_Mode\_Change\_from\_Level\_and\_Mode\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

start\_ack\_to\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.439. SoM\_SR\_FS\_OS\_LS\_SH\_SN\_UN

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

Status\_MA\_FS\_SR\_OS\_LS\_SH\_from\_MA\_L2\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Status\_Mode\_Change\_from\_Level\_and\_Mode\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

request\_MA\_FS\_SR\_OS\_LS\_SH\_to\_MA\_L2\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

request\_Mode\_Change\_SB\_to\_FS\_to\_Level\_and\_Mode\_Management

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

start\_ack\_to\_TIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.440. bothBrakesActive

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

speedSupbrakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelBrakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

brakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.441. getTIUStatusFromCommand**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

in\_IsolationStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_brake\_command

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.442. handleTraction**

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - In Ports

in\_train\_commands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

outTrainCommands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.443. mapModeToTractionCutOff

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

#### - In Ports

inModeLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



**- Out Ports**

tractionCutOff

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.444. TIU\_OutputIntegration**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

in\_IsolationStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SpeedSup\_brakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_brake\_inhibition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_train\_commands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_change\_traction\_system

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_passenger\_door\_control\_info

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_change\_of\_allowed\_current\_consumption

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outTIU\_to\_API

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outCommandStatusforEVC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.445. InputWrapper

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

TrainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

dataFromTrackAtlas

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

mrsp\_update\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ma\_update\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mrsp\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ma\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

gp\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

gp\_update\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.446. ABrakeFactory

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

T\_b

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aBrakeSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aBrakeService

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.447. TargetManagement

Description :

Hypothesis :

Scope : Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

MRSP\_updated

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA\_updated

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MRSP

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

TrainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

A\_Expected

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

A\_Safe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

curveCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.449. LimitLocations

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

MRSP\_Profile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

curveCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

T\_b

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData\_int

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

FLOlisSBI1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

locations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MostRestrictiveDisplayedTarget

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

speeds

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.450. Commands

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

floilsSB1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

allTargets

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

speeds

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

locations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

mrdt

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MLrequestEB

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MLrequestSB

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TrainData\_int

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NationalValues

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

targetSpeedReached

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

eoOverpassed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sdmCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

sdmToDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

brakeCmd

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.451. AGradient

Description :

Hypothesis :

Scope : Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



**- In Ports**

TrainLocations

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

targetCollection

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

GradientProfile\_updated

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

GradientProfile

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

A\_gradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

aBrakeSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aGradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

aSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.453. addGradient2

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

aBrakeSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

aGradient

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

aSafe

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.454. bothBrakesActive**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

speedSupbrakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

levelBrakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

brakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.455. getTIUStatusFromCommand

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

in\_IsolationStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_brake\_command

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.456. handleTraction

**Description :**

**Hypothesis :**

**Scope :** Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

in\_train\_commands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outTrainCommands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.457. mapModeToTractionCutOff**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

inModeLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

tractionCutOff

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.458. TIU\_OutputIntegration

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

in\_IsolationStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SpeedSup\_brakeCommand

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_brake\_inhibition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_train\_commands

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_change\_traction\_system

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_passenger\_door\_control\_info

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_change\_of\_allowed\_current\_consumption



Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

outTIU\_to\_API

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outCommandStatusforEVC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.459. CaseLinkingInUse1

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

storedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trackSideForCheck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

q\_nvlocacc

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

passedBG\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errorLinkedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.460. CaseLinkingNotInUse1

Description :

Hypothesis :

Scope : Internal

### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

### - In Ports

trackSideForCheck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

q\_nvlocacc

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

applyServiceBrake

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

badBaliseMessageToDMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errorUnlinkedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.461. Receive\_TrackSide\_Msg

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

API\_TrackSide\_Msg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inActualOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

outTrackMessage\_for\_check

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.462. InformationFilter

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- Barriers

Barrier

Name	Feared Events	Feared Events Familie	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- In Ports**

inMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inModus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inSupervisingDevice

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingL1Transition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingL2L3Transition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingAckOfTrainDataFromRBC

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inEmergencyStopAccepted

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inLastAckTextMessageld

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPendingNTCTransition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inActiveCab

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inTrainDataValid

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inFilterEvents

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

outAcceptedMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outPacketsForML

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Local Analysis**

[Barrier](A) = [outMessage](A)  
[Barrier](U) = [outMessage](U)  
[Barrier](E) = [outMessage](E)



3.463. validateDataDirection

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

inMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inLRBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPositionedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

outMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.464. CheckEuroRadioMessage

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

rtmMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

tNvContact

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastRelevantEventTimestamp

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

connectionStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

activateCheck

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

checkedMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

radioSequenceError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

tNvContactError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

otherTimingError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

radioMessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.465. trainDataStorage**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

eventsForTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDatafromTIU

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDatafromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainDataAckfromDriver

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

updatedStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

actualTrainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Local Analysis

[actualStatus](A) | [eventsForTrainData](A) | [trainDatafromTIU](A) | [trainDatafromDriver](A) | [trainDataAckfromDriver](A) = [actualTrainData](A)  
[trainDatafromDriver](U) | [trainDataAckfromDriver](U) | [eventsForTrainData](U) | [actualStatus](U) | [trainDatafromTIU](U) = [actualTrainData](U)  
[actualStatus](E) | [eventsForTrainData](E) | [trainDatafromDriver](E) | [trainDataAckfromDriver](E) = [actualTrainData](E)

3.466. sendAcknowledgementRBC

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

EVC\_t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

nidEngine

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RBC\_timeStamp

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

updatedStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outMessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.467. checkRadioMessages**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trackMessages

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



**- Out Ports**

ackReceived

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ackRequested

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.468. sendValidTrainDataRBC**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

actualStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainData

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

evc\_t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

nidEngine

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

p0\_positionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

p1\_positionReport

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inVersion

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## - Out Ports

updatedStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

outMessageBus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

## 3.469. TrackAtlasETCS

Description :

Hypothesis :

Scope : Internal

## - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

TrainData\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

fromDriverToMA\_R

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MessageIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ModeAndLevel\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

TrainPositionIn

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

train\_length

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SystemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

preindicationLocation

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

P203V1\_onboard

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

PermanentDataP003

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

bus\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

To\_ModeAndLevel

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

to\_DMI

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

to\_Supervision

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA\_onboard\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ces\_accepted

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

ces\_revoked

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trip\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

NV\_raw\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

MA\_request\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

message147

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SSP\_available

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

bus\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.470. linkedBG\_missed

**Description :**

**Hypothesis :**

**Scope :** Internal



- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

enable

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

position

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

missed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

indexOfBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.471. twoConsecutiveLinkedBGs\_missed**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msgFromTrack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

missed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

missedLinkedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

secondConsecutiveBG\_missed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.472. addAnnouncedBGs**

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

overrun

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.473. calculateBGLocations

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

lastBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

BGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errors

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedPositionedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.474. calculateTrainpositionAttributes

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

trainPositionInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

trainPosition

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.475. calculateTrainPositionInfo**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

recalculateBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reset

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

currentOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



**- Out Ports**

positionCalculationNotConsistent

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPositionInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.476. delDispensableBGs**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

deleteBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs\_in

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

BGs\_out

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.477. msg\_2\_passedBG**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

msgFromTrack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

BG\_passed

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

passedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

onlyBGsAnnouncedViaRadio

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.478. Abstract definition**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- Barriers**

Barrier

Name	Feared Events	Feared Events Familie	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- In Ports

currentOdometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

PassedBG

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

msgFromTrack

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProperties

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

Train position

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

BGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

errors

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Local Analysis**

[currentOdometry](A) | [msgFromTrack](A) | [trainProperties](A) = [errors](A)  
[currentOdometry](U) | [PassedBG](U) | [msgFromTrack](U) | [trainProperties](U) = [errors](U)  
[trainProperties](E) | [currentOdometry](E) | [PassedBG](E) | [msgFromTrack](E) = [errors](E)

3.479. AddBGToFIFO

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

reportIsSent

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

out\_reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.480. AggregatePackets

Description :  
Hypothesis :  
Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

inPacket0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPacket1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPacket4

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inPacket5

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

outPackets

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

3.481. Build\_Packets0\_1

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure



- In Ports

modeLevelStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPos

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

train2trackStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

prvDirTrain

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### - Out Ports

packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### 3.482. Build\_SinglePosReport

Description :

Hypothesis :

Scope : Internal

#### - Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

errorMsg

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

in\_packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

t\_train

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Out Ports

posRepHeader

Name	Feared Events	Feared Events Families	Description
A	Missing Message		The standard 'absent' failure mode
U	Untiming Event		The standard 'untimely' failure mode
E	Erroneous Message		The standard 'erroneous' failure mode

packet0

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet1

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet4

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

packet5

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

- Local Analysis

[errorMsg](E) | [trainProps](E) = [posRepHeader](E)

3.483. PosReport\_Supervision

Description :

Hypothesis :

Scope : Internal

- Local Events

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

- In Ports

systemTime

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

rbcComm

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

modeLevelStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posRepParam

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

train2trackStatus

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

present

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trackInfo

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainPos

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

odometry

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

prvDirTrain

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

trainProps

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**- Out Ports**

trigger

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

out\_reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posRep

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.484. ReceiveReportParameters**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

inMessage

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode



**- Out Ports**

out\_reportedBGs

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

present

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posRep

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

posRepParam

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

**3.485. ErrorManager**

Description :

Hypothesis :

Scope : Internal

**- Local Events**

Name	Description
Internal Failure	Default local event corresponding to a block internal failure

**- In Ports**

BG\_LinkingConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

LinkedBG\_MessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

UnlinkedBG\_MessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RadioMessageConsistencyError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RadioSequenceError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

RadioSafeRadioConnectionError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

SafetyCriticalFailure

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### DoubleLinkingError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

#### DoubleRepositioningError

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Out Ports

#### errorVector

Name	Feared Events	Feared Events Families	Description
A			The standard 'absent' failure mode
U			The standard 'untimely' failure mode
E			The standard 'erroneous' failure mode

### - Local Analysis

[BG\_LinkingConsistencyError](E) | [DoubleLinkingError](E) | [DoubleRepositioningError](E) |  
 [LinkedBG\_MessageConsistencyError](E) | [RadioMessageConsistencyError](E) | [RadioSafeRadioConnectionError](E) |  
 [RadioSequenceError](E) | [SafetyCriticalFailure](E) | [UnlinkedBG\_MessageConsistencyError](E) |  
 [BG\_LinkingConsistencyError](U) | [LinkedBG\_MessageConsistencyError](U) | [UnlinkedBG\_MessageConsistencyError]  
 (U) | [RadioMessageConsistencyError](U) | [RadioSequenceError](U) | [RadioSafeRadioConnectionError](U) |  
 [SafetyCriticalFailure](U) | [DoubleLinkingError](U) | [DoubleRepositioningError](U) | [BG\_LinkingConsistencyError](A) |  
 [LinkedBG\_MessageConsistencyError](A) | [UnlinkedBG\_MessageConsistencyError](A) | [RadioMessageConsistencyError]  
 (A) | [RadioSequenceError](A) | [RadioSafeRadioConnectionError](A) | [SafetyCriticalFailure](A) | [DoubleLinkingError](A) |  
 [DoubleRepositioningError](A) = [errorVector](E)

## 4. Data links

Connector1

Source :	Port	Owner
	trackSide_ForCheck	CheckBGConsistency
Target :	Port	Owner
	trackSideForCheck	CaseLinkingNotInUse1

Connector2

Source :	Port	Owner
	trackSide_ForCheck	CheckBGConsistency
Target :	Port	Owner
	trackSideForCheck	CaseLinkingInUse1

Connector3

Source :	Port	Owner
	errorUnlinkedBG	CaseLinkingNotInUse1
Target :	Port	Owner
	errorUnlinkedBG	CheckBGConsistency

Connector4

Source :	Port	Owner
	applyServiceBrake	CaseLinkingNotInUse1
Target :	Port	Owner
	applyServiceBrake	CheckBGConsistency

Connector5

Source :	Port	Owner
	errorLinkedBG	CaseLinkingInUse1
Target :	Port	Owner
	errorLinkedBG	CheckBGConsistency

Connector6

Source :	Port	Owner
	passedBG_out	CaseLinkingNotInUse1
Target :	Port	Owner
	passedBG_out	CheckBGConsistency

Connector7

Source :	Port	Owner
	passedBG_out	CaseLinkingInUse1
Target :	Port	Owner
	passedBG_out	CheckBGConsistency

Connector1

<b>Source :</b>	Port	Owner
	reset	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	reset	Receive_TrackSide_Msg

#### Connector2

<b>Source :</b>	Port	Owner
	API_trackSide_Message	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	API_TrackSide_Msg	Receive_TrackSide_Msg

#### Connector3

<b>Source :</b>	Port	Owner
	inActiveCab	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	inActualOdometry	Receive_TrackSide_Msg

#### Connector4

<b>Source :</b>	Port	Owner
	outTrackMessage_for_check	Receive_TrackSide_Msg
<b>Target :</b>	Port	Owner
	trackSide_ForCheck	CheckBGConsistency

#### Connector5

<b>Source :</b>	Port	Owner
	applyServiceBrake	CheckBGConsistency
<b>Target :</b>	Port	Owner
	ApplyServiceBrake	F2.1 Manage_TrackSideInformation_Integration

#### Connector6

<b>Source :</b>	Port	Owner
	outTrackMessage_for_check	Receive_TrackSide_Msg
<b>Target :</b>	Port	Owner
	rtmMessage	CheckEuroRadioMessage

#### Connector7

<b>Source :</b>	Port	Owner
	outMessage	InformationFilter
<b>Target :</b>	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration

#### Connector8

<b>Source :</b>	Port	Owner
	inTrainDataValid	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	inTrainDataValid	InformationFilter

#### Connector9

<b>Source :</b>	Port	Owner
	passedBG_out	CheckBGConsistency
<b>Target :</b>	Port	Owner
	inMessage	validateDataDirection

#### Connector10

<b>Source :</b>	Port	Owner
	checkedMessage	CheckEuroRadioMessage
<b>Target :</b>	Port	Owner
	inMessage	validateDataDirection

#### Connector11

<b>Source :</b>	Port	Owner
	outMessage	validateDataDirection
<b>Target :</b>	Port	Owner
	inMessage	InformationFilter

#### Connector12

<b>Source :</b>	Port	Owner
	inActiveCab	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	inActiveCab	InformationFilter

#### Connector13

<b>Source :</b>	Port	Owner
	intrainVersion	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	trainVersion	CheckBGConsistency

#### Connector14

<b>Source :</b>	Port	Owner
	trainPosition	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	trainPosition	CheckBGConsistency

#### Connector15

Source :	Port	Owner
	inFilterEvents	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	inFilterEvents	InformationFilter

#### Connector16

Source :	Port	Owner
	outPacketsForML	InformationFilter
Target :	Port	Owner
	Data_to_From_Track_Packets_at_ML	F2.1 Manage_TrackSideInformation_Integration

#### Connector17

Source :	Port	Owner
	ActualOdometry	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	inActualOdometry	Receive_TrackSide_Msg

#### Connector1

Source :	Port	Owner
	TrainPosition	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	TrainPosition	InputWrapper

#### Connector3

Source :	Port	Owner
	trainProps	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	trainProps	InputWrapper

#### Connector4

Source :	Port	Owner
	dataFromTrackAtlas	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	dataFromTrackAtlas	InputWrapper

#### Connector11

Source :	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	ABrakeFactory

#### Connector12



Source :	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	trainData	ABrakeFactory

#### Connector13

Source :	Port	Owner
	mrsp_out	InputWrapper
Target :	Port	Owner
	MRSP	TargetManagement

#### Connector14

Source :	Port	Owner
	mrsp_update_out	InputWrapper
Target :	Port	Owner
	MRSP_updated	TargetManagement

#### Connector15

Source :	Port	Owner
	ma_out	InputWrapper
Target :	Port	Owner
	MA	TargetManagement

#### Connector16

Source :	Port	Owner
	ma_update_out	InputWrapper
Target :	Port	Owner
	MA_updated	TargetManagement

#### Connector17

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	trainLocations	TargetManagement

#### Connector18

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	TrainLocations	CalcBrakingCurves

#### Connector19

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	CalcBrakingCurves

Connector22

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	LimitLocations

Connector23

Source :	Port	Owner
	mrsp_out	InputWrapper
Target :	Port	Owner
	MRSP_Profile	LimitLocations

Connector24

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	trainLocations	LimitLocations

Connector26

Source :	Port	Owner
	curveCollection	CalcBrakingCurves
Target :	Port	Owner
	curveCollection	LimitLocations

Connector27

Source :	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	LimitLocations

Connector29

Source :	Port	Owner
	T_b	ABrakeFactory
Target :	Port	Owner
	T_b	LimitLocations

Connector30

Source :	Port	Owner
	ma_out	InputWrapper
Target :	Port	Owner
	MA	LimitLocations

Connector35

Source :	Port	Owner
	locations	LimitLocations
Target :	Port	Owner
	locations	Commands

Connector36

Source :	Port	Owner
	speeds	LimitLocations
Target :	Port	Owner
	speeds	Commands

Connector37

Source :	Port	Owner
	MostRestrictiveDisplayedTarget	LimitLocations
Target :	Port	Owner
	mrdt	Commands

Connector38

Source :	Port	Owner
	FLOlisSB11	LimitLocations
Target :	Port	Owner
	floilsSB1	Commands

Connector43

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	allTargets	Commands

#### Connector46

Source :	Port	Owner
	MostRestrictiveDisplayedTarget	LimitLocations
Target :	Port	Owner
	target	F2.7 SpeedSupervision_Integration

#### Connector47

Source :	Port	Owner
	sdmToDMI	Commands
Target :	Port	Owner
	sdmToDMI	F2.7 SpeedSupervision_Integration

#### Connector48

Source :	Port	Owner
	brakeCmd	Commands
Target :	Port	Owner
	brakeCmd	F2.7 SpeedSupervision_Integration

#### Connector49

Source :	Port	Owner
	sdmCmd	Commands
Target :	Port	Owner
	sdmCommands	F2.7 SpeedSupervision_Integration

#### Connector50

Source :	Port	Owner
	targetSpeedReached	Commands
Target :	Port	Owner
	Target_Speed_Reached	F2.7 SpeedSupervision_Integration

#### Connector51

Source :	Port	Owner
	eoOverpassed	Commands
Target :	Port	Owner
	EOA_overpassed	F2.7 SpeedSupervision_Integration

#### Connector52

Source :	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	Commands

#### Connector53

Source :	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	TrainData_int	Commands

#### Connector54

Source :	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	trainData_int	LimitLocations

#### Connector55

Source :	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	LimitLocations

#### Connector56

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	trainLocations	LimitLocations

#### Connector57

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	TrainLocations	CalcBrakingCurves

#### Connector58

Source :	Port	Owner
	Service_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	MLrequestSB	Commands

#### Connector59

Source :	Port	Owner
	Emergency_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	MLrequestEB	Commands

#### Connector60

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	allTargets	Commands

#### Connector61

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	LimitLocations

#### Connector62

Source :	Port	Owner
	ma_out	InputWrapper
Target :	Port	Owner
	MA	LimitLocations

#### Connector63

Source :	Port	Owner
	mrsp_out	InputWrapper
Target :	Port	Owner
	MRSP_Profile	LimitLocations

#### Connector64

Source :	Port	Owner
	odometry	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	odometry	LimitLocations

#### Connector65

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	AGradient

#### Connector66

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	TrainLocations	AGradient

#### Connector67

Source :	Port	Owner
	gp_out	InputWrapper
Target :	Port	Owner
	GradientProfile	AGradient

#### Connector68

Source :	Port	Owner
	gp_update_out	InputWrapper
Target :	Port	Owner
	GradientProfile_updated	AGradient

#### Connector69

Source :	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	trainData	AGradient

#### Connector70

Source :	Port	Owner
	aBrakeSafe	ABrakeFactory
Target :	Port	Owner
	aBrakeSafe	addGradient1

#### Connector71

Source :	Port	Owner
	aBrakeService	ABrakeFactory
Target :	Port	Owner
	aBrakeSafe	addGradient2

#### Connector72

Source :	Port	Owner
	aSafe	addGradient1
Target :	Port	Owner
	A_Safe	CalcBrakingCurves

#### Connector73

Source :	Port	Owner
	aSafe	addGradient2
Target :	Port	Owner
	A_Expected	CalcBrakingCurves

#### Connector74

Source :	Port	Owner
	A_gradient	AGradient
Target :	Port	Owner
	aGradient	addGradient1

#### Connector75

Source :	Port	Owner
	A_gradient	AGradient
Target :	Port	Owner
	aGradient	addGradient2

#### Connector1

Source :	Port	Owner
	packet0	Build_SinglePosReport
Target :	Port	Owner
	inPacket0	AggregatePackets

#### Connector2

Source :	Port	Owner
	packet1	Build_SinglePosReport
Target :	Port	Owner
	inPacket1	AggregatePackets



Connector3

Source :	Port	Owner
	packet4	Build_SinglePosReport
Target :	Port	Owner
	inPacket4	AggregatePackets

Connector4

Source :	Port	Owner
	packet5	Build_SinglePosReport
Target :	Port	Owner
	inPacket5	AggregatePackets

Connector6

Source :	Port	Owner
	present	ReceiveReportParameters
Target :	Port	Owner
	present	PosReport_Supervision

Connector7

Source :	Port	Owner
	posRepParam	ReceiveReportParameters
Target :	Port	Owner
	posRepParam	PosReport_Supervision

Connector9

Source :	Port	Owner
	trigger	PosReport_Supervision
Target :	Port	Owner
	reportIsSent	AddBGToFIFO

Connector10

Source :	Port	Owner
	posRepHeader	Build_SinglePosReport
Target :	Port	Owner
	posRep	F2.8 ProvidePositionReport

Connector11

Source :	Port	Owner
	packet0	Build_Packets0_1
Target :	Port	Owner
	in_packet0	Build_SinglePosReport

Connector12

Source :	Port	Owner
	packet1	Build_Packets0_1
Target :	Port	Owner
	in_packet1	Build_SinglePosReport

#### Connector13

Source :	Port	Owner
	packet0	Build_Packets0_1
Target :	Port	Owner
	packet0	F2.8 ProvidePositionReport

#### Connector14

Source :	Port	Owner
	packet1	Build_Packets0_1
Target :	Port	Owner
	packet1	F2.8 ProvidePositionReport

#### Connector15

Source :	Port	Owner
	errorVector	ErrorManager
Target :	Port	Owner
	errorMsg	Build_SinglePosReport

#### Connector16

Source :	Port	Owner
	BG_LinkingConsistencyError	F2.8 ProvidePositionReport
Target :	Port	Owner
	BG_LinkingConsistencyError	ErrorManager

#### Connector17

Source :	Port	Owner
	LinkedBG_MessageConsistencyError	F2.8 ProvidePositionReport
Target :	Port	Owner
	LinkedBG_MessageConsistencyError	ErrorManager

#### Connector18

Source :	Port	Owner
	UnlinkedBG_MessageConsistencyError	F2.8 ProvidePositionReport
Target :	Port	Owner
	UnlinkedBG_MessageConsistencyError	ErrorManager

#### Connector19

<b>Source :</b>	Port	Owner
	RadioMessageConsistencyError	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	RadioMessageConsistencyError	ErrorManager

#### Connector20

<b>Source :</b>	Port	Owner
	RadioSequenceError	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	RadioSequenceError	ErrorManager

#### Connector21

<b>Source :</b>	Port	Owner
	RadioSafeRadioConnectionError	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	RadioSafeRadioConnectionError	ErrorManager

#### Connector22

<b>Source :</b>	Port	Owner
	SafetyCriticalFailure	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	SafetyCriticalFailure	ErrorManager

#### Connector23

<b>Source :</b>	Port	Owner
	DoubleLinkingError	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	DoubleLinkingError	ErrorManager

#### Connector24

<b>Source :</b>	Port	Owner
	DoubleRepositioningError	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	DoubleRepositioningError	ErrorManager

#### Connector25

<b>Source :</b>	Port	Owner
	modeLevelStatus	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	modeLevelStatus	PosReport_Supervision

#### Connector26

Source :	Port	Owner
	modeLevelStatus	F2.8 ProvidePositionReport
Target :	Port	Owner
	modeLevelStatus	Build_Packets0_1

#### Connector27

Source :	Port	Owner
	posBGs	F2.8 ProvidePositionReport
Target :	Port	Owner
	posBGs	PosReport_Supervision

#### Connector28

Source :	Port	Owner
	posBGs	F2.8 ProvidePositionReport
Target :	Port	Owner
	posBGs	Build_Packets0_1

#### Connector29

Source :	Port	Owner
	trainPos	F2.8 ProvidePositionReport
Target :	Port	Owner
	trainPos	PosReport_Supervision

#### Connector30

Source :	Port	Owner
	trainPos	F2.8 ProvidePositionReport
Target :	Port	Owner
	trainPos	Build_Packets0_1

#### Connector31

Source :	Port	Owner
	odometry	F2.8 ProvidePositionReport
Target :	Port	Owner
	odometry	PosReport_Supervision

#### Connector32

Source :	Port	Owner
	odometry	F2.8 ProvidePositionReport
Target :	Port	Owner
	odometry	Build_Packets0_1

#### Connector33

<b>Source :</b>	Port	Owner
	trainProps	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	trainProps	Build_SinglePosReport

#### Connector35

<b>Source :</b>	Port	Owner
	trainProps	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	trainProps	Build_Packets0_1

#### Connector36

<b>Source :</b>	Port	Owner
	inMessage	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	inMessage	ReceiveReportParameters

#### Connector37

<b>Source :</b>	Port	Owner
	out_reportedBGs	AddBGTToFIFO
<b>Target :</b>	Port	Owner
	reportedBGs	ReceiveReportParameters

#### Connector38

<b>Source :</b>	Port	Owner
	t_train	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	t_train	Build_SinglePosReport

#### Connector39

<b>Source :</b>	Port	Owner
	prvDirTrain	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	prvDirTrain	Build_Packets0_1

#### Connector41

<b>Source :</b>	Port	Owner
	train2trackStatus	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	train2trackStatus	Build_Packets0_1

#### Connector42

<b>Source :</b>	Port	Owner
	trackInfo	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	trackInfo	PosReport_Supervision

**Connector43**

<b>Source :</b>	Port	Owner
	systemTime	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	systemTime	PosReport_Supervision

**Connector44**

<b>Source :</b>	Port	Owner
	rcbComm	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	rcbComm	PosReport_Supervision

**Connector45**

<b>Source :</b>	Port	Owner
	train2trackStatus	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	train2trackStatus	PosReport_Supervision

**Connector46**

<b>Source :</b>	Port	Owner
	posBGs	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	posBGs	AddBGToFIFO

Connector47

Source :	Port	Owner
	out_reportedBGs	ReceiveReportParameters
Target :	Port	Owner
	reportedBGs	AddBGToFIFO

Connector51

Source :	Port	Owner
	prvDirTrain	F2.8 ProvidePositionReport
Target :	Port	Owner
	prvDirTrain	PosReport_Supervision

Connector52

Source :	Port	Owner
	out_reportedBGs	ReceiveReportParameters
Target :	Port	Owner
	reportedBGs	PosReport_Supervision

Connector53

Source :	Port	Owner
	trainProps	F2.8 ProvidePositionReport
Target :	Port	Owner
	trainProps	PosReport_Supervision

Connector1

Source :	Port	Owner
	reset	F2.3 trainData
Target :	Port	Owner
	reset	trainDataStorage

Connector2

Source :	Port	Owner
	trainDatafromTIU	F2.3 trainData
Target :	Port	Owner
	trainDatafromTIU	trainDataStorage

Connector3

Source :	Port	Owner
	trainDatafromDriver	F2.3 trainData
Target :	Port	Owner
	trainDatafromDriver	trainDataStorage

Connector4

Source :	Port	Owner
	trainDataAckfromDriver	F2.3 trainData
Target :	Port	Owner
	trainDataAckfromDriver	trainDataStorage

#### Connector5

Source :	Port	Owner
	trackMessages	F2.3 trainData
Target :	Port	Owner
	trackMessages	checkRadioMessages

#### Connector6

Source :	Port	Owner
	eventsForTrainData	F2.3 trainData
Target :	Port	Owner
	eventsForTrainData	trainDataStorage

#### Connector7

Source :	Port	Owner
	actualTrainData	trainDataStorage
Target :	Port	Owner
	trainData	sendValidTrainDataRBC

#### Connector8

Source :	Port	Owner
	actualTrainData	trainDataStorage
Target :	Port	Owner
	actualTrainData	F2.3 trainData

#### Connector9

Source :	Port	Owner
	p0_positionReport	F2.3 trainData
Target :	Port	Owner
	p0_positionReport	sendValidTrainDataRBC

#### Connector10

Source :	Port	Owner
	p1_positionReport	F2.3 trainData
Target :	Port	Owner
	p1_positionReport	sendValidTrainDataRBC

#### Connector11



Source :	Port	Owner
	nidEngine	F2.3 trainData
Target :	Port	Owner
	nidEngine	sendValidTrainDataRBC

#### Connector12

Source :	Port	Owner
	nidEngine	F2.3 trainData
Target :	Port	Owner
	nidEngine	sendAcknowledgementRBC

#### Connector13

Source :	Port	Owner
	t_train	F2.3 trainData
Target :	Port	Owner
	evc_t_train	sendValidTrainDataRBC

#### Connector14

Source :	Port	Owner
	t_train	F2.3 trainData
Target :	Port	Owner
	EVC_t_train	sendAcknowledgementRBC

#### Connector15

Source :	Port	Owner
	trackMessages	F2.3 trainData
Target :	Port	Owner
	RBC_timeStamp	sendAcknowledgementRBC

#### Connector16

Source :	Port	Owner
	outMessageBus	sendAcknowledgementRBC
Target :	Port	Owner
	outMessageBus	F2.3 trainData

#### Connector17

Source :	Port	Owner
	outMessageBus	sendValidTrainDataRBC
Target :	Port	Owner
	outMessageBus	F2.3 trainData

#### Connector18

Source :	Port	Owner
	MessageBus	F2.3 trainData
Target :	Port	Owner
	MessageBus	sendAcknowledgementRBC

#### Connector19

Source :	Port	Owner
	MessageBus	F2.3 trainData
Target :	Port	Owner
	MessageBus	sendValidTrainDataRBC

#### Connector1

Source :	Port	Owner
	API_fromTIU	F2 ETCS Kernel
Target :	Port	Owner
	inTIUfromAPI	F2.12 manageTIU_input

#### Connector10

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	systemtime	F2.2 Manage_ETCS_Procedures

#### Connector11

Source :	Port	Owner
	EVC_reset	F2 ETCS Kernel
Target :	Port	Owner
	reset	F2.1 Manage_TrackSideInformation_Integration

#### Connector12

Source :	Port	Owner
	API_fromTrack	F2 ETCS Kernel
Target :	Port	Owner
	API_trackSide_Message	F2.1 Manage_TrackSideInformation_Integration

#### Connector13

Source :	Port	Owner
	API_Odometry	F2 ETCS Kernel
Target :	Port	Owner
	ActualOdometry	F2.1 Manage_TrackSideInformation_Integration

#### Connector30

Source :	Port	Owner
	EVC_reset	F2 ETCS Kernel
Target :	Port	Owner
	reset	F2.3 trainData

#### Connector31

Source :	Port	Owner
	API_fromTrack	F2 ETCS Kernel
Target :	Port	Owner
	trackMessages	F2.3 trainData

#### Connector32

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	t_train	F2.3 trainData

#### Connector38

Source :	Port	Owner
	EVC_reset	F2 ETCS Kernel
Target :	Port	Owner
	reset	F2.6 calculateTrainPosition

#### Connector39

Source :	Port	Owner
	API_Odometry	F2 ETCS Kernel
Target :	Port	Owner
	currentOdometry	F2.6 calculateTrainPosition

#### Connector41

Source :	Port	Owner
	API_fromDMI	F2 ETCS Kernel
Target :	Port	Owner
	fromDMI	F2.10 manageDMI_Input

#### Connector42

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	currentTime	F2.9 MoRC_HO

#### Connector43

Source :	Port	Owner
	EVC_reset	F2 ETCS Kernel
Target :	Port	Owner
	reset	F2.9 MoRC_HO

#### Connector44

Source :	Port	Owner
	to_DMI	F2.11 manageDMI_Output
Target :	Port	Owner
	API_toDMI	F2 ETCS Kernel

#### Connector45

Source :	Port	Owner
	outTIU_to_API	F2.13 manageTIU_output
Target :	Port	Owner
	API_toTIU	F2 ETCS Kernel

#### Connector46

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	trainPosition	F2.1 Manage_TrackSideInformation_Integration

#### Connector50

Source :	Port	Owner
	BGs	F2.6 calculateTrainPosition
Target :	Port	Owner
	inAnnouncedBGs	F2.1 Manage_TrackSideInformation_Integration

Connector51

Source :	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
Target :	Port	Owner
	trainProperties	F2.6 calculateTrainPosition

Connector52

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	trainProperties	F2.6 calculateTrainPosition

Connector53

Source :	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	msgFromTrack	F2.6 calculateTrainPosition

Connector54

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	inTrainPosition	F2.11 manageDMI_Output

Connector55

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	TrainPosition	F2.7 SpeedSupervision_Integration

Connector56

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	trainPos	F2.8 ProvidePositionReport

Connector57

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	Data_From_Localisation	F2.5 ManageLevelAndMode

Connector58

<b>Source :</b>	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	statusValid_Position_from_Position_Calculation	F2.2 Manage_ETCS_Procedures

#### Connector59

<b>Source :</b>	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	prvDirTrain	F2.8 ProvidePositionReport

#### Connector60

<b>Source :</b>	Port	Owner
	BGs	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	posBGs	F2.8 ProvidePositionReport

#### Connector61

<b>Source :</b>	Port	Owner
	errors	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	DoubleRepositioningError	F2.8 ProvidePositionReport

#### Connector62

<b>Source :</b>	Port	Owner
	errors	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	DoubleLinkingError	F2.8 ProvidePositionReport

#### Connector63

<b>Source :</b>	Port	Owner
	errors	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	BG_LinkingConsistencyError	F2.8 ProvidePositionReport

#### Connector64

<b>Source :</b>	Port	Owner
	API_fromDMI	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	fromDMI	F2.10 manageDMI_Input

#### Connector65

<b>Source :</b>	Port	Owner
	EVC_reset	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	dmiStatusReset	F2.10 manageDMI_Input

#### Connector66

<b>Source :</b>	Port	Owner
	API_SystemTime	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	inSystemTime	F2.10 manageDMI_Input

#### Connector67

<b>Source :</b>	Port	Owner
	outStatusList	F2.11 manageDMI_Output
<b>Target :</b>	Port	Owner
	inStatusList	F2.10 manageDMI_Input

#### Connector68

<b>Source :</b>	Port	Owner
	currentDMIStatus	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	statusDMI_from_DMI	F2.2 Manage_ETCS_Procedures

#### Connector69

<b>Source :</b>	Port	Owner
	currentDMIStatus	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	incurrentDMIStatus	F2.11 manageDMI_Output

#### Connector70

<b>Source :</b>	Port	Owner
	currentDMIStatus	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	LevelValid_from_Level_and_Mode_Management	F2.2 Manage_ETCS_Procedures

#### Connector71

<b>Source :</b>	Port	Owner
	outUpdateLevelsDMI	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	dmiUpdateLevelsDMI	F2.11 manageDMI_Output

#### Connector72

<b>Source :</b>	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	trainProperties	F2.9 MoRC_HO

#### Connector73

<b>Source :</b>	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	trainProps	F2.7 SpeedSupervision_Integration

#### Connector74

<b>Source :</b>	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	trainProps	F2.8 ProvidePositionReport

#### Connector75

<b>Source :</b>	Port	Owner
	fromDMI_TrainData	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	trainDatafromDriver	F2.3 trainData

#### Connector76

<b>Source :</b>	Port	Owner
	fromDMI_TrainDataAck	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	trainDataAckfromDriver	F2.3 trainData

#### Connector77

<b>Source :</b>	Port	Owner
	forModesAndLevel	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	Data_From_DMI	F2.5 ManageLevelAndMode

#### Connector78

<b>Source :</b>	Port	Owner
	ML_levelTransition	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	driver_level_transition_In	F2.5 ManageLevelAndMode

#### Connector79



Source :	Port	Owner
	outStatusList	F2.10 manageDMI_Input
Target :	Port	Owner
	inStatusList	F2.11 manageDMI_Output

#### Connector80

Source :	Port	Owner
	outDriverRequest	F2.10 manageDMI_Input
Target :	Port	Owner
	status_DMIIlevel_from_DMI	F2.2 Manage_ETCS_Procedures

#### Connector81

Source :	Port	Owner
	updatedNTC	F2.10 manageDMI_Input
Target :	Port	Owner
	train2trackStatus	F2.8 ProvidePositionReport

#### Connector82

Source :	Port	Owner
	updatedNTC	F2.10 manageDMI_Input
Target :	Port	Owner
	inNTC	F2.11 manageDMI_Output

#### Connector83

Source :	Port	Owner
	API_Odometry	F2 ETCS Kernel
Target :	Port	Owner
	inOdometry	F2.11 manageDMI_Output

#### Connector84

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	inSystemTime	F2.11 manageDMI_Output

#### Connector85

Source :	Port	Owner
	outTIUStatus	F2.12 manageTIU_input
Target :	Port	Owner
	TIU_TrainStatus	F2.11 manageDMI_Output

#### Connector86

<b>Source :</b>	Port	Owner
	brakeCmd	F2.7 SpeedSupervision_Integration
<b>Target :</b>	Port	Owner
	inBrakeCommand	F2.11 manageDMI_Output

#### Connector87

<b>Source :</b>	Port	Owner
	sdmToDMI	F2.7 SpeedSupervision_Integration
<b>Target :</b>	Port	Owner
	inSpeedSupervision	F2.11 manageDMI_Output

#### Connector88

<b>Source :</b>	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	inModeAndLevel	F2.11 manageDMI_Output

#### Connector89

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	trainDataFromEVC	F2.11 manageDMI_Output

#### Connector90

<b>Source :</b>	Port	Owner
	DMI_Entry_Request_to_DMI	F2.2 Manage_ETCS_Procedures
<b>Target :</b>	Port	Owner
	dmi_entryRequest	F2.11 manageDMI_Output

Connector91

Source :	Port	Owner
	BadBaliseMessageToDMI	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	dmi_fromBG	F2.11 manageDMI_Output

Connector93

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	evc_trainData	F2.12 manageTIU_input

Connector94

Source :	Port	Owner
	outTIUStatus	F2.12 manageTIU_input
Target :	Port	Owner
	cabStatus_from_TIU	F2.2 Manage_ETCS_Procedures

Connector95

Source :	Port	Owner
	outTIUStatus	F2.12 manageTIU_input
Target :	Port	Owner
	inActiveCab	F2.1 Manage_TrackSideInformation_Integration

Connector96

Source :	Port	Owner
	outTIUStatus	F2.12 manageTIU_input
Target :	Port	Owner
	Cab_In	F2.5 ManageLevelAndMode

Connector97

Source :	Port	Owner
	outTIUCurrentInfo	F2.12 manageTIU_input
Target :	Port	Owner
	Data_From_TIU	F2.5 ManageLevelAndMode

Connector100

Source :	Port	Owner
	brakeCmd	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	in_brake_command	F2.13 manageTIU_output

Connector101

<b>Source :</b>	Port	Owner
	EB_Requested	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	Emergency_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration

#### Connector102

<b>Source :</b>	Port	Owner
	API_Odometry	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	odometry	F2.7 SpeedSupervision_Integration

#### Connector103

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	trainProps	F2.7 SpeedSupervision_Integration

#### Connector104

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration

#### Connector105

<b>Source :</b>	Port	Owner
	ApplyServiceBrake	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	Service_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration

#### Connector106

<b>Source :</b>	Port	Owner
	API_fromTIU	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	trainDatafromTIU	F2.3 trainData

#### Connector107

<b>Source :</b>	Port	Owner
	outputMessageForRadioAck	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	trackMessages	F2.3 trainData

#### Connector109

<b>Source :</b>	Port	Owner
	packet0	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	p0_positionReport	F2.3 trainData

#### Connector110

<b>Source :</b>	Port	Owner
	packet1	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	p1_positionReport	F2.3 trainData

#### Connector111

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	trainProps	F2.8 ProvidePositionReport

#### Connector112

<b>Source :</b>	Port	Owner
	updatedStatus	F2.3 trainData
<b>Target :</b>	Port	Owner
	inFilterEvents	F2.1 Manage_TrackSideInformation_Integration

#### Connector113

<b>Source :</b>	Port	Owner
	updatedStatus	F2.3 trainData
<b>Target :</b>	Port	Owner
	inTrainDataValid	F2.1 Manage_TrackSideInformation_Integration

#### Connector116

<b>Source :</b>	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	inMessage	F2.8 ProvidePositionReport

#### Connector117

<b>Source :</b>	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	LinkedBG_MessageConsistencyError	F2.8 ProvidePositionReport

#### Connector118

<b>Source :</b>	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	UnlinkedBG_MessageConsistencyError	F2.8 ProvidePositionReport

#### Connector119

<b>Source :</b>	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	RadioMessageConsistencyError	F2.8 ProvidePositionReport

#### Connector120

<b>Source :</b>	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	RadioSequenceError	F2.8 ProvidePositionReport

#### Connector121

<b>Source :</b>	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	Data_From_F2_Functions	F2.5 ManageLevelAndMode

#### Connector123

<b>Source :</b>	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	StatusModeandLevel_from_Level_and_Mode_Managem	F2.2 Manage_ETCS_Procedures

#### Connector125

<b>Source :</b>	Port	Owner
	API_SystemTime	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	systemTime	F2.8 ProvidePositionReport

#### Connector126

<b>Source :</b>	Port	Owner
	API_Odometry	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	odometry	F2.8 ProvidePositionReport

#### Connector127

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	in_train_commands	F2.13 manageTIU_output

#### Connector128

Source :	Port	Owner
	Data_To_DMI_Ack	F2.5 ManageLevelAndMode
Target :	Port	Owner
	inModeLevel_Ack	F2.11 manageDMI_Output

#### Connector129

Source :	Port	Owner
	announcedLevel	F2.5 ManageLevelAndMode
Target :	Port	Owner
	announcedLevel	F2.11 manageDMI_Output

#### Connector130

Source :	Port	Owner
	Service_Brake_Command	F2.5 ManageLevelAndMode
Target :	Port	Owner
	Service_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration

#### Connector131

Source :	Port	Owner
	Data_to_From_Track_Packets_at_ML	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	Data_From_Track_Packets	F2.5 ManageLevelAndMode

#### Connector132

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	modeAndLevel	F2.1 Manage_TrackSideInformation_Integration

#### Connector133

Source :	Port	Owner
	forLevelManagement	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	Data_from_Track_MASSPGradient	F2.5 ManageLevelAndMode

#### Connector134

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	modeLevelStatus	F2.8 ProvidePositionReport

#### Connector135

Source :	Port	Owner
	posRep	F2.8 ProvidePositionReport
Target :	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

#### Connector150

Source :	Port	Owner
	outMessageBus	F2.3 trainData
Target :	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

#### Connector157

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	transitionPositionPassed	F2.1 Manage_TrackSideInformation_Integration

#### Connector161

Source :	Port	Owner
	errors	F2.6 calculateTrainPosition
Target :	Port	Owner
	Data_From_Localisation	F2.5 ManageLevelAndMode



Connector162

Source :	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	MessageIn	F2.4 TrackAtlas

Connector163

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	ModeAndLevel_in	F2.4 TrackAtlas

Connector164

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	TrainData_in	F2.4 TrackAtlas

Connector165

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	train_length	F2.4 TrackAtlas

Connector166

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	TrainPositionIn	F2.4 TrackAtlas

Connector167

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	SystemTime	F2.4 TrackAtlas

Connector168

Source :	Port	Owner
	API_Odometry	F2 ETCS Kernel
Target :	Port	Owner
	odometry	F2.4 TrackAtlas

Connector169

Source :	Port	Owner
	sdmToDMI	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	preindicationLocation	F2.4 TrackAtlas

#### Connector170

Source :	Port	Owner
	outForMA	F2.10 managedDMI_Input
Target :	Port	Owner
	fromDriverToMA_R	F2.4 TrackAtlas

#### Connector171

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	trainProps	F2.4 TrackAtlas

#### Connector172

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	trainProps	F2.4 TrackAtlas

#### Connector173

Source :	Port	Owner
	packet0	F2.8 ProvidePositionReport
Target :	Port	Owner
	packet0	F2.4 TrackAtlas

#### Connector174

Source :	Port	Owner
	packet1	F2.8 ProvidePositionReport
Target :	Port	Owner
	packet1	F2.4 TrackAtlas

#### Connector175

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	t_train	F2.4 TrackAtlas

#### Connector178

<b>Source :</b>	Port	Owner
	To_ModeAndLevel	F2.4 TrackAtlas
<b>Target :</b>	Port	Owner
	Data_From_Track_Messages	F2.5 ManageLevelAndMode

#### Connector179

<b>Source :</b>	Port	Owner
	to_DMI	F2.4 TrackAtlas
<b>Target :</b>	Port	Owner
	dmi_trackDescription	F2.11 manageDMI_Output

#### Connector180

<b>Source :</b>	Port	Owner
	to_Supervision	F2.4 TrackAtlas
<b>Target :</b>	Port	Owner
	dataFromTrackAtlas	F2.7 SpeedSupervision_Integration

#### Connector181

<b>Source :</b>	Port	Owner
	MA_request_out	F2.4 TrackAtlas
<b>Target :</b>	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

#### Connector183

<b>Source :</b>	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	trainProps	F2.4 TrackAtlas

#### Connector185

<b>Source :</b>	Port	Owner
	API_Odometry	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	Data_From_Localisation	F2.5 ManageLevelAndMode

#### Connector188

<b>Source :</b>	Port	Owner
	outMessageBus	F2.3 trainData
<b>Target :</b>	Port	Owner
	bus_in	F2.4 TrackAtlas

#### Connector190

Source :	Port	Owner
	bus_out	F2.4 TrackAtlas
Target :	Port	Owner
	MessageBus	F2.8 ProvidePositionReport

#### Connector191

Source :	Port	Owner
	API_mobileHWStatus	F2 ETCS Kernel
Target :	Port	Owner
	mobileRegistrationContext_1	F2.9 MoRC_HO

#### Connector192

Source :	Port	Owner
	API_mobileHWStatus	F2 ETCS Kernel
Target :	Port	Owner
	mobileConnectionContext_1	F2.9 MoRC_HO

#### Connector193

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	mode	F2.9 MoRC_HO

#### Connector194

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	level	F2.9 MoRC_HO

#### Connector195

Source :	Port	Owner
	powerUp_to_MoRC	F2.2 Manage_ETCS_Procedures
Target :	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector196

Source :	Port	Owner
	statusstartofmissionongoing_to_MoRC	F2.2 Manage_ETCS_Procedures
Target :	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector197

Source :	Port	Owner
	powerOff_to_MoRC	F2.2 Manage_ETCS_Procedures
Target :	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector198

Source :	Port	Owner
	request_Start_Mobile_Terminal_and_RBC_Registration_	F2.2 Manage_ETCS_Procedures
Target :	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector199

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector200

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	t_train	F2.9 MoRC_HO

#### Connector201

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	t_train_global	F2.9 MoRC_HO

#### Connector202

Source :	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	dataFromTrack_in	F2.9 MoRC_HO

#### Connector203

Source :	Port	Owner
	posReport	F2.8 ProvidePositionReport
Target :	Port	Owner
	msgBusToRBC_in	F2.9 MoRC_HO

#### Connector204

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	trainPosition	F2.9 MoRC_HO

#### Connector205

Source :	Port	Owner
	BGs	F2.6 calculateTrainPosition
Target :	Port	Owner
	BGs	F2.9 MoRC_HO

#### Connector206

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	trainProperties	F2.9 MoRC_HO

#### Connector207

Source :	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
Target :	Port	Owner
	mobileStatus	F2.2 Manage_ETCS_Procedures

#### Connector208

Source :	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
Target :	Port	Owner
	radioStatus	F2.1 Manage_TrackSideInformation_Integration

**Connector209**

<b>Source :</b>	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	inMoRC_status	F2.11 manageDMI_Output

**Connector210**

<b>Source :</b>	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	eventsForTrainData	F2.3 trainData

**Connector211**

<b>Source :</b>	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	rcbComm	F2.8 ProvidePositionReport

**Connector212**

<b>Source :</b>	Port	Owner
	mobileConnectionCmd_1	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

**Connector213**

<b>Source :</b>	Port	Owner
	mobileRegistrationCmd_1	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

**Connector214**

<b>Source :</b>	Port	Owner
	supervisingRBC	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	inSupervisingRbcmd	F2.1 Manage_TrackSideInformation_Integration

**Connector215**

<b>Source :</b>	Port	Owner
	ready	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	eventsForTrainData	F2.3 trainData

**Connector216**

<b>Source :</b>	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	intrainVersion	F2.1 Manage_TrackSideInformation_Integration

#### Connector217

<b>Source :</b>	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	q_nvlocacc	F2.1 Manage_TrackSideInformation_Integration

#### Connector218

<b>Source :</b>	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	tNvContact	F2.1 Manage_TrackSideInformation_Integration

#### Connector219

<b>Source :</b>	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	nidEngine	F2.3 trainData

#### Connector220

<b>Source :</b>	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	P203V1_onboard	F2.4 TrackAtlas

#### Connector221

<b>Source :</b>	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	PermanentDataP003	F2.4 TrackAtlas

#### Connector222

<b>Source :</b>	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	ERTMS_capabilities_In	F2.5 ManageLevelAndMode

#### Connector223



<b>Source :</b>	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	Data_From_STM	F2.5 ManageLevelAndMode

#### Connector224

<b>Source :</b>	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration

#### Connector225

<b>Source :</b>	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	t_train	F2.8 ProvidePositionReport

#### Connector1

<b>Source :</b>	Port	Owner
	TracksideOut	F1 Receive Information from Trackside
<b>Target :</b>	Port	Owner
	API_fromTrack	F2 ETCS Kernel

#### Connector2

<b>Source :</b>	Port	Owner
	DMIOut	F6 DMI Controller
<b>Target :</b>	Port	Owner
	API_fromDMI	F2 ETCS Kernel

#### Connector3

<b>Source :</b>	Port	Owner
	API_toDMI	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	DMIIn	F6 DMI Controller

#### Connector4

<b>Source :</b>	Port	Owner
	API_toTIU	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	TIUIn	F7 TIU Controller

#### Connector5

Source :	Port	Owner
	TIUOut	F7 TIU Controller
Target :	Port	Owner
	API_fromTIU	F2 ETCS Kernel

#### Connector6

Source :	Port	Owner
	API_toEuroradio	F2 ETCS Kernel
Target :	Port	Owner
	RadioIn	F4 Radio Communication Controller

#### Connector7

Source :	Port	Owner
	RadioOut	F4 Radio Communication Controller
Target :	Port	Owner
	API_mobileHWStatus	F2 ETCS Kernel

#### Connector8

Source :	Port	Owner
	OdometryOut	F3 Measure Train Movement
Target :	Port	Owner
	API_Odometry	F2 ETCS Kernel

#### Connector14

Source :	Port	Owner
	RBCBTMIn	ETCS OBU
Target :	Port	Owner
	RBCBTMIn	F1 Receive Information from Trackside

#### Connector17

Source :	Port	Owner
	OdometryIn	ETCS OBU
Target :	Port	Owner
	OdometryIn	F3 Measure Train Movement

#### Connector19

Source :	Port	Owner
	PersistentDataOut	F8 Persistent Data
Target :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel

#### Connector20

<b>Source :</b>	Port	Owner
	API_persistentDataOut	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	PersistentDataIn	F8 Persistent Data

#### Connector1

<b>Source :</b>	Port	Owner
	trackSide_ForCheck	CheckBGConsistency
<b>Target :</b>	Port	Owner
	trackSideForCheck	CaseLinkingNotInUse1

#### Connector2

<b>Source :</b>	Port	Owner
	trackSide_ForCheck	CheckBGConsistency
<b>Target :</b>	Port	Owner
	trackSideForCheck	CaseLinkingInUse1

#### Connector3

<b>Source :</b>	Port	Owner
	errorUnlinkedBG	CaseLinkingNotInUse1
<b>Target :</b>	Port	Owner
	errorUnlinkedBG	CheckBGConsistency

#### Connector4

<b>Source :</b>	Port	Owner
	applyServiceBrake	CaseLinkingNotInUse1
<b>Target :</b>	Port	Owner
	applyServiceBrake	CheckBGConsistency

#### Connector5

<b>Source :</b>	Port	Owner
	errorLinkedBG	CaseLinkingInUse1
<b>Target :</b>	Port	Owner
	errorLinkedBG	CheckBGConsistency

#### Connector6

<b>Source :</b>	Port	Owner
	passedBG_out	CaseLinkingNotInUse1
<b>Target :</b>	Port	Owner
	passedBG_out	CheckBGConsistency

#### Connector7

Source :	Port	Owner
	passedBG_out	CaseLinkingInUse1
Target :	Port	Owner
	passedBG_out	CheckBGConsistency

#### Connector1

Source :	Port	Owner
	reset	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	reset	Receive_TrackSide_Msg

#### Connector2

Source :	Port	Owner
	API_trackSide_Message	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	API_TrackSide_Msg	Receive_TrackSide_Msg

#### Connector3

Source :	Port	Owner
	inActiveCab	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	inActualOdometry	Receive_TrackSide_Msg

#### Connector4

Source :	Port	Owner
	outTrackMessage_for_check	Receive_TrackSide_Msg
Target :	Port	Owner
	trackSide_ForCheck	CheckBGConsistency

Connector5

Source :	Port	Owner
	applyServiceBrake	CheckBGConsistency
Target :	Port	Owner
	ApplyServiceBrake	F2.1 Manage_TrackSideInformation_Integration

Connector6

Source :	Port	Owner
	outTrackMessage_for_check	Receive_TrackSide_Msg
Target :	Port	Owner
	rtmMessage	CheckEuroRadioMessage

Connector7

Source :	Port	Owner
	outMessage	InformationFilter
Target :	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration

Connector8

Source :	Port	Owner
	inTrainDataValid	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	inTrainDataValid	InformationFilter

Connector9

Source :	Port	Owner
	passedBG_out	CheckBGConsistency
Target :	Port	Owner
	inMessage	validateDataDirection

Connector10

Source :	Port	Owner
	checkedMessage	CheckEuroRadioMessage
Target :	Port	Owner
	inMessage	validateDataDirection

Connector11

Source :	Port	Owner
	outMessage	validateDataDirection
Target :	Port	Owner
	inMessage	InformationFilter

Connector12

Source :	Port	Owner
	inActiveCab	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	inActiveCab	InformationFilter

#### Connector13

Source :	Port	Owner
	intrainVersion	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	trainVersion	CheckBGConsistency

#### Connector14

Source :	Port	Owner
	trainPosition	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	trainPosition	CheckBGConsistency

#### Connector15

Source :	Port	Owner
	inFilterEvents	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	inFilterEvents	InformationFilter

#### Connector16

Source :	Port	Owner
	outPacketsForML	InformationFilter
Target :	Port	Owner
	Data_to_From_Track_Packets_at_ML	F2.1 Manage_TrackSideInformation_Integration

#### Connector17

Source :	Port	Owner
	ActualOdometry	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	inActualOdometry	Receive_TrackSide_Msg

#### Connector1

Source :	Port	Owner
	TrainPosition	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	TrainPosition	InputWrapper

#### Connector3

Source :	Port	Owner
	trainProps	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	trainProps	InputWrapper

#### Connector4

Source :	Port	Owner
	dataFromTrackAtlas	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	dataFromTrackAtlas	InputWrapper

#### Connector11

Source :	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	ABrakeFactory

#### Connector12

Source :	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	trainData	ABrakeFactory

#### Connector13

Source :	Port	Owner
	mrsp_out	InputWrapper
Target :	Port	Owner
	MRSP	TargetManagement

#### Connector14

Source :	Port	Owner
	mrsp_update_out	InputWrapper
Target :	Port	Owner
	MRSP_updated	TargetManagement

#### Connector15

Source :	Port	Owner
	ma_out	InputWrapper
Target :	Port	Owner
	MA	TargetManagement

#### Connector16

Source :	Port	Owner
	ma_update_out	InputWrapper
Target :	Port	Owner
	MA_updated	TargetManagement

#### Connector17

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	trainLocations	TargetManagement

#### Connector18

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	TrainLocations	CalcBrakingCurves

#### Connector19

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	CalcBrakingCurves

#### Connector22

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	LimitLocations

#### Connector23

Source :	Port	Owner
	mrsp_out	InputWrapper
Target :	Port	Owner
	MRSP_Profile	LimitLocations

#### Connector24

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	trainLocations	LimitLocations

#### Connector26



Source :	Port	Owner
	curveCollection	CalcBrakingCurves
Target :	Port	Owner
	curveCollection	LimitLocations

#### Connector27

Source :	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	LimitLocations

#### Connector29

Source :	Port	Owner
	T_b	ABrakeFactory
Target :	Port	Owner
	T_b	LimitLocations

#### Connector30

Source :	Port	Owner
	ma_out	InputWrapper
Target :	Port	Owner
	MA	LimitLocations

#### Connector35

Source :	Port	Owner
	locations	LimitLocations
Target :	Port	Owner
	locations	Commands

#### Connector36

Source :	Port	Owner
	speeds	LimitLocations
Target :	Port	Owner
	speeds	Commands

#### Connector37

Source :	Port	Owner
	MostRestrictiveDisplayedTarget	LimitLocations
Target :	Port	Owner
	mrdt	Commands

#### Connector38

Source :	Port	Owner
	FLOlisSB11	LimitLocations
Target :	Port	Owner
	floilsSB1	Commands

#### Connector43

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	allTargets	Commands

#### Connector46

Source :	Port	Owner
	MostRestrictiveDisplayedTarget	LimitLocations
Target :	Port	Owner
	target	F2.7 SpeedSupervision_Integration

#### Connector47

Source :	Port	Owner
	sdmToDMI	Commands
Target :	Port	Owner
	sdmToDMI	F2.7 SpeedSupervision_Integration

#### Connector48

Source :	Port	Owner
	brakeCmd	Commands
Target :	Port	Owner
	brakeCmd	F2.7 SpeedSupervision_Integration

Connector49

Source :	Port	Owner
	sdmCmd	Commands
Target :	Port	Owner
	sdmCommands	F2.7 SpeedSupervision_Integration

Connector50

Source :	Port	Owner
	targetSpeedReached	Commands
Target :	Port	Owner
	Target_Speed_Reached	F2.7 SpeedSupervision_Integration

Connector51

Source :	Port	Owner
	eoasOverpassed	Commands
Target :	Port	Owner
	EOA_overpassed	F2.7 SpeedSupervision_Integration

Connector52

Source :	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	Commands

Connector53

Source :	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	TrainData_int	Commands

Connector54

Source :	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	trainData_int	LimitLocations

Connector55

Source :	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	LimitLocations

Connector56

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	trainLocations	LimitLocations

#### Connector57

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	TrainLocations	CalcBrakingCurves

#### Connector58

Source :	Port	Owner
	Service_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	MLrequestSB	Commands

#### Connector59

Source :	Port	Owner
	Emergency_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	MLrequestEB	Commands

#### Connector60

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	allTargets	Commands

#### Connector61

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	LimitLocations

#### Connector62

Source :	Port	Owner
	ma_out	InputWrapper
Target :	Port	Owner
	MA	LimitLocations

#### Connector63

Source :	Port	Owner
	mrsp_out	InputWrapper
Target :	Port	Owner
	MRSP_Profile	LimitLocations

#### Connector64

Source :	Port	Owner
	odometry	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	odometry	LimitLocations

#### Connector65

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	AGradient

#### Connector66

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	TrainLocations	AGradient

#### Connector67

Source :	Port	Owner
	gp_out	InputWrapper
Target :	Port	Owner
	GradientProfile	AGradient

#### Connector68

Source :	Port	Owner
	gp_update_out	InputWrapper
Target :	Port	Owner
	GradientProfile_updated	AGradient

#### Connector69

Source :	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	trainData	AGradient

#### Connector70

Source :	Port	Owner
	aBrakeSafe	ABrakeFactory
Target :	Port	Owner
	aBrakeSafe	addGradient1

#### Connector71

Source :	Port	Owner
	aBrakeService	ABrakeFactory
Target :	Port	Owner
	aBrakeSafe	addGradient2

#### Connector72

Source :	Port	Owner
	aSafe	addGradient1
Target :	Port	Owner
	A_Safe	CalcBrakingCurves

#### Connector73

Source :	Port	Owner
	aSafe	addGradient2
Target :	Port	Owner
	A_Expected	CalcBrakingCurves

#### Connector74

Source :	Port	Owner
	A_gradient	AGradient
Target :	Port	Owner
	aGradient	addGradient1

#### Connector75

Source :	Port	Owner
	A_gradient	AGradient
Target :	Port	Owner
	aGradient	addGradient2

#### Connector1

Source :	Port	Owner
	packet0	Build_SinglePosReport
Target :	Port	Owner
	inPacket0	AggregatePackets

#### Connector2

Source :	Port	Owner
	packet1	Build_SinglePosReport

Target :	Port	Owner
	inPacket1	AggregatePackets

#### Connector3

Source :	Port	Owner
	packet4	Build_SinglePosReport

Target :	Port	Owner
	inPacket4	AggregatePackets

#### Connector4

Source :	Port	Owner
	packet5	Build_SinglePosReport

Target :	Port	Owner
	inPacket5	AggregatePackets

#### Connector6

Source :	Port	Owner
	present	ReceiveReportParameters

Target :	Port	Owner
	present	PosReport_Supervision

#### Connector7

Source :	Port	Owner
	posRepParam	ReceiveReportParameters

Target :	Port	Owner
	posRepParam	PosReport_Supervision

#### Connector9

Source :	Port	Owner
	trigger	PosReport_Supervision

Target :	Port	Owner
	reportIsSent	AddBGToFIFO

#### Connector10

Source :	Port	Owner
	posRepHeader	Build_SinglePosReport

Target :	Port	Owner
	posRep	F2.8 ProvidePositionReport

#### Connector11

Source :	Port	Owner
	packet0	Build_Packets0_1
Target :	Port	Owner
	in_packet0	Build_SinglePosReport

#### Connector12

Source :	Port	Owner
	packet1	Build_Packets0_1
Target :	Port	Owner
	in_packet1	Build_SinglePosReport

#### Connector13

Source :	Port	Owner
	packet0	Build_Packets0_1
Target :	Port	Owner
	packet0	F2.8 ProvidePositionReport

#### Connector14

Source :	Port	Owner
	packet1	Build_Packets0_1
Target :	Port	Owner
	packet1	F2.8 ProvidePositionReport

#### Connector15

Source :	Port	Owner
	errorVector	ErrorManager
Target :	Port	Owner
	errorMsg	Build_SinglePosReport



Connector16

Source :	Port	Owner
	BG_LinkingConsistencyError	F2.8 ProvidePositionReport
Target :	Port	Owner
	BG_LinkingConsistencyError	ErrorManager

Connector17

Source :	Port	Owner
	LinkedBG_MessageConsistencyError	F2.8 ProvidePositionReport
Target :	Port	Owner
	LinkedBG_MessageConsistencyError	ErrorManager

Connector18

Source :	Port	Owner
	UnlinkedBG_MessageConsistencyError	F2.8 ProvidePositionReport
Target :	Port	Owner
	UnlinkedBG_MessageConsistencyError	ErrorManager

Connector19

Source :	Port	Owner
	RadioMessageConsistencyError	F2.8 ProvidePositionReport
Target :	Port	Owner
	RadioMessageConsistencyError	ErrorManager

Connector20

Source :	Port	Owner
	RadioSequenceError	F2.8 ProvidePositionReport
Target :	Port	Owner
	RadioSequenceError	ErrorManager

Connector21

Source :	Port	Owner
	RadioSafeRadioConnectionError	F2.8 ProvidePositionReport
Target :	Port	Owner
	RadioSafeRadioConnectionError	ErrorManager

Connector22

Source :	Port	Owner
	SafetyCriticalFailure	F2.8 ProvidePositionReport
Target :	Port	Owner
	SafetyCriticalFailure	ErrorManager

Connector23

<b>Source :</b>	Port	Owner
	DoubleLinkingError	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	DoubleLinkingError	ErrorManager

#### Connector24

<b>Source :</b>	Port	Owner
	DoubleRepositioningError	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	DoubleRepositioningError	ErrorManager

#### Connector25

<b>Source :</b>	Port	Owner
	modeLevelStatus	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	modeLevelStatus	PosReport_Supervision

#### Connector26

<b>Source :</b>	Port	Owner
	modeLevelStatus	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	modeLevelStatus	Build_Packets0_1

#### Connector27

<b>Source :</b>	Port	Owner
	posBGs	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	posBGs	PosReport_Supervision

#### Connector28

<b>Source :</b>	Port	Owner
	posBGs	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	posBGs	Build_Packets0_1

#### Connector29

<b>Source :</b>	Port	Owner
	trainPos	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	trainPos	PosReport_Supervision

#### Connector30

<b>Source :</b>	Port	Owner
	trainPos	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	trainPos	Build_Packets0_1

#### Connector31

<b>Source :</b>	Port	Owner
	odometry	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	odometry	PosReport_Supervision

#### Connector32

<b>Source :</b>	Port	Owner
	odometry	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	odometry	Build_Packets0_1

#### Connector33

<b>Source :</b>	Port	Owner
	trainProps	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	trainProps	Build_SinglePosReport

#### Connector35

<b>Source :</b>	Port	Owner
	trainProps	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	trainProps	Build_Packets0_1

#### Connector36

<b>Source :</b>	Port	Owner
	inMessage	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	inMessage	ReceiveReportParameters

#### Connector37

<b>Source :</b>	Port	Owner
	out_reportedBGs	AddBGToFIFO
<b>Target :</b>	Port	Owner
	reportedBGs	ReceiveReportParameters

#### Connector38

Source :	Port	Owner
	t_train	F2.8 ProvidePositionReport
Target :	Port	Owner
	t_train	Build_SinglePosReport

#### Connector39

Source :	Port	Owner
	prvDirTrain	F2.8 ProvidePositionReport
Target :	Port	Owner
	prvDirTrain	Build_Packets0_1

#### Connector41

Source :	Port	Owner
	train2trackStatus	F2.8 ProvidePositionReport
Target :	Port	Owner
	train2trackStatus	Build_Packets0_1

#### Connector42

Source :	Port	Owner
	trackInfo	F2.8 ProvidePositionReport
Target :	Port	Owner
	trackInfo	PosReport_Supervision

#### Connector43

Source :	Port	Owner
	systemTime	F2.8 ProvidePositionReport
Target :	Port	Owner
	systemTime	PosReport_Supervision

#### Connector44

Source :	Port	Owner
	rcbComm	F2.8 ProvidePositionReport
Target :	Port	Owner
	rcbComm	PosReport_Supervision

#### Connector45

Source :	Port	Owner
	train2trackStatus	F2.8 ProvidePositionReport
Target :	Port	Owner
	train2trackStatus	PosReport_Supervision

#### Connector46

Source :	Port	Owner
	posBGs	F2.8 ProvidePositionReport
Target :	Port	Owner
	posBGs	AddBGTToFIFO

#### Connector47

Source :	Port	Owner
	out_reportedBGs	ReceiveReportParameters
Target :	Port	Owner
	reportedBGs	AddBGTToFIFO

#### Connector51

Source :	Port	Owner
	prvDirTrain	F2.8 ProvidePositionReport
Target :	Port	Owner
	prvDirTrain	PosReport_Supervision

#### Connector52

Source :	Port	Owner
	out_reportedBGs	ReceiveReportParameters
Target :	Port	Owner
	reportedBGs	PosReport_Supervision

#### Connector53

Source :	Port	Owner
	trainProps	F2.8 ProvidePositionReport
Target :	Port	Owner
	trainProps	PosReport_Supervision

#### Connector1

Source :	Port	Owner
	reset	F2.3 trainData
Target :	Port	Owner
	reset	trainDataStorage

#### Connector2

Source :	Port	Owner
	trainDatafromTIU	F2.3 trainData
Target :	Port	Owner
	trainDatafromTIU	trainDataStorage

#### Connector3

<b>Source :</b>	Port	Owner
	trainDatafromDriver	F2.3 trainData

<b>Target :</b>	Port	Owner
	trainDatafromDriver	trainDataStorage

#### Connector4

<b>Source :</b>	Port	Owner
	trainDataAckfromDriver	F2.3 trainData

<b>Target :</b>	Port	Owner
	trainDataAckfromDriver	trainDataStorage

#### Connector5

<b>Source :</b>	Port	Owner
	trackMessages	F2.3 trainData

<b>Target :</b>	Port	Owner
	trackMessages	checkRadioMessages

#### Connector6

<b>Source :</b>	Port	Owner
	eventsForTrainData	F2.3 trainData

<b>Target :</b>	Port	Owner
	eventsForTrainData	trainDataStorage

#### Connector7

<b>Source :</b>	Port	Owner
	actualTrainData	trainDataStorage

<b>Target :</b>	Port	Owner
	trainData	sendValidTrainDataRBC

Connector8

Source :	Port	Owner
	actualTrainData	trainDataStorage
Target :	Port	Owner
	actualTrainData	F2.3 trainData

Connector9

Source :	Port	Owner
	p0_positionReport	F2.3 trainData
Target :	Port	Owner
	p0_positionReport	sendValidTrainDataRBC

Connector10

Source :	Port	Owner
	p1_positionReport	F2.3 trainData
Target :	Port	Owner
	p1_positionReport	sendValidTrainDataRBC

Connector11

Source :	Port	Owner
	nidEngine	F2.3 trainData
Target :	Port	Owner
	nidEngine	sendValidTrainDataRBC

Connector12

Source :	Port	Owner
	nidEngine	F2.3 trainData
Target :	Port	Owner
	nidEngine	sendAcknowledgementRBC

Connector13

Source :	Port	Owner
	t_train	F2.3 trainData
Target :	Port	Owner
	evc_t_train	sendValidTrainDataRBC

Connector14

Source :	Port	Owner
	t_train	F2.3 trainData
Target :	Port	Owner
	EVC_t_train	sendAcknowledgementRBC

Connector15

Source :	Port	Owner
	trackMessages	F2.3 trainData
Target :	Port	Owner
	RBC_timeStamp	sendAcknowledgementRBC

#### Connector16

Source :	Port	Owner
	outMessageBus	sendAcknowledgementRBC
Target :	Port	Owner
	outMessageBus	F2.3 trainData

#### Connector17

Source :	Port	Owner
	outMessageBus	sendValidTrainDataRBC
Target :	Port	Owner
	outMessageBus	F2.3 trainData

#### Connector18

Source :	Port	Owner
	MessageBus	F2.3 trainData
Target :	Port	Owner
	MessageBus	sendAcknowledgementRBC

#### Connector19

Source :	Port	Owner
	MessageBus	F2.3 trainData
Target :	Port	Owner
	MessageBus	sendValidTrainDataRBC

#### Connector1

Source :	Port	Owner
	API_fromTIU	F2 ETCS Kernel
Target :	Port	Owner
	inTIUfromAPI	F2.12 manageTIU_input

#### Connector10

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	systemtime	F2.2 Manage_ETCS_Procedures

#### Connector11



Source :	Port	Owner
	EVC_reset	F2 ETCS Kernel
Target :	Port	Owner
	reset	F2.1 Manage_TrackSideInformation_Integration

#### Connector12

Source :	Port	Owner
	API_fromTrack	F2 ETCS Kernel
Target :	Port	Owner
	API_trackSide_Message	F2.1 Manage_TrackSideInformation_Integration

#### Connector13

Source :	Port	Owner
	API_Odometry	F2 ETCS Kernel
Target :	Port	Owner
	ActualOdometry	F2.1 Manage_TrackSideInformation_Integration

#### Connector30

Source :	Port	Owner
	EVC_reset	F2 ETCS Kernel
Target :	Port	Owner
	reset	F2.3 trainData

#### Connector31

Source :	Port	Owner
	API_fromTrack	F2 ETCS Kernel
Target :	Port	Owner
	trackMessages	F2.3 trainData

#### Connector32

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	t_train	F2.3 trainData

#### Connector38

Source :	Port	Owner
	EVC_reset	F2 ETCS Kernel
Target :	Port	Owner
	reset	F2.6 calculateTrainPosition

#### Connector39

Source :	Port	Owner
	API_Odometry	F2 ETCS Kernel
Target :	Port	Owner
	currentOdometry	F2.6 calculateTrainPosition

#### Connector41

Source :	Port	Owner
	API_fromDMI	F2 ETCS Kernel
Target :	Port	Owner
	fromDMI	F2.10 manageDMI_Input

#### Connector42

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	currentTime	F2.9 MoRC_HO

#### Connector43

Source :	Port	Owner
	EVC_reset	F2 ETCS Kernel
Target :	Port	Owner
	reset	F2.9 MoRC_HO

#### Connector44

Source :	Port	Owner
	to_DMI	F2.11 manageDMI_Output
Target :	Port	Owner
	API_toDMI	F2 ETCS Kernel

#### Connector45

Source :	Port	Owner
	outTIU_to_API	F2.13 manageTIU_output
Target :	Port	Owner
	API_toTIU	F2 ETCS Kernel

#### Connector46

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	trainPosition	F2.1 Manage_TrackSideInformation_Integration

#### Connector50

Source :	Port	Owner
	BGs	F2.6 calculateTrainPosition
Target :	Port	Owner
	inAnnouncedBGs	F2.1 Manage_TrackSideInformation_Integration

#### Connector51

Source :	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
Target :	Port	Owner
	trainProperties	F2.6 calculateTrainPosition

#### Connector52

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	trainProperties	F2.6 calculateTrainPosition

#### Connector53

Source :	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	msgFromTrack	F2.6 calculateTrainPosition

#### Connector54

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	inTrainPosition	F2.11 manageDMI_Output

#### Connector55

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	TrainPosition	F2.7 SpeedSupervision_Integration

#### Connector56

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	trainPos	F2.8 ProvidePositionReport

#### Connector57

<b>Source :</b>	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	Data_From_Localisation	F2.5 ManageLevelAndMode

#### Connector58

<b>Source :</b>	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	statusValid_Position_from_Position_Calculation	F2.2 Manage_ETCS_Procedures

#### Connector59

<b>Source :</b>	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	prvDirTrain	F2.8 ProvidePositionReport

#### Connector60

<b>Source :</b>	Port	Owner
	BGs	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	posBGs	F2.8 ProvidePositionReport

#### Connector61

<b>Source :</b>	Port	Owner
	errors	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	DoubleRepositioningError	F2.8 ProvidePositionReport

Connector62

Source :	Port	Owner
	errors	F2.6 calculateTrainPosition
Target :	Port	Owner
	DoubleLinkingError	F2.8 ProvidePositionReport

Connector63

Source :	Port	Owner
	errors	F2.6 calculateTrainPosition
Target :	Port	Owner
	BG_LinkingConsistencyError	F2.8 ProvidePositionReport

Connector64

Source :	Port	Owner
	API_fromDMI	F2 ETCS Kernel
Target :	Port	Owner
	fromDMI	F2.10 manageDMI_Input

Connector65

Source :	Port	Owner
	EVC_reset	F2 ETCS Kernel
Target :	Port	Owner
	dmiStatusReset	F2.10 manageDMI_Input

Connector66

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	inSystemTime	F2.10 manageDMI_Input

Connector67

Source :	Port	Owner
	outStatusList	F2.11 manageDMI_Output
Target :	Port	Owner
	inStatusList	F2.10 manageDMI_Input

Connector68

Source :	Port	Owner
	currentDMISStatus	F2.10 manageDMI_Input
Target :	Port	Owner
	statusDMI_from_DMI	F2.2 Manage_ETCS_Procedures

Connector69

Source :	Port	Owner
	currentDMIStatus	F2.10 manageDMI_Input
Target :	Port	Owner
	incurrentDMIStatus	F2.11 manageDMI_Output

#### Connector70

Source :	Port	Owner
	currentDMIStatus	F2.10 manageDMI_Input
Target :	Port	Owner
	LevelValid_from_Level_and_Mode_Management	F2.2 Manage_ETCS_Procedures

#### Connector71

Source :	Port	Owner
	outUpdateLevelsDMI	F2.10 manageDMI_Input
Target :	Port	Owner
	dmiUpdateLevelsDMI	F2.11 manageDMI_Output

#### Connector72

Source :	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
Target :	Port	Owner
	trainProperties	F2.9 MoRC_HO

#### Connector73

Source :	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
Target :	Port	Owner
	trainProps	F2.7 SpeedSupervision_Integration

#### Connector74

Source :	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
Target :	Port	Owner
	trainProps	F2.8 ProvidePositionReport

#### Connector75

Source :	Port	Owner
	fromDMI_TrainData	F2.10 manageDMI_Input
Target :	Port	Owner
	trainDatafromDriver	F2.3 trainData

#### Connector76

<b>Source :</b>	Port	Owner
	fromDMI_TrainDataAck	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	trainDataAckfromDriver	F2.3 trainData

#### Connector77

<b>Source :</b>	Port	Owner
	forModesAndLevel	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	Data_From_DMI	F2.5 ManageLevelAndMode

#### Connector78

<b>Source :</b>	Port	Owner
	ML_levelTransition	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	driver_level_transition_In	F2.5 ManageLevelAndMode

#### Connector79

<b>Source :</b>	Port	Owner
	outStatusList	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	inStatusList	F2.11 manageDMI_Output

#### Connector80

<b>Source :</b>	Port	Owner
	outDriverRequest	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	status_DMILEvel_from_DMI	F2.2 Manage_ETCS_Procedures

#### Connector81

<b>Source :</b>	Port	Owner
	updatedNTC	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	train2trackStatus	F2.8 ProvidePositionReport

#### Connector82

<b>Source :</b>	Port	Owner
	updatedNTC	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	inNTC	F2.11 manageDMI_Output

#### Connector83

<b>Source :</b>	Port	Owner
	API_Odometry	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	inOdometry	F2.11 manageDMI_Output

#### Connector84

<b>Source :</b>	Port	Owner
	API_SystemTime	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	inSystemTime	F2.11 manageDMI_Output

#### Connector85

<b>Source :</b>	Port	Owner
	outTIUStatus	F2.12 manageTIU_input
<b>Target :</b>	Port	Owner
	TIU_TrainStatus	F2.11 manageDMI_Output

#### Connector86

<b>Source :</b>	Port	Owner
	brakeCmd	F2.7 SpeedSupervision_Integration
<b>Target :</b>	Port	Owner
	inBrakeCommand	F2.11 manageDMI_Output

#### Connector87

<b>Source :</b>	Port	Owner
	sdmToDMI	F2.7 SpeedSupervision_Integration
<b>Target :</b>	Port	Owner
	inSpeedSupervision	F2.11 manageDMI_Output

#### Connector88

<b>Source :</b>	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	inModeAndLevel	F2.11 manageDMI_Output

#### Connector89

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	trainDataFromEVC	F2.11 manageDMI_Output

#### Connector90



<b>Source :</b>	Port	Owner
	DMI_Entry_Request_to_DMI	F2.2 Manage_ETCS_Procedures
<b>Target :</b>	Port	Owner
	dmi_entryRequest	F2.11 manageDMI_Output

#### Connector91

<b>Source :</b>	Port	Owner
	BadBaliseMessageToDMI	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	dmi_fromBG	F2.11 manageDMI_Output

#### Connector93

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	evc_trainData	F2.12 manageTIU_input

#### Connector94

<b>Source :</b>	Port	Owner
	outTIUStatus	F2.12 manageTIU_input
<b>Target :</b>	Port	Owner
	cabStatus_from_TIU	F2.2 Manage_ETCS_Procedures

#### Connector95

<b>Source :</b>	Port	Owner
	outTIUStatus	F2.12 manageTIU_input
<b>Target :</b>	Port	Owner
	inActiveCab	F2.1 Manage_TrackSideInformation_Integration

#### Connector96

<b>Source :</b>	Port	Owner
	outTIUStatus	F2.12 manageTIU_input
<b>Target :</b>	Port	Owner
	Cab_In	F2.5 ManageLevelAndMode

#### Connector97

<b>Source :</b>	Port	Owner
	outTIUCurrentInfo	F2.12 manageTIU_input
<b>Target :</b>	Port	Owner
	Data_From_TIU	F2.5 ManageLevelAndMode

#### Connector100

Source :	Port	Owner
	brakeCmd	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	in_brake_command	F2.13 manageTIU_output

#### Connector101

Source :	Port	Owner
	EB_Requested	F2.5 ManageLevelAndMode
Target :	Port	Owner
	Emergency_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration

#### Connector102

Source :	Port	Owner
	API_Odometry	F2 ETCS Kernel
Target :	Port	Owner
	odometry	F2.7 SpeedSupervision_Integration

#### Connector103

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	trainProps	F2.7 SpeedSupervision_Integration

#### Connector104

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration

**Connector105**

<b>Source :</b>	Port	Owner
	ApplyServiceBrake	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	Service_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration

**Connector106**

<b>Source :</b>	Port	Owner
	API_fromTIU	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	trainDatafromTIU	F2.3 trainData

**Connector107**

<b>Source :</b>	Port	Owner
	outputMessageForRadioAck	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	trackMessages	F2.3 trainData

**Connector109**

<b>Source :</b>	Port	Owner
	packet0	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	p0_positionReport	F2.3 trainData

**Connector110**

<b>Source :</b>	Port	Owner
	packet1	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	p1_positionReport	F2.3 trainData

**Connector111**

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	trainProps	F2.8 ProvidePositionReport

**Connector112**

<b>Source :</b>	Port	Owner
	updatedStatus	F2.3 trainData
<b>Target :</b>	Port	Owner
	inFilterEvents	F2.1 Manage_TrackSideInformation_Integration

**Connector113**

<b>Source :</b>	Port	Owner
	updatedStatus	F2.3 trainData
<b>Target :</b>	Port	Owner
	inTrainDataValid	F2.1 Manage_TrackSideInformation_Integration

#### Connector116

<b>Source :</b>	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	inMessage	F2.8 ProvidePositionReport

#### Connector117

<b>Source :</b>	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	LinkedBG_MessageConsistencyError	F2.8 ProvidePositionReport

#### Connector118

<b>Source :</b>	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	UnlinkedBG_MessageConsistencyError	F2.8 ProvidePositionReport

#### Connector119

<b>Source :</b>	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	RadioMessageConsistencyError	F2.8 ProvidePositionReport

#### Connector120

<b>Source :</b>	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	RadioSequenceError	F2.8 ProvidePositionReport

#### Connector121

<b>Source :</b>	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	Data_From_F2_Functions	F2.5 ManageLevelAndMode

#### Connector123

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	StatusModeandLevel_from_Level_and_Mode_Managem	F2.2 Manage_ETCS_Procedures

#### Connector125

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	systemTime	F2.8 ProvidePositionReport

#### Connector126

Source :	Port	Owner
	API_Odometry	F2 ETCS Kernel
Target :	Port	Owner
	odometry	F2.8 ProvidePositionReport

#### Connector127

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	in_train_commands	F2.13 manageTIU_output

#### Connector128

Source :	Port	Owner
	Data_To_DMI_Ack	F2.5 ManageLevelAndMode
Target :	Port	Owner
	inModeLevel_Ack	F2.11 manageDMI_Output

#### Connector129

Source :	Port	Owner
	announcedLevel	F2.5 ManageLevelAndMode
Target :	Port	Owner
	announcedLevel	F2.11 manageDMI_Output

#### Connector130

Source :	Port	Owner
	Service_Brake_Command	F2.5 ManageLevelAndMode
Target :	Port	Owner
	Service_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration

#### Connector131

<b>Source :</b>	Port	Owner
	Data_to_From_Track_Packets_at_ML	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	Data_From_Track_Packets	F2.5 ManageLevelAndMode

#### Connector132

<b>Source :</b>	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	modeAndLevel	F2.1 Manage_TrackSideInformation_Integration

#### Connector133

<b>Source :</b>	Port	Owner
	forLevelManagement	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	Data_from_Track_MASSPGradient	F2.5 ManageLevelAndMode

#### Connector134

<b>Source :</b>	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	modeLevelStatus	F2.8 ProvidePositionReport

#### Connector135

<b>Source :</b>	Port	Owner
	posRep	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

#### Connector150

<b>Source :</b>	Port	Owner
	outMessageBus	F2.3 trainData
<b>Target :</b>	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

#### Connector157

<b>Source :</b>	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	transitionPositionPassed	F2.1 Manage_TrackSideInformation_Integration

#### Connector161

<b>Source :</b>	Port	Owner
	errors	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	Data_From_Localisation	F2.5 ManageLevelAndMode

#### Connector162

<b>Source :</b>	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	MessageIn	F2.4 TrackAtlas

#### Connector163

<b>Source :</b>	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	ModeAndLevel_in	F2.4 TrackAtlas

#### Connector164

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	TrainData_in	F2.4 TrackAtlas

#### Connector165

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	train_length	F2.4 TrackAtlas

#### Connector166

<b>Source :</b>	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	TrainPositionIn	F2.4 TrackAtlas

#### Connector167

<b>Source :</b>	Port	Owner
	API_SystemTime	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	SystemTime	F2.4 TrackAtlas

#### Connector168

Source :	Port	Owner
	API_Odometry	F2 ETCS Kernel
Target :	Port	Owner
	odometry	F2.4 TrackAtlas

#### Connector169

Source :	Port	Owner
	sdmToDMI	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	preindicationLocation	F2.4 TrackAtlas

#### Connector170

Source :	Port	Owner
	outForMA	F2.10 manageDMI_Input
Target :	Port	Owner
	fromDriverToMA_R	F2.4 TrackAtlas

#### Connector171

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	trainProps	F2.4 TrackAtlas

#### Connector172

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	trainProps	F2.4 TrackAtlas



Connector173

Source :	Port	Owner
	packet0	F2.8 ProvidePositionReport
Target :	Port	Owner
	packet0	F2.4 TrackAtlas

Connector174

Source :	Port	Owner
	packet1	F2.8 ProvidePositionReport
Target :	Port	Owner
	packet1	F2.4 TrackAtlas

Connector175

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	t_train	F2.4 TrackAtlas

Connector178

Source :	Port	Owner
	To_ModeAndLevel	F2.4 TrackAtlas
Target :	Port	Owner
	Data_From_Track_Messages	F2.5 ManageLevelAndMode

Connector179

Source :	Port	Owner
	to_DMI	F2.4 TrackAtlas
Target :	Port	Owner
	dmi_trackDescription	F2.11 manageDMI_Output

Connector180

Source :	Port	Owner
	to_Supervision	F2.4 TrackAtlas
Target :	Port	Owner
	dataFromTrackAtlas	F2.7 SpeedSupervision_Integration

Connector181

Source :	Port	Owner
	MA_request_out	F2.4 TrackAtlas
Target :	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

Connector183

<b>Source :</b>	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	trainProps	F2.4 TrackAtlas

#### Connector185

<b>Source :</b>	Port	Owner
	API_Odometry	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	Data_From_Localisation	F2.5 ManageLevelAndMode

#### Connector188

<b>Source :</b>	Port	Owner
	outMessageBus	F2.3 trainData
<b>Target :</b>	Port	Owner
	bus_in	F2.4 TrackAtlas

#### Connector190

<b>Source :</b>	Port	Owner
	bus_out	F2.4 TrackAtlas
<b>Target :</b>	Port	Owner
	MessageBus	F2.8 ProvidePositionReport

#### Connector191

<b>Source :</b>	Port	Owner
	API_mobileHWStatus	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	mobileRegistrationContext_1	F2.9 MoRC_HO

#### Connector192

<b>Source :</b>	Port	Owner
	API_mobileHWStatus	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	mobileConnectionContext_1	F2.9 MoRC_HO

#### Connector193

<b>Source :</b>	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	mode	F2.9 MoRC_HO

#### Connector194

<b>Source :</b>	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	level	F2.9 MoRC_HO

#### Connector195

<b>Source :</b>	Port	Owner
	powerUp_to_MoRC	F2.2 Manage_ETCS_Procedures
<b>Target :</b>	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector196

<b>Source :</b>	Port	Owner
	statusstartofmissionongoing_to_MoRC	F2.2 Manage_ETCS_Procedures
<b>Target :</b>	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector197

<b>Source :</b>	Port	Owner
	powerOff_to_MoRC	F2.2 Manage_ETCS_Procedures
<b>Target :</b>	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector198

<b>Source :</b>	Port	Owner
	request_Start_Mobile_Terminal_and_RBC_Registration_	F2.2 Manage_ETCS_Procedures
<b>Target :</b>	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector199

<b>Source :</b>	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector200

<b>Source :</b>	Port	Owner
	API_SystemTime	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	t_train	F2.9 MoRC_HO

#### Connector201

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	t_train_global	F2.9 MoRC_HO

#### Connector202

Source :	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	dataFromTrack_in	F2.9 MoRC_HO

#### Connector203

Source :	Port	Owner
	posReport	F2.8 ProvidePositionReport
Target :	Port	Owner
	msgBusToRBC_in	F2.9 MoRC_HO

#### Connector204

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	trainPosition	F2.9 MoRC_HO

#### Connector205

Source :	Port	Owner
	BGs	F2.6 calculateTrainPosition
Target :	Port	Owner
	BGs	F2.9 MoRC_HO

#### Connector206

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	trainProperties	F2.9 MoRC_HO

#### Connector207

Source :	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
Target :	Port	Owner
	mobileStatus	F2.2 Manage_ETCS_Procedures

#### Connector208

Source :	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
Target :	Port	Owner
	radioStatus	F2.1 Manage_TrackSideInformation_Integration

#### Connector209

Source :	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
Target :	Port	Owner
	inMoRC_status	F2.11 manageDMI_Output

#### Connector210

Source :	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
Target :	Port	Owner
	eventsForTrainData	F2.3 trainData

#### Connector211

Source :	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
Target :	Port	Owner
	rcbComm	F2.8 ProvidePositionReport

#### Connector212

Source :	Port	Owner
	mobileConnectionCmd_1	F2.9 MoRC_HO
Target :	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

#### Connector213

Source :	Port	Owner
	mobileRegistrationCmd_1	F2.9 MoRC_HO
Target :	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

#### Connector214

Source :	Port	Owner
	supervisingRBC	F2.9 MoRC_HO
Target :	Port	Owner
	inSupervisingRbcId	F2.1 Manage_TrackSideInformation_Integration

#### Connector215

Source :	Port	Owner
	ready	F2.9 MoRC_HO
Target :	Port	Owner
	eventsForTrainData	F2.3 trainData

#### Connector216

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	intrainVersion	F2.1 Manage_TrackSideInformation_Integration

#### Connector217

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	q_nvlocacc	F2.1 Manage_TrackSideInformation_Integration

#### Connector218

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	tNvContact	F2.1 Manage_TrackSideInformation_Integration

#### Connector219

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	nidEngine	F2.3 trainData

Connector220

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	P203V1_onboard	F2.4 TrackAtlas

Connector221

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	PermanentDataP003	F2.4 TrackAtlas

Connector222

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	ERTMS_capabilities_In	F2.5 ManageLevelAndMode

Connector223

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	Data_From_STM	F2.5 ManageLevelAndMode

Connector224

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration

Connector225

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	t_train	F2.8 ProvidePositionReport

Connector1

Source :	Port	Owner
	TracksideOut	F1 Receive Information from Trackside
Target :	Port	Owner
	API_fromTrack	F2 ETCS Kernel

Connector2

Source :	Port	Owner
	DMIOut	F6 DMI Controller

Target :	Port	Owner
	API_fromDMI	F2 ETCS Kernel

#### Connector3

Source :	Port	Owner
	API_toDMI	F2 ETCS Kernel

Target :	Port	Owner
	DMIIIn	F6 DMI Controller

#### Connector4

Source :	Port	Owner
	API_toTIU	F2 ETCS Kernel

Target :	Port	Owner
	TIUIIn	F7 TIU Controller

#### Connector5

Source :	Port	Owner
	TIUOut	F7 TIU Controller

Target :	Port	Owner
	API_fromTIU	F2 ETCS Kernel

#### Connector6

Source :	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

Target :	Port	Owner
	RadioIn	F4 Radio Communication Controller

#### Connector7

Source :	Port	Owner
	RadioOut	F4 Radio Communication Controller

Target :	Port	Owner
	API_mobileHWStatus	F2 ETCS Kernel

#### Connector8

Source :	Port	Owner
	OdometryOut	F3 Measure Train Movement

Target :	Port	Owner
	API_Odometry	F2 ETCS Kernel

#### Connector14



Source :	Port	Owner
	RBCBTMIn	ETCS OBU
Target :	Port	Owner
	RBCBTMIn	F1 Receive Information from Trackside

#### Connector17

Source :	Port	Owner
	OdometryIn	ETCS OBU
Target :	Port	Owner
	OdometryIn	F3 Measure Train Movement

#### Connector19

Source :	Port	Owner
	PersistentDataOut	F8 Persistent Data
Target :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel

#### Connector20

Source :	Port	Owner
	API_persistentDataOut	F2 ETCS Kernel
Target :	Port	Owner
	PersistentDataIn	F8 Persistent Data

#### Connector3

Source :	Port	Owner
	Output1	Eurobalise
Target :	Port	Owner
	Input1	ERTMS Track

#### Connector6

Source :	Port	Owner
	Output1	ERTMS Track
Target :	Port	Owner
	RBCBTMIn	ETCS OBU

#### Connector7

Source :	Port	Owner
	Output1	Configuration
Target :	Port	Owner
	Input1	ETCS OBU

#### Connector9

Source :	Port	Owner
	Output1	Train Movement
Target :	Port	Owner
	OdometryIn	ETCS OBU

#### Connector11

Source :	Port	Owner
	Output1	RBC
Target :	Port	Owner
	Input2	ERTMS Track

#### Connector12

Source :	Port	Owner
	Output2	Eurobalise
Target :	Port	Owner
	Input1	Interlocking

#### Connector13

Source :	Port	Owner
	Output1	Interlocking
Target :	Port	Owner
	Input1	Eurobalise

#### Connector14

Source :	Port	Owner
	Output2	RBC
Target :	Port	Owner
	Input2	Interlocking

#### Connector15

Source :	Port	Owner
	Output2	Interlocking
Target :	Port	Owner
	Input1	RBC

#### Connector16

Source :	Port	Owner
	DriverOut	ETCS OBU
Target :	Port	Owner
	Input1	Driver

#### Connector17

Source :	Port	Owner
	Output1	Driver
Target :	Port	Owner
	DriverIn	ETCS OBU

#### Connector18

Source :	Port	Owner
	RBCOut	ETCS OBU
Target :	Port	Owner
	Input2	RBC

#### Connector19

Source :	Port	Owner
	Output3	RBC
Target :	Port	Owner
	RBCIN	ETCS OBU

#### Connector20

Source :	Port	Owner
	Output1	Train
Target :	Port	Owner
	TrainIn	ETCS OBU

#### Connector21

Source :	Port	Owner
	TrainOut	ETCS OBU
Target :	Port	Owner
	Input1	Train

#### Connector1

Source :	Port	Owner
	trackSide_ForCheck	CheckBGConsistency
Target :	Port	Owner
	trackSideForCheck	CaseLinkingNotInUse1

#### Connector2

Source :	Port	Owner
	trackSide_ForCheck	CheckBGConsistency
Target :	Port	Owner
	trackSideForCheck	CaseLinkingInUse1

#### Connector3

Source :	Port	Owner
	errorUnlinkedBG	CaseLinkingNotInUse1
Target :	Port	Owner
	errorUnlinkedBG	CheckBGConsistency

#### Connector4

Source :	Port	Owner
	applyServiceBrake	CaseLinkingNotInUse1
Target :	Port	Owner
	applyServiceBrake	CheckBGConsistency

#### Connector5

Source :	Port	Owner
	errorLinkedBG	CaseLinkingInUse1
Target :	Port	Owner
	errorLinkedBG	CheckBGConsistency

#### Connector6

Source :	Port	Owner
	passedBG_out	CaseLinkingNotInUse1
Target :	Port	Owner
	passedBG_out	CheckBGConsistency

#### Connector7

Source :	Port	Owner
	passedBG_out	CaseLinkingInUse1
Target :	Port	Owner
	passedBG_out	CheckBGConsistency

Connector1

Source :	Port	Owner
	reset	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	reset	Receive_TrackSide_Msg

Connector2

Source :	Port	Owner
	API_trackSide_Message	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	API_TrackSide_Msg	Receive_TrackSide_Msg

Connector3

Source :	Port	Owner
	inActiveCab	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	inActualOdometry	Receive_TrackSide_Msg

Connector4

Source :	Port	Owner
	outTrackMessage_for_check	Receive_TrackSide_Msg
Target :	Port	Owner
	trackSide_ForCheck	CheckBGConsistency

Connector5

Source :	Port	Owner
	applyServiceBrake	CheckBGConsistency
Target :	Port	Owner
	ApplyServiceBrake	F2.1 Manage_TrackSideInformation_Integration

Connector6

Source :	Port	Owner
	outTrackMessage_for_check	Receive_TrackSide_Msg
Target :	Port	Owner
	rtmMessage	CheckEuroRadioMessage

Connector7

Source :	Port	Owner
	outMessage	InformationFilter
Target :	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration

Connector8

<b>Source :</b>	Port	Owner
	inTrainDataValid	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	inTrainDataValid	InformationFilter

#### Connector9

<b>Source :</b>	Port	Owner
	passedBG_out	CheckBGConsistency
<b>Target :</b>	Port	Owner
	inMessage	validateDataDirection

#### Connector10

<b>Source :</b>	Port	Owner
	checkedMessage	CheckEuroRadioMessage
<b>Target :</b>	Port	Owner
	inMessage	validateDataDirection

#### Connector11

<b>Source :</b>	Port	Owner
	outMessage	validateDataDirection
<b>Target :</b>	Port	Owner
	inMessage	InformationFilter

#### Connector12

<b>Source :</b>	Port	Owner
	inActiveCab	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	inActiveCab	InformationFilter

#### Connector13

<b>Source :</b>	Port	Owner
	intrainVersion	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	trainVersion	CheckBGConsistency

#### Connector14

<b>Source :</b>	Port	Owner
	trainPosition	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	trainPosition	CheckBGConsistency

#### Connector15

Source :	Port	Owner
	inFilterEvents	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	inFilterEvents	InformationFilter

#### Connector16

Source :	Port	Owner
	outPacketsForML	InformationFilter
Target :	Port	Owner
	Data_to_From_Track_Packets_at_ML	F2.1 Manage_TrackSideInformation_Integration

#### Connector17

Source :	Port	Owner
	ActualOdometry	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	inActualOdometry	Receive_TrackSide_Msg

#### Connector1

Source :	Port	Owner
	TrainPosition	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	TrainPosition	InputWrapper

#### Connector3

Source :	Port	Owner
	trainProps	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	trainProps	InputWrapper

#### Connector4

Source :	Port	Owner
	dataFromTrackAtlas	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	dataFromTrackAtlas	InputWrapper

#### Connector11

Source :	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	ABrakeFactory

#### Connector12

Source :	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	trainData	ABrakeFactory

#### Connector13

Source :	Port	Owner
	mrsp_out	InputWrapper
Target :	Port	Owner
	MRSP	TargetManagement

#### Connector14

Source :	Port	Owner
	mrsp_update_out	InputWrapper
Target :	Port	Owner
	MRSP_updated	TargetManagement

#### Connector15

Source :	Port	Owner
	ma_out	InputWrapper
Target :	Port	Owner
	MA	TargetManagement

#### Connector16

Source :	Port	Owner
	ma_update_out	InputWrapper
Target :	Port	Owner
	MA_updated	TargetManagement

#### Connector17

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	trainLocations	TargetManagement

#### Connector18

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	TrainLocations	CalcBrakingCurves

#### Connector19



Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	CalcBrakingCurves

#### Connector22

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	LimitLocations

#### Connector23

Source :	Port	Owner
	mrsp_out	InputWrapper
Target :	Port	Owner
	MRSP_Profile	LimitLocations

#### Connector24

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	trainLocations	LimitLocations

#### Connector26

Source :	Port	Owner
	curveCollection	CalcBrakingCurves
Target :	Port	Owner
	curveCollection	LimitLocations

#### Connector27

Source :	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	LimitLocations

#### Connector29

Source :	Port	Owner
	T_b	ABrakeFactory
Target :	Port	Owner
	T_b	LimitLocations

#### Connector30

Source :	Port	Owner
	ma_out	InputWrapper
Target :	Port	Owner
	MA	LimitLocations

#### Connector35

Source :	Port	Owner
	locations	LimitLocations
Target :	Port	Owner
	locations	Commands

#### Connector36

Source :	Port	Owner
	speeds	LimitLocations
Target :	Port	Owner
	speeds	Commands

#### Connector37

Source :	Port	Owner
	MostRestrictiveDisplayedTarget	LimitLocations
Target :	Port	Owner
	mrdt	Commands

#### Connector38

Source :	Port	Owner
	FLOIsSBI1	LimitLocations
Target :	Port	Owner
	floilsSB1	Commands

Connector43

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	allTargets	Commands

Connector46

Source :	Port	Owner
	MostRestrictiveDisplayedTarget	LimitLocations
Target :	Port	Owner
	target	F2.7 SpeedSupervision_Integration

Connector47

Source :	Port	Owner
	sdmToDMI	Commands
Target :	Port	Owner
	sdmToDMI	F2.7 SpeedSupervision_Integration

Connector48

Source :	Port	Owner
	brakeCmd	Commands
Target :	Port	Owner
	brakeCmd	F2.7 SpeedSupervision_Integration

Connector49

Source :	Port	Owner
	sdmCmd	Commands
Target :	Port	Owner
	sdmCommands	F2.7 SpeedSupervision_Integration

Connector50

Source :	Port	Owner
	targetSpeedReached	Commands
Target :	Port	Owner
	Target_Speed_Reached	F2.7 SpeedSupervision_Integration

Connector51

Source :	Port	Owner
	eoasOverpassed	Commands
Target :	Port	Owner
	EOA_overpassed	F2.7 SpeedSupervision_Integration

Connector52

Source :	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	Commands

#### Connector53

Source :	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	TrainData_int	Commands

#### Connector54

Source :	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	trainData_int	LimitLocations

#### Connector55

Source :	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	LimitLocations

#### Connector56

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	trainLocations	LimitLocations

#### Connector57

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	TrainLocations	CalcBrakingCurves

#### Connector58

Source :	Port	Owner
	Service_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	MLrequestSB	Commands

#### Connector59

Source :	Port	Owner
	Emergency_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	MLrequestEB	Commands

#### Connector60

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	allTargets	Commands

#### Connector61

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	LimitLocations

#### Connector62

Source :	Port	Owner
	ma_out	InputWrapper
Target :	Port	Owner
	MA	LimitLocations

#### Connector63

Source :	Port	Owner
	mrsp_out	InputWrapper
Target :	Port	Owner
	MRSP_Profile	LimitLocations

#### Connector64

Source :	Port	Owner
	odometry	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	odometry	LimitLocations

#### Connector65

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	AGradient

#### Connector66

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	TrainLocations	AGradient

#### Connector67

Source :	Port	Owner
	gp_out	InputWrapper
Target :	Port	Owner
	GradientProfile	AGradient

#### Connector68

Source :	Port	Owner
	gp_update_out	InputWrapper
Target :	Port	Owner
	GradientProfile_updated	AGradient

#### Connector69

Source :	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	trainData	AGradient

#### Connector70

Source :	Port	Owner
	aBrakeSafe	ABrakeFactory
Target :	Port	Owner
	aBrakeSafe	addGradient1

#### Connector71

Source :	Port	Owner
	aBrakeService	ABrakeFactory
Target :	Port	Owner
	aBrakeSafe	addGradient2

#### Connector72

Source :	Port	Owner
	aSafe	addGradient1
Target :	Port	Owner
	A_Safe	CalcBrakingCurves

#### Connector73

Source :	Port	Owner
	aSafe	addGradient2
Target :	Port	Owner
	A_Expected	CalcBrakingCurves

#### Connector74

Source :	Port	Owner
	A_gradient	AGradient
Target :	Port	Owner
	aGradient	addGradient1

#### Connector75

Source :	Port	Owner
	A_gradient	AGradient
Target :	Port	Owner
	aGradient	addGradient2

#### Connector1

Source :	Port	Owner
	packet0	Build_SinglePosReport
Target :	Port	Owner
	inPacket0	AggregatePackets

#### Connector2

Source :	Port	Owner
	packet1	Build_SinglePosReport
Target :	Port	Owner
	inPacket1	AggregatePackets

#### Connector3

Source :	Port	Owner
	packet4	Build_SinglePosReport
Target :	Port	Owner
	inPacket4	AggregatePackets

#### Connector4

Source :	Port	Owner
	packet5	Build_SinglePosReport
Target :	Port	Owner
	inPacket5	AggregatePackets

#### Connector6

Source :	Port	Owner
	present	ReceiveReportParameters

Target :	Port	Owner
	present	PosReport_Supervision

#### Connector7

Source :	Port	Owner
	posRepParam	ReceiveReportParameters

Target :	Port	Owner
	posRepParam	PosReport_Supervision

#### Connector9

Source :	Port	Owner
	trigger	PosReport_Supervision

Target :	Port	Owner
	reportIsSent	AddBGTToFIFO

#### Connector10

Source :	Port	Owner
	posRepHeader	Build_SinglePosReport

Target :	Port	Owner
	posRep	F2.8 ProvidePositionReport

#### Connector11

Source :	Port	Owner
	packet0	Build_Packets0_1

Target :	Port	Owner
	in_packet0	Build_SinglePosReport



Connector12

Source :	Port	Owner
	packet1	Build_Packets0_1
Target :	Port	Owner
	in_packet1	Build_SinglePosReport

Connector13

Source :	Port	Owner
	packet0	Build_Packets0_1
Target :	Port	Owner
	packet0	F2.8 ProvidePositionReport

Connector14

Source :	Port	Owner
	packet1	Build_Packets0_1
Target :	Port	Owner
	packet1	F2.8 ProvidePositionReport

Connector15

Source :	Port	Owner
	errorVector	ErrorManager
Target :	Port	Owner
	errorMsg	Build_SinglePosReport

Connector16

Source :	Port	Owner
	BG_LinkingConsistencyError	F2.8 ProvidePositionReport
Target :	Port	Owner
	BG_LinkingConsistencyError	ErrorManager

Connector17

Source :	Port	Owner
	LinkedBG_MessageConsistencyError	F2.8 ProvidePositionReport
Target :	Port	Owner
	LinkedBG_MessageConsistencyError	ErrorManager

Connector18

Source :	Port	Owner
	UnlinkedBG_MessageConsistencyError	F2.8 ProvidePositionReport
Target :	Port	Owner
	UnlinkedBG_MessageConsistencyError	ErrorManager

Connector19

<b>Source :</b>	Port	Owner
	RadioMessageConsistencyError	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	RadioMessageConsistencyError	ErrorManager

#### Connector20

<b>Source :</b>	Port	Owner
	RadioSequenceError	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	RadioSequenceError	ErrorManager

#### Connector21

<b>Source :</b>	Port	Owner
	RadioSafeRadioConnectionError	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	RadioSafeRadioConnectionError	ErrorManager

#### Connector22

<b>Source :</b>	Port	Owner
	SafetyCriticalFailure	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	SafetyCriticalFailure	ErrorManager

#### Connector23

<b>Source :</b>	Port	Owner
	DoubleLinkingError	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	DoubleLinkingError	ErrorManager

#### Connector24

<b>Source :</b>	Port	Owner
	DoubleRepositioningError	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	DoubleRepositioningError	ErrorManager

#### Connector25

<b>Source :</b>	Port	Owner
	modeLevelStatus	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	modeLevelStatus	PosReport_Supervision

#### Connector26

<b>Source :</b>	Port	Owner
	modeLevelStatus	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	modeLevelStatus	Build_Packets0_1

#### Connector27

<b>Source :</b>	Port	Owner
	posBGs	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	posBGs	PosReport_Supervision

#### Connector28

<b>Source :</b>	Port	Owner
	posBGs	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	posBGs	Build_Packets0_1

#### Connector29

<b>Source :</b>	Port	Owner
	trainPos	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	trainPos	PosReport_Supervision

#### Connector30

<b>Source :</b>	Port	Owner
	trainPos	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	trainPos	Build_Packets0_1

#### Connector31

<b>Source :</b>	Port	Owner
	odometry	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	odometry	PosReport_Supervision

#### Connector32

<b>Source :</b>	Port	Owner
	odometry	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	odometry	Build_Packets0_1

#### Connector33

<b>Source :</b>	Port	Owner
	trainProps	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	trainProps	Build_SinglePosReport

#### Connector35

<b>Source :</b>	Port	Owner
	trainProps	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	trainProps	Build_Packets0_1

#### Connector36

<b>Source :</b>	Port	Owner
	inMessage	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	inMessage	ReceiveReportParameters

#### Connector37

<b>Source :</b>	Port	Owner
	out_reportedBGs	AddBGTToFIFO
<b>Target :</b>	Port	Owner
	reportedBGs	ReceiveReportParameters

#### Connector38

<b>Source :</b>	Port	Owner
	t_train	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	t_train	Build_SinglePosReport

#### Connector39

<b>Source :</b>	Port	Owner
	prvDirTrain	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	prvDirTrain	Build_Packets0_1

#### Connector41

<b>Source :</b>	Port	Owner
	train2trackStatus	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	train2trackStatus	Build_Packets0_1

#### Connector42

Source :	Port	Owner
	trackInfo	F2.8 ProvidePositionReport
Target :	Port	Owner
	trackInfo	PosReport_Supervision

#### Connector43

Source :	Port	Owner
	systemTime	F2.8 ProvidePositionReport
Target :	Port	Owner
	systemTime	PosReport_Supervision

#### Connector44

Source :	Port	Owner
	rcbComm	F2.8 ProvidePositionReport
Target :	Port	Owner
	rcbComm	PosReport_Supervision

#### Connector45

Source :	Port	Owner
	train2trackStatus	F2.8 ProvidePositionReport
Target :	Port	Owner
	train2trackStatus	PosReport_Supervision

#### Connector46

Source :	Port	Owner
	posBGs	F2.8 ProvidePositionReport
Target :	Port	Owner
	posBGs	AddBGToFIFO

#### Connector47

Source :	Port	Owner
	out_reportedBGs	ReceiveReportParameters
Target :	Port	Owner
	reportedBGs	AddBGToFIFO

#### Connector51

Source :	Port	Owner
	prvDirTrain	F2.8 ProvidePositionReport
Target :	Port	Owner
	prvDirTrain	PosReport_Supervision

#### Connector52

Source :	Port	Owner
	out_reportedBGs	ReceiveReportParameters
Target :	Port	Owner
	reportedBGs	PosReport_Supervision

#### Connector53

Source :	Port	Owner
	trainProps	F2.8 ProvidePositionReport
Target :	Port	Owner
	trainProps	PosReport_Supervision

#### Connector1

Source :	Port	Owner
	reset	F2.3 trainData
Target :	Port	Owner
	reset	trainDataStorage

#### Connector2

Source :	Port	Owner
	trainDatafromTIU	F2.3 trainData
Target :	Port	Owner
	trainDatafromTIU	trainDataStorage

#### Connector3

Source :	Port	Owner
	trainDatafromDriver	F2.3 trainData
Target :	Port	Owner
	trainDatafromDriver	trainDataStorage

Connector4

Source :	Port	Owner
	trainDataAckfromDriver	F2.3 trainData
Target :	Port	Owner
	trainDataAckfromDriver	trainDataStorage

Connector5

Source :	Port	Owner
	trackMessages	F2.3 trainData
Target :	Port	Owner
	trackMessages	checkRadioMessages

Connector6

Source :	Port	Owner
	eventsForTrainData	F2.3 trainData
Target :	Port	Owner
	eventsForTrainData	trainDataStorage

Connector7

Source :	Port	Owner
	actualTrainData	trainDataStorage
Target :	Port	Owner
	trainData	sendValidTrainDataRBC

Connector8

Source :	Port	Owner
	actualTrainData	trainDataStorage
Target :	Port	Owner
	actualTrainData	F2.3 trainData

Connector9

Source :	Port	Owner
	p0_positionReport	F2.3 trainData
Target :	Port	Owner
	p0_positionReport	sendValidTrainDataRBC

Connector10

Source :	Port	Owner
	p1_positionReport	F2.3 trainData
Target :	Port	Owner
	p1_positionReport	sendValidTrainDataRBC

Connector11

Source :	Port	Owner
	nidEngine	F2.3 trainData
Target :	Port	Owner
	nidEngine	sendValidTrainDataRBC

#### Connector12

Source :	Port	Owner
	nidEngine	F2.3 trainData
Target :	Port	Owner
	nidEngine	sendAcknowledgementRBC

#### Connector13

Source :	Port	Owner
	t_train	F2.3 trainData
Target :	Port	Owner
	evc_t_train	sendValidTrainDataRBC

#### Connector14

Source :	Port	Owner
	t_train	F2.3 trainData
Target :	Port	Owner
	EVC_t_train	sendAcknowledgementRBC

#### Connector15

Source :	Port	Owner
	trackMessages	F2.3 trainData
Target :	Port	Owner
	RBC_timeStamp	sendAcknowledgementRBC

#### Connector16

Source :	Port	Owner
	outMessageBus	sendAcknowledgementRBC
Target :	Port	Owner
	outMessageBus	F2.3 trainData

#### Connector17

Source :	Port	Owner
	outMessageBus	sendValidTrainDataRBC
Target :	Port	Owner
	outMessageBus	F2.3 trainData

#### Connector18



Source :	Port	Owner
	MessageBus	F2.3 trainData
Target :	Port	Owner
	MessageBus	sendAcknowledgementRBC

#### Connector19

Source :	Port	Owner
	MessageBus	F2.3 trainData
Target :	Port	Owner
	MessageBus	sendValidTrainDataRBC

#### Connector1

Source :	Port	Owner
	API_fromTIU	F2 ETCS Kernel
Target :	Port	Owner
	inTIUfromAPI	F2.12 manageTIU_input

#### Connector10

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	systemtime	F2.2 Manage_ETCS_Procedures

#### Connector11

Source :	Port	Owner
	EVC_reset	F2 ETCS Kernel
Target :	Port	Owner
	reset	F2.1 Manage_TrackSideInformation_Integration

#### Connector12

Source :	Port	Owner
	API_fromTrack	F2 ETCS Kernel
Target :	Port	Owner
	API_trackSide_Message	F2.1 Manage_TrackSideInformation_Integration

#### Connector13

Source :	Port	Owner
	API_Odometry	F2 ETCS Kernel
Target :	Port	Owner
	ActualOdometry	F2.1 Manage_TrackSideInformation_Integration

#### Connector30

Source :	Port	Owner
	EVC_reset	F2 ETCS Kernel
Target :	Port	Owner
	reset	F2.3 trainData

#### Connector31

Source :	Port	Owner
	API_fromTrack	F2 ETCS Kernel
Target :	Port	Owner
	trackMessages	F2.3 trainData

#### Connector32

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	t_train	F2.3 trainData

#### Connector38

Source :	Port	Owner
	EVC_reset	F2 ETCS Kernel
Target :	Port	Owner
	reset	F2.6 calculateTrainPosition

#### Connector39

Source :	Port	Owner
	API_Odometry	F2 ETCS Kernel
Target :	Port	Owner
	currentOdometry	F2.6 calculateTrainPosition

#### Connector41

Source :	Port	Owner
	API_fromDMI	F2 ETCS Kernel
Target :	Port	Owner
	fromDMI	F2.10 manageDMI_Input

#### Connector42

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	currentTime	F2.9 MoRC_HO

#### Connector43

Source :	Port	Owner
	EVC_reset	F2 ETCS Kernel
Target :	Port	Owner
	reset	F2.9 MoRC_HO

#### Connector44

Source :	Port	Owner
	to_DMI	F2.11 manageDMI_Output
Target :	Port	Owner
	API_toDMI	F2 ETCS Kernel

#### Connector45

Source :	Port	Owner
	outTIU_to_API	F2.13 manageTIU_output
Target :	Port	Owner
	API_toTIU	F2 ETCS Kernel

#### Connector46

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	trainPosition	F2.1 Manage_TrackSideInformation_Integration

#### Connector50

Source :	Port	Owner
	BGs	F2.6 calculateTrainPosition
Target :	Port	Owner
	inAnnouncedBGs	F2.1 Manage_TrackSideInformation_Integration

#### Connector51

Source :	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
Target :	Port	Owner
	trainProperties	F2.6 calculateTrainPosition

#### Connector52

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	trainProperties	F2.6 calculateTrainPosition

#### Connector53

Source :	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	msgFromTrack	F2.6 calculateTrainPosition

#### Connector54

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	inTrainPosition	F2.11 manageDMI_Output

#### Connector55

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	TrainPosition	F2.7 SpeedSupervision_Integration

#### Connector56

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	trainPos	F2.8 ProvidePositionReport

#### Connector57

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	Data_From_Localisation	F2.5 ManageLevelAndMode

Connector58

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	statusValid_Position_from_Position_Calculation	F2.2 Manage_ETCS_Procedures

Connector59

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	prvDirTrain	F2.8 ProvidePositionReport

Connector60

Source :	Port	Owner
	BGs	F2.6 calculateTrainPosition
Target :	Port	Owner
	posBGs	F2.8 ProvidePositionReport

Connector61

Source :	Port	Owner
	errors	F2.6 calculateTrainPosition
Target :	Port	Owner
	DoubleRepositioningError	F2.8 ProvidePositionReport

Connector62

Source :	Port	Owner
	errors	F2.6 calculateTrainPosition
Target :	Port	Owner
	DoubleLinkingError	F2.8 ProvidePositionReport

Connector63

Source :	Port	Owner
	errors	F2.6 calculateTrainPosition
Target :	Port	Owner
	BG_LinkingConsistencyError	F2.8 ProvidePositionReport

Connector64

Source :	Port	Owner
	API_fromDMI	F2 ETCS Kernel
Target :	Port	Owner
	fromDMI	F2.10 managedDMI_Input

Connector65

Source :	Port	Owner
	EVC_reset	F2 ETCS Kernel
Target :	Port	Owner
	dmiStatusReset	F2.10 manageDMI_Input

#### Connector66

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	inSystemTime	F2.10 manageDMI_Input

#### Connector67

Source :	Port	Owner
	outStatusList	F2.11 manageDMI_Output
Target :	Port	Owner
	inStatusList	F2.10 manageDMI_Input

#### Connector68

Source :	Port	Owner
	currentDMIStatus	F2.10 manageDMI_Input
Target :	Port	Owner
	statusDMI_from_DMI	F2.2 Manage_ETCS_Procedures

#### Connector69

Source :	Port	Owner
	currentDMIStatus	F2.10 manageDMI_Input
Target :	Port	Owner
	incurrentDMIStatus	F2.11 manageDMI_Output

#### Connector70

Source :	Port	Owner
	currentDMIStatus	F2.10 manageDMI_Input
Target :	Port	Owner
	LevelValid_from_Level_and_Mode_Management	F2.2 Manage_ETCS_Procedures

#### Connector71

Source :	Port	Owner
	outUpdateLevelsDMI	F2.10 manageDMI_Input
Target :	Port	Owner
	dmiUpdateLevelsDMI	F2.11 manageDMI_Output

#### Connector72

<b>Source :</b>	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	trainProperties	F2.9 MoRC_HO

#### Connector73

<b>Source :</b>	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	trainProps	F2.7 SpeedSupervision_Integration

#### Connector74

<b>Source :</b>	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	trainProps	F2.8 ProvidePositionReport

#### Connector75

<b>Source :</b>	Port	Owner
	fromDMI_TrainData	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	trainDatafromDriver	F2.3 trainData

#### Connector76

<b>Source :</b>	Port	Owner
	fromDMI_TrainDataAck	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	trainDataAckfromDriver	F2.3 trainData

#### Connector77

<b>Source :</b>	Port	Owner
	forModesAndLevel	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	Data_From_DMI	F2.5 ManageLevelAndMode

#### Connector78

<b>Source :</b>	Port	Owner
	ML_levelTransition	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	driver_level_transition_In	F2.5 ManageLevelAndMode

#### Connector79

Source :	Port	Owner
	outStatusList	F2.10 manageDMI_Input
Target :	Port	Owner
	inStatusList	F2.11 manageDMI_Output

#### Connector80

Source :	Port	Owner
	outDriverRequest	F2.10 manageDMI_Input
Target :	Port	Owner
	status_DMIIlevel_from_DMI	F2.2 Manage_ETCS_Procedures

#### Connector81

Source :	Port	Owner
	updatedNTC	F2.10 manageDMI_Input
Target :	Port	Owner
	train2trackStatus	F2.8 ProvidePositionReport

#### Connector82

Source :	Port	Owner
	updatedNTC	F2.10 manageDMI_Input
Target :	Port	Owner
	inNTC	F2.11 manageDMI_Output

#### Connector83

Source :	Port	Owner
	API_Odometry	F2 ETCS Kernel
Target :	Port	Owner
	inOdometry	F2.11 manageDMI_Output

#### Connector84

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	inSystemTime	F2.11 manageDMI_Output

#### Connector85

Source :	Port	Owner
	outTIUStatus	F2.12 manageTIU_input
Target :	Port	Owner
	TIU_TrainStatus	F2.11 manageDMI_Output

#### Connector86



Source :	Port	Owner
	brakeCmd	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	inBrakeCommand	F2.11 manageDMI_Output

#### Connector87

Source :	Port	Owner
	sdmToDMI	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	inSpeedSupervision	F2.11 manageDMI_Output

#### Connector88

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	inModeAndLevel	F2.11 manageDMI_Output

#### Connector89

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	trainDataFromEVC	F2.11 manageDMI_Output

#### Connector90

Source :	Port	Owner
	DMI_Entry_Request_to_DMI	F2.2 Manage_ETCS_Procedures
Target :	Port	Owner
	dmi_entryRequest	F2.11 manageDMI_Output

#### Connector91

Source :	Port	Owner
	BadBaliseMessageToDMI	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	dmi_fromBG	F2.11 manageDMI_Output

#### Connector93

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	evc_trainData	F2.12 manageTIU_input

#### Connector94

<b>Source :</b>	Port	Owner
	outTIUStatus	F2.12 manageTIU_input
<b>Target :</b>	Port	Owner
	cabStatus_from_TIU	F2.2 Manage_ETCS_Procedures

#### Connector95

<b>Source :</b>	Port	Owner
	outTIUStatus	F2.12 manageTIU_input
<b>Target :</b>	Port	Owner
	inActiveCab	F2.1 Manage_TrackSideInformation_Integration

#### Connector96

<b>Source :</b>	Port	Owner
	outTIUStatus	F2.12 manageTIU_input
<b>Target :</b>	Port	Owner
	Cab_In	F2.5 ManageLevelAndMode

#### Connector97

<b>Source :</b>	Port	Owner
	outTIUCurrentInfo	F2.12 manageTIU_input
<b>Target :</b>	Port	Owner
	Data_From_TIU	F2.5 ManageLevelAndMode

#### Connector100

<b>Source :</b>	Port	Owner
	brakeCmd	F2.7 SpeedSupervision_Integration
<b>Target :</b>	Port	Owner
	in_brake_command	F2.13 manageTIU_output

**Connector101**

<b>Source :</b>	Port	Owner
	EB_Requested	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	Emergency_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration

**Connector102**

<b>Source :</b>	Port	Owner
	API_Odometry	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	odometry	F2.7 SpeedSupervision_Integration

**Connector103**

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	trainProps	F2.7 SpeedSupervision_Integration

**Connector104**

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration

**Connector105**

<b>Source :</b>	Port	Owner
	ApplyServiceBrake	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	Service_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration

**Connector106**

<b>Source :</b>	Port	Owner
	API_fromTIU	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	trainDatafromTIU	F2.3 trainData

**Connector107**

<b>Source :</b>	Port	Owner
	outputMessageForRadioAck	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	trackMessages	F2.3 trainData

**Connector109**

Source :	Port	Owner
	packet0	F2.8 ProvidePositionReport
Target :	Port	Owner
	p0_positionReport	F2.3 trainData

#### Connector110

Source :	Port	Owner
	packet1	F2.8 ProvidePositionReport
Target :	Port	Owner
	p1_positionReport	F2.3 trainData

#### Connector111

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	trainProps	F2.8 ProvidePositionReport

#### Connector112

Source :	Port	Owner
	updatedStatus	F2.3 trainData
Target :	Port	Owner
	inFilterEvents	F2.1 Manage_TrackSideInformation_Integration

#### Connector113

Source :	Port	Owner
	updatedStatus	F2.3 trainData
Target :	Port	Owner
	inTrainDataValid	F2.1 Manage_TrackSideInformation_Integration

#### Connector116

Source :	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	inMessage	F2.8 ProvidePositionReport

#### Connector117

Source :	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	LinkedBG_MessageConsistencyError	F2.8 ProvidePositionReport

#### Connector118

Source :	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	UnlinkedBG_MessageConsistencyError	F2.8 ProvidePositionReport

#### Connector119

Source :	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	RadioMessageConsistencyError	F2.8 ProvidePositionReport

#### Connector120

Source :	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	RadioSequenceError	F2.8 ProvidePositionReport

#### Connector121

Source :	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	Data_From_F2_Functions	F2.5 ManageLevelAndMode

#### Connector123

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	StatusModeandLevel_from_Level_and_Mode_Managem	F2.2 Manage_ETCS_Procedures

#### Connector125

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	systemTime	F2.8 ProvidePositionReport

#### Connector126

Source :	Port	Owner
	API_Odometry	F2 ETCS Kernel
Target :	Port	Owner
	odometry	F2.8 ProvidePositionReport

#### Connector127

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	in_train_commands	F2.13 manageTIU_output

#### Connector128

Source :	Port	Owner
	Data_To_DMI_Ack	F2.5 ManageLevelAndMode
Target :	Port	Owner
	inModeLevel_Ack	F2.11 manageDMI_Output

#### Connector129

Source :	Port	Owner
	announcedLevel	F2.5 ManageLevelAndMode
Target :	Port	Owner
	announcedLevel	F2.11 manageDMI_Output

#### Connector130

Source :	Port	Owner
	Service_Brake_Command	F2.5 ManageLevelAndMode
Target :	Port	Owner
	Service_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration

#### Connector131

Source :	Port	Owner
	Data_to_From_Track_Packets_at_ML	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	Data_From_Track_Packets	F2.5 ManageLevelAndMode

#### Connector132

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	modeAndLevel	F2.1 Manage_TrackSideInformation_Integration

#### Connector133

Source :	Port	Owner
	forLevelManagement	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	Data_from_Track_MASSPGradient	F2.5 ManageLevelAndMode

#### Connector134

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	modeLevelStatus	F2.8 ProvidePositionReport

#### Connector135

Source :	Port	Owner
	posRep	F2.8 ProvidePositionReport
Target :	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

#### Connector150

Source :	Port	Owner
	outMessageBus	F2.3 trainData
Target :	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

#### Connector157

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	transitionPositionPassed	F2.1 Manage_TrackSideInformation_Integration

#### Connector161

Source :	Port	Owner
	errors	F2.6 calculateTrainPosition
Target :	Port	Owner
	Data_From_Localisation	F2.5 ManageLevelAndMode

#### Connector162

Source :	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	MessageIn	F2.4 TrackAtlas

#### Connector163

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	ModeAndLevel_in	F2.4 TrackAtlas

#### Connector164

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	TrainData_in	F2.4 TrackAtlas

#### Connector165

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	train_length	F2.4 TrackAtlas

#### Connector166

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	TrainPositionIn	F2.4 TrackAtlas

#### Connector167

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	SystemTime	F2.4 TrackAtlas

#### Connector168

Source :	Port	Owner
	API_Odometry	F2 ETCS Kernel
Target :	Port	Owner
	odometry	F2.4 TrackAtlas



Connector169

Source :	Port	Owner
	sdmToDMI	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	preindicationLocation	F2.4 TrackAtlas

Connector170

Source :	Port	Owner
	outForMA	F2.10 managedDMI_Input
Target :	Port	Owner
	fromDriverToMA_R	F2.4 TrackAtlas

Connector171

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	trainProps	F2.4 TrackAtlas

Connector172

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	trainProps	F2.4 TrackAtlas

Connector173

Source :	Port	Owner
	packet0	F2.8 ProvidePositionReport
Target :	Port	Owner
	packet0	F2.4 TrackAtlas

Connector174

Source :	Port	Owner
	packet1	F2.8 ProvidePositionReport
Target :	Port	Owner
	packet1	F2.4 TrackAtlas

Connector175

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	t_train	F2.4 TrackAtlas

Connector178

<b>Source :</b>	Port	Owner
	To_ModeAndLevel	F2.4 TrackAtlas
<b>Target :</b>	Port	Owner
	Data_From_Track_Messages	F2.5 ManageLevelAndMode

#### Connector179

<b>Source :</b>	Port	Owner
	to_DMI	F2.4 TrackAtlas
<b>Target :</b>	Port	Owner
	dmi_trackDescription	F2.11 manageDMI_Output

#### Connector180

<b>Source :</b>	Port	Owner
	to_Supervision	F2.4 TrackAtlas
<b>Target :</b>	Port	Owner
	dataFromTrackAtlas	F2.7 SpeedSupervision_Integration

#### Connector181

<b>Source :</b>	Port	Owner
	MA_request_out	F2.4 TrackAtlas
<b>Target :</b>	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

#### Connector183

<b>Source :</b>	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	trainProps	F2.4 TrackAtlas

#### Connector185

<b>Source :</b>	Port	Owner
	API_Odometry	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	Data_From_Localisation	F2.5 ManageLevelAndMode

#### Connector188

<b>Source :</b>	Port	Owner
	outMessageBus	F2.3 trainData
<b>Target :</b>	Port	Owner
	bus_in	F2.4 TrackAtlas

#### Connector190

Source :	Port	Owner
	bus_out	F2.4 TrackAtlas
Target :	Port	Owner
	MessageBus	F2.8 ProvidePositionReport

#### Connector191

Source :	Port	Owner
	API_mobileHWStatus	F2 ETCS Kernel
Target :	Port	Owner
	mobileRegistrationContext_1	F2.9 MoRC_HO

#### Connector192

Source :	Port	Owner
	API_mobileHWStatus	F2 ETCS Kernel
Target :	Port	Owner
	mobileConnectionContext_1	F2.9 MoRC_HO

#### Connector193

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	mode	F2.9 MoRC_HO

#### Connector194

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	level	F2.9 MoRC_HO

#### Connector195

Source :	Port	Owner
	powerUp_to_MoRC	F2.2 Manage_ETCS_Procedures
Target :	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector196

Source :	Port	Owner
	statusstartofmissionongoing_to_MoRC	F2.2 Manage_ETCS_Procedures
Target :	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector197

Source :	Port	Owner
	powerOff_to_MoRC	F2.2 Manage_ETCS_Procedures
Target :	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector198

Source :	Port	Owner
	request_Start_Mobile_Terminal_and_RBC_Registration_	F2.2 Manage_ETCS_Procedures
Target :	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector199

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector200

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	t_train	F2.9 MoRC_HO

#### Connector201

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	t_train_global	F2.9 MoRC_HO

#### Connector202

Source :	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	dataFromTrack_in	F2.9 MoRC_HO

#### Connector203

Source :	Port	Owner
	posReport	F2.8 ProvidePositionReport
Target :	Port	Owner
	msgBusToRBC_in	F2.9 MoRC_HO

#### Connector204

<b>Source :</b>	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	trainPosition	F2.9 MoRC_HO

#### Connector205

<b>Source :</b>	Port	Owner
	BGs	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	BGs	F2.9 MoRC_HO

#### Connector206

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	trainProperties	F2.9 MoRC_HO

#### Connector207

<b>Source :</b>	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	mobileStatus	F2.2 Manage_ETCS_Procedures

#### Connector208

<b>Source :</b>	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	radioStatus	F2.1 Manage_TrackSideInformation_Integration

#### Connector209

<b>Source :</b>	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	inMoRC_status	F2.11 manageDMI_Output

#### Connector210

<b>Source :</b>	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	eventsForTrainData	F2.3 trainData

#### Connector211

<b>Source :</b>	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	rcbComm	F2.8 ProvidePositionReport

#### Connector212

<b>Source :</b>	Port	Owner
	mobileConnectionCmd_1	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

#### Connector213

<b>Source :</b>	Port	Owner
	mobileRegistrationCmd_1	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

#### Connector214

<b>Source :</b>	Port	Owner
	supervisingRBC	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	inSupervisingRbclId	F2.1 Manage_TrackSideInformation_Integration

#### Connector215

<b>Source :</b>	Port	Owner
	ready	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	eventsForTrainData	F2.3 trainData

Connector216

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	intrainVersion	F2.1 Manage_TrackSideInformation_Integration

Connector217

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	q_nvlocacc	F2.1 Manage_TrackSideInformation_Integration

Connector218

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	tNvContact	F2.1 Manage_TrackSideInformation_Integration

Connector219

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	nidEngine	F2.3 trainData

Connector220

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	P203V1_onboard	F2.4 TrackAtlas

Connector221

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	PermanentDataP003	F2.4 TrackAtlas

Connector222

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	ERTMS_capabilities_In	F2.5 ManageLevelAndMode

Connector223

<b>Source :</b>	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	Data_From_STM	F2.5 ManageLevelAndMode

#### Connector224

<b>Source :</b>	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration

#### Connector225

<b>Source :</b>	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	t_train	F2.8 ProvidePositionReport

#### Connector1

<b>Source :</b>	Port	Owner
	TracksideOut	F1 Receive Information from Trackside
<b>Target :</b>	Port	Owner
	API_fromTrack	F2 ETCS Kernel

#### Connector2

<b>Source :</b>	Port	Owner
	DMIOut	F6 DMI Controller
<b>Target :</b>	Port	Owner
	API_fromDMI	F2 ETCS Kernel

#### Connector3

<b>Source :</b>	Port	Owner
	API_toDMI	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	DMIIn	F6 DMI Controller

#### Connector4

<b>Source :</b>	Port	Owner
	API_toTIU	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	TIUIn	F7 TIU Controller

#### Connector5



Source :	Port	Owner
	TIUOut	F7 TIU Controller
Target :	Port	Owner
	API_fromTIU	F2 ETCS Kernel

#### Connector6

Source :	Port	Owner
	API_toEuroradio	F2 ETCS Kernel
Target :	Port	Owner
	RadioIn	F4 Radio Communication Controller

#### Connector7

Source :	Port	Owner
	RadioOut	F4 Radio Communication Controller
Target :	Port	Owner
	API_mobileHWStatus	F2 ETCS Kernel

#### Connector8

Source :	Port	Owner
	OdometryOut	F3 Measure Train Movement
Target :	Port	Owner
	API_Odometry	F2 ETCS Kernel

#### Connector14

Source :	Port	Owner
	RBCBTMIn	ETCS OBU
Target :	Port	Owner
	RBCBTMIn	F1 Receive Information from Trackside

#### Connector17

Source :	Port	Owner
	OdometryIn	ETCS OBU
Target :	Port	Owner
	OdometryIn	F3 Measure Train Movement

#### Connector19

Source :	Port	Owner
	PersistentDataOut	F8 Persistent Data
Target :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel

#### Connector20

Source :	Port	Owner
	API_persistentDataOut	F2 ETCS Kernel
Target :	Port	Owner
	PersistentDataIn	F8 Persistent Data

#### Connector1

Source :	Port	Owner
	trackSide_ForCheck	CheckBGConsistency
Target :	Port	Owner
	trackSideForCheck	CaseLinkingNotInUse1

#### Connector2

Source :	Port	Owner
	trackSide_ForCheck	CheckBGConsistency
Target :	Port	Owner
	trackSideForCheck	CaseLinkingInUse1

#### Connector3

Source :	Port	Owner
	errorUnlinkedBG	CaseLinkingNotInUse1
Target :	Port	Owner
	errorUnlinkedBG	CheckBGConsistency

#### Connector4

Source :	Port	Owner
	applyServiceBrake	CaseLinkingNotInUse1
Target :	Port	Owner
	applyServiceBrake	CheckBGConsistency

#### Connector5

Source :	Port	Owner
	errorLinkedBG	CaseLinkingInUse1
Target :	Port	Owner
	errorLinkedBG	CheckBGConsistency

#### Connector6

Source :	Port	Owner
	passedBG_out	CaseLinkingNotInUse1
Target :	Port	Owner
	passedBG_out	CheckBGConsistency

#### Connector7

Source :	Port	Owner
	passedBG_out	CaseLinkingInUse1
Target :	Port	Owner
	passedBG_out	CheckBGConsistency

#### Connector1

Source :	Port	Owner
	packet0	Build_SinglePosReport
Target :	Port	Owner
	inPacket0	AggregatePackets

#### Connector2

Source :	Port	Owner
	packet1	Build_SinglePosReport
Target :	Port	Owner
	inPacket1	AggregatePackets

#### Connector3

Source :	Port	Owner
	packet4	Build_SinglePosReport
Target :	Port	Owner
	inPacket4	AggregatePackets

#### Connector4

Source :	Port	Owner
	packet5	Build_SinglePosReport
Target :	Port	Owner
	inPacket5	AggregatePackets

#### Connector6

Source :	Port	Owner
	present	ReceiveReportParameters
Target :	Port	Owner
	present	PosReport_Supervision

#### Connector7

Source :	Port	Owner
	posRepParam	ReceiveReportParameters
Target :	Port	Owner
	posRepParam	PosReport_Supervision

#### Connector9

Source :	Port	Owner
	trigger	PosReport_Supervision
Target :	Port	Owner
	reportIsSent	AddBGToFIFO

#### Connector10

Source :	Port	Owner
	posRepHeader	Build_SinglePosReport
Target :	Port	Owner
	posRep	ProvidePositionReport

#### Connector11

Source :	Port	Owner
	packet0	Build_Packets0_1
Target :	Port	Owner
	in_packet0	Build_SinglePosReport

#### Connector12

Source :	Port	Owner
	packet1	Build_Packets0_1
Target :	Port	Owner
	in_packet1	Build_SinglePosReport

#### Connector13

Source :	Port	Owner
	packet0	Build_Packets0_1
Target :	Port	Owner
	packet0	ProvidePositionReport

Connector14

Source :	Port	Owner
	packet1	Build_Packets0_1
Target :	Port	Owner
	packet1	ProvidePositionReport

Connector15

Source :	Port	Owner
	errorVector	ErrorManager
Target :	Port	Owner
	errorMsg	Build_SinglePosReport

Connector16

Source :	Port	Owner
	BG_LinkingConsistencyError	ProvidePositionReport
Target :	Port	Owner
	BG_LinkingConsistencyError	ErrorManager

Connector17

Source :	Port	Owner
	LinkedBG_MessageConsistencyError	ProvidePositionReport
Target :	Port	Owner
	LinkedBG_MessageConsistencyError	ErrorManager

Connector18

Source :	Port	Owner
	UnlinkedBG_MessageConsistencyError	ProvidePositionReport
Target :	Port	Owner
	UnlinkedBG_MessageConsistencyError	ErrorManager

Connector19

Source :	Port	Owner
	RadioMessageConsistencyError	ProvidePositionReport
Target :	Port	Owner
	RadioMessageConsistencyError	ErrorManager

Connector20

Source :	Port	Owner
	RadioSequenceError	ProvidePositionReport
Target :	Port	Owner
	RadioSequenceError	ErrorManager

Connector21

Source :	Port	Owner
	RadioSafeRadioConnectionError	ProvidePositionReport
Target :	Port	Owner
	RadioSafeRadioConnectionError	ErrorManager

#### Connector22

Source :	Port	Owner
	SafetyCriticalFailure	ProvidePositionReport
Target :	Port	Owner
	SafetyCriticalFailure	ErrorManager

#### Connector23

Source :	Port	Owner
	DoubleLinkingError	ProvidePositionReport
Target :	Port	Owner
	DoubleLinkingError	ErrorManager

#### Connector24

Source :	Port	Owner
	DoubleRepositioningError	ProvidePositionReport
Target :	Port	Owner
	DoubleRepositioningError	ErrorManager

#### Connector25

Source :	Port	Owner
	modeLevelStatus	ProvidePositionReport
Target :	Port	Owner
	modeLevelStatus	PosReport_Supervision

#### Connector26

Source :	Port	Owner
	modeLevelStatus	ProvidePositionReport
Target :	Port	Owner
	modeLevelStatus	Build_Packets0_1

#### Connector27

Source :	Port	Owner
	posBGs	ProvidePositionReport
Target :	Port	Owner
	posBGs	PosReport_Supervision

#### Connector28

Source :	Port	Owner
	posBGs	ProvidePositionReport
Target :	Port	Owner
	posBGs	Build_Packets0_1

#### Connector29

Source :	Port	Owner
	trainPos	ProvidePositionReport
Target :	Port	Owner
	trainPos	PosReport_Supervision

#### Connector30

Source :	Port	Owner
	trainPos	ProvidePositionReport
Target :	Port	Owner
	trainPos	Build_Packets0_1

#### Connector31

Source :	Port	Owner
	odometry	ProvidePositionReport
Target :	Port	Owner
	odometry	PosReport_Supervision

#### Connector32

Source :	Port	Owner
	odometry	ProvidePositionReport
Target :	Port	Owner
	odometry	Build_Packets0_1

#### Connector33

Source :	Port	Owner
	trainProps	ProvidePositionReport
Target :	Port	Owner
	trainProps	Build_SinglePosReport

#### Connector35

Source :	Port	Owner
	trainProps	ProvidePositionReport
Target :	Port	Owner
	trainProps	Build_Packets0_1

#### Connector36

<b>Source :</b>	Port	Owner
	inMessage	ProvidePositionReport
<b>Target :</b>	Port	Owner
	inMessage	ReceiveReportParameters

#### Connector37

<b>Source :</b>	Port	Owner
	out_reportedBGs	AddBGTToFIFO
<b>Target :</b>	Port	Owner
	reportedBGs	ReceiveReportParameters

#### Connector38

<b>Source :</b>	Port	Owner
	t_train	ProvidePositionReport
<b>Target :</b>	Port	Owner
	t_train	Build_SinglePosReport

#### Connector39

<b>Source :</b>	Port	Owner
	prvDirTrain	ProvidePositionReport
<b>Target :</b>	Port	Owner
	prvDirTrain	Build_Packets0_1

#### Connector41

<b>Source :</b>	Port	Owner
	train2trackStatus	ProvidePositionReport
<b>Target :</b>	Port	Owner
	train2trackStatus	Build_Packets0_1

#### Connector42

<b>Source :</b>	Port	Owner
	trackInfo	ProvidePositionReport
<b>Target :</b>	Port	Owner
	trackInfo	PosReport_Supervision

#### Connector43

<b>Source :</b>	Port	Owner
	systemTime	ProvidePositionReport
<b>Target :</b>	Port	Owner
	systemTime	PosReport_Supervision

#### Connector44



Source :	Port	Owner
	rcbComm	ProvidePositionReport
Target :	Port	Owner
	rcbComm	PosReport_Supervision

#### Connector45

Source :	Port	Owner
	train2trackStatus	ProvidePositionReport
Target :	Port	Owner
	train2trackStatus	PosReport_Supervision

#### Connector46

Source :	Port	Owner
	posBGs	ProvidePositionReport
Target :	Port	Owner
	posBGs	AddBGTToFIFO

#### Connector47

Source :	Port	Owner
	out_reportedBGs	ReceiveReportParameters
Target :	Port	Owner
	reportedBGs	AddBGTToFIFO

#### Connector51

Source :	Port	Owner
	prvDirTrain	ProvidePositionReport
Target :	Port	Owner
	prvDirTrain	PosReport_Supervision

#### Connector52

Source :	Port	Owner
	out_reportedBGs	ReceiveReportParameters
Target :	Port	Owner
	reportedBGs	PosReport_Supervision

#### Connector53

Source :	Port	Owner
	trainProps	ProvidePositionReport
Target :	Port	Owner
	trainProps	PosReport_Supervision

#### Connector1

Source :	Port	Owner
	trackSide_ForCheck	CheckBGConsistency

Target :	Port	Owner
	trackSideForCheck	CaseLinkingNotInUse1

#### Connector2

Source :	Port	Owner
	trackSide_ForCheck	CheckBGConsistency

Target :	Port	Owner
	trackSideForCheck	CaseLinkingInUse1

#### Connector3

Source :	Port	Owner
	errorUnlinkedBG	CaseLinkingNotInUse1

Target :	Port	Owner
	errorUnlinkedBG	CheckBGConsistency

#### Connector4

Source :	Port	Owner
	applyServiceBrake	CaseLinkingNotInUse1

Target :	Port	Owner
	applyServiceBrake	CheckBGConsistency

#### Connector5

Source :	Port	Owner
	errorLinkedBG	CaseLinkingInUse1

Target :	Port	Owner
	errorLinkedBG	CheckBGConsistency

Connector6

Source :	Port	Owner
	passedBG_out	CaseLinkingNotInUse1
Target :	Port	Owner
	passedBG_out	CheckBGConsistency

Connector7

Source :	Port	Owner
	passedBG_out	CaseLinkingInUse1
Target :	Port	Owner
	passedBG_out	CheckBGConsistency

Connector1

Source :	Port	Owner
	reset	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	reset	Receive_TrackSide_Msg

Connector2

Source :	Port	Owner
	API_trackSide_Message	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	API_TrackSide_Msg	Receive_TrackSide_Msg

Connector3

Source :	Port	Owner
	inActiveCab	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	inActualOdometry	Receive_TrackSide_Msg

Connector4

Source :	Port	Owner
	outTrackMessage_for_check	Receive_TrackSide_Msg
Target :	Port	Owner
	trackSide_ForCheck	CheckBGConsistency

Connector5

Source :	Port	Owner
	applyServiceBrake	CheckBGConsistency
Target :	Port	Owner
	ApplyServiceBrake	F2.1 Manage_TrackSideInformation_Integration

Connector6

<b>Source :</b>	Port	Owner
	outTrackMessage_for_check	Receive_TrackSide_Msg
<b>Target :</b>	Port	Owner
	rtmMessage	CheckEuroRadioMessage

#### Connector7

<b>Source :</b>	Port	Owner
	outMessage	InformationFilter
<b>Target :</b>	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration

#### Connector8

<b>Source :</b>	Port	Owner
	inTrainDataValid	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	inTrainDataValid	InformationFilter

#### Connector9

<b>Source :</b>	Port	Owner
	passedBG_out	CheckBGConsistency
<b>Target :</b>	Port	Owner
	inMessage	validateDataDirection

#### Connector10

<b>Source :</b>	Port	Owner
	checkedMessage	CheckEuroRadioMessage
<b>Target :</b>	Port	Owner
	inMessage	validateDataDirection

#### Connector11

<b>Source :</b>	Port	Owner
	outMessage	validateDataDirection
<b>Target :</b>	Port	Owner
	inMessage	InformationFilter

#### Connector12

<b>Source :</b>	Port	Owner
	inActiveCab	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	inActiveCab	InformationFilter

#### Connector13

<b>Source :</b>	Port	Owner
	intrainVersion	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	trainVersion	CheckBGConsistency

#### Connector14

<b>Source :</b>	Port	Owner
	trainPosition	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	trainPosition	CheckBGConsistency

#### Connector15

<b>Source :</b>	Port	Owner
	inFilterEvents	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	inFilterEvents	InformationFilter

#### Connector16

<b>Source :</b>	Port	Owner
	outPacketsForML	InformationFilter
<b>Target :</b>	Port	Owner
	Data_to_From_Track_Packets_at_ML	F2.1 Manage_TrackSideInformation_Integration

#### Connector17

<b>Source :</b>	Port	Owner
	ActualOdometry	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	inActualOdometry	Receive_TrackSide_Msg

#### Connector1

<b>Source :</b>	Port	Owner
	TrainPosition	F2.7 SpeedSupervision_Integration
<b>Target :</b>	Port	Owner
	TrainPosition	InputWrapper

#### Connector3

<b>Source :</b>	Port	Owner
	trainProps	F2.7 SpeedSupervision_Integration
<b>Target :</b>	Port	Owner
	trainProps	InputWrapper

#### Connector4

<b>Source :</b>	Port	Owner
	dataFromTrackAtlas	F2.7 SpeedSupervision_Integration
<b>Target :</b>	Port	Owner
	dataFromTrackAtlas	InputWrapper

#### Connector11

<b>Source :</b>	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration
<b>Target :</b>	Port	Owner
	NationalValues	ABrakeFactory

#### Connector12

<b>Source :</b>	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration
<b>Target :</b>	Port	Owner
	trainData	ABrakeFactory

#### Connector13

<b>Source :</b>	Port	Owner
	mrsp_out	InputWrapper
<b>Target :</b>	Port	Owner
	MRSP	TargetManagement

#### Connector14

<b>Source :</b>	Port	Owner
	mrsp_update_out	InputWrapper
<b>Target :</b>	Port	Owner
	MRSP_updated	TargetManagement

#### Connector15

<b>Source :</b>	Port	Owner
	ma_out	InputWrapper
<b>Target :</b>	Port	Owner
	MA	TargetManagement

#### Connector16

<b>Source :</b>	Port	Owner
	ma_update_out	InputWrapper
<b>Target :</b>	Port	Owner
	MA_updated	TargetManagement

#### Connector17

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	trainLocations	TargetManagement

#### Connector18

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	TrainLocations	CalcBrakingCurves

#### Connector19

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	CalcBrakingCurves

#### Connector22

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	LimitLocations

#### Connector23

Source :	Port	Owner
	mrsp_out	InputWrapper
Target :	Port	Owner
	MRSP_Profile	LimitLocations

#### Connector24

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	trainLocations	LimitLocations

#### Connector26

Source :	Port	Owner
	curveCollection	CalcBrakingCurves
Target :	Port	Owner
	curveCollection	LimitLocations

#### Connector27

Source :	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	LimitLocations

#### Connector29

Source :	Port	Owner
	T_b	ABrakeFactory
Target :	Port	Owner
	T_b	LimitLocations

#### Connector30

Source :	Port	Owner
	ma_out	InputWrapper
Target :	Port	Owner
	MA	LimitLocations

#### Connector35

Source :	Port	Owner
	locations	LimitLocations
Target :	Port	Owner
	locations	Commands

#### Connector36

Source :	Port	Owner
	speeds	LimitLocations
Target :	Port	Owner
	speeds	Commands



Connector37

Source :	Port	Owner
	MostRestrictiveDisplayedTarget	LimitLocations
Target :	Port	Owner
	mrdt	Commands

Connector38

Source :	Port	Owner
	FLOIsSB1	LimitLocations
Target :	Port	Owner
	floIsSB1	Commands

Connector43

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	allTargets	Commands

Connector46

Source :	Port	Owner
	MostRestrictiveDisplayedTarget	LimitLocations
Target :	Port	Owner
	target	F2.7 SpeedSupervision_Integration

Connector47

Source :	Port	Owner
	sdmToDMI	Commands
Target :	Port	Owner
	sdmToDMI	F2.7 SpeedSupervision_Integration

Connector48

Source :	Port	Owner
	brakeCmd	Commands
Target :	Port	Owner
	brakeCmd	F2.7 SpeedSupervision_Integration

Connector49

Source :	Port	Owner
	sdmCmd	Commands
Target :	Port	Owner
	sdmCommands	F2.7 SpeedSupervision_Integration

Connector50

Source :	Port	Owner
	targetSpeedReached	Commands
Target :	Port	Owner
	Target_Speed_Reached	F2.7 SpeedSupervision_Integration

#### Connector51

Source :	Port	Owner
	eoasOverpassed	Commands
Target :	Port	Owner
	EOA_overpassed	F2.7 SpeedSupervision_Integration

#### Connector52

Source :	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	Commands

#### Connector53

Source :	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	TrainData_int	Commands

#### Connector54

Source :	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	trainData_int	LimitLocations

#### Connector55

Source :	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	LimitLocations

#### Connector56

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	trainLocations	LimitLocations

#### Connector57

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	TrainLocations	CalcBrakingCurves

#### Connector58

Source :	Port	Owner
	Service_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	MLrequestSB	Commands

#### Connector59

Source :	Port	Owner
	Emergency_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	MLrequestEB	Commands

#### Connector60

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	allTargets	Commands

#### Connector61

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	LimitLocations

#### Connector62

Source :	Port	Owner
	ma_out	InputWrapper
Target :	Port	Owner
	MA	LimitLocations

#### Connector63

Source :	Port	Owner
	mrsp_out	InputWrapper
Target :	Port	Owner
	MRSP_Profile	LimitLocations

#### Connector64

Source :	Port	Owner
	odometry	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	odometry	LimitLocations

#### Connector65

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	AGradient

#### Connector66

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	TrainLocations	AGradient

#### Connector67

Source :	Port	Owner
	gp_out	InputWrapper
Target :	Port	Owner
	GradientProfile	AGradient

#### Connector68

Source :	Port	Owner
	gp_update_out	InputWrapper
Target :	Port	Owner
	GradientProfile_updated	AGradient

#### Connector69

Source :	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	trainData	AGradient

#### Connector70

Source :	Port	Owner
	aBrakeSafe	ABrakeFactory
Target :	Port	Owner
	aBrakeSafe	addGradient1

#### Connector71

Source :	Port	Owner
	aBrakeService	ABrakeFactory
Target :	Port	Owner
	aBrakeSafe	addGradient2

#### Connector72

Source :	Port	Owner
	aSafe	addGradient1
Target :	Port	Owner
	A_Safe	CalcBrakingCurves

#### Connector73

Source :	Port	Owner
	aSafe	addGradient2
Target :	Port	Owner
	A_Expected	CalcBrakingCurves

#### Connector74

Source :	Port	Owner
	A_gradient	AGradient
Target :	Port	Owner
	aGradient	addGradient1

#### Connector75

Source :	Port	Owner
	A_gradient	AGradient
Target :	Port	Owner
	aGradient	addGradient2

#### Connector1

Source :	Port	Owner
	packet0	Build_SinglePosReport
Target :	Port	Owner
	inPacket0	AggregatePackets

#### Connector2

Source :	Port	Owner
	packet1	Build_SinglePosReport
Target :	Port	Owner
	inPacket1	AggregatePackets

#### Connector3

Source :	Port	Owner
	packet4	Build_SinglePosReport

Target :	Port	Owner
	inPacket4	AggregatePackets

#### Connector4

Source :	Port	Owner
	packet5	Build_SinglePosReport

Target :	Port	Owner
	inPacket5	AggregatePackets

#### Connector6

Source :	Port	Owner
	present	ReceiveReportParameters

Target :	Port	Owner
	present	PosReport_Supervision

#### Connector7

Source :	Port	Owner
	posRepParam	ReceiveReportParameters

Target :	Port	Owner
	posRepParam	PosReport_Supervision

#### Connector9

Source :	Port	Owner
	trigger	PosReport_Supervision

Target :	Port	Owner
	reportIsSent	AddBGToFIFO

Connector10

Source :	Port	Owner
	posRepHeader	Build_SinglePosReport
Target :	Port	Owner
	posRep	F2.8 ProvidePositionReport

Connector11

Source :	Port	Owner
	packet0	Build_Packets0_1
Target :	Port	Owner
	in_packet0	Build_SinglePosReport

Connector12

Source :	Port	Owner
	packet1	Build_Packets0_1
Target :	Port	Owner
	in_packet1	Build_SinglePosReport

Connector13

Source :	Port	Owner
	packet0	Build_Packets0_1
Target :	Port	Owner
	packet0	F2.8 ProvidePositionReport

Connector14

Source :	Port	Owner
	packet1	Build_Packets0_1
Target :	Port	Owner
	packet1	F2.8 ProvidePositionReport

Connector15

Source :	Port	Owner
	errorVector	ErrorManager
Target :	Port	Owner
	errorMsg	Build_SinglePosReport

Connector16

Source :	Port	Owner
	BG_LinkingConsistencyError	F2.8 ProvidePositionReport
Target :	Port	Owner
	BG_LinkingConsistencyError	ErrorManager

Connector17

<b>Source :</b>	Port	Owner
	LinkedBG_MessageConsistencyError	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	LinkedBG_MessageConsistencyError	ErrorManager

#### Connector18

<b>Source :</b>	Port	Owner
	UnlinkedBG_MessageConsistencyError	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	UnlinkedBG_MessageConsistencyError	ErrorManager

#### Connector19

<b>Source :</b>	Port	Owner
	RadioMessageConsistencyError	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	RadioMessageConsistencyError	ErrorManager

#### Connector20

<b>Source :</b>	Port	Owner
	RadioSequenceError	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	RadioSequenceError	ErrorManager

#### Connector21

<b>Source :</b>	Port	Owner
	RadioSafeRadioConnectionError	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	RadioSafeRadioConnectionError	ErrorManager

#### Connector22

<b>Source :</b>	Port	Owner
	SafetyCriticalFailure	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	SafetyCriticalFailure	ErrorManager

#### Connector23

<b>Source :</b>	Port	Owner
	DoubleLinkingError	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	DoubleLinkingError	ErrorManager

#### Connector24



<b>Source :</b>	Port	Owner
	DoubleRepositioningError	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	DoubleRepositioningError	ErrorManager

#### Connector25

<b>Source :</b>	Port	Owner
	modeLevelStatus	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	modeLevelStatus	PosReport_Supervision

#### Connector26

<b>Source :</b>	Port	Owner
	modeLevelStatus	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	modeLevelStatus	Build_Packets0_1

#### Connector27

<b>Source :</b>	Port	Owner
	posBGs	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	posBGs	PosReport_Supervision

#### Connector28

<b>Source :</b>	Port	Owner
	posBGs	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	posBGs	Build_Packets0_1

#### Connector29

<b>Source :</b>	Port	Owner
	trainPos	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	trainPos	PosReport_Supervision

#### Connector30

<b>Source :</b>	Port	Owner
	trainPos	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	trainPos	Build_Packets0_1

#### Connector31

Source :	Port	Owner
	odometry	F2.8 ProvidePositionReport
Target :	Port	Owner
	odometry	PosReport_Supervision

#### Connector32

Source :	Port	Owner
	odometry	F2.8 ProvidePositionReport
Target :	Port	Owner
	odometry	Build_Packets0_1

#### Connector33

Source :	Port	Owner
	trainProps	F2.8 ProvidePositionReport
Target :	Port	Owner
	trainProps	Build_SinglePosReport

#### Connector35

Source :	Port	Owner
	trainProps	F2.8 ProvidePositionReport
Target :	Port	Owner
	trainProps	Build_Packets0_1

#### Connector36

Source :	Port	Owner
	inMessage	F2.8 ProvidePositionReport
Target :	Port	Owner
	inMessage	ReceiveReportParameters

#### Connector37

Source :	Port	Owner
	out_reportedBGs	AddBGToFIFO
Target :	Port	Owner
	reportedBGs	ReceiveReportParameters

#### Connector38

Source :	Port	Owner
	t_train	F2.8 ProvidePositionReport
Target :	Port	Owner
	t_train	Build_SinglePosReport

#### Connector39

Source :	Port	Owner
	prvDirTrain	F2.8 ProvidePositionReport
Target :	Port	Owner
	prvDirTrain	Build_Packets0_1

#### Connector41

Source :	Port	Owner
	train2trackStatus	F2.8 ProvidePositionReport
Target :	Port	Owner
	train2trackStatus	Build_Packets0_1

#### Connector42

Source :	Port	Owner
	trackInfo	F2.8 ProvidePositionReport
Target :	Port	Owner
	trackInfo	PosReport_Supervision

#### Connector43

Source :	Port	Owner
	systemTime	F2.8 ProvidePositionReport
Target :	Port	Owner
	systemTime	PosReport_Supervision

#### Connector44

Source :	Port	Owner
	rcbComm	F2.8 ProvidePositionReport
Target :	Port	Owner
	rcbComm	PosReport_Supervision

#### Connector45

Source :	Port	Owner
	train2trackStatus	F2.8 ProvidePositionReport
Target :	Port	Owner
	train2trackStatus	PosReport_Supervision

#### Connector46

Source :	Port	Owner
	posBGs	F2.8 ProvidePositionReport
Target :	Port	Owner
	posBGs	AddBGToFIFO

#### Connector47

Source :	Port	Owner
	out_reportedBGs	ReceiveReportParameters
Target :	Port	Owner
	reportedBGs	AddBGToFIFO

#### Connector51

Source :	Port	Owner
	prvDirTrain	F2.8 ProvidePositionReport
Target :	Port	Owner
	prvDirTrain	PosReport_Supervision

#### Connector52

Source :	Port	Owner
	out_reportedBGs	ReceiveReportParameters
Target :	Port	Owner
	reportedBGs	PosReport_Supervision

#### Connector53

Source :	Port	Owner
	trainProps	F2.8 ProvidePositionReport
Target :	Port	Owner
	trainProps	PosReport_Supervision

#### Connector1

Source :	Port	Owner
	reset	F2.3 trainData
Target :	Port	Owner
	reset	trainDataStorage

Connector2

Source :	Port	Owner
	trainDatafromTIU	F2.3 trainData
Target :	Port	Owner
	trainDatafromTIU	trainDataStorage

Connector3

Source :	Port	Owner
	trainDatafromDriver	F2.3 trainData
Target :	Port	Owner
	trainDatafromDriver	trainDataStorage

Connector4

Source :	Port	Owner
	trainDataAckfromDriver	F2.3 trainData
Target :	Port	Owner
	trainDataAckfromDriver	trainDataStorage

Connector5

Source :	Port	Owner
	trackMessages	F2.3 trainData
Target :	Port	Owner
	trackMessages	checkRadioMessages

Connector6

Source :	Port	Owner
	eventsForTrainData	F2.3 trainData
Target :	Port	Owner
	eventsForTrainData	trainDataStorage

Connector7

Source :	Port	Owner
	actualTrainData	trainDataStorage
Target :	Port	Owner
	trainData	sendValidTrainDataRBC

Connector8

Source :	Port	Owner
	actualTrainData	trainDataStorage
Target :	Port	Owner
	actualTrainData	F2.3 trainData

Connector9

Source :	Port	Owner
	p0_positionReport	F2.3 trainData
Target :	Port	Owner
	p0_positionReport	sendValidTrainDataRBC

#### Connector10

Source :	Port	Owner
	p1_positionReport	F2.3 trainData
Target :	Port	Owner
	p1_positionReport	sendValidTrainDataRBC

#### Connector11

Source :	Port	Owner
	nidEngine	F2.3 trainData
Target :	Port	Owner
	nidEngine	sendValidTrainDataRBC

#### Connector12

Source :	Port	Owner
	nidEngine	F2.3 trainData
Target :	Port	Owner
	nidEngine	sendAcknowledgementRBC

#### Connector13

Source :	Port	Owner
	t_train	F2.3 trainData
Target :	Port	Owner
	evc_t_train	sendValidTrainDataRBC

#### Connector14

Source :	Port	Owner
	t_train	F2.3 trainData
Target :	Port	Owner
	EVC_t_train	sendAcknowledgementRBC

#### Connector15

Source :	Port	Owner
	trackMessages	F2.3 trainData
Target :	Port	Owner
	RBC_timeStamp	sendAcknowledgementRBC

#### Connector16

Source :	Port	Owner
	outMessageBus	sendAcknowledgementRBC
Target :	Port	Owner
	outMessageBus	F2.3 trainData

#### Connector17

Source :	Port	Owner
	outMessageBus	sendValidTrainDataRBC
Target :	Port	Owner
	outMessageBus	F2.3 trainData

#### Connector18

Source :	Port	Owner
	MessageBus	F2.3 trainData
Target :	Port	Owner
	MessageBus	sendAcknowledgementRBC

#### Connector19

Source :	Port	Owner
	MessageBus	F2.3 trainData
Target :	Port	Owner
	MessageBus	sendValidTrainDataRBC

#### Connector1

Source :	Port	Owner
	API_fromTIU	F2 ETCS Kernel
Target :	Port	Owner
	inTIUfromAPI	F2.12 manageTIU_input

#### Connector10

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	systemtime	F2.2 Manage_ETCS_Procedures

#### Connector11

Source :	Port	Owner
	EVC_reset	F2 ETCS Kernel
Target :	Port	Owner
	reset	F2.1 Manage_TrackSideInformation_Integration

#### Connector12

Source :	Port	Owner
	API_fromTrack	F2 ETCS Kernel
Target :	Port	Owner
	API_trackSide_Message	F2.1 Manage_TrackSideInformation_Integration

#### Connector13

Source :	Port	Owner
	API_Odometry	F2 ETCS Kernel
Target :	Port	Owner
	ActualOdometry	F2.1 Manage_TrackSideInformation_Integration

#### Connector30

Source :	Port	Owner
	EVC_reset	F2 ETCS Kernel
Target :	Port	Owner
	reset	F2.3 trainData

#### Connector31

Source :	Port	Owner
	API_fromTrack	F2 ETCS Kernel
Target :	Port	Owner
	trackMessages	F2.3 trainData

#### Connector32

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	t_train	F2.3 trainData

#### Connector38

Source :	Port	Owner
	EVC_reset	F2 ETCS Kernel
Target :	Port	Owner
	reset	F2.6 calculateTrainPosition

#### Connector39

Source :	Port	Owner
	API_Odometry	F2 ETCS Kernel
Target :	Port	Owner
	currentOdometry	F2.6 calculateTrainPosition

#### Connector41



Source :	Port	Owner
	API_fromDMI	F2 ETCS Kernel
Target :	Port	Owner
	fromDMI	F2.10 manageDMI_Input

#### Connector42

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	currentTime	F2.9 MoRC_HO

#### Connector43

Source :	Port	Owner
	EVC_reset	F2 ETCS Kernel
Target :	Port	Owner
	reset	F2.9 MoRC_HO

#### Connector44

Source :	Port	Owner
	to_DMI	F2.11 manageDMI_Output
Target :	Port	Owner
	API_toDMI	F2 ETCS Kernel

#### Connector45

Source :	Port	Owner
	outTIU_to_API	F2.13 manageTIU_output
Target :	Port	Owner
	API_toTIU	F2 ETCS Kernel

#### Connector46

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	trainPosition	F2.1 Manage_TrackSideInformation_Integration

#### Connector50

Source :	Port	Owner
	BGs	F2.6 calculateTrainPosition
Target :	Port	Owner
	inAnnouncedBGs	F2.1 Manage_TrackSideInformation_Integration

#### Connector51

Source :	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
Target :	Port	Owner
	trainProperties	F2.6 calculateTrainPosition

#### Connector52

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	trainProperties	F2.6 calculateTrainPosition

#### Connector53

Source :	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	msgFromTrack	F2.6 calculateTrainPosition

#### Connector54

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	inTrainPosition	F2.11 manageDMI_Output

#### Connector55

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	TrainPosition	F2.7 SpeedSupervision_Integration

Connector56

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	trainPos	F2.8 ProvidePositionReport

Connector57

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	Data_From_Localisation	F2.5 ManageLevelAndMode

Connector58

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	statusValid_Position_from_Position_Calculation	F2.2 Manage_ETCS_Procedures

Connector59

Source :	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
Target :	Port	Owner
	prvDirTrain	F2.8 ProvidePositionReport

Connector60

Source :	Port	Owner
	BGs	F2.6 calculateTrainPosition
Target :	Port	Owner
	posBGs	F2.8 ProvidePositionReport

Connector61

Source :	Port	Owner
	errors	F2.6 calculateTrainPosition
Target :	Port	Owner
	DoubleRepositioningError	F2.8 ProvidePositionReport

Connector62

Source :	Port	Owner
	errors	F2.6 calculateTrainPosition
Target :	Port	Owner
	DoubleLinkingError	F2.8 ProvidePositionReport

Connector63

<b>Source :</b>	Port	Owner
	errors	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	BG_LinkingConsistencyError	F2.8 ProvidePositionReport

#### Connector64

<b>Source :</b>	Port	Owner
	API_fromDMI	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	fromDMI	F2.10 manageDMI_Input

#### Connector65

<b>Source :</b>	Port	Owner
	EVC_reset	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	dmiStatusReset	F2.10 manageDMI_Input

#### Connector66

<b>Source :</b>	Port	Owner
	API_SystemTime	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	inSystemTime	F2.10 manageDMI_Input

#### Connector67

<b>Source :</b>	Port	Owner
	outStatusList	F2.11 manageDMI_Output
<b>Target :</b>	Port	Owner
	inStatusList	F2.10 manageDMI_Input

#### Connector68

<b>Source :</b>	Port	Owner
	currentDMISStatus	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	statusDMI_from_DMI	F2.2 Manage_ETCS_Procedures

#### Connector69

<b>Source :</b>	Port	Owner
	currentDMISStatus	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	incurrentDMISStatus	F2.11 manageDMI_Output

#### Connector70

<b>Source :</b>	Port	Owner
	currentDMIStatus	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	LevelValid_from_Level_and_Mode_Management	F2.2 Manage_ETCS_Procedures

#### Connector71

<b>Source :</b>	Port	Owner
	outUpdateLevelsDMI	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	dmiUpdateLevelsDMI	F2.11 manageDMI_Output

#### Connector72

<b>Source :</b>	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	trainProperties	F2.9 MoRC_HO

#### Connector73

<b>Source :</b>	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	trainProps	F2.7 SpeedSupervision_Integration

#### Connector74

<b>Source :</b>	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	trainProps	F2.8 ProvidePositionReport

#### Connector75

<b>Source :</b>	Port	Owner
	fromDMI_TrainData	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	trainDatafromDriver	F2.3 trainData

#### Connector76

<b>Source :</b>	Port	Owner
	fromDMI_TrainDataAck	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	trainDataAckfromDriver	F2.3 trainData

#### Connector77

<b>Source :</b>	Port	Owner
	forModesAndLevel	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	Data_From_DMI	F2.5 ManageLevelAndMode

#### Connector78

<b>Source :</b>	Port	Owner
	ML_levelTransition	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	driver_level_transition_In	F2.5 ManageLevelAndMode

#### Connector79

<b>Source :</b>	Port	Owner
	outStatusList	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	inStatusList	F2.11 manageDMI_Output

#### Connector80

<b>Source :</b>	Port	Owner
	outDriverRequest	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	status_DMILEvel_from_DMI	F2.2 Manage_ETCS_Procedures

#### Connector81

<b>Source :</b>	Port	Owner
	updatedNTC	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	train2trackStatus	F2.8 ProvidePositionReport

#### Connector82

<b>Source :</b>	Port	Owner
	updatedNTC	F2.10 manageDMI_Input
<b>Target :</b>	Port	Owner
	inNTC	F2.11 manageDMI_Output

#### Connector83

<b>Source :</b>	Port	Owner
	API_Odometry	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	inOdometry	F2.11 manageDMI_Output

#### Connector84

<b>Source :</b>	Port	Owner
	API_SystemTime	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	inSystemTime	F2.11 manageDMI_Output

#### Connector85

<b>Source :</b>	Port	Owner
	outTIUStatus	F2.12 manageTIU_input
<b>Target :</b>	Port	Owner
	TIU_TrainStatus	F2.11 manageDMI_Output

#### Connector86

<b>Source :</b>	Port	Owner
	brakeCmd	F2.7 SpeedSupervision_Integration
<b>Target :</b>	Port	Owner
	inBrakeCommand	F2.11 manageDMI_Output

#### Connector87

<b>Source :</b>	Port	Owner
	sdmToDMI	F2.7 SpeedSupervision_Integration
<b>Target :</b>	Port	Owner
	inSpeedSupervision	F2.11 manageDMI_Output

#### Connector88

<b>Source :</b>	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	inModeAndLevel	F2.11 manageDMI_Output

#### Connector89

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	trainDataFromEVC	F2.11 manageDMI_Output

#### Connector90

<b>Source :</b>	Port	Owner
	DMI_Entry_Request_to_DMI	F2.2 Manage_ETCS_Procedures
<b>Target :</b>	Port	Owner
	dmi_entryRequest	F2.11 manageDMI_Output

#### Connector91

<b>Source :</b>	Port	Owner
	BadBaliseMessageToDMI	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	dmi_fromBG	F2.11 manageDMI_Output

#### Connector93

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	evc_trainData	F2.12 manageTIU_input

#### Connector94

<b>Source :</b>	Port	Owner
	outTIUStatus	F2.12 manageTIU_input
<b>Target :</b>	Port	Owner
	cabStatus_from_TIU	F2.2 Manage_ETCS_Procedures

#### Connector95

<b>Source :</b>	Port	Owner
	outTIUStatus	F2.12 manageTIU_input
<b>Target :</b>	Port	Owner
	inActiveCab	F2.1 Manage_TrackSideInformation_Integration

#### Connector96

<b>Source :</b>	Port	Owner
	outTIUStatus	F2.12 manageTIU_input
<b>Target :</b>	Port	Owner
	Cab_In	F2.5 ManageLevelAndMode



**Connector97**

<b>Source :</b>	Port	Owner
	outTIUCurrentInfo	F2.12 manageTIU_input
<b>Target :</b>	Port	Owner
	Data_From_TIU	F2.5 ManageLevelAndMode

**Connector100**

<b>Source :</b>	Port	Owner
	brakeCmd	F2.7 SpeedSupervision_Integration
<b>Target :</b>	Port	Owner
	in_brake_command	F2.13 manageTIU_output

**Connector101**

<b>Source :</b>	Port	Owner
	EB_Requested	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	Emergency_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration

**Connector102**

<b>Source :</b>	Port	Owner
	API_Odometry	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	odometry	F2.7 SpeedSupervision_Integration

**Connector103**

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	trainProps	F2.7 SpeedSupervision_Integration

**Connector104**

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	trainData	F2.7 SpeedSupervision_Integration

**Connector105**

<b>Source :</b>	Port	Owner
	ApplyServiceBrake	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	Service_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration

**Connector106**

<b>Source :</b>	Port	Owner
	API_fromTIU	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	trainDatafromTIU	F2.3 trainData

#### Connector107

<b>Source :</b>	Port	Owner
	outputMessageForRadioAck	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	trackMessages	F2.3 trainData

#### Connector109

<b>Source :</b>	Port	Owner
	packet0	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	p0_positionReport	F2.3 trainData

#### Connector110

<b>Source :</b>	Port	Owner
	packet1	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	p1_positionReport	F2.3 trainData

#### Connector111

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	trainProps	F2.8 ProvidePositionReport

#### Connector112

<b>Source :</b>	Port	Owner
	updatedStatus	F2.3 trainData
<b>Target :</b>	Port	Owner
	inFilterEvents	F2.1 Manage_TrackSideInformation_Integration

#### Connector113

<b>Source :</b>	Port	Owner
	updatedStatus	F2.3 trainData
<b>Target :</b>	Port	Owner
	inTrainDataValid	F2.1 Manage_TrackSideInformation_Integration

#### Connector116

<b>Source :</b>	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	inMessage	F2.8 ProvidePositionReport

#### Connector117

<b>Source :</b>	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	LinkedBG_MessageConsistencyError	F2.8 ProvidePositionReport

#### Connector118

<b>Source :</b>	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	UnlinkedBG_MessageConsistencyError	F2.8 ProvidePositionReport

#### Connector119

<b>Source :</b>	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	RadioMessageConsistencyError	F2.8 ProvidePositionReport

#### Connector120

<b>Source :</b>	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	RadioSequenceError	F2.8 ProvidePositionReport

#### Connector121

<b>Source :</b>	Port	Owner
	outCheckErrors	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	Data_From_F2_Functions	F2.5 ManageLevelAndMode

#### Connector123

<b>Source :</b>	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	StatusModeandLevel_from_Level_and_Mode_Managem	F2.2 Manage_ETCS_Procedures

#### Connector125

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	systemTime	F2.8 ProvidePositionReport

#### Connector126

Source :	Port	Owner
	API_Odometry	F2 ETCS Kernel
Target :	Port	Owner
	odometry	F2.8 ProvidePositionReport

#### Connector127

Source :	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
Target :	Port	Owner
	in_train_commands	F2.13 manageTIU_output

#### Connector128

Source :	Port	Owner
	Data_To_DMI_Ack	F2.5 ManageLevelAndMode
Target :	Port	Owner
	inModeLevel_Ack	F2.11 manageDMI_Output

#### Connector129

Source :	Port	Owner
	announcedLevel	F2.5 ManageLevelAndMode
Target :	Port	Owner
	announcedLevel	F2.11 manageDMI_Output

#### Connector130

Source :	Port	Owner
	Service_Brake_Command	F2.5 ManageLevelAndMode
Target :	Port	Owner
	Service_brake_requested_by_modes_and_levels	F2.7 SpeedSupervision_Integration

#### Connector131

Source :	Port	Owner
	Data_to_From_Track_Packets_at_ML	F2.1 Manage_TrackSideInformation_Integration
Target :	Port	Owner
	Data_From_Track_Packets	F2.5 ManageLevelAndMode

#### Connector132

<b>Source :</b>	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	modeAndLevel	F2.1 Manage_TrackSideInformation_Integration

#### Connector133

<b>Source :</b>	Port	Owner
	forLevelManagement	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	Data_from_Track_MASSPGradient	F2.5 ManageLevelAndMode

#### Connector134

<b>Source :</b>	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	modeLevelStatus	F2.8 ProvidePositionReport

#### Connector135

<b>Source :</b>	Port	Owner
	posRep	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

#### Connector150

<b>Source :</b>	Port	Owner
	outMessageBus	F2.3 trainData
<b>Target :</b>	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

#### Connector157

<b>Source :</b>	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	transitionPositionPassed	F2.1 Manage_TrackSideInformation_Integration

#### Connector161

<b>Source :</b>	Port	Owner
	errors	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	Data_From_Localisation	F2.5 ManageLevelAndMode

#### Connector162

<b>Source :</b>	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	MessageIn	F2.4 TrackAtlas

#### Connector163

<b>Source :</b>	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	ModeAndLevel_in	F2.4 TrackAtlas

#### Connector164

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	TrainData_in	F2.4 TrackAtlas

#### Connector165

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	train_length	F2.4 TrackAtlas

#### Connector166

<b>Source :</b>	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	TrainPositionIn	F2.4 TrackAtlas

Connector167

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	SystemTime	F2.4 TrackAtlas

Connector168

Source :	Port	Owner
	API_Odometry	F2 ETCS Kernel
Target :	Port	Owner
	odometry	F2.4 TrackAtlas

Connector169

Source :	Port	Owner
	sdmToDMI	F2.7 SpeedSupervision_Integration
Target :	Port	Owner
	preindicationLocation	F2.4 TrackAtlas

Connector170

Source :	Port	Owner
	outForMA	F2.10 manageDMI_Input
Target :	Port	Owner
	fromDriverToMA_R	F2.4 TrackAtlas

Connector171

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	trainProps	F2.4 TrackAtlas

Connector172

Source :	Port	Owner
	actualTrainData	F2.3 trainData
Target :	Port	Owner
	trainProps	F2.4 TrackAtlas

Connector173

Source :	Port	Owner
	packet0	F2.8 ProvidePositionReport
Target :	Port	Owner
	packet0	F2.4 TrackAtlas

Connector174

Source :	Port	Owner
	packet1	F2.8 ProvidePositionReport
Target :	Port	Owner
	packet1	F2.4 TrackAtlas

#### Connector175

Source :	Port	Owner
	API_SystemTime	F2 ETCS Kernel
Target :	Port	Owner
	t_train	F2.4 TrackAtlas

#### Connector178

Source :	Port	Owner
	To_ModeAndLevel	F2.4 TrackAtlas
Target :	Port	Owner
	Data_From_Track_Messages	F2.5 ManageLevelAndMode

#### Connector179

Source :	Port	Owner
	to_DMI	F2.4 TrackAtlas
Target :	Port	Owner
	dmi_trackDescription	F2.11 manageDMI_Output

#### Connector180

Source :	Port	Owner
	to_Supervision	F2.4 TrackAtlas
Target :	Port	Owner
	dataFromTrackAtlas	F2.7 SpeedSupervision_Integration

#### Connector181

Source :	Port	Owner
	MA_request_out	F2.4 TrackAtlas
Target :	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

#### Connector183

Source :	Port	Owner
	fromDMI_TrainRunningNumber	F2.10 manageDMI_Input
Target :	Port	Owner
	trainProps	F2.4 TrackAtlas

#### Connector185



<b>Source :</b>	Port	Owner
	API_Odometry	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	Data_From_Localisation	F2.5 ManageLevelAndMode

#### Connector188

<b>Source :</b>	Port	Owner
	outMessageBus	F2.3 trainData
<b>Target :</b>	Port	Owner
	bus_in	F2.4 TrackAtlas

#### Connector190

<b>Source :</b>	Port	Owner
	bus_out	F2.4 TrackAtlas
<b>Target :</b>	Port	Owner
	MessageBus	F2.8 ProvidePositionReport

#### Connector191

<b>Source :</b>	Port	Owner
	API_mobileHWStatus	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	mobileRegistrationContext_1	F2.9 MoRC_HO

#### Connector192

<b>Source :</b>	Port	Owner
	API_mobileHWStatus	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	mobileConnectionContext_1	F2.9 MoRC_HO

#### Connector193

<b>Source :</b>	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	mode	F2.9 MoRC_HO

#### Connector194

<b>Source :</b>	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	level	F2.9 MoRC_HO

#### Connector195

<b>Source :</b>	Port	Owner
	powerUp_to_MoRC	F2.2 Manage_ETCS_Procedures
<b>Target :</b>	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector196

<b>Source :</b>	Port	Owner
	statusstartofmissionongoing_to_MoRC	F2.2 Manage_ETCS_Procedures
<b>Target :</b>	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector197

<b>Source :</b>	Port	Owner
	powerOff_to_MoRC	F2.2 Manage_ETCS_Procedures
<b>Target :</b>	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector198

<b>Source :</b>	Port	Owner
	request_Start_Mobile_Terminal_and_RBC_Registration_	F2.2 Manage_ETCS_Procedures
<b>Target :</b>	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector199

<b>Source :</b>	Port	Owner
	Compatible_Mode_And_Level	F2.5 ManageLevelAndMode
<b>Target :</b>	Port	Owner
	eventsAndPhases	F2.9 MoRC_HO

#### Connector200

<b>Source :</b>	Port	Owner
	API_SystemTime	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	t_train	F2.9 MoRC_HO

#### Connector201

<b>Source :</b>	Port	Owner
	API_SystemTime	F2 ETCS Kernel
<b>Target :</b>	Port	Owner
	t_train_global	F2.9 MoRC_HO

#### Connector202

<b>Source :</b>	Port	Owner
	outputMessage	F2.1 Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	dataFromTrack_in	F2.9 MoRC_HO

#### Connector203

<b>Source :</b>	Port	Owner
	posReport	F2.8 ProvidePositionReport
<b>Target :</b>	Port	Owner
	msgBusToRBC_in	F2.9 MoRC_HO

#### Connector204

<b>Source :</b>	Port	Owner
	trainPosition	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	trainPosition	F2.9 MoRC_HO

#### Connector205

<b>Source :</b>	Port	Owner
	BGs	F2.6 calculateTrainPosition
<b>Target :</b>	Port	Owner
	BGs	F2.9 MoRC_HO

#### Connector206

<b>Source :</b>	Port	Owner
	actualTrainData	F2.3 trainData
<b>Target :</b>	Port	Owner
	trainProperties	F2.9 MoRC_HO

#### Connector207

<b>Source :</b>	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	mobileStatus	F2.2 Manage_ETCS_Procedures

#### Connector208

<b>Source :</b>	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	radioStatus	F2.1 Manage_TrackSideInformation_Integration

#### Connector209

<b>Source :</b>	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	inMoRC_status	F2.11 managedDMI_Output

#### Connector210

<b>Source :</b>	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	eventsForTrainData	F2.3 trainData

#### Connector211

<b>Source :</b>	Port	Owner
	radioStatus_1	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	rcbComm	F2.8 ProvidePositionReport

#### Connector212

<b>Source :</b>	Port	Owner
	mobileConnectionCmd_1	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

#### Connector213

<b>Source :</b>	Port	Owner
	mobileRegistrationCmd_1	F2.9 MoRC_HO
<b>Target :</b>	Port	Owner
	API_toEuroradio	F2 ETCS Kernel

Connector214

Source :	Port	Owner
	supervisingRBC	F2.9 MoRC_HO
Target :	Port	Owner
	inSupervisingRbclId	F2.1 Manage_TrackSideInformation_Integration

Connector215

Source :	Port	Owner
	ready	F2.9 MoRC_HO
Target :	Port	Owner
	eventsForTrainData	F2.3 trainData

Connector216

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	intrainVersion	F2.1 Manage_TrackSideInformation_Integration

Connector217

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	q_nvlocacc	F2.1 Manage_TrackSideInformation_Integration

Connector218

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	tNvContact	F2.1 Manage_TrackSideInformation_Integration

Connector219

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	nidEngine	F2.3 trainData

Connector220

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	P203V1_onboard	F2.4 TrackAtlas

Connector221

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	PermanentDataP003	F2.4 TrackAtlas

#### Connector222

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	ERTMS_capabilities_In	F2.5 ManageLevelAndMode

#### Connector223

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	Data_From_STM	F2.5 ManageLevelAndMode

#### Connector224

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	NationalValues	F2.7 SpeedSupervision_Integration

#### Connector225

Source :	Port	Owner
	API_persistentDataIn	F2 ETCS Kernel
Target :	Port	Owner
	t_train	F2.8 ProvidePositionReport

#### Connector1

Source :	Port	Owner
	TrainPosition	SpeedSupervision_Integration
Target :	Port	Owner
	TrainPosition	InputWrapper

#### Connector3

Source :	Port	Owner
	trainProps	SpeedSupervision_Integration
Target :	Port	Owner
	trainProps	InputWrapper

#### Connector4

<b>Source :</b>	Port	Owner
	dataFromTrackAtlas	SpeedSupervision_Integration
<b>Target :</b>	Port	Owner
	dataFromTrackAtlas	InputWrapper

#### Connector11

<b>Source :</b>	Port	Owner
	NationalValues	SpeedSupervision_Integration
<b>Target :</b>	Port	Owner
	NationalValues	ABrakeFactory

#### Connector12

<b>Source :</b>	Port	Owner
	trainData	SpeedSupervision_Integration
<b>Target :</b>	Port	Owner
	trainData	ABrakeFactory

#### Connector13

<b>Source :</b>	Port	Owner
	mrsp_out	InputWrapper
<b>Target :</b>	Port	Owner
	MRSP	TargetManagement

#### Connector14

<b>Source :</b>	Port	Owner
	mrsp_update_out	InputWrapper
<b>Target :</b>	Port	Owner
	MRSP_updated	TargetManagement

#### Connector15

<b>Source :</b>	Port	Owner
	ma_out	InputWrapper
<b>Target :</b>	Port	Owner
	MA	TargetManagement

#### Connector16

<b>Source :</b>	Port	Owner
	ma_update_out	InputWrapper
<b>Target :</b>	Port	Owner
	MA_updated	TargetManagement

#### Connector17

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	trainLocations	TargetManagement

#### Connector18

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	TrainLocations	CalcBrakingCurves

#### Connector19

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	CalcBrakingCurves

#### Connector22

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	LimitLocations

#### Connector23

Source :	Port	Owner
	mrsp_out	InputWrapper
Target :	Port	Owner
	MRSP_Profile	LimitLocations

#### Connector24

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	trainLocations	LimitLocations

#### Connector26

Source :	Port	Owner
	curveCollection	CalcBrakingCurves
Target :	Port	Owner
	curveCollection	LimitLocations

#### Connector27



<b>Source :</b>	Port	Owner
	NationalValues	SpeedSupervision_Integration
<b>Target :</b>	Port	Owner
	NationalValues	LimitLocations

#### Connector29

<b>Source :</b>	Port	Owner
	T_b	ABrakeFactory
<b>Target :</b>	Port	Owner
	T_b	LimitLocations

#### Connector30

<b>Source :</b>	Port	Owner
	ma_out	InputWrapper
<b>Target :</b>	Port	Owner
	MA	LimitLocations

#### Connector35

<b>Source :</b>	Port	Owner
	locations	LimitLocations
<b>Target :</b>	Port	Owner
	locations	Commands

#### Connector36

<b>Source :</b>	Port	Owner
	speeds	LimitLocations
<b>Target :</b>	Port	Owner
	speeds	Commands

#### Connector37

<b>Source :</b>	Port	Owner
	MostRestrictiveDisplayedTarget	LimitLocations
<b>Target :</b>	Port	Owner
	mrtd	Commands

#### Connector38

<b>Source :</b>	Port	Owner
	FLOIsSB11	LimitLocations
<b>Target :</b>	Port	Owner
	foilsSB1	Commands

#### Connector43

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	allTargets	Commands

#### Connector46

Source :	Port	Owner
	MostRestrictiveDisplayedTarget	LimitLocations
Target :	Port	Owner
	target	SpeedSupervision_Integration

#### Connector47

Source :	Port	Owner
	sdmToDMI	Commands
Target :	Port	Owner
	sdmToDMI	SpeedSupervision_Integration

#### Connector48

Source :	Port	Owner
	brakeCmd	Commands
Target :	Port	Owner
	brakeCmd	SpeedSupervision_Integration

#### Connector49

Source :	Port	Owner
	sdmCmd	Commands
Target :	Port	Owner
	sdmCommands	SpeedSupervision_Integration

Connector50

Source :	Port	Owner
	targetSpeedReached	Commands
Target :	Port	Owner
	Target_Speed_Reached	SpeedSupervision_Integration

Connector51

Source :	Port	Owner
	eoasOverpassed	Commands
Target :	Port	Owner
	EOA_overpassed	SpeedSupervision_Integration

Connector52

Source :	Port	Owner
	NationalValues	SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	Commands

Connector53

Source :	Port	Owner
	trainData	SpeedSupervision_Integration
Target :	Port	Owner
	TrainData_int	Commands

Connector54

Source :	Port	Owner
	trainData	SpeedSupervision_Integration
Target :	Port	Owner
	trainData_int	LimitLocations

Connector55

Source :	Port	Owner
	NationalValues	SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	LimitLocations

Connector56

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	trainLocations	LimitLocations

Connector57

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	TrainLocations	CalcBrakingCurves

#### Connector58

Source :	Port	Owner
	Service_brake_requested_by_modes_and_levels	SpeedSupervision_Integration
Target :	Port	Owner
	MLrequestSB	Commands

#### Connector59

Source :	Port	Owner
	Emergency_brake_requested_by_modes_and_levels	SpeedSupervision_Integration
Target :	Port	Owner
	MLrequestEB	Commands

#### Connector60

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	allTargets	Commands

#### Connector61

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	LimitLocations

#### Connector62

Source :	Port	Owner
	ma_out	InputWrapper
Target :	Port	Owner
	MA	LimitLocations

#### Connector63

Source :	Port	Owner
	mrsp_out	InputWrapper
Target :	Port	Owner
	MRSP_Profile	LimitLocations

#### Connector64

Source :	Port	Owner
	odometry	SpeedSupervision_Integration
Target :	Port	Owner
	odometry	LimitLocations

#### Connector65

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	AGradient

#### Connector66

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	TrainLocations	AGradient

#### Connector67

Source :	Port	Owner
	gp_out	InputWrapper
Target :	Port	Owner
	GradientProfile	AGradient

#### Connector68

Source :	Port	Owner
	gp_update_out	InputWrapper
Target :	Port	Owner
	GradientProfile_updated	AGradient

#### Connector69

Source :	Port	Owner
	trainData	SpeedSupervision_Integration
Target :	Port	Owner
	trainData	AGradient

#### Connector70

Source :	Port	Owner
	aBrakeSafe	ABrakeFactory
Target :	Port	Owner
	aBrakeSafe	addGradient1

#### Connector71

Source :	Port	Owner
	aBrakeService	ABrakeFactory
Target :	Port	Owner
	aBrakeSafe	addGradient2

#### Connector72

Source :	Port	Owner
	aSafe	addGradient1
Target :	Port	Owner
	A_Safe	CalcBrakingCurves

#### Connector73

Source :	Port	Owner
	aSafe	addGradient2
Target :	Port	Owner
	A_Expected	CalcBrakingCurves

#### Connector74

Source :	Port	Owner
	A_gradient	AGradient
Target :	Port	Owner
	aGradient	addGradient1

#### Connector75

Source :	Port	Owner
	A_gradient	AGradient
Target :	Port	Owner
	aGradient	addGradient2

#### Link12

Source :	Port	Owner
	fromDMI_TrainData	Abstract
Target :	Port	Owner
	fromDMI_TrainData	manageDMI_Input

#### Link22

Source :	Port	Owner
	fromDMI_TrainDataAck	Abstract
Target :	Port	Owner
	fromDMI_TrainDataAck	manageDMI_Input

#### Link32

Source :	Port	Owner
	outUpdateLevelsDMI	Abstract
Target :	Port	Owner
	outUpdateLevelsDMI	manageDMI_Input

#### Link42

Source :	Port	Owner
	outStatusList	Abstract
Target :	Port	Owner
	outStatusList	manageDMI_Input

#### Link52

Source :	Port	Owner
	CurrentDMIStatus	Abstract
Target :	Port	Owner
	currentDMIStatus	manageDMI_Input

#### Link62

Source :	Port	Owner
	updatedNTC	Abstract
Target :	Port	Owner
	updatedNTC	manageDMI_Input

#### Link72

Source :	Port	Owner
	inStatusList	manageDMI_Input
Target :	Port	Owner
	inStatusList	Abstract

#### Link82

Source :	Port	Owner
	fromDMI_TrainRunningNumber	Abstract
Target :	Port	Owner
	fromDMI_TrainRunningNumber	manageDMI_Input

#### Connector1

Source :	Port	Owner
	trackSide_ForCheck	CheckBGConsistency
Target :	Port	Owner
	trackSideForCheck	CaseLinkingNotInUse1

#### Connector2

<b>Source :</b>	Port	Owner
	trackSide_ForCheck	CheckBGConsistency

<b>Target :</b>	Port	Owner
	trackSideForCheck	CaseLinkingInUse1

#### Connector3

<b>Source :</b>	Port	Owner
	errorUnlinkedBG	CaseLinkingNotInUse1

<b>Target :</b>	Port	Owner
	errorUnlinkedBG	CheckBGConsistency

#### Connector4

<b>Source :</b>	Port	Owner
	applyServiceBrake	CaseLinkingNotInUse1

<b>Target :</b>	Port	Owner
	applyServiceBrake	CheckBGConsistency

#### Connector5

<b>Source :</b>	Port	Owner
	errorLinkedBG	CaseLinkingInUse1

<b>Target :</b>	Port	Owner
	errorLinkedBG	CheckBGConsistency

#### Connector6

<b>Source :</b>	Port	Owner
	passedBG_out	CaseLinkingNotInUse1

<b>Target :</b>	Port	Owner
	passedBG_out	CheckBGConsistency



Connector7

Source :	Port	Owner
	passedBG_out	CaseLinkingInUse1
Target :	Port	Owner
	passedBG_out	CheckBGConsistency

Link13

Source :	Port	Owner
	dmiUpdateLevelsDMI	manageDMI_Output
Target :	Port	Owner
	dmiUpdateLevelsDMI	Abstract

Link23

Source :	Port	Owner
	inStatusList	manageDMI_Output
Target :	Port	Owner
	inStatusList	Abstract

Link33

Source :	Port	Owner
	incurrentDMIStatus	manageDMI_Output
Target :	Port	Owner
	inCurrentDMIStatus	Abstract

Link43

Source :	Port	Owner
	inNTC	manageDMI_Output
Target :	Port	Owner
	inNTC	Abstract

Link53

Source :	Port	Owner
	outStatusList	Abstract
Target :	Port	Owner
	outStatusList	manageDMI_Output

Connector1

Source :	Port	Owner
	TrainPosition	SpeedSupervision_Integration
Target :	Port	Owner
	TrainPosition	InputWrapper

Connector3

Source :	Port	Owner
	trainProps	SpeedSupervision_Integration
Target :	Port	Owner
	trainProps	InputWrapper

#### Connector4

Source :	Port	Owner
	dataFromTrackAtlas	SpeedSupervision_Integration
Target :	Port	Owner
	dataFromTrackAtlas	InputWrapper

#### Connector11

Source :	Port	Owner
	NationalValues	SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	ABrakeFactory

#### Connector12

Source :	Port	Owner
	trainData	SpeedSupervision_Integration
Target :	Port	Owner
	trainData	ABrakeFactory

#### Connector13

Source :	Port	Owner
	mrsp_out	InputWrapper
Target :	Port	Owner
	MRSP	TargetManagement

#### Connector14

Source :	Port	Owner
	mrsp_update_out	InputWrapper
Target :	Port	Owner
	MRSP_updated	TargetManagement

#### Connector15

Source :	Port	Owner
	ma_out	InputWrapper
Target :	Port	Owner
	MA	TargetManagement

#### Connector16

Source :	Port	Owner
	ma_update_out	InputWrapper
Target :	Port	Owner
	MA_updated	TargetManagement

#### Connector17

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	trainLocations	TargetManagement

#### Connector18

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	TrainLocations	CalcBrakingCurves

#### Connector19

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	CalcBrakingCurves

#### Connector22

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	LimitLocations

#### Connector23

Source :	Port	Owner
	mrsp_out	InputWrapper
Target :	Port	Owner
	MRSP_Profile	LimitLocations

#### Connector24

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	trainLocations	LimitLocations

#### Connector26

Source :	Port	Owner
	curveCollection	CalcBrakingCurves
Target :	Port	Owner
	curveCollection	LimitLocations

#### Connector27

Source :	Port	Owner
	NationalValues	SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	LimitLocations

#### Connector29

Source :	Port	Owner
	T_b	ABrakeFactory
Target :	Port	Owner
	T_b	LimitLocations

#### Connector30

Source :	Port	Owner
	ma_out	InputWrapper
Target :	Port	Owner
	MA	LimitLocations

#### Connector35

Source :	Port	Owner
	locations	LimitLocations
Target :	Port	Owner
	locations	Commands

#### Connector36

Source :	Port	Owner
	speeds	LimitLocations
Target :	Port	Owner
	speeds	Commands

#### Connector37

Source :	Port	Owner
	MostRestrictiveDisplayedTarget	LimitLocations
Target :	Port	Owner
	mrdt	Commands

#### Connector38

Source :	Port	Owner
	FLOlisSB11	LimitLocations
Target :	Port	Owner
	floilsSB1	Commands

#### Connector43

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	allTargets	Commands

#### Connector46

Source :	Port	Owner
	MostRestrictiveDisplayedTarget	LimitLocations
Target :	Port	Owner
	target	SpeedSupervision_Integration

#### Connector47

Source :	Port	Owner
	sdmToDMI	Commands
Target :	Port	Owner
	sdmToDMI	SpeedSupervision_Integration

#### Connector48

Source :	Port	Owner
	brakeCmd	Commands
Target :	Port	Owner
	brakeCmd	SpeedSupervision_Integration

#### Connector49

Source :	Port	Owner
	sdmCmd	Commands
Target :	Port	Owner
	sdmCommands	SpeedSupervision_Integration

#### Connector50

Source :	Port	Owner
	targetSpeedReached	Commands
Target :	Port	Owner
	Target_Speed_Reached	SpeedSupervision_Integration

#### Connector51

Source :	Port	Owner
	eoOverpassed	Commands
Target :	Port	Owner
	EOA_overpassed	SpeedSupervision_Integration

Connector52

Source :	Port	Owner
	NationalValues	SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	Commands

Connector53

Source :	Port	Owner
	trainData	SpeedSupervision_Integration
Target :	Port	Owner
	TrainData_int	Commands

Connector54

Source :	Port	Owner
	trainData	SpeedSupervision_Integration
Target :	Port	Owner
	trainData_int	LimitLocations

Connector55

Source :	Port	Owner
	NationalValues	SpeedSupervision_Integration
Target :	Port	Owner
	NationalValues	LimitLocations

Connector56

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	trainLocations	LimitLocations

Connector57

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	TrainLocations	CalcBrakingCurves

Connector58

Source :	Port	Owner
	Service_brake_requested_by_modes_and_levels	SpeedSupervision_Integration
Target :	Port	Owner
	MLrequestSB	Commands

Connector59

Source :	Port	Owner
	Emergency_brake_requested_by_modes_and_levels	SpeedSupervision_Integration
Target :	Port	Owner
	MLrequestEB	Commands

Connector60

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	allTargets	Commands

Connector61

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	LimitLocations

Connector62

Source :	Port	Owner
	ma_out	InputWrapper
Target :	Port	Owner
	MA	LimitLocations

Connector63

Source :	Port	Owner
	mrsp_out	InputWrapper
Target :	Port	Owner
	MRSP_Profile	LimitLocations

#### Connector64

Source :	Port	Owner
	odometry	SpeedSupervision_Integration
Target :	Port	Owner
	odometry	LimitLocations

#### Connector65

Source :	Port	Owner
	targetCollection	TargetManagement
Target :	Port	Owner
	targetCollection	AGradient

#### Connector66

Source :	Port	Owner
	trainLocations	InputWrapper
Target :	Port	Owner
	TrainLocations	AGradient

#### Connector67

Source :	Port	Owner
	gp_out	InputWrapper
Target :	Port	Owner
	GradientProfile	AGradient

#### Connector68

Source :	Port	Owner
	gp_update_out	InputWrapper
Target :	Port	Owner
	GradientProfile_updated	AGradient

#### Connector69

Source :	Port	Owner
	trainData	SpeedSupervision_Integration
Target :	Port	Owner
	trainData	AGradient

#### Connector70



Source :	Port	Owner
	aBrakeSafe	ABrakeFactory
Target :	Port	Owner
	aBrakeSafe	addGradient1

#### Connector71

Source :	Port	Owner
	aBrakeService	ABrakeFactory
Target :	Port	Owner
	aBrakeSafe	addGradient2

#### Connector72

Source :	Port	Owner
	aSafe	addGradient1
Target :	Port	Owner
	A_Safe	CalcBrakingCurves

#### Connector73

Source :	Port	Owner
	aSafe	addGradient2
Target :	Port	Owner
	A_Expected	CalcBrakingCurves

#### Connector74

Source :	Port	Owner
	A_gradient	AGradient
Target :	Port	Owner
	aGradient	addGradient1

#### Connector75

Source :	Port	Owner
	A_gradient	AGradient
Target :	Port	Owner
	aGradient	addGradient2

#### Connector1

Source :	Port	Owner
	trackSide_ForCheck	CheckBGConsistency
Target :	Port	Owner
	trackSideForCheck	CaseLinkingNotInUse1

#### Connector2

Source :	Port	Owner
	trackSide_ForCheck	CheckBGConsistency

Target :	Port	Owner
	trackSideForCheck	CaseLinkingInUse1

#### Connector3

Source :	Port	Owner
	errorUnlinkedBG	CaseLinkingNotInUse1

Target :	Port	Owner
	errorUnlinkedBG	CheckBGConsistency

#### Connector4

Source :	Port	Owner
	applyServiceBrake	CaseLinkingNotInUse1

Target :	Port	Owner
	applyServiceBrake	CheckBGConsistency

#### Connector5

Source :	Port	Owner
	errorLinkedBG	CaseLinkingInUse1

Target :	Port	Owner
	errorLinkedBG	CheckBGConsistency

#### Connector6

Source :	Port	Owner
	passedBG_out	CaseLinkingNotInUse1

Target :	Port	Owner
	passedBG_out	CheckBGConsistency

#### Connector7

Source :	Port	Owner
	passedBG_out	CaseLinkingInUse1

Target :	Port	Owner
	passedBG_out	CheckBGConsistency

#### Connector1

Source :	Port	Owner
	reset	Manage_TrackSideInformation_Integration

Target :	Port	Owner
	reset	Receive_TrackSide_Msg

#### Connector2

<b>Source :</b>	Port	Owner
	API_trackSide_Message	Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	API_TrackSide_Msg	Receive_TrackSide_Msg

#### Connector3

<b>Source :</b>	Port	Owner
	inActiveCab	Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	inActualOdometry	Receive_TrackSide_Msg

#### Connector4

<b>Source :</b>	Port	Owner
	outTrackMessage_for_check	Receive_TrackSide_Msg
<b>Target :</b>	Port	Owner
	trackSide_ForCheck	CheckBGConsistency

#### Connector5

<b>Source :</b>	Port	Owner
	applyServiceBrake	CheckBGConsistency
<b>Target :</b>	Port	Owner
	ApplyServiceBrake	Manage_TrackSideInformation_Integration

#### Connector6

<b>Source :</b>	Port	Owner
	outTrackMessage_for_check	Receive_TrackSide_Msg
<b>Target :</b>	Port	Owner
	rtmMessage	CheckEuroRadioMessage

#### Connector7

<b>Source :</b>	Port	Owner
	outMessage	InformationFilter
<b>Target :</b>	Port	Owner
	outputMessage	Manage_TrackSideInformation_Integration

#### Connector8

<b>Source :</b>	Port	Owner
	inTrainDataValid	Manage_TrackSideInformation_Integration
<b>Target :</b>	Port	Owner
	inTrainDataValid	InformationFilter

#### Connector9

Source :	Port	Owner
	passedBG_out	CheckBGConsistency
Target :	Port	Owner
	inMessage	validateDataDirection

#### Connector10

Source :	Port	Owner
	checkedMessage	CheckEuroRadioMessage
Target :	Port	Owner
	inMessage	validateDataDirection

#### Connector11

Source :	Port	Owner
	outMessage	validateDataDirection
Target :	Port	Owner
	inMessage	InformationFilter

#### Connector12

Source :	Port	Owner
	inActiveCab	Manage_TrackSideInformation_Integration
Target :	Port	Owner
	inActiveCab	InformationFilter

#### Connector13

Source :	Port	Owner
	intrainVersion	Manage_TrackSideInformation_Integration
Target :	Port	Owner
	trainVersion	CheckBGConsistency

Connector14

Source :	Port	Owner
	trainPosition	Manage_TrackSideInformation_Integration
Target :	Port	Owner
	trainPosition	CheckBGConsistency

Connector15

Source :	Port	Owner
	inFilterEvents	Manage_TrackSideInformation_Integration
Target :	Port	Owner
	inFilterEvents	InformationFilter

Connector16

Source :	Port	Owner
	outPacketsForML	InformationFilter
Target :	Port	Owner
	Data_to_From_Track_Packets_at_ML	Manage_TrackSideInformation_Integration

Connector17

Source :	Port	Owner
	ActualOdometry	Manage_TrackSideInformation_Integration
Target :	Port	Owner
	inActualOdometry	Receive_TrackSide_Msg

Connector1

Source :	Port	Owner
	reset	trainData
Target :	Port	Owner
	reset	trainDataStorage

Connector2

Source :	Port	Owner
	trainDatafromTIU	trainData
Target :	Port	Owner
	trainDatafromTIU	trainDataStorage

Connector3

Source :	Port	Owner
	trainDatafromDriver	trainData
Target :	Port	Owner
	trainDatafromDriver	trainDataStorage

Connector4

Source :	Port	Owner
	trainDataAckfromDriver	trainData
Target :	Port	Owner
	trainDataAckfromDriver	trainDataStorage

#### Connector5

Source :	Port	Owner
	trackMessages	trainData
Target :	Port	Owner
	trackMessages	checkRadioMessages

#### Connector6

Source :	Port	Owner
	eventsForTrainData	trainData
Target :	Port	Owner
	eventsForTrainData	trainDataStorage

#### Connector7

Source :	Port	Owner
	actualTrainData	trainDataStorage
Target :	Port	Owner
	trainData	sendValidTrainDataRBC

#### Connector8

Source :	Port	Owner
	actualTrainData	trainDataStorage
Target :	Port	Owner
	actualTrainData	trainData

#### Connector9

Source :	Port	Owner
	p0_positionReport	trainData
Target :	Port	Owner
	p0_positionReport	sendValidTrainDataRBC

#### Connector10

Source :	Port	Owner
	p1_positionReport	trainData
Target :	Port	Owner
	p1_positionReport	sendValidTrainDataRBC

#### Connector11

Source :	Port	Owner
	nidEngine	trainData
Target :	Port	Owner
	nidEngine	sendValidTrainDataRBC

#### Connector12

Source :	Port	Owner
	nidEngine	trainData
Target :	Port	Owner
	nidEngine	sendAcknowledgementRBC

#### Connector13

Source :	Port	Owner
	t_train	trainData
Target :	Port	Owner
	evc_t_train	sendValidTrainDataRBC

#### Connector14

Source :	Port	Owner
	t_train	trainData
Target :	Port	Owner
	EVC_t_train	sendAcknowledgementRBC

#### Connector15

Source :	Port	Owner
	trackMessages	trainData
Target :	Port	Owner
	RBC_timeStamp	sendAcknowledgementRBC

#### Connector16

Source :	Port	Owner
	outMessageBus	sendAcknowledgementRBC
Target :	Port	Owner
	outMessageBus	trainData

#### Connector17

Source :	Port	Owner
	outMessageBus	sendValidTrainDataRBC
Target :	Port	Owner
	outMessageBus	trainData

#### Connector18

Source :	Port	Owner
	MessageBus	trainData
Target :	Port	Owner
	MessageBus	sendAcknowledgementRBC

#### Connector19

Source :	Port	Owner
	MessageBus	trainData
Target :	Port	Owner
	MessageBus	sendValidTrainDataRBC

#### Link

Source :	Port	Owner
	errors	Abstract definition
Target :	Port	Owner
	errors	calculateTrainPosition

#### Link2

Source :	Port	Owner
	currentOdometry	calculateTrainPosition
Target :	Port	Owner
	currentOdometry	Abstract definition

#### Link3

Source :	Port	Owner
	passedBG	calculateTrainPosition
Target :	Port	Owner
	PassedBG	Abstract definition

#### Link4

Source :	Port	Owner
	msgFromTrack	calculateTrainPosition
Target :	Port	Owner
	msgFromTrack	Abstract definition

#### Link5

Source :	Port	Owner
	trainProperties	calculateTrainPosition
Target :	Port	Owner
	trainProperties	Abstract definition

#### Connector1



Source :	Port	Owner
	packet0	Build_SinglePosReport

Target :	Port	Owner
	inPacket0	AggregatePackets

#### Connector2

Source :	Port	Owner
	packet1	Build_SinglePosReport

Target :	Port	Owner
	inPacket1	AggregatePackets

#### Connector3

Source :	Port	Owner
	packet4	Build_SinglePosReport

Target :	Port	Owner
	inPacket4	AggregatePackets

#### Connector4

Source :	Port	Owner
	packet5	Build_SinglePosReport

Target :	Port	Owner
	inPacket5	AggregatePackets

#### Connector6

Source :	Port	Owner
	present	ReceiveReportParameters

Target :	Port	Owner
	present	PosReport_Supervision

#### Connector7

Source :	Port	Owner
	posRepParam	ReceiveReportParameters

Target :	Port	Owner
	posRepParam	PosReport_Supervision

#### Connector9

Source :	Port	Owner
	trigger	PosReport_Supervision

Target :	Port	Owner
	reportIsSent	AddBGTtoFIFO

#### Connector10

Source :	Port	Owner
	posRepHeader	Build_SinglePosReport
Target :	Port	Owner
	posRep	ProvidePositionReport

#### Connector11

Source :	Port	Owner
	packet0	Build_Packets0_1
Target :	Port	Owner
	in_packet0	Build_SinglePosReport

#### Connector12

Source :	Port	Owner
	packet1	Build_Packets0_1
Target :	Port	Owner
	in_packet1	Build_SinglePosReport

#### Connector13

Source :	Port	Owner
	packet0	Build_Packets0_1
Target :	Port	Owner
	packet0	ProvidePositionReport

#### Connector14

Source :	Port	Owner
	packet1	Build_Packets0_1
Target :	Port	Owner
	packet1	ProvidePositionReport

Connector15

Source :	Port	Owner
	errorVect	ErrorManager
Target :	Port	Owner
	errorMsg	Build_SinglePosReport

Connector16

Source :	Port	Owner
	BG_LinkingConsistencyError	ProvidePositionReport
Target :	Port	Owner
	BG_LinkingConsistencyError	ErrorManager

Connector17

Source :	Port	Owner
	LinkedBG_MessageConsistencyError	ProvidePositionReport
Target :	Port	Owner
	LinkedBG_MessageConsistencyError	ErrorManager

Connector18

Source :	Port	Owner
	UnlinkedBG_MessageConsistencyError	ProvidePositionReport
Target :	Port	Owner
	UnlinkedBG_MessageConsistencyError	ErrorManager

Connector19

Source :	Port	Owner
	RadioMessageConsistencyError	ProvidePositionReport
Target :	Port	Owner
	RadioMessageConsistencyError	ErrorManager

Connector20

Source :	Port	Owner
	RadioSequenceError	ProvidePositionReport
Target :	Port	Owner
	RadioSequenceError	ErrorManager

Connector21

Source :	Port	Owner
	RadioSafeRadioConnectionError	ProvidePositionReport
Target :	Port	Owner
	RadioSafeRadioConnectionError	ErrorManager

Connector22

<b>Source :</b>	Port	Owner
	SafetyCriticalFailure	ProvidePositionReport
<b>Target :</b>	Port	Owner
	SafetyCriticalFailure	ErrorManager

#### Connector23

<b>Source :</b>	Port	Owner
	DoubleLinkingError	ProvidePositionReport
<b>Target :</b>	Port	Owner
	DoubleLinkingError	ErrorManager

#### Connector24

<b>Source :</b>	Port	Owner
	DoubleRepositioningError	ProvidePositionReport
<b>Target :</b>	Port	Owner
	DoubleRepositioningError	ErrorManager

#### Connector25

<b>Source :</b>	Port	Owner
	modeLevelStatus	ProvidePositionReport
<b>Target :</b>	Port	Owner
	modeLevelStatus	PosReport_Supervision

#### Connector26

<b>Source :</b>	Port	Owner
	modeLevelStatus	ProvidePositionReport
<b>Target :</b>	Port	Owner
	modeLevelStatus	Build_Packets0_1

#### Connector27

<b>Source :</b>	Port	Owner
	posBGs	ProvidePositionReport
<b>Target :</b>	Port	Owner
	posBGs	PosReport_Supervision

#### Connector28

<b>Source :</b>	Port	Owner
	posBGs	ProvidePositionReport
<b>Target :</b>	Port	Owner
	posBGs	Build_Packets0_1

#### Connector29

Source :	Port	Owner
	trainPos	ProvidePositionReport
Target :	Port	Owner
	trainPos	PosReport_Supervision

#### Connector30

Source :	Port	Owner
	trainPos	ProvidePositionReport
Target :	Port	Owner
	trainPos	Build_Packets0_1

#### Connector31

Source :	Port	Owner
	odometry	ProvidePositionReport
Target :	Port	Owner
	odometry	PosReport_Supervision

#### Connector32

Source :	Port	Owner
	odometry	ProvidePositionReport
Target :	Port	Owner
	odometry	Build_Packets0_1

#### Connector33

Source :	Port	Owner
	trainProps	ProvidePositionReport
Target :	Port	Owner
	trainProps	Build_SinglePosReport

#### Connector35

Source :	Port	Owner
	trainProps	ProvidePositionReport
Target :	Port	Owner
	trainProps	Build_Packets0_1

#### Connector36

Source :	Port	Owner
	inMessage	ProvidePositionReport
Target :	Port	Owner
	inMessage	ReceiveReportParameters

#### Connector37

Source :	Port	Owner
	out_reportedBGs	AddBGToFIFO
Target :	Port	Owner
	reportedBGs	ReceiveReportParameters

#### Connector38

Source :	Port	Owner
	t_train	ProvidePositionReport
Target :	Port	Owner
	t_train	Build_SinglePosReport

#### Connector39

Source :	Port	Owner
	prvDirTrain	ProvidePositionReport
Target :	Port	Owner
	prvDirTrain	Build_Packets0_1

#### Connector41

Source :	Port	Owner
	train2trackStatus	ProvidePositionReport
Target :	Port	Owner
	train2trackStatus	Build_Packets0_1

#### Connector42

Source :	Port	Owner
	trackInfo	ProvidePositionReport
Target :	Port	Owner
	trackInfo	PosReport_Supervision

#### Connector43

Source :	Port	Owner
	systemTime	ProvidePositionReport
Target :	Port	Owner
	systemTime	PosReport_Supervision

#### Connector44

Source :	Port	Owner
	rcbComm	ProvidePositionReport
Target :	Port	Owner
	rbcComm	PosReport_Supervision

#### Connector45

Source :	Port	Owner
	train2trackStatus	ProvidePositionReport
Target :	Port	Owner
	train2trackStatus	PosReport_Supervision

#### Connector46

Source :	Port	Owner
	posBGs	ProvidePositionReport
Target :	Port	Owner
	posBGs	AddBGToFIFO

#### Connector47

Source :	Port	Owner
	out_reportedBGs	ReceiveReportParameters
Target :	Port	Owner
	reportedBGs	AddBGToFIFO

#### Connector51

Source :	Port	Owner
	prvDirTrain	ProvidePositionReport
Target :	Port	Owner
	prvDirTrain	PosReport_Supervision

#### Connector52

Source :	Port	Owner
	out_reportedBGs	ReceiveReportParameters
Target :	Port	Owner
	reportedBGs	PosReport_Supervision

#### Connector53

Source :	Port	Owner
	trainProps	ProvidePositionReport
Target :	Port	Owner
	trainProps	PosReport_Supervision

#### F2.6ErrorLink1

Source :	Port	Owner
	errors	calculateTrainPosition
Target :	Port	Owner
	BG_LinkingConsistencyError	ProvidePositionReport

#### F2.6ErrorLink2

Source :	Port	Owner
	errors	calculateTrainPosition
Target :	Port	Owner
	DoubleLinkingError	ProvidePositionReport

#### F2.6ErrorLink3

Source :	Port	Owner
	errors	calculateTrainPosition
Target :	Port	Owner
	DoubleRepositioningError	ProvidePositionReport

#### F2.1ErrorLink1

Source :	Port	Owner
	outCheckErrors	Manage_TrackSideInformation_Integration
Target :	Port	Owner
	LinkedBG_MessageConsistencyError	ProvidePositionReport

#### F2.1ErrorLink2

Source :	Port	Owner
	outCheckErrors	Manage_TrackSideInformation_Integration
Target :	Port	Owner
	UnlinkedBG_MessageConsistencyError	ProvidePositionReport

#### F2.1ErrorLink3

Source :	Port	Owner
	outCheckErrors	Manage_TrackSideInformation_Integration
Target :	Port	Owner
	RadioMessageConsistencyError	ProvidePositionReport



F2.1ErrorLink4

Source :	Port	Owner
	outCheckErrors	Manage_TrackSideInformation_Integration
Target :	Port	Owner
	RadioSequenceError	ProvidePositionReport

F2.1MsgLink1

Source :	Port	Owner
	outputMessage	Manage_TrackSideInformation_Integration
Target :	Port	Owner
	msgFromTrack	calculateTrainPosition

F2.10trainProperties

Source :	Port	Owner
	fromDMI_TrainRunningNumber	manageDMI_Input
Target :	Port	Owner
	trainProperties	calculateTrainPosition

F2.3TrainProperties

Source :	Port	Owner
	actualTrainData	trainData
Target :	Port	Owner
	trainProperties	calculateTrainPosition

F2.10TrainData

Source :	Port	Owner
	fromDMI_TrainData	manageDMI_Input
Target :	Port	Owner
	trainDatafromDriver	trainData

F2.10TrainDataAck

Source :	Port	Owner
	fromDMI_TrainDataAck	manageDMI_Input
Target :	Port	Owner
	trainDataAckfromDriver	trainData

F2.9Radio

Source :	Port	Owner
	radioStatus_1	MoRC_HO
Target :	Port	Owner
	eventsForTrainData	trainData

F2.9Ready

Source :	Port	Owner
	ready	MoRC_HO
Target :	Port	Owner
	eventsForTrainData	trainData

#### F2.11StatusList

Source :	Port	Owner
	outStatusList	manageDMI_Output
Target :	Port	Owner
	inStatusList	manageDMI_Input

#### F2.10StatusList

Source :	Port	Owner
	outStatusList	manageDMI_Input
Target :	Port	Owner
	inStatusList	manageDMI_Output

#### F2.10CurrentDMI

Source :	Port	Owner
	currentDMIStatus	manageDMI_Input
Target :	Port	Owner
	inCurrentDMIStatus	manageDMI_Output

#### F2.10NTC

Source :	Port	Owner
	updatedNTC	manageDMI_Input
Target :	Port	Owner
	inNTC	manageDMI_Output

#### F2.10DMI\_update

Source :	Port	Owner
	outUpdateLevelsDMI	manageDMI_Input
Target :	Port	Owner
	dmiUpdateLevelsDMI	manageDMI_Output

## 5. System inputs

Owner	Port
ETCS OBU	RBCBTMIn
ETCS OBU	OdometryIn
ETCS OBU	Input1
ETCS OBU	DriverIn
ETCS OBU	RBCIN
ETCS OBU	TrainIn
F2 ETCS Kernel	EVC_reset
F2 ETCS Kernel	API_SystemTime
F2.1 Manage_TrackSideInformation_Integration	fullChecks
F2.1 Manage_TrackSideInformation_Integration	lastRelevantEventTimestamp
CheckBGConsistency	storedBGs
CheckBGConsistency	mMode
CheckBGConsistency	q_nvlocacc
CaseLinkingInUse1	storedBGs
CaseLinkingInUse1	q_nvlocacc
CaseLinkingNotInUse1	q_nvlocacc
InformationFilter	inSupervisingDevice
InformationFilter	inPendingL1Transition
InformationFilter	inPendingL2L3Transition
InformationFilter	inPendingAckOfTrainDataFromRBC
InformationFilter	inEmergencyStopAccepted
InformationFilter	inLastAckTextMessageId
InformationFilter	inPendingNTCTransition
InformationFilter	inLevel
InformationFilter	inModus
validateDataDirection	inLRBG
validateDataDirection	inPositionedBGs
validateDataDirection	trainPosition
CheckEuroRadioMessage	activateCheck
CheckEuroRadioMessage	tNvContact
CheckEuroRadioMessage	lastRelevantEventTimestamp
CheckEuroRadioMessage	connectionStatus
F2.10 manageDMI_Input	lasttNTC
changeLevelByDiver1	levelData
changeLevelByDiver1	lasttNTC
doDriverRequests1	inDriverRequest
receiveRequestsModesAndLevel1	fromDMI_driverRequest
receiveRequestsModesAndLevel1	fromDMI_Icon_Ack
receiveRequestsModesAndLevel1	fromDMI_TextMsg_Ack
receiveRequestsModesAndLevel1	inSystemTime

Owner	Port
receiveRequestsModesAndLevel1	inStatusList
triggerForMA1	fromDMI_driverRequest
updateDMIStatus1	sndValidationRequested
updateDMIStatus1	oldStatus
updateDMIStatus1	fromDMI
getTIUStatusFromData	inTIUActualData
mergeTIU_Info	newInfo
mergeTIU_Info	storedInfo
mergeTIU_Info	EVC_trainData
selectTrainData	newTIUTrainData
selectTrainData	in_train_commands
selectTrainData	EVC_trainData
F2.2 Manage_ETCS_Procedures	Status_MA_FS_SR_OS_LS_SH_from_MA_L2_Management
F2.2 Manage_ETCS_Procedures	statusRBCSessionEstablished_status_from_MoRC
SoM_NTC_SN	Status_Mode_Change_from_Level_and_Mode_Management
SoM_SR_FS_OS_LS_SH_SN_UN	Status_MA_FS_SR_OS_LS_SH_from_MA_L2_Management
SoM_SR_FS_OS_LS_SH_SN_UN	Status_Mode_Change_from_Level_and_Mode_Management
F2.9 MoRC_HO	atPowerUpRadioNetworkID
F2.9 MoRC_HO	newRadioNetworkIDFromDriver
F2.9 MoRC_HO	mobileRegistrationContext_2
F2.9 MoRC_HO	mobileConnectionContext_2
F2.9 MoRC_HO	sessionManagementAbility
F2.9 MoRC_HO	configData
F2.9 MoRC_HO	onboardPhoneNumbers_b
F2.9 MoRC_HO	m_version
processHandingOver	sessionManagementAbility
processHandingOver	mode
processHandingOver	morcStatus_1
processHandingOver	morcStatus_2
processHandingOver	dataFromTrack_in
processHandingOver	trainPosition
processHandingOver	BGs
processHandingOver	trainProperties
MoRC_Main_v21	eventsAndPhases
MoRC_Main_v21	reset
MoRC_Main_v21	msg_in
MoRC_Main_v21	atPowerUpRadioNetworkID
MoRC_Main_v21	newRadioNetworkIDFromDriver
MoRC_Main_v21	mode
MoRC_Main_v21	level

Owner	Port
MoRC_Main_v21	mobileRegistrationContext
MoRC_Main_v21	mobileConnectionContext
MoRC_Main_v21	currentTime
MoRC_Main_v21	t_train
MoRC_Main_v21	configData
MoRC_Main_v22	eventsAndPhases
MoRC_Main_v22	reset
MoRC_Main_v22	msg_in
MoRC_Main_v22	atPowerUpRadioNetworkID
MoRC_Main_v22	newRadioNetworkIDFromDriver
MoRC_Main_v22	mode
MoRC_Main_v22	level
MoRC_Main_v22	mobileRegistrationContext
MoRC_Main_v22	mobileConnectionContext
MoRC_Main_v22	currentTime
MoRC_Main_v22	t_train
MoRC_Main_v22	configData
mobileDataRouter_out	useInformationFromAcceptingRBC
mobileDataRouter_out	handingOverRBC_is_RBC_1
mobileDataRouter_out	sendPositionReport_2_acceptingRBC
mobileDataRouter_out	sendPositionReport_2_handingOverRBC
mobileDataRouter_out	sendPositionReport_2_RBC_1
mobileDataRouter_out	sendPositionReport_2_RBC_2
mobileDataRouter_out	sendTrainData_2_acceptingRBC
mobileDataRouter_out	sessionManagementAbility
mobileDataRouter_out	dataToRBC
mobileDataRouter_out	positionReport_in
mobileDataRouter_out	trainData_in
mobileDataRouter_out	morcMsgToRBC_1
mobileDataRouter_out	morcMsgToRBC_2
Commands	trainLocations
F2.8 ProvidePositionReport	trackInfo
F2.8 ProvidePositionReport	RadioSafeRadioConnectionError
F2.8 ProvidePositionReport	SafetyCriticalFailure
F2.8 ProvidePositionReport	reportedBGs
F2.8 ProvidePositionReport	inVersion
F2.13 manageTIU_output	in_IsolationStatus
F2.13 manageTIU_output	in_brake_inhibition
F2.13 manageTIU_output	in_change_traction_system
F2.13 manageTIU_output	in_passenger_door_control_info

Owner	Port
F2.13 manageTIU_output	in_change_of_allowed_current_consumption
bothBrakesActive	speedSupbrakeCommand
bothBrakesActive	levelBrakeCommand
getTIUStatusFromCommand	in_IsolationStatus
getTIUStatusFromCommand	in_brake_command
handleTraction	in_train_commands
handleTraction	inModeLevel
mapModeToTractionCutOff	inModeLevel
TIU_OutputIntegration	in_IsolationStatus
TIU_OutputIntegration	SpeedSup_brakeCommand
TIU_OutputIntegration	in_brake_inhibition
TIU_OutputIntegration	in_train_commands
TIU_OutputIntegration	in_change_traction_system
TIU_OutputIntegration	in_passenger_door_control_info
TIU_OutputIntegration	in_change_of_allowed_current_consumption
TIU_OutputIntegration	inModeAndLevel
F2.11 manageDMI_Output	dmi_dynamic
F2.11 manageDMI_Output	dmi_menuRequest
F2.11 manageDMI_Output	dmi_evc_coded_train_data
F2.11 manageDMI_Output	dmi_text_message
F2.11 manageDMI_Output	evc_systemVersion
F2.11 manageDMI_Output	dmi_displayControl
F2.11 manageDMI_Output	dmi_EVC_levelData
F2.11 manageDMI_Output	dmi_EVC_radioNet
F2.11 manageDMI_Output	dmi_driverIdentifier
F2.11 manageDMI_Output	dmi_trainRunningNumber
F2.11 manageDMI_Output	dmi_trainData
F2.11 manageDMI_Output	dmi_adhesionFactor
F2.11 manageDMI_Output	dmi_iconRequest
F2.11 manageDMI_Output	inSystemTime
F2.11 manageDMI_Output	inNationalValues
F2.11 manageDMI_Output	inMovementAuthority
F2.11 manageDMI_Output	dmi_EVC_levelList
calcDistances1	inTrainPosition
collectDMIPackets1	TIU_TrainStatus
collectDMIPackets1	dmi_dynamic
collectDMIPackets1	dmi_menuRequest
collectDMIPackets1	dmi_entryRequest
collectDMIPackets1	dmi_evc_coded_train_data
collectDMIPackets1	dmi_text_message

Owner	Port
collectDMIPackets1	dmi_trackDescription
collectDMIPackets1	dmi_identifierRequest
collectDMIPackets1	dmi_systemVersion
collectDMIPackets1	dmi_displayControl
collectDMIPackets1	dmi_EVC_levelData
collectDMIPackets1	dmi_EVC_radioNet
collectDMIPackets1	dmi_driverIdentifier
collectDMIPackets1	dmi_trainRunningNumber
collectDMIPackets1	dmi_trainData
collectDMIPackets1	dmi_adhesionFactor
collectDMIPackets1	dmi_iconRequest
collectDMIPackets1	systemTime
convert_cm_s_km_h1	cm_s
copyGradientElement1	dmiUpdateLevelsDMI
copyGradientElement1	dmi_fromBG
copyGradientElement1	inCurrentDMIStatus
copyGradientElement1	inSystemTime
copyGradientElement1	TIU_TrainStatus
copyGradientElement1	inOdometry
copyGradientElement1	inTrainPosition
copyGradientElement1	inBrakeCommand
copyGradientElement1	inSpeedSupervision
copyGradientElement1	inModeAndLevel
copyGradientElement1	inNationalValues
copyGradientElement1	inMovementAuthority
copyGradientElement1	inRadioConnectionStatus
copyGradientElement1	trainDataFromEVC
copyGradientElement1	dmi_entryRequest
copyGradientElement1	dmi_evc_coded_train_data
copyGradientElement1	dmi_trackDescription
copyGradientElement1	dmi_identifierRequest
copyGradientElement1	dmi_displayControl
copyGradientElement1	dmi_EVC_levelList
copyGradientElement1	dmi_EVC_radioNet
copyGradientElement1	dmi_driverIdentifier
copyGradientElement1	dmi_trainRunningNumber
copyGradientElement1	dmi_adhesionFactor
copyGradientElement1	dmi_fromModesAndLevel
copyGradientElement1	inNTC
copyGradientElement1	inStatusList

Owner	Port
copyGradientElement1	index
copyGradientElement1	fromTrackAtlas
copySpeedProfileElement1	index
copySpeedProfileElement1	fromTrackAtlas
copyTrackDescription1	fromTrackAtlas
copyTrackDescription1	inSystemTime
cyclicReportToDMI1	inCurrentDMIStatus
cyclicReportToDMI1	inSystemTime
cyclicReportToDMI1	inOdometry
cyclicReportToDMI1	inTrainPosition
cyclicReportToDMI1	inSpeedSupervision
cyclicReportToDMI1	inModeAndLevel
cyclicReportToDMI1	inNationalValues
cyclicReportToDMI1	inMovementAuthority
cyclicReportToDMI1	inMoRC_status
cyclicReportToDMI1	inNTC
doEntryRequest1	dmi_entryRequest
doEntryRequest1	inSystemTime
doldentifierRequest1	TIU_TrainStatus
doldentifierRequest1	inSystemTime
doldentifierRequest1	ownVersion
isSendingNeeded1	inSystemTime
isSendingNeeded1	inCurrentDMIStatus
mapEntryForLevel1	dmi_entryRequest
mapMoRCtoRadio_CS1	inMoRC_status
sendBrakesToDMI1	brakeCommand
sendBrakesToDMI1	inSystemTime
sendDynamic1	inSystemTime
sendDynamic1	inOdometry
sendDynamic1	inTrainPosition
sendDynamic1	inSpeedSupervision
sendDynamic1	inModeLevel_Ack
sendDynamic1	inNationalValues
sendDynamic1	inMoRC_status
sendDynamic1	inNTC
sendDynamic1	inModeAndLevel
sendDynamic1	inMovementAuthority
sendLevelListPkg1	UpdateLevelsRequested
sendLevelListPkg1	levelList
sendLevelListPkg1	inSystemTime



Owner	Port
sendTrainData1	inSystemTime
sendTrainData1	trainDataFromEVC
sendVersion1	ownVersion
sendVersion1	dmiStatus
sendVersion1	inSystemTime
synchWithDMI1	outputStatus
synchWithDMI1	dmi_identifierRequest
synchWithDMI1	TIU_TrainStatus
synchWithDMI1	systemTime
F2.3 trainData	MessageBus
F2.3 trainData	inVersion
trainDataStorage	actualStatus
sendAcknowledgementRBC	actualStatus
sendAcknowledgementRBC	inVersion
checkRadioMessages	actualStatus
sendValidTrainDataRBC	actualStatus
sendValidTrainDataRBC	inVersion
F2.6 calculateTrainPosition	passedBG
linkedBG_missed	enable
linkedBG_missed	position
linkedBG_missed	BGs_in
twoConsecutiveLinkedBGs_missed	reset
twoConsecutiveLinkedBGs_missed	passedBG
twoConsecutiveLinkedBGs_missed	msgFromTrack
twoConsecutiveLinkedBGs_missed	missed
twoConsecutiveLinkedBGs_missed	missedLinkedBG
addAnnouncedBGs	passedBG
addAnnouncedBGs	BGs_in
addAnnouncedBGs	trainProperties
calculateBGLocations	reset
calculateBGLocations	passedBG
calculateBGLocations	lastBGs
calculateBGLocations	trainProperties
calculateTrainpositionAttributes	trainPositionInfo
calculateTrainpositionAttributes	currentOdometry
calculateTrainpositionAttributes	trainProperties
calculateTrainPositionInfo	recalculateBGs
calculateTrainPositionInfo	reset
calculateTrainPositionInfo	currentOdometry
calculateTrainPositionInfo	BGs

Owner	Port
calculateTrainPositionInfo	passedBG
delDispensableBGs	deleteBG
delDispensableBGs	BGs_in
msg_2_passedBG	msgFromTrack
F2.5 ManageLevelAndMode	Data_From_Speed_and_Supervision
F2.5 ManageLevelAndMode	MemorizedLevelIn
Input	Data_From_DMI
Input	Data_From_TIU
Input	Data_From_Track_Messages
Input	Data_From_Track_Packets
Input	Data_From_STM
Input	Data_From_Localisation
Input	Data_From_Speed_and_Supervision
Input	Data_From_F2_Functions
Input	Cab_In
Input	driver_level_transition_In
Input	ERTMS_capabilities_In
Input	startOfMissionEnded
Input	Data_From_Track_MASSPGradient
ManageLevels	trainStandstill
ManageLevels	levelAck
ManageLevels	driverLevelTransition
ManageLevels	trainPosition
ManageLevels	ERTMScapabilities
ManageLevels	DataFromTrackToLevel
ManageLevels	MemorizedLevelIn
CheckLevelAndMode	Level
CheckLevelAndMode	Mode
ManageModes	Current_Level
ManageModes	Cab
ManageModes	Data_From_DMI
ManageModes	Data_From_F2_Functions
ManageModes	Data_From_Localisation
ManageModes	Data_From_Speed_and_Supervision
ManageModes	Data_From_STM
ManageModes	Data_From_TIU
ManageModes	Data_From_Track
ManageModes	TripModeFromLevel
Output	needsAckFromDriver
Output	service_brake_from_level

Owner	Port
Output	LevelsTransitionPositionPassed
Output	EB_Requested_From_Mode
Output	Service_Brake_Command_From_Mode
Output	Level_Mode_Compatible
Output	next_level
Output	TripTrain
Output	previous_level
Output	MemorizedLevelIn
Output	announce_driver_selection
Output	currentMode
Output	Data_To_DMI_From_Mode
Output	Data_To_BG_Management_From_Mode
TrackAtlasETCS	TrainData_in
TrackAtlasETCS	fromDriverToMA_R
TrackAtlasETCS	MessageIn
TrackAtlasETCS	ModeAndLevel_in
TrackAtlasETCS	TrainPositionIn
TrackAtlasETCS	train_length
TrackAtlasETCS	SystemTime
TrackAtlasETCS	preindicationLocation
TrackAtlasETCS	odometry
TrackAtlasETCS	trainProps
TrackAtlasETCS	packet0
TrackAtlasETCS	packet1
TrackAtlasETCS	t_train
TrackAtlasETCS	P203V1_onboard
TrackAtlasETCS	PermanentDataP003
TrackAtlasETCS	bus_in
F2.9 MoRC_Main	obuEventsAndPhases
F2.9 MoRC_Main	radioNetworkIDs
F2.9 MoRC_Main	statusOfMobile
F2.9 MoRC_Main	connectionStatusTimerInterval
F2.9 MoRC_Main	currentTime
F2.9 MoRC_Main	mode
F2.9 MoRC_Main	level
F2.9 MoRC_Main	inMessage_new
F2.9 MoRC_Main	t_train
F2.9 MoRC_Main	t_train_global
F2.9 MoRC_Main	msgBus_in
F2.9 MoRC_Main	nid_engine

Owner	Port
F2.9 MoRC_Main	onboardPhoneNumbers
F2.9 MoRC_Main	onboardPhoneNumbers_b
F2.9 MoRC_Main	m_version
Driver	Input1
F2 ETCS Kernel	EVC_reset
F2 ETCS Kernel	API_SystemTime
F2.1 Manage_TrackSideInformation_Integration	fullChecks
F2.1 Manage_TrackSideInformation_Integration	lastRelevantEventTimestamp
CheckBGConsistency	storedBGs
CheckBGConsistency	mMode
CheckBGConsistency	q_nvlocacc
CaseLinkingInUse1	storedBGs
CaseLinkingInUse1	q_nvlocacc
CaseLinkingNotInUse1	q_nvlocacc
InformationFilter	inLevel
InformationFilter	inModus
InformationFilter	inSupervisingDevice
InformationFilter	inPendingL1Transition
InformationFilter	inPendingL2L3Transition
InformationFilter	inPendingAckOfTrainDataFromRBC
InformationFilter	inEmergencyStopAccepted
InformationFilter	inLastAckTextMessageId
InformationFilter	inPendingNTCTransition
validateDataDirection	inLRBG
validateDataDirection	inPositionedBGs
validateDataDirection	trainPosition
CheckEuroRadioMessage	tNvContact
CheckEuroRadioMessage	lastRelevantEventTimestamp
CheckEuroRadioMessage	connectionStatus
CheckEuroRadioMessage	activateCheck
F2.10 manageDMI_Input	lasttNTC
changeLevelByDiver1	levelData
changeLevelByDiver1	lasttNTC
doDriverRequests1	inDriverRequest
receiveRequestsModesAndLevel1	fromDMI_driverRequest
receiveRequestsModesAndLevel1	fromDMI_Icon_Ack
receiveRequestsModesAndLevel1	fromDMI_TextMsg_Ack
receiveRequestsModesAndLevel1	inSystemTime
receiveRequestsModesAndLevel1	inStatusList
triggerForMA1	fromDMI_driverRequest

Owner	Port
updateDMIStatus1	oldStatus
updateDMIStatus1	fromDMI
updateDMIStatus1	sndValidationRequested
getTIUStatusFromData	inTIUActualData
mergeTIU_Info	newInfo
mergeTIU_Info	storedInfo
mergeTIU_Info	EVC_trainData
selectTrainData	newTIUTrainData
selectTrainData	EVC_trainData
F2.2 Manage_ETCS_Procedures	Status_MA_FS_SR_OS_LS_SH_from_MA_L2_Management
F2.2 Manage_ETCS_Procedures	statusRBCSessionEstablished_status_from_MoRC
SoM_NTC_SN	Status_Mode_Change_from_Level_and_Mode_Management
SoM_SR_FS_OS_LS_SH_SN_UN	Status_MA_FS_SR_OS_LS_SH_from_MA_L2_Management
SoM_SR_FS_OS_LS_SH_SN_UN	Status_Mode_Change_from_Level_and_Mode_Management
F2.9 MoRC_HO	atPowerUpRadioNetworkID
F2.9 MoRC_HO	newRadioNetworkIDFromDriver
F2.9 MoRC_HO	mobileRegistrationContext_2
F2.9 MoRC_HO	mobileConnectionContext_2
F2.9 MoRC_HO	sessionManagementAbility
F2.9 MoRC_HO	configData
F2.9 MoRC_HO	onboardPhoneNumbers_b
F2.9 MoRC_HO	m_version
processHandingOver	mode
processHandingOver	morcStatus_1
processHandingOver	morcStatus_2
processHandingOver	dataFromTrack_in
processHandingOver	trainPosition
processHandingOver	BGs
processHandingOver	sessionManagementAbility
processHandingOver	trainProperties
MoRC_Main_v21	msg_in
MoRC_Main_v21	eventsAndPhases
MoRC_Main_v21	atPowerUpRadioNetworkID
MoRC_Main_v21	newRadioNetworkIDFromDriver
MoRC_Main_v21	mode
MoRC_Main_v21	level
MoRC_Main_v21	mobileRegistrationContext
MoRC_Main_v21	mobileConnectionContext
MoRC_Main_v21	currentTime
MoRC_Main_v21	reset

Owner	Port
MoRC_Main_v21	t_train
MoRC_Main_v21	configData
MoRC_Main_v22	msg_in
MoRC_Main_v22	eventsAndPhases
MoRC_Main_v22	atPowerUpRadioNetworkID
MoRC_Main_v22	newRadioNetworkIDFromDriver
MoRC_Main_v22	mode
MoRC_Main_v22	level
MoRC_Main_v22	mobileRegistrationContext
MoRC_Main_v22	mobileConnectionContext
MoRC_Main_v22	currentTime
MoRC_Main_v22	reset
MoRC_Main_v22	t_train
MoRC_Main_v22	configData
mobileDataRouter_out	dataToRBC
mobileDataRouter_out	positionReport_in
mobileDataRouter_out	trainData_in
mobileDataRouter_out	morcMsgToRBC_1
mobileDataRouter_out	morcMsgToRBC_2
mobileDataRouter_out	useInformationFromAcceptingRBC
mobileDataRouter_out	handingOverRBC_is_RBC_1
mobileDataRouter_out	sendPositionReport_2_acceptingRBC
mobileDataRouter_out	sendPositionReport_2_handingOverRBC
mobileDataRouter_out	sendPositionReport_2_RBC_1
mobileDataRouter_out	sendPositionReport_2_RBC_2
mobileDataRouter_out	sendTrainData_2_acceptingRBC
mobileDataRouter_out	sessionManagementAbility
Commands	trainLocations
F2.8 ProvidePositionReport	trackInfo
F2.8 ProvidePositionReport	RadioSafeRadioConnectionError
F2.8 ProvidePositionReport	SafetyCriticalFailure
F2.8 ProvidePositionReport	reportedBGs
F2.8 ProvidePositionReport	inVersion
F2.13 manageTIU_output	in_IsolationStatus
F2.13 manageTIU_output	in_brake_inhibition
F2.13 manageTIU_output	in_change_traction_system
F2.13 manageTIU_output	in_passenger_door_control_info
F2.13 manageTIU_output	in_change_of_allowed_current_consumption
bothBrakesActive	speedSupbrakeCommand
bothBrakesActive	levelBrakeCommand

Owner	Port
getTIUStatusFromCommand	in_IsolationStatus
getTIUStatusFromCommand	in_brake_command
handleTraction	in_train_commands
handleTraction	inModeLevel
mapModeToTractionCutOff	inModeLevel
TIU_OutputIntegration	in_IsolationStatus
TIU_OutputIntegration	SpeedSup_brakeCommand
TIU_OutputIntegration	in_brake_inhibition
TIU_OutputIntegration	in_train_commands
TIU_OutputIntegration	in_change_traction_system
TIU_OutputIntegration	in_passenger_door_control_info
TIU_OutputIntegration	in_change_of_allowed_current_consumption
TIU_OutputIntegration	inModeAndLevel
F2.11 manageDMI_Output	inNationalValues
F2.11 manageDMI_Output	inMovementAuthority
F2.11 manageDMI_Output	dmi_evc_coded_train_data
F2.11 manageDMI_Output	evc_systemVersion
F2.11 manageDMI_Output	dmi_displayControl
F2.11 manageDMI_Output	dmi_EVC_levelList
F2.11 manageDMI_Output	dmi_EVC_radioNet
F2.11 manageDMI_Output	dmi_driverIdentifier
F2.11 manageDMI_Output	dmi_trainRunningNumber
F2.11 manageDMI_Output	dmi_adhesionFactor
calcDistances1	inTrainPosition
collectDMIPackets1	TIU_TrainStatus
collectDMIPackets1	dmi_dynamic
collectDMIPackets1	dmi_menuRequest
collectDMIPackets1	dmi_entryRequest
collectDMIPackets1	dmi_evc_coded_train_data
collectDMIPackets1	dmi_text_message
collectDMIPackets1	dmi_trackDescription
collectDMIPackets1	dmi_identifierRequest
collectDMIPackets1	dmi_systemVersion
collectDMIPackets1	dmi_displayControl
collectDMIPackets1	dmi_EVC_levelData
collectDMIPackets1	dmi_EVC_radioNet
collectDMIPackets1	dmi_driverIdentifier
collectDMIPackets1	dmi_trainRunningNumber
collectDMIPackets1	dmi_trainData
collectDMIPackets1	dmi_adhesionFactor

Owner	Port
collectDMIPackets1	dmi_iconRequest
collectDMIPackets1	systemTime
convert_cm_s_km_h1	cm_s
copyGradientElement1	index
copyGradientElement1	fromTrackAtlas
copySpeedProfileElement1	index
copySpeedProfileElement1	fromTrackAtlas
copyTrackDescription1	fromTrackAtlas
copyTrackDescription1	inSystemTime
cyclicReportToDMI1	inCurrentDMIStatus
cyclicReportToDMI1	inSystemTime
cyclicReportToDMI1	inOdometry
cyclicReportToDMI1	inTrainPosition
cyclicReportToDMI1	inSpeedSupervision
cyclicReportToDMI1	inModeAndLevel
cyclicReportToDMI1	inNationalValues
cyclicReportToDMI1	inMovementAuthority
cyclicReportToDMI1	inMoRC_status
cyclicReportToDMI1	inNTC
doEntryRequest1	dmi_entryRequest
doEntryRequest1	inSystemTime
doldentifierRequest1	TIU_TrainStatus
doldentifierRequest1	inSystemTime
doldentifierRequest1	ownVersion
isSendingNeeded1	inSystemTime
isSendingNeeded1	inCurrentDMIStatus
mapEntryForLevel1	dmi_entryRequest
mapMoRCtoRadio_CS1	inMoRC_status
sendBrakesToDMI1	brakeCommand
sendBrakesToDMI1	inSystemTime
sendDynamic1	inSystemTime
sendDynamic1	inOdometry
sendDynamic1	inTrainPosition
sendDynamic1	inSpeedSupervision
sendDynamic1	inModeAndLevel
sendDynamic1	inNationalValues
sendDynamic1	inMoRC_status
sendDynamic1	inMovementAuthority
sendDynamic1	inNTC
sendLevelListPkg1	levelList



Owner	Port
sendLevelListPkg1	UpdateLevelsRequested
sendLevelListPkg1	inSystemTime
sendTrainData1	inSystemTime
sendTrainData1	trainDataFromEVC
sendVersion1	ownVersion
sendVersion1	dmiStatus
sendVersion1	inSystemTime
synchWithDMI1	dmi_identifierRequest
synchWithDMI1	TIU_TrainStatus
synchWithDMI1	outputStatus
synchWithDMI1	systemTime
F2.3 trainData	MessageBus
F2.3 trainData	inVersion
trainDataStorage	actualStatus
sendAcknowledgementRBC	actualStatus
sendAcknowledgementRBC	inVersion
checkRadioMessages	actualStatus
sendValidTrainDataRBC	actualStatus
sendValidTrainDataRBC	inVersion
F2.6 calculateTrainPosition	passedBG
linkedBG_missed	position
linkedBG_missed	BGs_in
linkedBG_missed	enable
twoConsecutiveLinkedBGs_missed	missed
twoConsecutiveLinkedBGs_missed	missedLinkedBG
twoConsecutiveLinkedBGs_missed	passedBG
twoConsecutiveLinkedBGs_missed	reset
addAnnouncedBGs	passedBG
addAnnouncedBGs	BGs_in
addAnnouncedBGs	trainProperties
calculateBGLocations	passedBG
calculateBGLocations	lastBGs
calculateBGLocations	reset
calculateBGLocations	trainProperties
calculateTrainpositionAttributes	trainPositionInfo
calculateTrainpositionAttributes	currentOdometry
calculateTrainpositionAttributes	trainProperties
calculateTrainPositionInfo	currentOdometry
calculateTrainPositionInfo	BGs
calculateTrainPositionInfo	recalculateBGs

Owner	Port
calculateTrainPositionInfo	passedBG
calculateTrainPositionInfo	reset
delDispensableBGs	BGs_in
delDispensableBGs	deleteBG
msg_2_passedBG	msgFromTrack
F2.5 ManageLevelAndMode	Data_From_Speed_and_Supervision
F2.5 ManageLevelAndMode	MemorizedLevelIn
Input	Data_From_DMI
Input	Data_From_TIU
Input	Data_From_Track_Messages
Input	Data_From_Track_Packets
Input	Data_From_STM
Input	Data_From_Localisation
Input	Data_From_Speed_and_Supervision
Input	Data_From_F2_Functions
Input	Cab_In
Input	driver_level_transition_In
Input	ERTMS_capabilities_In
Input	startOfMissionEnded
Input	Data_From_Track_MASSPGradient
ManageLevels	trainStandstill
ManageLevels	driverLevelTransition
ManageLevels	levelAck
ManageLevels	trainPosition
ManageLevels	ERTMScapabilities
ManageLevels	DataFromTrackToLevel
ManageLevels	MemorizedLevelIn
CheckLevelAndMode	Level
CheckLevelAndMode	Mode
ManageModes	Current_Level
ManageModes	Cab
ManageModes	Data_From_DMI
ManageModes	Data_From_F2_Functions
ManageModes	Data_From_Localisation
ManageModes	Data_From_Speed_and_Supervision
ManageModes	Data_From_STM
ManageModes	Data_From_TIU
ManageModes	Data_From_Track
ManageModes	TripModeFromLevel
Output	next_level

Owner	Port
Output	TripTrain
Output	previous_level
Output	needsAckFromDriver
Output	announce_driver_selection
Output	service_brake_from_level
Output	LevelsTransitionPositionPassed
Output	currentMode
Output	EB_Requested_From_Mode
Output	Service_Brake_Command_From_Mode
Output	Data_To_DMI_From_Mode
Output	Data_To_BG_Management_From_Mode
Output	Level_Mode_Compatible
TrackAtlasETCS	MessageIn
TrackAtlasETCS	ModeAndLevel_in
TrackAtlasETCS	TrainData_in
TrackAtlasETCS	TrainPositionIn
TrackAtlasETCS	train_length
TrackAtlasETCS	SystemTime
TrackAtlasETCS	preindicationLocation
TrackAtlasETCS	odometry
TrackAtlasETCS	fromDriverToMA_R
TrackAtlasETCS	trainProps
TrackAtlasETCS	packet0
TrackAtlasETCS	packet1
TrackAtlasETCS	t_train
TrackAtlasETCS	bus_in
TrackAtlasETCS	P203V1_onboard
TrackAtlasETCS	PermanentDataP003
F2.9 MoRC_Main	currentTime
F2.9 MoRC_Main	mode
F2.9 MoRC_Main	level
F2.9 MoRC_Main	obuEventsAndPhases
F2.9 MoRC_Main	radioNetworkIDs
F2.9 MoRC_Main	statusOfMobile
F2.9 MoRC_Main	inMessage_new
F2.9 MoRC_Main	t_train
F2.9 MoRC_Main	t_train_global
F2.9 MoRC_Main	msgBus_in
F2.9 MoRC_Main	connectionStatusTimerInterval
F2.9 MoRC_Main	nid_engine

Owner	Port
F2.9 MoRC_Main	onboardPhoneNumbers
F2.9 MoRC_Main	onboardPhoneNumbers_b
F2.9 MoRC_Main	m_version
Driver	Input1
ManageLevelAndMode	Data_From_DMI
ManageLevelAndMode	Data_From_Localisation
ManageLevelAndMode	Data_From_TIU
ManageLevelAndMode	Data_From_Track_Messages
ManageLevelAndMode	Data_From_Track_Packets
ManageLevelAndMode	Data_From_Speed_and_Supervision
ManageLevelAndMode	Cab_In
ManageLevelAndMode	driver_level_transition_In
ManageLevelAndMode	ERTMS_capabilities_In
ManageLevelAndMode	Data_from_Track_MASSPGradient
ManageLevelAndMode	Data_From_F2_Functions
ManageLevelAndMode	Data_From_STM
ManageLevelAndMode	MemorizedLevelIn
Input	Data_From_DMI
Input	Data_From_TIU
Input	Data_From_Track_Messages
Input	Data_From_Track_Packets
Input	Data_From_STM
Input	Data_From_Localisation
Input	Data_From_Speed_and_Supervision
Input	Data_From_F2_Functions
Input	Cab_In
Input	driver_level_transition_In
Input	ERTMS_capabilities_In
Input	startOfMissionEnded
Input	Data_From_Track_MASSPGradient
ManageLevels	trainStandstill
ManageLevels	levelAck
ManageLevels	driverLevelTransition
ManageLevels	trainPosition
ManageLevels	ERTMScapabilities
ManageLevels	DataFromTrackToLevel
ManageLevels	MemorizedLevelIn
CheckLevelAndMode	Level
CheckLevelAndMode	Mode
ManageModes	Current_Level

Owner	Port
ManageModes	Cab
ManageModes	Data_From_DMI
ManageModes	Data_From_F2_Functions
ManageModes	Data_From_Localisation
ManageModes	Data_From_Speed_and_Supervision
ManageModes	Data_From_STM
ManageModes	Data_From_TIU
ManageModes	Data_From_Track
ManageModes	TripModeFromLevel
Output	needsAckFromDriver
Output	service_brake_from_level
Output	LevelsTransitionPositionPassed
Output	EB_Requested_From_Mode
Output	Service_Brake_Command_From_Mode
Output	Level_Mode_Compatible
Output	next_level
Output	TripTrain
Output	previous_level
Output	MemorizedLevelIn
Output	announce_driver_selection
Output	currentMode
Output	Data_To_DMI_From_Mode
Output	Data_To_BG_Management_From_Mode
ETCS OBU	RBCBTMin
ETCS OBU	OdometryIn
ETCS OBU	Input1
ETCS OBU	DriverIn
ETCS OBU	RBCIN
ETCS OBU	TrainIn
F2 ETCS Kernel	EVC_reset
F2 ETCS Kernel	API_SystemTime
F2.1 Manage_TrackSideInformation_Integration	fullChecks
F2.1 Manage_TrackSideInformation_Integration	lastRelevantEventTimestamp
CheckBGConsistency	storedBGs
CheckBGConsistency	mMode
CheckBGConsistency	q_nvlocacc
CaseLinkingInUse1	storedBGs
CaseLinkingInUse1	q_nvlocacc
CaseLinkingNotInUse1	q_nvlocacc
InformationFilter	inLevel

Owner	Port
InformationFilter	inModus
InformationFilter	inSupervisingDevice
InformationFilter	inPendingL1Transition
InformationFilter	inPendingL2L3Transition
InformationFilter	inPendingAckOfTrainDataFromRBC
InformationFilter	inEmergencyStopAccepted
InformationFilter	inLastAckTextMessageId
InformationFilter	inPendingNTCTransition
validateDataDirection	inLRBG
validateDataDirection	inPositionedBGs
validateDataDirection	trainPosition
CheckEuroRadioMessage	tNvContact
CheckEuroRadioMessage	lastRelevantEventTimestamp
CheckEuroRadioMessage	connectionStatus
CheckEuroRadioMessage	activateCheck
F2.10 manageDMI_Input	lasttNTC
changeLevelByDiver1	levelData
changeLevelByDiver1	lasttNTC
doDriverRequests1	inDriverRequest
receiveRequestsModesAndLevel1	fromDMI_driverRequest
receiveRequestsModesAndLevel1	fromDMI_Icon_Ack
receiveRequestsModesAndLevel1	fromDMI_TextMsg_Ack
receiveRequestsModesAndLevel1	inSystemTime
receiveRequestsModesAndLevel1	inStatusList
triggerForMA1	fromDMI_driverRequest
updateDMIStatus1	oldStatus
updateDMIStatus1	fromDMI
updateDMIStatus1	sndValidationRequested
getTIUStatusFromData	inTIUActualData
mergeTIU_Info	newInfo
mergeTIU_Info	storedInfo
mergeTIU_Info	EVC_trainData
selectTrainData	newTIUTrainData
selectTrainData	EVC_trainData
F2.2 Manage_ETCS_Procedures	Status_MA_FS_SR_OS_LS_SH_from_MA_L2_Management
F2.2 Manage_ETCS_Procedures	statusRBCSessionEstablished_status_from_MoRC
SoM_NTC_SN	Status_Mode_Change_from_Level_and_Mode_Management
SoM_SR_FS_OS_LS_SH_SN_UN	Status_MA_FS_SR_OS_LS_SH_from_MA_L2_Management
SoM_SR_FS_OS_LS_SH_SN_UN	Status_Mode_Change_from_Level_and_Mode_Management
F2.9 MoRC_HO	atPowerUpRadioNetworkID

Owner	Port
F2.9 MoRC_HO	newRadioNetworkIDFromDriver
F2.9 MoRC_HO	mobileRegistrationContext_2
F2.9 MoRC_HO	mobileConnectionContext_2
F2.9 MoRC_HO	sessionManagementAbility
F2.9 MoRC_HO	configData
F2.9 MoRC_HO	onboardPhoneNumbers_b
F2.9 MoRC_HO	m_version
processHandingOver	mode
processHandingOver	morcStatus_1
processHandingOver	morcStatus_2
processHandingOver	dataFromTrack_in
processHandingOver	trainPosition
processHandingOver	BGs
processHandingOver	sessionManagementAbility
processHandingOver	trainProperties
MoRC_Main_v21	msg_in
MoRC_Main_v21	eventsAndPhases
MoRC_Main_v21	atPowerUpRadioNetworkID
MoRC_Main_v21	newRadioNetworkIDFromDriver
MoRC_Main_v21	mode
MoRC_Main_v21	level
MoRC_Main_v21	mobileRegistrationContext
MoRC_Main_v21	mobileConnectionContext
MoRC_Main_v21	currentTime
MoRC_Main_v21	reset
MoRC_Main_v21	t_train
MoRC_Main_v21	configData
MoRC_Main_v22	msg_in
MoRC_Main_v22	eventsAndPhases
MoRC_Main_v22	atPowerUpRadioNetworkID
MoRC_Main_v22	newRadioNetworkIDFromDriver
MoRC_Main_v22	mode
MoRC_Main_v22	level
MoRC_Main_v22	mobileRegistrationContext
MoRC_Main_v22	mobileConnectionContext
MoRC_Main_v22	currentTime
MoRC_Main_v22	reset
MoRC_Main_v22	t_train
MoRC_Main_v22	configData
mobileDataRouter_out	dataToRBC

Owner	Port
mobileDataRouter_out	positionReport_in
mobileDataRouter_out	trainData_in
mobileDataRouter_out	morcMsgToRBC_1
mobileDataRouter_out	morcMsgToRBC_2
mobileDataRouter_out	useInformationFromAcceptingRBC
mobileDataRouter_out	handingOverRBC_is_RBC_1
mobileDataRouter_out	sendPositionReport_2_acceptingRBC
mobileDataRouter_out	sendPositionReport_2_handingOverRBC
mobileDataRouter_out	sendPositionReport_2_RBC_1
mobileDataRouter_out	sendPositionReport_2_RBC_2
mobileDataRouter_out	sendTrainData_2_acceptingRBC
mobileDataRouter_out	sessionManagementAbility
Commands	trainLocations
F2.8 ProvidePositionReport	trackInfo
F2.8 ProvidePositionReport	RadioSafeRadioConnectionError
F2.8 ProvidePositionReport	SafetyCriticalFailure
F2.8 ProvidePositionReport	reportedBGs
F2.8 ProvidePositionReport	inVersion
F2.13 manageTIU_output	in_IsolationStatus
F2.13 manageTIU_output	in_brake_inhibition
F2.13 manageTIU_output	in_change_traction_system
F2.13 manageTIU_output	in_passenger_door_control_info
F2.13 manageTIU_output	in_change_of_allowed_current_consumption
bothBrakesActive	speedSupbrakeCommand
bothBrakesActive	levelBrakeCommand
getTIUStatusFromCommand	in_IsolationStatus
getTIUStatusFromCommand	in_brake_command
handleTraction	in_train_commands
handleTraction	inModeLevel
mapModeToTractionCutOff	inModeLevel
TIU_OutputIntegration	in_IsolationStatus
TIU_OutputIntegration	SpeedSup_brakeCommand
TIU_OutputIntegration	in_brake_inhibition
TIU_OutputIntegration	in_train_commands
TIU_OutputIntegration	in_change_traction_system
TIU_OutputIntegration	in_passenger_door_control_info
TIU_OutputIntegration	in_change_of_allowed_current_consumption
TIU_OutputIntegration	inModeAndLevel
F2.11 manageDMI_Output	inNationalValues
F2.11 manageDMI_Output	inMovementAuthority



Owner	Port
F2.11 manageDMI_Output	dmi_evc_coded_train_data
F2.11 manageDMI_Output	evc_systemVersion
F2.11 manageDMI_Output	dmi_displayControl
F2.11 manageDMI_Output	dmi_EVC_levelList
F2.11 manageDMI_Output	dmi_EVC_radioNet
F2.11 manageDMI_Output	dmi_driverIdentifier
F2.11 manageDMI_Output	dmi_trainRunningNumber
F2.11 manageDMI_Output	dmi_adhesionFactor
calcDistances1	inTrainPosition
collectDMIPackets1	TIU_TrainStatus
collectDMIPackets1	dmi_dynamic
collectDMIPackets1	dmi_menuRequest
collectDMIPackets1	dmi_entryRequest
collectDMIPackets1	dmi_evc_coded_train_data
collectDMIPackets1	dmi_text_message
collectDMIPackets1	dmi_trackDescription
collectDMIPackets1	dmi_identifierRequest
collectDMIPackets1	dmi_systemVersion
collectDMIPackets1	dmi_displayControl
collectDMIPackets1	dmi_EVC_levelData
collectDMIPackets1	dmi_EVC_radioNet
collectDMIPackets1	dmi_driverIdentifier
collectDMIPackets1	dmi_trainRunningNumber
collectDMIPackets1	dmi_trainData
collectDMIPackets1	dmi_adhesionFactor
collectDMIPackets1	dmi_iconRequest
collectDMIPackets1	systemTime
convert_cm_s_km_h1	cm_s
copyGradientElement1	index
copyGradientElement1	fromTrackAtlas
copySpeedProfileElement1	index
copySpeedProfileElement1	fromTrackAtlas
copyTrackDescription1	fromTrackAtlas
copyTrackDescription1	inSystemTime
cyclicReportToDMI1	incurrentDMIStatus
cyclicReportToDMI1	inSystemTime
cyclicReportToDMI1	inOdometry
cyclicReportToDMI1	inTrainPosition
cyclicReportToDMI1	inSpeedSupervision
cyclicReportToDMI1	inModeAndLevel

Owner	Port
cyclicReportToDMI1	inNationalValues
cyclicReportToDMI1	inMovementAuthority
cyclicReportToDMI1	inMoRC_status
cyclicReportToDMI1	inNTC
doEntryRequest1	dmi_entryRequest
doEntryRequest1	inSystemTime
doldentifierRequest1	TIU_TrainStatus
doldentifierRequest1	inSystemTime
doldentifierRequest1	ownVersion
isSendingNeeded1	inSystemTime
isSendingNeeded1	inCurrentDMIStatus
mapEntryForLevel1	dmi_entryRequest
mapMoRCtoRadio_CS1	inMoRC_status
sendBrakesToDMI1	brakeCommand
sendBrakesToDMI1	inSystemTime
sendDynamic1	inSystemTime
sendDynamic1	inOdometry
sendDynamic1	inTrainPosition
sendDynamic1	inSpeedSupervision
sendDynamic1	inModeAndLevel
sendDynamic1	inNationalValues
sendDynamic1	inMoRC_status
sendDynamic1	inMovementAuthority
sendDynamic1	inNTC
sendLevelListPkg1	levelList
sendLevelListPkg1	UpdateLevelsRequested
sendLevelListPkg1	inSystemTime
sendTrainData1	inSystemTime
sendTrainData1	trainDataFromEVC
sendVersion1	ownVersion
sendVersion1	dmiStatus
sendVersion1	inSystemTime
synchWithDMI1	dmi_identifierRequest
synchWithDMI1	TIU_TrainStatus
synchWithDMI1	outputStatus
synchWithDMI1	systemTime
F2.3 trainData	MessageBus
F2.3 trainData	inVersion
trainDataStorage	actualStatus
sendAcknowledgementRBC	actualStatus

Owner	Port
sendAcknowledgementRBC	inVersion
checkRadioMessages	actualStatus
sendValidTrainDataRBC	actualStatus
sendValidTrainDataRBC	inVersion
F2.6 calculateTrainPosition	passedBG
linkedBG_missed	position
linkedBG_missed	BGs_in
linkedBG_missed	enable
twoConsecutiveLinkedBGs_missed	missed
twoConsecutiveLinkedBGs_missed	missedLinkedBG
twoConsecutiveLinkedBGs_missed	passedBG
twoConsecutiveLinkedBGs_missed	reset
addAnnouncedBGs	passedBG
addAnnouncedBGs	BGs_in
addAnnouncedBGs	trainProperties
calculateBGLocations	passedBG
calculateBGLocations	lastBGs
calculateBGLocations	reset
calculateBGLocations	trainProperties
calculateTrainpositionAttributes	trainPositionInfo
calculateTrainpositionAttributes	currentOdometry
calculateTrainpositionAttributes	trainProperties
calculateTrainPositionInfo	currentOdometry
calculateTrainPositionInfo	BGs
calculateTrainPositionInfo	recalculateBGs
calculateTrainPositionInfo	passedBG
calculateTrainPositionInfo	reset
delDispensableBGs	BGs_in
delDispensableBGs	deleteBG
msg_2_passedBG	msgFromTrack
F2.5 ManageLevelAndMode	Data_From_Speed_and_Supervision
F2.5 ManageLevelAndMode	MemorizedLevelIn
Input	Data_From_DMI
Input	Data_From_TIU
Input	Data_From_Track_Messages
Input	Data_From_Track_Packets
Input	Data_From_STM
Input	Data_From_Localisation
Input	Data_From_Speed_and_Supervision
Input	Data_From_F2_Functions

Owner	Port
Input	Cab_In
Input	driver_level_transition_In
Input	ERTMS_capabilities_In
Input	startOfMissionEnded
Input	Data_From_Track_MASSPGradient
ManageLevels	trainStandstill
ManageLevels	driverLevelTransition
ManageLevels	levelAck
ManageLevels	trainPosition
ManageLevels	ERTMScapabilities
ManageLevels	DataFromTrackToLevel
ManageLevels	MemorizedLevelIn
CheckLevelAndMode	Level
CheckLevelAndMode	Mode
ManageModes	Current_Level
ManageModes	Cab
ManageModes	Data_From_DMI
ManageModes	Data_From_F2_Functions
ManageModes	Data_From_Localisation
ManageModes	Data_From_Speed_and_Supervision
ManageModes	Data_From_STM
ManageModes	Data_From_TIU
ManageModes	Data_From_Track
ManageModes	TripModeFromLevel
Output	next_level
Output	TripTrain
Output	previous_level
Output	needsAckFromDriver
Output	announce_driver_selection
Output	service_brake_from_level
Output	LevelsTransitionPositionPassed
Output	currentMode
Output	EB_Requested_From_Mode
Output	Service_Brake_Command_From_Mode
Output	Data_To_DMI_From_Mode
Output	Data_To_BG_Management_From_Mode
Output	Level_Mode_Compatible
TrackAtlasETCS	MessageIn
TrackAtlasETCS	ModeAndLevel_in
TrackAtlasETCS	TrainData_in

Owner	Port
TrackAtlasETCS	TrainPositionIn
TrackAtlasETCS	train_length
TrackAtlasETCS	SystemTime
TrackAtlasETCS	preindicationLocation
TrackAtlasETCS	odometry
TrackAtlasETCS	fromDriverToMA_R
TrackAtlasETCS	trainProps
TrackAtlasETCS	packet0
TrackAtlasETCS	packet1
TrackAtlasETCS	t_train
TrackAtlasETCS	bus_in
TrackAtlasETCS	P203V1_onboard
TrackAtlasETCS	PermanentDataP003
F2.9 MoRC_Main	currentTime
F2.9 MoRC_Main	mode
F2.9 MoRC_Main	level
F2.9 MoRC_Main	obuEventsAndPhases
F2.9 MoRC_Main	radioNetworkIDs
F2.9 MoRC_Main	statusOfMobile
F2.9 MoRC_Main	inMessage_new
F2.9 MoRC_Main	t_train
F2.9 MoRC_Main	t_train_global
F2.9 MoRC_Main	msgBus_in
F2.9 MoRC_Main	connectionStatusTimerInterval
F2.9 MoRC_Main	nid_engine
F2.9 MoRC_Main	onboardPhoneNumbers
F2.9 MoRC_Main	onboardPhoneNumbers_b
F2.9 MoRC_Main	m_version
Driver	Input1
MoRC_HO	mode
MoRC_HO	level
MoRC_HO	eventsAndPhases
MoRC_HO	atPowerUpRadioNetworkID
MoRC_HO	newRadioNetworkIDFromDriver
MoRC_HO	mobileRegistrationContext_1
MoRC_HO	mobileRegistrationContext_2
MoRC_HO	mobileConnectionContext_1
MoRC_HO	mobileConnectionContext_2
MoRC_HO	dataFromTrack_in
MoRC_HO	msgBusToRBC_in

Owner	Port
MoRC_HO	trainPosition
MoRC_HO	BGs
MoRC_HO	t_train
MoRC_HO	t_train_global
MoRC_HO	currentTime
MoRC_HO	reset
MoRC_HO	sessionManagementAbility
MoRC_HO	trainProperties
MoRC_HO	configData
MoRC_HO	onboardPhoneNumbers_b
MoRC_HO	m_version
processHandingOver	mode
processHandingOver	morcStatus_1
processHandingOver	morcStatus_2
processHandingOver	dataFromTrack_in
processHandingOver	trainPosition
processHandingOver	BGs
processHandingOver	sessionManagementAbility
processHandingOver	trainProperties
MoRC_Main_v21	msg_in
MoRC_Main_v21	eventsAndPhases
MoRC_Main_v21	atPowerUpRadioNetworkID
MoRC_Main_v21	newRadioNetworkIDFromDriver
MoRC_Main_v21	mode
MoRC_Main_v21	level
MoRC_Main_v21	mobileRegistrationContext
MoRC_Main_v21	mobileConnectionContext
MoRC_Main_v21	currentTime
MoRC_Main_v21	reset
MoRC_Main_v21	t_train
MoRC_Main_v21	configData
MoRC_Main_v22	msg_in
MoRC_Main_v22	eventsAndPhases
MoRC_Main_v22	atPowerUpRadioNetworkID
MoRC_Main_v22	newRadioNetworkIDFromDriver
MoRC_Main_v22	mode
MoRC_Main_v22	level
MoRC_Main_v22	mobileRegistrationContext
MoRC_Main_v22	mobileConnectionContext
MoRC_Main_v22	currentTime

Owner	Port
MoRC_Main_v22	reset
MoRC_Main_v22	t_train
MoRC_Main_v22	configData
mobileDataRouter_out	dataToRBC
mobileDataRouter_out	positionReport_in
mobileDataRouter_out	trainData_in
mobileDataRouter_out	morcMsgToRBC_1
mobileDataRouter_out	morcMsgToRBC_2
mobileDataRouter_out	useInformationFromAcceptingRBC
mobileDataRouter_out	handingOverRBC_is_RBC_1
mobileDataRouter_out	sendPositionReport_2_acceptingRBC
mobileDataRouter_out	sendPositionReport_2_handingOverRBC
mobileDataRouter_out	sendPositionReport_2_RBC_1
mobileDataRouter_out	sendPositionReport_2_RBC_2
mobileDataRouter_out	sendTrainData_2_acceptingRBC
mobileDataRouter_out	sessionManagementAbility
CheckBGConsistency	storedBGs
CheckBGConsistency	trainPosition
CheckBGConsistency	mMode
CheckBGConsistency	trackSide_ForCheck
CheckBGConsistency	q_nvlocacc
CheckBGConsistency	trainVersion
CaseLinkingInUse1	storedBGs
CaseLinkingInUse1	q_nvlocacc
CaseLinkingNotInUse1	q_nvlocacc
ProvidePositionReport	posBGs
ProvidePositionReport	trainPos
ProvidePositionReport	odometry
ProvidePositionReport	trainProps
ProvidePositionReport	trackInfo
ProvidePositionReport	inMessage
ProvidePositionReport	systemTime
ProvidePositionReport	rcbComm
ProvidePositionReport	train2trackStatus
ProvidePositionReport	prvDirTrain
ProvidePositionReport	BG_LinkingConsistencyError
ProvidePositionReport	LinkedBG_MessageConsistencyError
ProvidePositionReport	UnlinkedBG_MessageConsistencyError
ProvidePositionReport	RadioMessageConsistencyError
ProvidePositionReport	RadioSequenceError

Owner	Port
ProvidePositionReport	RadioSafeRadioConnectionError
ProvidePositionReport	SafetyCriticalFailure
ProvidePositionReport	DoubleLinkingError
ProvidePositionReport	DoubleRepositioningError
ProvidePositionReport	modeLevelStatus
ProvidePositionReport	reportedBGs
ProvidePositionReport	MessageBus
ProvidePositionReport	inVersion
ProvidePositionReport	t_train
manageDMI_Output	incurrentDMIStatus
manageDMI_Output	inSystemTime
manageDMI_Output	TIU_TrainStatus
manageDMI_Output	inOdometry
manageDMI_Output	inTrainPosition
manageDMI_Output	inBrakeCommand
manageDMI_Output	inSpeedSupervision
manageDMI_Output	inModeAndLevel
manageDMI_Output	inNationalValues
manageDMI_Output	inMovementAuthority
manageDMI_Output	inMoRC_status
manageDMI_Output	trainDataFromEVC
manageDMI_Output	dmi_entryRequest
manageDMI_Output	dmi_evc_coded_train_data
manageDMI_Output	dmi_trackDescription
manageDMI_Output	evc_systemVersion
manageDMI_Output	dmi_displayControl
manageDMI_Output	dmi_EVC_levelList
manageDMI_Output	dmiUpdateLevelsDMI
manageDMI_Output	dmi_EVC_radioNet
manageDMI_Output	dmi_driverIdentifier
manageDMI_Output	dmi_trainRunningNumber
manageDMI_Output	dmi_adhesionFactor
manageDMI_Output	dmi_fromBG
manageDMI_Output	inModeLevel_Ack
manageDMI_Output	announcedLevel
manageDMI_Output	inNTC
manageDMI_Output	inStatusList
calcDistances1	inTrainPosition
collectDMIPackets1	TIU_TrainStatus
collectDMIPackets1	dmi_dynamic



Owner	Port
collectDMIPackets1	dmi_menuRequest
collectDMIPackets1	dmi_entryRequest
collectDMIPackets1	dmi_evc_coded_train_data
collectDMIPackets1	dmi_text_message
collectDMIPackets1	dmi_trackDescription
collectDMIPackets1	dmi_identifierRequest
collectDMIPackets1	dmi_systemVersion
collectDMIPackets1	dmi_displayControl
collectDMIPackets1	dmi_EVC_levelData
collectDMIPackets1	dmi_EVC_radioNet
collectDMIPackets1	dmi_driverIdentifier
collectDMIPackets1	dmi_trainRunningNumber
collectDMIPackets1	dmi_trainData
collectDMIPackets1	dmi_adhesionFactor
collectDMIPackets1	dmi_iconRequest
collectDMIPackets1	systemTime
convert_cm_s_km_h1	cm_s
copyGradientElement1	index
copyGradientElement1	fromTrackAtlas
copySpeedProfileElement1	index
copySpeedProfileElement1	fromTrackAtlas
copyTrackDescription1	fromTrackAtlas
copyTrackDescription1	inSystemTime
cyclicReportToDMI1	inCurrentDMIStatus
cyclicReportToDMI1	inSystemTime
cyclicReportToDMI1	inOdometry
cyclicReportToDMI1	inTrainPosition
cyclicReportToDMI1	inSpeedSupervision
cyclicReportToDMI1	inModeAndLevel
cyclicReportToDMI1	inNationalValues
cyclicReportToDMI1	inMovementAuthority
cyclicReportToDMI1	inMoRC_status
cyclicReportToDMI1	inNTC
doEntryRequest1	dmi_entryRequest
doEntryRequest1	inSystemTime
doldentifierRequest1	TIU_TrainStatus
doldentifierRequest1	inSystemTime
doldentifierRequest1	ownVersion
isSendingNeeded1	inSystemTime
isSendingNeeded1	inCurrentDMIStatus

Owner	Port
mapEntryForLevel1	dmi_entryRequest
mapMoRCtoRadio_CS1	inMoRC_status
sendBrakesToDMI1	brakeCommand
sendBrakesToDMI1	inSystemTime
sendDynamic1	inSystemTime
sendDynamic1	inOdometry
sendDynamic1	inTrainPosition
sendDynamic1	inSpeedSupervision
sendDynamic1	inModeAndLevel
sendDynamic1	inNationalValues
sendDynamic1	inMoRC_status
sendDynamic1	inMovementAuthority
sendDynamic1	inNTC
sendLevelListPkg1	levelList
sendLevelListPkg1	UpdateLevelsRequested
sendLevelListPkg1	inSystemTime
sendTrainData1	inSystemTime
sendTrainData1	trainDataFromEVC
sendVersion1	ownVersion
sendVersion1	dmiStatus
sendVersion1	inSystemTime
synchWithDMI1	dmi_identifierRequest
synchWithDMI1	TIU_TrainStatus
synchWithDMI1	outputStatus
synchWithDMI1	systemTime
F2 ETCS Kernel	EVC_reset
F2 ETCS Kernel	API_Odometry
F2 ETCS Kernel	API_SystemTime
F2 ETCS Kernel	API_fromTrack
F2 ETCS Kernel	API_fromDMI
F2 ETCS Kernel	API_fromTIU
F2 ETCS Kernel	API_mobileHWStatus
F2 ETCS Kernel	API_persistentDataIn
F2.1 Manage_TrackSideInformation_Integration	fullChecks
F2.1 Manage_TrackSideInformation_Integration	lastRelevantEventTimestamp
CheckBGConsistency	storedBGs
CheckBGConsistency	mMode
CheckBGConsistency	q_nvlocacc
CaseLinkingInUse1	storedBGs
CaseLinkingInUse1	q_nvlocacc

Owner	Port
CaseLinkingNotInUse1	q_nvlocacc
InformationFilter	inSupervisingDevice
InformationFilter	inPendingL1Transition
InformationFilter	inPendingL2L3Transition
InformationFilter	inPendingAckOfTrainDataFromRBC
InformationFilter	inEmergencyStopAccepted
InformationFilter	inLastAckTextMessageId
InformationFilter	inPendingNTCTransition
InformationFilter	inLevel
InformationFilter	inModus
validateDataDirection	inLRBG
validateDataDirection	inPositionedBGs
validateDataDirection	trainPosition
CheckEuroRadioMessage	activateCheck
CheckEuroRadioMessage	tNvContact
CheckEuroRadioMessage	lastRelevantEventTimestamp
CheckEuroRadioMessage	connectionStatus
F2.10 manageDMI_Input	lasttNTC
changeLevelByDiver1	levelData
changeLevelByDiver1	lasttNTC
doDriverRequests1	inDriverRequest
receiveRequestsModesAndLevel1	fromDMI_driverRequest
receiveRequestsModesAndLevel1	fromDMI_Icon_Ack
receiveRequestsModesAndLevel1	fromDMI_TextMsg_Ack
receiveRequestsModesAndLevel1	inSystemTime
receiveRequestsModesAndLevel1	inStatusList
triggerForMA1	fromDMI_driverRequest
updateDMIStatus1	sndValidationRequested
updateDMIStatus1	oldStatus
updateDMIStatus1	fromDMI
getTIUStatusFromData	inTIUActualData
mergeTIU_Info	newInfo
mergeTIU_Info	storedInfo
mergeTIU_Info	EVC_trainData
selectTrainData	newTIUTrainData
selectTrainData	in_train_commands
selectTrainData	EVC_trainData
F2.2 Manage_ETCS_Procedures	Status_MA_FS_SR_OS_LS_SH_from_MA_L2_Management
F2.2 Manage_ETCS_Procedures	statusRBCSessioneEstablished_status_from_MoRC
SoM_NTC_SN	Status_Mode_Change_from_Level_and_Mode_Management

Owner	Port
SoM_SR_FS_OS_LS_SH_SN_UN	Status_MA_FS_SR_OS_LS_SH_from_MA_L2_Management
SoM_SR_FS_OS_LS_SH_SN_UN	Status_Mode_Change_from_Level_and_Mode_Management
F2.9 MoRC_HO	atPowerUpRadioNetworkID
F2.9 MoRC_HO	newRadioNetworkIDFromDriver
F2.9 MoRC_HO	mobileRegistrationContext_2
F2.9 MoRC_HO	mobileConnectionContext_2
F2.9 MoRC_HO	sessionManagementAbility
F2.9 MoRC_HO	configData
F2.9 MoRC_HO	onboardPhoneNumbers_b
F2.9 MoRC_HO	m_version
processHandingOver	sessionManagementAbility
processHandingOver	mode
processHandingOver	morcStatus_1
processHandingOver	morcStatus_2
processHandingOver	dataFromTrack_in
processHandingOver	trainPosition
processHandingOver	BGs
processHandingOver	trainProperties
MoRC_Main_v21	eventsAndPhases
MoRC_Main_v21	reset
MoRC_Main_v21	msg_in
MoRC_Main_v21	atPowerUpRadioNetworkID
MoRC_Main_v21	newRadioNetworkIDFromDriver
MoRC_Main_v21	mode
MoRC_Main_v21	level
MoRC_Main_v21	mobileRegistrationContext
MoRC_Main_v21	mobileConnectionContext
MoRC_Main_v21	currentTime
MoRC_Main_v21	t_train
MoRC_Main_v21	configData
MoRC_Main_v22	eventsAndPhases
MoRC_Main_v22	reset
MoRC_Main_v22	msg_in
MoRC_Main_v22	atPowerUpRadioNetworkID
MoRC_Main_v22	newRadioNetworkIDFromDriver
MoRC_Main_v22	mode
MoRC_Main_v22	level
MoRC_Main_v22	mobileRegistrationContext
MoRC_Main_v22	mobileConnectionContext
MoRC_Main_v22	currentTime

Owner	Port
MoRC_Main_v22	t_train
MoRC_Main_v22	configData
mobileDataRouter_out	useInformationFromAcceptingRBC
mobileDataRouter_out	handingOverRBC_is_RBC_1
mobileDataRouter_out	sendPositionReport_2_acceptingRBC
mobileDataRouter_out	sendPositionReport_2_handingOverRBC
mobileDataRouter_out	sendPositionReport_2_RBC_1
mobileDataRouter_out	sendPositionReport_2_RBC_2
mobileDataRouter_out	sendTrainData_2_acceptingRBC
mobileDataRouter_out	sessionManagementAbility
mobileDataRouter_out	dataToRBC
mobileDataRouter_out	positionReport_in
mobileDataRouter_out	trainData_in
mobileDataRouter_out	morcMsgToRBC_1
mobileDataRouter_out	morcMsgToRBC_2
Commands	trainLocations
F2.8 ProvidePositionReport	trackInfo
F2.8 ProvidePositionReport	RadioSafeRadioConnectionError
F2.8 ProvidePositionReport	SafetyCriticalFailure
F2.8 ProvidePositionReport	reportedBGs
F2.8 ProvidePositionReport	inVersion
F2.13 manageTIU_output	in_IsolationStatus
F2.13 manageTIU_output	in_brake_inhibition
F2.13 manageTIU_output	in_change_traction_system
F2.13 manageTIU_output	in_passenger_door_control_info
F2.13 manageTIU_output	in_change_of_allowed_current_consumption
bothBrakesActive	speedSupbrakeCommand
bothBrakesActive	levelBrakeCommand
getTIUStatusFromCommand	in_IsolationStatus
getTIUStatusFromCommand	in_brake_command
handleTraction	in_train_commands
handleTraction	inModeLevel
mapModeToTractionCutOff	inModeLevel
TIU_OutputIntegration	in_IsolationStatus
TIU_OutputIntegration	SpeedSup_brakeCommand
TIU_OutputIntegration	in_brake_inhibition
TIU_OutputIntegration	in_train_commands
TIU_OutputIntegration	in_change_traction_system
TIU_OutputIntegration	in_passenger_door_control_info
TIU_OutputIntegration	in_change_of_allowed_current_consumption

Owner	Port
TIU_OutputIntegration	inModeAndLevel
F2.11 manageDMI_Output	dmi_dynamic
F2.11 manageDMI_Output	dmi_menuRequest
F2.11 manageDMI_Output	dmi_evc_coded_train_data
F2.11 manageDMI_Output	dmi_text_message
F2.11 manageDMI_Output	evc_systemVersion
F2.11 manageDMI_Output	dmi_displayControl
F2.11 manageDMI_Output	dmi_EVC_levelData
F2.11 manageDMI_Output	dmi_EVC_radioNet
F2.11 manageDMI_Output	dmi_driverIdentifier
F2.11 manageDMI_Output	dmi_trainRunningNumber
F2.11 manageDMI_Output	dmi_trainData
F2.11 manageDMI_Output	dmi_adhesionFactor
F2.11 manageDMI_Output	dmi_iconRequest
F2.11 manageDMI_Output	inSystemTime
F2.11 manageDMI_Output	inNationalValues
F2.11 manageDMI_Output	inMovementAuthority
F2.11 manageDMI_Output	dmi_EVC_levelList
calcDistances1	inTrainPosition
collectDMIPackets1	TIU_TrainStatus
collectDMIPackets1	dmi_dynamic
collectDMIPackets1	dmi_menuRequest
collectDMIPackets1	dmi_entryRequest
collectDMIPackets1	dmi_evc_coded_train_data
collectDMIPackets1	dmi_text_message
collectDMIPackets1	dmi_trackDescription
collectDMIPackets1	dmi_identifierRequest
collectDMIPackets1	dmi_systemVersion
collectDMIPackets1	dmi_displayControl
collectDMIPackets1	dmi_EVC_levelData
collectDMIPackets1	dmi_EVC_radioNet
collectDMIPackets1	dmi_driverIdentifier
collectDMIPackets1	dmi_trainRunningNumber
collectDMIPackets1	dmi_trainData
collectDMIPackets1	dmi_adhesionFactor
collectDMIPackets1	dmi_iconRequest
collectDMIPackets1	systemTime
convert_cm_s_km_h1	cm_s
copyGradientElement1	dmiUpdateLevelsDMI
copyGradientElement1	dmi_fromBG

Owner	Port
copyGradientElement1	inCurrentDMIStatus
copyGradientElement1	inSystemTime
copyGradientElement1	TIU_TrainStatus
copyGradientElement1	inOdometry
copyGradientElement1	inTrainPosition
copyGradientElement1	inBrakeCommand
copyGradientElement1	inSpeedSupervision
copyGradientElement1	inModeAndLevel
copyGradientElement1	inNationalValues
copyGradientElement1	inMovementAuthority
copyGradientElement1	inRadioConnectionStatus
copyGradientElement1	trainDataFromEVC
copyGradientElement1	dmi_entryRequest
copyGradientElement1	dmi_evc_coded_train_data
copyGradientElement1	dmi_trackDescription
copyGradientElement1	dmi_identifierRequest
copyGradientElement1	dmi_displayControl
copyGradientElement1	dmi_EVC_levelList
copyGradientElement1	dmi_EVC_radioNet
copyGradientElement1	dmi_driverIdentifier
copyGradientElement1	dmi_trainRunningNumber
copyGradientElement1	dmi_adhesionFactor
copyGradientElement1	dmi_fromModesAndLevel
copyGradientElement1	inNTC
copyGradientElement1	inStatusList
copyGradientElement1	index
copyGradientElement1	fromTrackAtlas
copySpeedProfileElement1	index
copySpeedProfileElement1	fromTrackAtlas
copyTrackDescription1	fromTrackAtlas
copyTrackDescription1	inSystemTime
cyclicReportToDMI1	inCurrentDMIStatus
cyclicReportToDMI1	inSystemTime
cyclicReportToDMI1	inOdometry
cyclicReportToDMI1	inTrainPosition
cyclicReportToDMI1	inSpeedSupervision
cyclicReportToDMI1	inModeAndLevel
cyclicReportToDMI1	inNationalValues
cyclicReportToDMI1	inMovementAuthority
cyclicReportToDMI1	inMoRC_status

Owner	Port
cyclicReportToDMI1	inNTC
doEntryRequest1	dmi_entryRequest
doEntryRequest1	inSystemTime
doldentifierRequest1	TIU_TrainStatus
doldentifierRequest1	inSystemTime
doldentifierRequest1	ownVersion
isSendingNeeded1	inSystemTime
isSendingNeeded1	incurrentDMIStatus
mapEntryForLevel1	dmi_entryRequest
mapMoRCtoRadio_CS1	inMoRC_status
sendBrakesToDMI1	brakeCommand
sendBrakesToDMI1	inSystemTime
sendDynamic1	inSystemTime
sendDynamic1	inOdometry
sendDynamic1	inTrainPosition
sendDynamic1	inSpeedSupervision
sendDynamic1	inModeLevel_Ack
sendDynamic1	inNationalValues
sendDynamic1	inMoRC_status
sendDynamic1	inNTC
sendDynamic1	inModeAndLevel
sendDynamic1	inMovementAuthority
sendLevelListPkg1	UpdateLevelsRequested
sendLevelListPkg1	levelList
sendLevelListPkg1	inSystemTime
sendTrainData1	inSystemTime
sendTrainData1	trainDataFromEVC
sendVersion1	ownVersion
sendVersion1	dmiStatus
sendVersion1	inSystemTime
synchWithDMI1	outputStatus
synchWithDMI1	dmi_identifierRequest
synchWithDMI1	TIU_TrainStatus
synchWithDMI1	systemTime
F2.3 trainData	MessageBus
F2.3 trainData	inVersion
trainDataStorage	actualStatus
sendAcknowledgementRBC	actualStatus
sendAcknowledgementRBC	inVersion
checkRadioMessages	actualStatus



Owner	Port
sendValidTrainDataRBC	actualStatus
sendValidTrainDataRBC	inVersion
F2.6 calculateTrainPosition	passedBG
linkedBG_missed	enable
linkedBG_missed	position
linkedBG_missed	BGs_in
twoConsecutiveLinkedBGs_missed	reset
twoConsecutiveLinkedBGs_missed	passedBG
twoConsecutiveLinkedBGs_missed	msgFromTrack
twoConsecutiveLinkedBGs_missed	missed
twoConsecutiveLinkedBGs_missed	missedLinkedBG
addAnnouncedBGs	passedBG
addAnnouncedBGs	BGs_in
addAnnouncedBGs	trainProperties
calculateBGLocations	reset
calculateBGLocations	passedBG
calculateBGLocations	lastBGs
calculateBGLocations	trainProperties
calculateTrainpositionAttributes	trainPositionInfo
calculateTrainpositionAttributes	currentOdometry
calculateTrainpositionAttributes	trainProperties
calculateTrainPositionInfo	recalculateBGs
calculateTrainPositionInfo	reset
calculateTrainPositionInfo	currentOdometry
calculateTrainPositionInfo	BGs
calculateTrainPositionInfo	passedBG
delDispensableBGs	deleteBG
delDispensableBGs	BGs_in
msg_2_passedBG	msgFromTrack
F2.5 ManageLevelAndMode	Data_From_Speed_and_Supervision
F2.5 ManageLevelAndMode	MemorizedLevelIn
Input	Data_From_DMI
Input	Data_From_TIU
Input	Data_From_Track_Messages
Input	Data_From_Track_Packets
Input	Data_From_STM
Input	Data_From_Localisation
Input	Data_From_Speed_and_Supervision
Input	Data_From_F2_Functions
Input	Cab_In

Owner	Port
Input	driver_level_transition_In
Input	ERTMS_capabilities_In
Input	startOfMissionEnded
Input	Data_From_Track_MASSPGradient
ManageLevels	trainStandstill
ManageLevels	levelAck
ManageLevels	driverLevelTransition
ManageLevels	trainPosition
ManageLevels	ERTMScapabilities
ManageLevels	DataFromTrackToLevel
ManageLevels	MemorizedLevelIn
CheckLevelAndMode	Level
CheckLevelAndMode	Mode
ManageModes	Current_Level
ManageModes	Cab
ManageModes	Data_From_DMI
ManageModes	Data_From_F2_Functions
ManageModes	Data_From_Localisation
ManageModes	Data_From_Speed_and_Supervision
ManageModes	Data_From_STM
ManageModes	Data_From_TIU
ManageModes	Data_From_Track
ManageModes	TripModeFromLevel
Output	needsAckFromDriver
Output	service_brake_from_level
Output	LevelsTransitionPositionPassed
Output	EB_Requested_From_Mode
Output	Service_Brake_Command_From_Mode
Output	Level_Mode_Compatible
Output	next_level
Output	TripTrain
Output	previous_level
Output	MemorizedLevelIn
Output	announce_driver_selection
Output	currentMode
Output	Data_To_DMI_From_Mode
Output	Data_To_BG_Management_From_Mode
TrackAtlasETCS	TrainData_in
TrackAtlasETCS	fromDriverToMA_R
TrackAtlasETCS	MessageIn

Owner	Port
TrackAtlasETCS	ModeAndLevel_in
TrackAtlasETCS	TrainPositionIn
TrackAtlasETCS	train_length
TrackAtlasETCS	SystemTime
TrackAtlasETCS	preindicationLocation
TrackAtlasETCS	odometry
TrackAtlasETCS	trainProps
TrackAtlasETCS	packet0
TrackAtlasETCS	packet1
TrackAtlasETCS	t_train
TrackAtlasETCS	P203V1_onboard
TrackAtlasETCS	PermanentDataP003
TrackAtlasETCS	bus_in
F2.9 MoRC_Main	obuEventsAndPhases
F2.9 MoRC_Main	radioNetworkIDs
F2.9 MoRC_Main	statusOfMobile
F2.9 MoRC_Main	connectionStatusTimerInterval
F2.9 MoRC_Main	currentTime
F2.9 MoRC_Main	mode
F2.9 MoRC_Main	level
F2.9 MoRC_Main	inMessage_new
F2.9 MoRC_Main	t_train
F2.9 MoRC_Main	t_train_global
F2.9 MoRC_Main	msgBus_in
F2.9 MoRC_Main	nid_engine
F2.9 MoRC_Main	onboardPhoneNumbers
F2.9 MoRC_Main	onboardPhoneNumbers_b
F2.9 MoRC_Main	m_version
MoRC_HO	reset
MoRC_HO	mode
MoRC_HO	level
MoRC_HO	eventsAndPhases
MoRC_HO	atPowerUpRadioNetworkID
MoRC_HO	newRadioNetworkIDFromDriver
MoRC_HO	mobileRegistrationContext_1
MoRC_HO	mobileRegistrationContext_2
MoRC_HO	mobileConnectionContext_1
MoRC_HO	mobileConnectionContext_2
MoRC_HO	dataFromTrack_in
MoRC_HO	msgBusToRBC_in

Owner	Port
MoRC_HO	trainPosition
MoRC_HO	BGs
MoRC_HO	t_train
MoRC_HO	currentTime
MoRC_HO	sessionManagementAbility
MoRC_HO	trainProperties
MoRC_HO	configData
MoRC_HO	t_train_global
MoRC_HO	onboardPhoneNumbers_b
MoRC_HO	m_version
processHandingOver	sessionManagementAbility
processHandingOver	mode
processHandingOver	morcStatus_1
processHandingOver	morcStatus_2
processHandingOver	dataFromTrack_in
processHandingOver	trainPosition
processHandingOver	BGs
processHandingOver	trainProperties
MoRC_Main_v21	eventsAndPhases
MoRC_Main_v21	reset
MoRC_Main_v21	msg_in
MoRC_Main_v21	atPowerUpRadioNetworkID
MoRC_Main_v21	newRadioNetworkIDFromDriver
MoRC_Main_v21	mode
MoRC_Main_v21	level
MoRC_Main_v21	mobileRegistrationContext
MoRC_Main_v21	mobileConnectionContext
MoRC_Main_v21	currentTime
MoRC_Main_v21	t_train
MoRC_Main_v21	configData
MoRC_Main_v22	eventsAndPhases
MoRC_Main_v22	reset
MoRC_Main_v22	msg_in
MoRC_Main_v22	atPowerUpRadioNetworkID
MoRC_Main_v22	newRadioNetworkIDFromDriver
MoRC_Main_v22	mode
MoRC_Main_v22	level
MoRC_Main_v22	mobileRegistrationContext
MoRC_Main_v22	mobileConnectionContext
MoRC_Main_v22	currentTime

Owner	Port
MoRC_Main_v22	t_train
MoRC_Main_v22	configData
mobileDataRouter_out	useInformationFromAcceptingRBC
mobileDataRouter_out	handingOverRBC_is_RBC_1
mobileDataRouter_out	sendPositionReport_2_acceptingRBC
mobileDataRouter_out	sendPositionReport_2_handingOverRBC
mobileDataRouter_out	sendPositionReport_2_RBC_1
mobileDataRouter_out	sendPositionReport_2_RBC_2
mobileDataRouter_out	sendTrainData_2_acceptingRBC
mobileDataRouter_out	sessionManagementAbility
mobileDataRouter_out	dataToRBC
mobileDataRouter_out	positionReport_in
mobileDataRouter_out	trainData_in
mobileDataRouter_out	morcMsgToRBC_1
mobileDataRouter_out	morcMsgToRBC_2
SpeedSupervision_Integration	NationalValues
SpeedSupervision_Integration	TrainPosition
SpeedSupervision_Integration	odometry
SpeedSupervision_Integration	trainProps
SpeedSupervision_Integration	trainData
SpeedSupervision_Integration	dataFromTrackAtlas
SpeedSupervision_Integration	Service_brake_requested_by_modes_and_levels
SpeedSupervision_Integration	Emergency_brake_requested_by_modes_and_levels
Commands	trainLocations
manageTIU_input	inTIUfromAPI
manageTIU_input	evc_trainData
getTIUStatusFromData	inTIUActualData
mergeTIU_Info	newInfo
mergeTIU_Info	storedInfo
mergeTIU_Info	EVC_trainData
selectTrainData	newTIUTrainData
selectTrainData	EVC_trainData
Master_Procedure	statusDMI_from_DMI
Master_Procedure	Status_MA_FS_SR_OS_LS_SH_from_MA_L2_Management
Master_Procedure	systemtime
Master_Procedure	StatusModeandLevel_from_Level_and_Mode_Management
Master_Procedure	mobileStatus
Master_Procedure	statusRBCSessionEstablished_status_from_MoRC
Master_Procedure	cabStatus_from_TIU
Master_Procedure	statusValid_Position_from_Position_Calculation

Owner	Port
Master_Procedure	status_DMILevel_from_DMI
Master_Procedure	LevelValid_from_Level_and_Mode_Management
SoM_NTC_SN	Status_Mode_Change_from_Level_and_Mode_Management
SoM_SR_FS_OS_LS_SH_SN_UN	Status_MA_FS_SR_OS_LS_SH_from_MA_L2_Management
SoM_SR_FS_OS_LS_SH_SN_UN	Status_Mode_Change_from_Level_and_Mode_Management
manageDMI_Input	dmiStatusReset
manageDMI_Input	fromDMI
manageDMI_Input	inSystemTime
manageDMI_Input	lasttNTC
changeLevelByDiver1	levelData
changeLevelByDiver1	lasttNTC
doDriverRequests1	inDriverRequest
receiveRequestsModesAndLevel1	fromDMI_driverRequest
receiveRequestsModesAndLevel1	fromDMI_Icon_Ack
receiveRequestsModesAndLevel1	fromDMI_TextMsg_Ack
receiveRequestsModesAndLevel1	inSystemTime
receiveRequestsModesAndLevel1	inStatusList
triggerForMA1	fromDMI_driverRequest
updateDMIStatus1	sndValidationRequested
updateDMIStatus1	oldStatus
updateDMIStatus1	fromDMI
Abstract	API_fromAPI
Abstract	dmiStatusReset
Abstract	InSystemTime
CheckBGConsistency	storedBGs
CheckBGConsistency	trainPosition
CheckBGConsistency	mMode
CheckBGConsistency	trackSide_ForCheck
CheckBGConsistency	q_nvlocacc
CheckBGConsistency	trainVersion
CaseLinkingInUse1	storedBGs
CaseLinkingInUse1	q_nvlocacc
CaseLinkingNotInUse1	q_nvlocacc
manageDMI_Output	TIU_TrainStatus
manageDMI_Output	dmi_dynamic
manageDMI_Output	dmi_menuRequest
manageDMI_Output	dmi_entryRequest
manageDMI_Output	dmi_evc_coded_train_data
manageDMI_Output	dmi_text_message
manageDMI_Output	dmi_trackDescription

Owner	Port
manageDMI_Output	evc_systemVersion
manageDMI_Output	dmi_displayControl
manageDMI_Output	dmi_EVC_levelData
manageDMI_Output	dmi_EVC_radioNet
manageDMI_Output	dmi_driverIdentifier
manageDMI_Output	dmi_trainRunningNumber
manageDMI_Output	dmi_trainData
manageDMI_Output	dmi_adhesionFactor
manageDMI_Output	dmi_iconRequest
manageDMI_Output	inSystemTime
manageDMI_Output	inSystemTime
manageDMI_Output	inOdometry
manageDMI_Output	inTrainPosition
manageDMI_Output	inBrakeCommand
manageDMI_Output	inSpeedSupervision
manageDMI_Output	inModeAndLevel
manageDMI_Output	inNationalValues
manageDMI_Output	inMovementAuthority
manageDMI_Output	trainDataFromEVC
manageDMI_Output	dmi_EVC_levelList
manageDMI_Output	dmi_fromBG
manageDMI_Output	announcedLevel
manageDMI_Output	inModeLevel_Ack
manageDMI_Output	inMoRC_status
calcDistances1	inTrainPosition
collectDMIPackets1	TIU_TrainStatus
collectDMIPackets1	dmi_dynamic
collectDMIPackets1	dmi_menuRequest
collectDMIPackets1	dmi_entryRequest
collectDMIPackets1	dmi_evc_coded_train_data
collectDMIPackets1	dmi_text_message
collectDMIPackets1	dmi_trackDescription
collectDMIPackets1	dmi_identifierRequest
collectDMIPackets1	dmi_systemVersion
collectDMIPackets1	dmi_displayControl
collectDMIPackets1	dmi_EVC_levelData
collectDMIPackets1	dmi_EVC_radioNet
collectDMIPackets1	dmi_driverIdentifier
collectDMIPackets1	dmi_trainRunningNumber
collectDMIPackets1	dmi_trainData

Owner	Port
collectDMIPackets1	dmi_adhesionFactor
collectDMIPackets1	dmi_iconRequest
collectDMIPackets1	systemTime
convert_cm_s_km_h1	cm_s
copyGradientElement1	dmiUpdateLevelsDMI
copyGradientElement1	dmi_fromBG
copyGradientElement1	incurrentDMIStatus
copyGradientElement1	inSystemTime
copyGradientElement1	TIU_TrainStatus
copyGradientElement1	inOdometry
copyGradientElement1	inTrainPosition
copyGradientElement1	inBrakeCommand
copyGradientElement1	inSpeedSupervision
copyGradientElement1	inModeAndLevel
copyGradientElement1	inNationalValues
copyGradientElement1	inMovementAuthority
copyGradientElement1	inRadioConnectionStatus
copyGradientElement1	trainDataFromEVC
copyGradientElement1	dmi_entryRequest
copyGradientElement1	dmi_evc_coded_train_data
copyGradientElement1	dmi_trackDescription
copyGradientElement1	dmi_identifierRequest
copyGradientElement1	dmi_displayControl
copyGradientElement1	dmi_EVC_levelList
copyGradientElement1	dmi_EVC_radioNet
copyGradientElement1	dmi_driverIdentifier
copyGradientElement1	dmi_trainRunningNumber
copyGradientElement1	dmi_adhesionFactor
copyGradientElement1	dmi_fromModesAndLevel
copyGradientElement1	inNTC
copyGradientElement1	inStatusList
copyGradientElement1	index
copyGradientElement1	fromTrackAtlas
copySpeedProfileElement1	index
copySpeedProfileElement1	fromTrackAtlas
copyTrackDescription1	fromTrackAtlas
copyTrackDescription1	inSystemTime
cyclicReportToDMI1	incurrentDMIStatus
cyclicReportToDMI1	inSystemTime
cyclicReportToDMI1	inOdometry



Owner	Port
cyclicReportToDMI1	inTrainPosition
cyclicReportToDMI1	inSpeedSupervision
cyclicReportToDMI1	inModeAndLevel
cyclicReportToDMI1	inNationalValues
cyclicReportToDMI1	inMovementAuthority
cyclicReportToDMI1	inMoRC_status
cyclicReportToDMI1	inNTC
doEntryRequest1	dmi_entryRequest
doEntryRequest1	inSystemTime
doldentifierRequest1	TIU_TrainStatus
doldentifierRequest1	inSystemTime
doldentifierRequest1	ownVersion
isSendingNeeded1	inSystemTime
isSendingNeeded1	inCurrentDMIStatus
mapEntryForLevel1	dmi_entryRequest
mapMoRCtoRadio_CS1	inMoRC_status
sendBrakesToDMI1	brakeCommand
sendBrakesToDMI1	inSystemTime
sendDynamic1	inSystemTime
sendDynamic1	inOdometry
sendDynamic1	inTrainPosition
sendDynamic1	inSpeedSupervision
sendDynamic1	inModeLevel_Ack
sendDynamic1	inNationalValues
sendDynamic1	inMoRC_status
sendDynamic1	inNTC
sendDynamic1	inModeAndLevel
sendDynamic1	inMovementAuthority
sendLevelListPkg1	UpdateLevelsRequested
sendLevelListPkg1	levelList
sendLevelListPkg1	inSystemTime
sendTrainData1	inSystemTime
sendTrainData1	trainDataFromEVC
sendVersion1	ownVersion
sendVersion1	dmiStatus
sendVersion1	inSystemTime
synchWithDMI1	outputStatus
synchWithDMI1	dmi_identifierRequest
synchWithDMI1	TIU_TrainStatus
synchWithDMI1	systemTime

Owner	Port
ManageLevelAndMode	Data_From_DMI
ManageLevelAndMode	Data_From_Localisation
ManageLevelAndMode	Data_From_TIU
ManageLevelAndMode	Data_From_Track_Messages
ManageLevelAndMode	Data_From_Track_Packets
ManageLevelAndMode	Data_From_Speed_and_Supervision
ManageLevelAndMode	Cab_In
ManageLevelAndMode	driver_level_transition_In
ManageLevelAndMode	ERTMS_capabilities_In
ManageLevelAndMode	Data_from_Track_MASSPGradient
ManageLevelAndMode	Data_From_F2_Functions
ManageLevelAndMode	Data_From_STM
ManageLevelAndMode	MemorizedLevelIn
Input	Data_From_DMI
Input	Data_From_TIU
Input	Data_From_Track_Messages
Input	Data_From_Track_Packets
Input	Data_From_STM
Input	Data_From_Localisation
Input	Data_From_Speed_and_Supervision
Input	Data_From_F2_Functions
Input	Cab_In
Input	driver_level_transition_In
Input	ERTMS_capabilities_In
Input	startOfMissionEnded
Input	Data_From_Track_MASSPGradient
ManageLevels	trainStandstill
ManageLevels	driverLevelTransition
ManageLevels	levelAck
ManageLevels	trainPosition
ManageLevels	ERTMScapabilities
ManageLevels	DataFromTrackToLevel
ManageLevels	MemorizedLevelIn
CheckLevelAndMode	Level
CheckLevelAndMode	Mode
ManageModes	Current_Level
ManageModes	Cab
ManageModes	Data_From_DMI
ManageModes	Data_From_F2_Functions
ManageModes	Data_From_Localisation

Owner	Port
ManageModes	Data_From_Speed_and_Supervision
ManageModes	Data_From_STM
ManageModes	Data_From_TIU
ManageModes	Data_From_Track
ManageModes	TripModeFromLevel
Output	next_level
Output	TripTrain
Output	previous_level
Output	needsAckFromDriver
Output	announce_driver_selection
Output	service_brake_from_level
Output	LevelsTransitionPositionPassed
Output	currentMode
Output	EB_Requested_From_Mode
Output	Service_Brake_Command_From_Mode
Output	Data_To_DMI_From_Mode
Output	Data_To_BG_Management_From_Mode
Output	Level_Mode_Compatible
manageTIU_input	inModeLevel
manageTIU_input	inTIUfromAPI
manageTIU_input	evc_trainData
getTIUStatusFromData	inTIUActualData
mergeTIU_Info	newInfo
mergeTIU_Info	storedInfo
mergeTIU_Info	EVC_trainData
selectTrainData	newTIUTrainData
selectTrainData	in_train_commands
selectTrainData	EVC_trainData
TrackAtlas	MessageIn
TrackAtlas	ModeAndLevel_in
TrackAtlas	TrainData_in
TrackAtlas	TrainPositionIn
TrackAtlas	train_length
TrackAtlas	SystemTime
TrackAtlas	preindicationLocation
TrackAtlas	odometry
TrackAtlas	fromDriverToMA_R
TrackAtlas	trainProps
TrackAtlas	packet0
TrackAtlas	packet1

Owner	Port
TrackAtlas	t_train
TrackAtlas	P203V1_onboard
TrackAtlas	PermanentDataP003
TrackAtlas	bus_in
TrackAtlasETCS	MessageIn
TrackAtlasETCS	ModeAndLevel_in
TrackAtlasETCS	TrainData_in
TrackAtlasETCS	TrainPositionIn
TrackAtlasETCS	train_length
TrackAtlasETCS	SystemTime
TrackAtlasETCS	preindicationLocation
TrackAtlasETCS	odometry
TrackAtlasETCS	fromDriverToMA_R
TrackAtlasETCS	trainProps
TrackAtlasETCS	packet0
TrackAtlasETCS	packet1
TrackAtlasETCS	t_train
TrackAtlasETCS	bus_in
TrackAtlasETCS	P203V1_onboard
TrackAtlasETCS	PermanentDataP003
Master_Procedure	Status_MA_FS_SR_OS_LS_SH_from_MA_L2_Management
Master_Procedure	statusValid_Position_from_Position_Calculation
Master_Procedure	statusDMI_from_DMI
Master_Procedure	systemtime
Master_Procedure	StatusModeandLevel_from_Level_and_Mode_Management
Master_Procedure	mobileStatus
Master_Procedure	statusRBCSessionEstablished_status_from_MoRC
Master_Procedure	cabStatus_from_TIU
Master_Procedure	LevelValid_from_Level_and_Mode_Management
Master_Procedure	status_DMILEvel_from_DMI
SoM_NTC_SN	Status_Mode_Change_from_Level_and_Mode_Management
SoM_SR_FS_OS_LS_SH_SN_UN	Status_MA_FS_SR_OS_LS_SH_from_MA_L2_Management
SoM_SR_FS_OS_LS_SH_SN_UN	Status_Mode_Change_from_Level_and_Mode_Management
manageTIU_output	in_IsolationStatus
manageTIU_output	in_brake_command
manageTIU_output	in_brake_inhibition
manageTIU_output	in_train_commands
manageTIU_output	in_change_traction_system
manageTIU_output	in_passenger_door_control_info
manageTIU_output	in_change_of_allowed_current_consumption

Owner	Port
bothBrakesActive	speedSupbrakeCommand
bothBrakesActive	levelBrakeCommand
getTIUStatusFromCommand	in_IsolationStatus
getTIUStatusFromCommand	in_brake_command
handleTraction	in_train_commands
handleTraction	inModeLevel
mapModeToTractionCutOff	inModeLevel
TIU_OutputIntegration	in_IsolationStatus
TIU_OutputIntegration	SpeedSup_brakeCommand
TIU_OutputIntegration	in_brake_inhibition
TIU_OutputIntegration	in_train_commands
TIU_OutputIntegration	in_change_traction_system
TIU_OutputIntegration	in_passenger_door_control_info
TIU_OutputIntegration	in_change_of_allowed_current_consumption
TIU_OutputIntegration	inModeAndLevel
SpeedSupervision_Integration	Service_brake_requested_by_modes_and_levels
SpeedSupervision_Integration	Emergency_brake_requested_by_modes_and_levels
SpeedSupervision_Integration	NationalValues
SpeedSupervision_Integration	TrainPosition
SpeedSupervision_Integration	odometry
SpeedSupervision_Integration	trainProps
SpeedSupervision_Integration	trainData
SpeedSupervision_Integration	dataFromTrackAtlas
Commands	trainLocations
manageTIU_output	in_IsolationStatus
manageTIU_output	in_brake_command
manageTIU_output	in_brake_inhibition
manageTIU_output	in_train_commands
manageTIU_output	in_change_traction_system
manageTIU_output	in_passenger_door_control_info
manageTIU_output	in_change_of_allowed_current_consumption
bothBrakesActive	speedSupbrakeCommand
bothBrakesActive	levelBrakeCommand
getTIUStatusFromCommand	in_IsolationStatus
getTIUStatusFromCommand	in_brake_command
handleTraction	in_train_commands
handleTraction	inModeLevel
mapModeToTractionCutOff	inModeLevel
TIU_OutputIntegration	in_IsolationStatus
TIU_OutputIntegration	SpeedSup_brakeCommand

Owner	Port
TIU_OutputIntegration	in_brake_inhibition
TIU_OutputIntegration	in_train_commands
TIU_OutputIntegration	in_change_traction_system
TIU_OutputIntegration	in_passenger_door_control_info
TIU_OutputIntegration	in_change_of_allowed_current_consumption
TIU_OutputIntegration	inModeAndLevel
Manage_TrackSideInformation_Integration	fullChecks
Manage_TrackSideInformation_Integration	API_trackSide_Message
Manage_TrackSideInformation_Integration	ActualOdometry
Manage_TrackSideInformation_Integration	reset
Manage_TrackSideInformation_Integration	trainPosition
Manage_TrackSideInformation_Integration	modeAndLevel
Manage_TrackSideInformation_Integration	tNvContact
Manage_TrackSideInformation_Integration	intrainVersion
Manage_TrackSideInformation_Integration	lastRelevantEventTimestamp
Manage_TrackSideInformation_Integration	radioStatus
Manage_TrackSideInformation_Integration	inSupervisingRbclid
Manage_TrackSideInformation_Integration	inAnnouncedBGs
Manage_TrackSideInformation_Integration	q_nvlocacc
Manage_TrackSideInformation_Integration	inActiveCab
Manage_TrackSideInformation_Integration	inTrainDataValid
Manage_TrackSideInformation_Integration	inFilterEvents
Manage_TrackSideInformation_Integration	transitionPositionPassed
CheckBGConsistency	storedBGs
CheckBGConsistency	mMode
CheckBGConsistency	q_nvlocacc
CaseLinkingInUse1	storedBGs
CaseLinkingInUse1	q_nvlocacc
CaseLinkingNotInUse1	q_nvlocacc
InformationFilter	inLevel
InformationFilter	inModus
InformationFilter	inSupervisingDevice
InformationFilter	inPendingL1Transition
InformationFilter	inPendingL2L3Transition
InformationFilter	inPendingAckOfTrainDataFromRBC
InformationFilter	inEmergencyStopAccepted
InformationFilter	inLastAckTextMessageId
InformationFilter	inPendingNTCTransition
validateDataDirection	inLRBG
validateDataDirection	inPositionedBGs

Owner	Port
validateDataDirection	trainPosition
CheckEuroRadioMessage	tNvContact
CheckEuroRadioMessage	lastRelevantEventTimestamp
CheckEuroRadioMessage	connectionStatus
CheckEuroRadioMessage	activateCheck
trainData	reset
trainData	trainDatafromTIU
trainData	trackMessages
trainData	t_train
trainData	nidEngine
trainData	p0_positionReport
trainData	p1_positionReport
trainData	MessageBus
trainData	inVersion
trainDataStorage	actualStatus
sendAcknowledgementRBC	actualStatus
sendAcknowledgementRBC	inVersion
checkRadioMessages	actualStatus
sendValidTrainDataRBC	actualStatus
sendValidTrainDataRBC	inVersion
TrackAtlas	TrainData_in
TrackAtlas	fromDriverToMA_R
TrackAtlas	MessageIn
TrackAtlas	ModeAndLevel_in
TrackAtlas	TrainPositionIn
TrackAtlas	train_length
TrackAtlas	SystemTime
TrackAtlas	preindicationLocation
TrackAtlas	odometry
TrackAtlas	trainProps
TrackAtlas	packet0
TrackAtlas	packet1
TrackAtlas	t_train
TrackAtlas	P203V1_onboard
TrackAtlas	PermanentDataP003
TrackAtlas	bus_in
TrackAtlasETCS	TrainData_in
TrackAtlasETCS	fromDriverToMA_R
TrackAtlasETCS	MessageIn
TrackAtlasETCS	ModeAndLevel_in

Owner	Port
TrackAtlasETCS	TrainPositionIn
TrackAtlasETCS	train_length
TrackAtlasETCS	SystemTime
TrackAtlasETCS	preindicationLocation
TrackAtlasETCS	odometry
TrackAtlasETCS	trainProps
TrackAtlasETCS	packet0
TrackAtlasETCS	packet1
TrackAtlasETCS	t_train
TrackAtlasETCS	P203V1_onboard
TrackAtlasETCS	PermanentDataP003
TrackAtlasETCS	bus_in
calculateTrainPosition	reset
calculateTrainPosition	currentOdometry
calculateTrainPosition	passedBG
linkedBG_missed	enable
linkedBG_missed	position
linkedBG_missed	BGs_in
twoConsecutiveLinkedBGs_missed	reset
twoConsecutiveLinkedBGs_missed	passedBG
twoConsecutiveLinkedBGs_missed	msgFromTrack
twoConsecutiveLinkedBGs_missed	missed
twoConsecutiveLinkedBGs_missed	missedLinkedBG
addAnnouncedBGs	passedBG
addAnnouncedBGs	BGs_in
addAnnouncedBGs	trainProperties
calculateBGLocations	reset
calculateBGLocations	passedBG
calculateBGLocations	lastBGs
calculateBGLocations	trainProperties
calculateTrainpositionAttributes	trainPositionInfo
calculateTrainpositionAttributes	currentOdometry
calculateTrainpositionAttributes	trainProperties
calculateTrainPositionInfo	recalculateBGs
calculateTrainPositionInfo	reset
calculateTrainPositionInfo	currentOdometry
calculateTrainPositionInfo	BGs
calculateTrainPositionInfo	passedBG
delDispensableBGs	deleteBG
delDispensableBGs	BGs_in



Owner	Port
msg_2_passedBG	msgFromTrack
ProvidePositionReport	trackInfo
ProvidePositionReport	systemTime
ProvidePositionReport	rcbComm
ProvidePositionReport	RadioSafeRadioConnectionError
ProvidePositionReport	SafetyCriticalFailure
ProvidePositionReport	modeLevelStatus
ProvidePositionReport	reportedBGs
ProvidePositionReport	posBGs
ProvidePositionReport	trainPos
ProvidePositionReport	odometry
ProvidePositionReport	trainProps
ProvidePositionReport	inMessage
ProvidePositionReport	train2trackStatus
ProvidePositionReport	prvDirTrain
ProvidePositionReport	t_train
ProvidePositionReport	MessageBus
ProvidePositionReport	inVersion

## 6. System outputs

Owner	Port
ETCS OBU	DriverOut
ETCS OBU	RBCOut
ETCS OBU	TrainOut
F2 ETCS Kernel	resetOut
F2 ETCS Kernel	debugPermittedSpeed
F2 ETCS Kernel	debugInterventionSpeed
F2 ETCS Kernel	debugTrainPositionNominal
F2 ETCS Kernel	debugTrainPositionDeltaMax
F2 ETCS Kernel	debugTrainPositionDeltaMin
F2 ETCS Kernel	debugCurrentMode
F2 ETCS Kernel	debugCurrentLevel
CheckBGConsistency	badBaliseMessageToDMI
CheckBGConsistency	errorLinkedBG
CheckBGConsistency	errorUnlinkedBG
CheckBGConsistency	incompatibleVersion
CaseLinkingNotInUse1	badBaliseMessageToDMI
InformationFilter	outAcceptedMessage
CheckEuroRadioMessage	radioSequenceError
CheckEuroRadioMessage	tNvContactError
CheckEuroRadioMessage	otherTimingError
CheckEuroRadioMessage	radioMessageConsistencyError
F2.10 manageDMI_Input	fromDMI_Identifier
F2.10 manageDMI_Input	fromDMI_DriverIdentifier
F2.10 manageDMI_Input	fromDMI_RadioNetData
F2.10 manageDMI_Input	fromDMI_Icon_Ack
F2.10 manageDMI_Input	fromDMI_AdhesionFactor
changeLevelByDiver1	ML_levelTransition
changeLevelByDiver1	updatedNTC
doDriverRequests1	outDriverRequestToLevels
doDriverRequests1	outDriverRequestToModes
receiveRequestsModesAndLevel1	outDriverRequestToLevels
receiveRequestsModesAndLevel1	forModesAndLevel
receiveRequestsModesAndLevel1	outStatusList
triggerForMA1	outForMA
updateDMIStatus1	newStatus
F2.12 manageTIU_input	tractionCutOff
getTIUStatusFromData	outStatus
mergeTIU_Info	updatedInfo
selectTrainData	outTrainData
F2.2 Manage_ETCS_Procedures	request_MA_FS_SR_OS_LS_SH_to_MA_L2_Management

Owner	Port
F2.2 Manage_ETCS_Procedures	request_Mode_Change_SB_to_FS_to_Level_and_Mode_Management
F2.2 Manage_ETCS_Procedures	start_ack_to_TIU
SoM_NTC_SN	start_ack_to_TIU
SoM_SR_FS_OS_LS_SH_SN_UN	request_MA_FS_SR_OS_LS_SH_to_MA_L2_Management
SoM_SR_FS_OS_LS_SH_SN_UN	request_Mode_Change_SB_to_FS_to_Level_and_Mode_Management
SoM_SR_FS_OS_LS_SH_SN_UN	start_ack_to_TIU
F2.9 MoRC_HO	bufferInformationFromAcceptingRBC
F2.9 MoRC_HO	trainPassesA_RBC_RBC_border_WithItsFrontEnd
F2.9 MoRC_HO	triggerPositionReport
F2.9 MoRC_HO	triggerTrainData
F2.9 MoRC_HO	rejectOrderToContactRBC_or_RIU
F2.9 MoRC_HO	informDriverNoCompatibleVersionSupported
F2.9 MoRC_HO	memorizeTheLastRadioNetworkID
F2.9 MoRC_HO	radioStatus_2
F2.9 MoRC_HO	mobileConnectionCmd_2
F2.9 MoRC_HO	mobileRegistrationCmd_2
F2.9 MoRC_HO	safeRadioIndication
F2.9 MoRC_HO	msgBus_2_RBC_1
F2.9 MoRC_HO	msgBus_2_RBC_2
F2.9 MoRC_HO	lastReceivedRadioNetworkID
processHandingOver	sendPositionReport_2_handingOverRBC
processHandingOver	sendPositionReport_2_acceptingRBC
processHandingOver	sendTrainData_2_acceptingRBC
processHandingOver	bufferInformationFromAcceptingRBC
processHandingOver	supervisingRBC
processHandingOver	useInformationFromAcceptingRBC
processHandingOver	handingOverMobile_is_mobile_1
processHandingOver	trainPassesA_RBC_RBC_border_WithItsFrontEnd
processHandingOver	notReady
processHandingOver	sessionCmds_2_MoRC_1
processHandingOver	sessionCmds_2_MoRC_2
MoRC_Main_v21	sendAPositionReport
MoRC_Main_v21	rejectOrderToContactRBC_or_RIU
MoRC_Main_v21	informDriverNoCompatibleVersionSupported
MoRC_Main_v21	memorizeTheLastRadioNetworkID
MoRC_Main_v21	notReady
MoRC_Main_v21	msgToRBC
MoRC_Main_v21	status
MoRC_Main_v21	safeRadioIndication
MoRC_Main_v21	mobileConnectionCmd

Owner	Port
MoRC_Main_v21	mobileRegistrationCmd
MoRC_Main_v21	lastReceivedRadioNetworkID
MoRC_Main_v22	sendAPositionReport
MoRC_Main_v22	rejectOrderToContactRBC_or_RIU
MoRC_Main_v22	infomDriverNoCompatibleVersionSupported
MoRC_Main_v22	memorizeTheLastRadioNetworkID
MoRC_Main_v22	notReady
MoRC_Main_v22	msgToRBC
MoRC_Main_v22	status
MoRC_Main_v22	safeRadioIndication
MoRC_Main_v22	mobileConnectionCmd
MoRC_Main_v22	mobileRegistrationCmd
MoRC_Main_v22	lastReceivedRadioNetworkID
mobileDataRouter_out	data_2_RBC_1
mobileDataRouter_out	data_2_RBC_2
F2.7 SpeedSupervision_Integration	EOA_overpassed
F2.7 SpeedSupervision_Integration	Target_Speed_Reached
F2.7 SpeedSupervision_Integration	target
F2.7 SpeedSupervision_Integration	sdmCommands
F2.8 ProvidePositionReport	out_reportedBGs
AggregatePackets	outPackets
PosReport_Supervision	out_reportedBGs
PosReport_Supervision	posRep
ReceiveReportParameters	posRep
F2.13 manageTIU_output	outCommandStatusforEVC
bothBrakesActive	brakeCommand
getTIUStatusFromCommand	outStatus
handleTraction	outTrainCommands
mapModeToTractionCutOff	tractionCutOff
TIU_OutputIntegration	outTIU_to_API
TIU_OutputIntegration	outCommandStatusforEVC
calcDistances1	outLocationKP_Balise_Track
calcDistances1	ouDistanceKP_Balise
calcDistances1	outDistance_ToTSA
collectDMIPackets1	to_DMI
convert_cm_s_km_h1	km_h
copyGradientElement1	to_DMI
copyGradientElement1	outStatusList
copyGradientElement1	continue
copyGradientElement1	toDMI

Owner	Port
copySpeedProfileElement1	fromDMI_TrainDataAck
copySpeedProfileElement1	continue
copySpeedProfileElement1	toDMI
copyTrackDescription1	toDMI
cyclicReportToDMI1	packetDynamic
doEntryRequest1	sendTrainDataToDMI
doEntryRequest1	new_menuRequest
doEntryRequest1	new_entryRequest
doEntryRequest1	outLevelsNeeded
dolIdentifierRequest1	identifierRequest
isSendingNeeded1	sendingNeeded
mapEntryForLevel1	new_entryRequest
mapMoRCtoRadio_CS1	outBMI_CS
sendBrakesToDMI1	dmi_iconRequest
sendDynamic1	packetDynamic
sendLevelListPkg1	levelDataPkg
sendTrainData1	trainData_ForDMI
sendVersion1	VersionPkg
synchWithDMI1	updatedOutputStatus
synchWithDMI1	send_dmi_identifierRequest
F2.3 trainData	triggerFromTrainData
trainDataStorage	updatedStatus
sendAcknowledgementRBC	updatedStatus
checkRadioMessages	ackReceived
checkRadioMessages	ackRequested
sendValidTrainDataRBC	updatedStatus
linkedBG_missed	missed
linkedBG_missed	indexOfBG
linkedBG_missed	BG
linkedBG_missed	BGs_out
twoConsecutiveLinkedBGs_missed	secondConsecutiveBG_missed
addAnnouncedBGs	overrun
addAnnouncedBGs	BGs_out
calculateBGLocations	BGs
calculateBGLocations	errors
calculateBGLocations	passedPositionedBG
calculateTrainpositionAttributes	trainPosition
calculateTrainPositionInfo	positionCalculationNotConsistent
calculateTrainPositionInfo	trainPositionInfo
delDispensableBGs	BGs_out

Owner	Port
msg_2_passedBG	BG_passed
msg_2_passedBG	passedBG
msg_2_passedBG	onlyBGsAnnouncedViaRadio
F2.5 ManageLevelAndMode	Data_To_BG_Management
Input	train_standstill
Input	levelAck
Input	outStartOfMissionEnded
Input	driver_level_transition
Input	currentPosition
Input	ERTMS_capabilities
Input	Data_From_Track_to_Level
Input	Cab
Input	Data_From_DMI_To_Mode
Input	Data_From_F2_Functions_to_Mode
Input	Data_From_Localisation_To_Mode
Input	Data_From_Speed_and_Supervision_To_Mode
Input	Data_From_STM_to_Mode
Input	Data_From_TIU_To_Mode
Input	Data_From_Track_To_Mode
ManageLevels	TripTrainRequested
ManageLevels	needsAckFromDriver
ManageLevels	serviceBrakeRequested
ManageLevels	nextLevel
ManageLevels	announced_level_transition
ManageLevels	positionReportNeeded
ManageLevels	levellsNew
ManageLevels	isAvailableForUse
ManageLevels	announcedLevelTransition
ManageLevels	connectionToRBCRequested
CheckLevelAndMode	Level_Mode_Compatible
ManageModes	EB_Requested
ManageModes	Service_Brake_Command
ManageModes	currentMode
ManageModes	Data_To_DMI
ManageModes	Data_To_BG_Management
Output	Service_Brake_Command
Output	EB_Requested
Output	transitionPositionPassed
Output	Compatible_Mode_And_Level
Output	Data_To_DMI

Owner	Port
Output	Data_To_BG_Management
F2.4 TrackAtlas	MA_onboard_out
F2.4 TrackAtlas	MRSP
F2.4 TrackAtlas	ces_accepted
F2.4 TrackAtlas	ces_revoked
F2.4 TrackAtlas	trip_train
F2.4 TrackAtlas	NV_raw_out
F2.4 TrackAtlas	message147
TrackAtlasETCS	To_ModeAndLevel
TrackAtlasETCS	to_DMI
TrackAtlasETCS	to_Supervision
TrackAtlasETCS	MA_onboard_out
TrackAtlasETCS	ces_accepted
TrackAtlasETCS	ces_revoked
TrackAtlasETCS	trip_train
TrackAtlasETCS	NV_raw_out
TrackAtlasETCS	MA_request_out
TrackAtlasETCS	message147
TrackAtlasETCS	SSP_available
TrackAtlasETCS	bus_out
F2.9 MoRC_Main	ignoreMessagesFromRBC_except_m39_AckOfTerminationOfC
F2.9 MoRC_Main	sendAPositionReport
F2.9 MoRC_Main	cmdsToMobile
F2.9 MoRC_Main	memorizeTheLastRadioNetworkID
F2.9 MoRC_Main	orderTheRegistrationOfItsConnectedMobiles
F2.9 MoRC_Main	rejectOrderToContactRBC_or_RIU
F2.9 MoRC_Main	InformTheDriverThatNoConnectionWasSetup
F2.9 MoRC_Main	safeRadioConnectionStatus_toDriver
F2.9 MoRC_Main	mobileSWStatus
F2.9 MoRC_Main	requestTheSetupOfASafeRadioConnection
F2.9 MoRC_Main	requestReleaseOfSafeRadioConnectionWithTrackside
F2.9 MoRC_Main	sessionSuccessfullyEstablished
F2.9 MoRC_Main	ready
F2.9 MoRC_Main	currentRadioNetworkID
F2.9 MoRC_Main	sessionStatus
F2.9 MoRC_Main	MessageToRBC
F2.9 MoRC_Main	msgBus_out
Driver	Output1
Configuration1	Output1
F2 ETCS Kernel	resetOut

Owner	Port
F2 ETCS Kernel	debugTrainPositionNominal
F2 ETCS Kernel	debugTrainPositionDeltaMax
F2 ETCS Kernel	debugTrainPositionDeltaMin
F2 ETCS Kernel	debugPermittedSpeed
F2 ETCS Kernel	debugInterventionSpeed
F2 ETCS Kernel	debugCurrentMode
F2 ETCS Kernel	debugCurrentLevel
CheckBGConsistency	badBaliseMessageToDMI
CheckBGConsistency	errorLinkedBG
CheckBGConsistency	errorUnlinkedBG
CheckBGConsistency	incompatibleVersion
CaseLinkingNotInUse1	badBaliseMessageToDMI
InformationFilter	outAcceptedMessage
CheckEuroRadioMessage	radioSequenceError
CheckEuroRadioMessage	tNvContactError
CheckEuroRadioMessage	otherTimingError
CheckEuroRadioMessage	radioMessageConsistencyError
F2.10 manageDMI_Input	fromDMI_Identifier
F2.10 manageDMI_Input	fromDMI_DriverIdentifier
F2.10 manageDMI_Input	fromDMI_RadioNetData
F2.10 manageDMI_Input	fromDMI_Icon_Ack
F2.10 manageDMI_Input	fromDMI_AdhesionFactor
changeLevelByDiver1	ML_levelTransition
changeLevelByDiver1	updatedNTC
doDriverRequests1	outDriverRequestToModes
doDriverRequests1	outDriverRequestToLevels
receiveRequestsModesAndLevel1	forModesAndLevel
receiveRequestsModesAndLevel1	outStatusList
receiveRequestsModesAndLevel1	outDriverRequestToLevels
triggerForMA1	outForMA
updateDMIStatus1	newStatus
getTIUStatusFromData	outStatus
mergeTIU_Info	updatedInfo
selectTrainData	outTrainData
F2.2 Manage_ETCS_Procedures	request_MA_FS_SR_OS_LS_SH_to_MA_L2_Management
F2.2 Manage_ETCS_Procedures	request_Mode_Change_SB_to_FS_to_Level_and_Mode_Management
F2.2 Manage_ETCS_Procedures	start_ack_to_TIU
SoM_NTC_SN	start_ack_to_TIU
SoM_SR_FS_OS_LS_SH_SN_UN	request_MA_FS_SR_OS_LS_SH_to_MA_L2_Management
SoM_SR_FS_OS_LS_SH_SN_UN	request_Mode_Change_SB_to_FS_to_Level_and_Mode_Management



Owner	Port
SoM_SR_FS_OS_LS_SH_SN_UN	start_ack_to_TIU
F2.9 MoRC_HO	radioStatus_2
F2.9 MoRC_HO	mobileConnectionCmd_2
F2.9 MoRC_HO	mobileRegistrationCmd_2
F2.9 MoRC_HO	safeRadioIndication
F2.9 MoRC_HO	bufferInformationFromAcceptingRBC
F2.9 MoRC_HO	trainPassesA_RBC_RBC_border_WithItsFrontEnd
F2.9 MoRC_HO	msgBus_2_RBC_1
F2.9 MoRC_HO	msgBus_2_RBC_2
F2.9 MoRC_HO	triggerPositionReport
F2.9 MoRC_HO	triggerTrainData
F2.9 MoRC_HO	rejectOrderToContactRBC_or_RIU
F2.9 MoRC_HO	infomDriverNoCompatibleVersionSupported
F2.9 MoRC_HO	memorizeTheLastRadioNetworkID
F2.9 MoRC_HO	lastReceivedRadioNetworkID
processHandingOver	sessionCmds_2_MoRC_1
processHandingOver	sessionCmds_2_MoRC_2
processHandingOver	sendPositionReport_2_handingOverRBC
processHandingOver	sendPositionReport_2_acceptingRBC
processHandingOver	sendTrainData_2_acceptingRBC
processHandingOver	bufferInformationFromAcceptingRBC
processHandingOver	supervisingRBC
processHandingOver	useInformationFromAcceptingRBC
processHandingOver	handingOverMobile_is_mobile_1
processHandingOver	trainPassesA_RBC_RBC_border_WithItsFrontEnd
processHandingOver	notReady
MoRC_Main_v21	msgToRBC
MoRC_Main_v21	sendAPositionReport
MoRC_Main_v21	rejectOrderToContactRBC_or_RIU
MoRC_Main_v21	infomDriverNoCompatibleVersionSupported
MoRC_Main_v21	status
MoRC_Main_v21	safeRadioIndication
MoRC_Main_v21	mobileConnectionCmd
MoRC_Main_v21	mobileRegistrationCmd
MoRC_Main_v21	memorizeTheLastRadioNetworkID
MoRC_Main_v21	lastReceivedRadioNetworkID
MoRC_Main_v21	notReady
MoRC_Main_v22	msgToRBC
MoRC_Main_v22	sendAPositionReport
MoRC_Main_v22	rejectOrderToContactRBC_or_RIU

Owner	Port
MoRC_Main_v22	infomDriverNoCompatibleVersionSupported
MoRC_Main_v22	status
MoRC_Main_v22	safeRadioIndication
MoRC_Main_v22	mobileConnectionCmd
MoRC_Main_v22	mobileRegistrationCmd
MoRC_Main_v22	memorizeTheLastRadioNetworkID
MoRC_Main_v22	lastReceivedRadioNetworkID
MoRC_Main_v22	notReady
mobileDataRouter_out	data_2_RBC_1
mobileDataRouter_out	data_2_RBC_2
F2.7 SpeedSupervision_Integration	target
F2.7 SpeedSupervision_Integration	sdmCommands
F2.7 SpeedSupervision_Integration	EOA_overpassed
F2.7 SpeedSupervision_Integration	Target_Speed_Reached
F2.8 ProvidePositionReport	out_reportedBGs
AggregatePackets	outPackets
F2.13 manageTIU_output	outCommandStatusforEVC
bothBrakesActive	brakeCommand
getTIUStatusFromCommand	outStatus
handleTraction	outTrainCommands
mapModeToTractionCutOff	tractionCutOff
TIU_OutputIntegration	outTIU_to_API
TIU_OutputIntegration	outCommandStatusforEVC
calcDistances1	outLocationKP_Balise_Track
calcDistances1	ouDistanceKP_Balise
calcDistances1	outDistance_ToTSA
collectDMIPackets1	to_DMI
convert_cm_s_km_h1	km_h
copyGradientElement1	continue
copyGradientElement1	toDMI
copySpeedProfileElement1	continue
copySpeedProfileElement1	toDMI
copyTrackDescription1	toDMI
cyclicReportToDMI1	packetDynamic
doEntryRequest1	new_menuRequest
doEntryRequest1	new_entryRequest
doEntryRequest1	sendTrainDataToDMI
doEntryRequest1	outLevelsNeeded
doldentifierRequest1	identifierRequest
isSendingNeeded1	sendingNeeded

Owner	Port
mapEntryForLevel1	new_entryRequest
mapMoRCtoRadio_CS1	outBMI_CS
sendBrakesToDMI1	dmi_iconRequest
sendDynamic1	packetDynamic
sendLevelListPkg1	levelDataPkg
sendTrainData1	trainData_ForDMI
sendVersion1	VersionPkg
synchWithDMI1	send_dmi_identifierRequest
synchWithDMI1	updatedOutputStatus
F2.3 trainData	triggerFromTrainData
trainDataStorage	updatedStatus
sendAcknowledgementRBC	updatedStatus
checkRadioMessages	ackReceived
checkRadioMessages	ackRequested
sendValidTrainDataRBC	updatedStatus
linkedBG_missed	missed
linkedBG_missed	indexOfBG
linkedBG_missed	BG
linkedBG_missed	BGs_out
twoConsecutiveLinkedBGs_missed	secondConsecutiveBG_missed
addAnnouncedBGs	BGs_out
addAnnouncedBGs	overrun
calculateBGLocations	BGs
calculateBGLocations	errors
calculateBGLocations	passedPositionedBG
calculateTrainpositionAttributes	trainPosition
calculateTrainPositionInfo	trainPositionInfo
calculateTrainPositionInfo	positionCalculationNotConsistent
delDispensableBGs	BGs_out
msg_2_passedBG	passedBG
msg_2_passedBG	BG_passed
msg_2_passedBG	onlyBGsAnnouncedViaRadio
F2.5 ManageLevelAndMode	Data_To_BG_Management
Input	train_standstill
Input	driver_level_transition
Input	levelAck
Input	currentPosition
Input	ERTMS_capabilities
Input	outStartOfMissionEnded
Input	Data_From_Track_to_Level

Owner	Port
Input	Cab
Input	Data_From_DMI_To_Mode
Input	Data_From_F2_Functions_to_Mode
Input	Data_From_Localisation_To_Mode
Input	Data_From_Speed_and_Supervision_To_Mode
Input	Data_From_STM_to_Mode
Input	Data_From_TIU_To_Mode
Input	Data_From_Track_To_Mode
ManageLevels	nextLevel
ManageLevels	TripTrainRequested
ManageLevels	needsAckFromDriver
ManageLevels	announcedLevelTransition
ManageLevels	serviceBrakeRequested
ManageLevels	connectionToRBCRequested
ManageLevels	positionReportNeeded
ManageLevels	levellsNew
ManageLevels	isAvailableForUse
CheckLevelAndMode	Level_Mode_Compatible
ManageModes	currentMode
ManageModes	EB_Requested
ManageModes	Service_Brake_Command
ManageModes	Data_To_DMI
ManageModes	Data_To_BG_Management
Output	Compatible_Mode_And_Level
Output	Data_To_DMI
Output	Data_To_BG_Management
Output	Service_Brake_Command
Output	EB_Requested
Output	transitionPositionPassed
F2.4 TrackAtlas	NV_raw_out
F2.4 TrackAtlas	MA_onboard_out
F2.4 TrackAtlas	MRSP
F2.4 TrackAtlas	message147
F2.4 TrackAtlas	ces_accepted
F2.4 TrackAtlas	ces_revoked
F2.4 TrackAtlas	trip_train
TrackAtlasETCS	SSP_available
TrackAtlasETCS	NV_raw_out
TrackAtlasETCS	To_ModeAndLevel
TrackAtlasETCS	to_DMI

Owner	Port
TrackAtlasETCS	to_Supervision
TrackAtlasETCS	MA_onboard_out
TrackAtlasETCS	MA_request_out
TrackAtlasETCS	bus_out
TrackAtlasETCS	message147
TrackAtlasETCS	ces_accepted
TrackAtlasETCS	ces_revoked
TrackAtlasETCS	trip_train
F2.9 MoRC_Main	ignoreMessagesFromRBC_except_m39_AckOfTerminationOfC
F2.9 MoRC_Main	sendAPositionReport
F2.9 MoRC_Main	cmdsToMobile
F2.9 MoRC_Main	memorizeTheLastRadioNetworkID
F2.9 MoRC_Main	currentRadioNetworkID
F2.9 MoRC_Main	orderTheRegistrationOfItsConnectedMobiles
F2.9 MoRC_Main	rejectOrderToContactRBC_or_RIU
F2.9 MoRC_Main	InformTheDriverThatNoConnectionWasSetup
F2.9 MoRC_Main	safeRadioConnectionStatus_toDriver
F2.9 MoRC_Main	mobileSWStatus
F2.9 MoRC_Main	requestTheSetupOfASafeRadioConnection
F2.9 MoRC_Main	requestReleaseOfSafeRadioConnectionWithTrackside
F2.9 MoRC_Main	sessionSuccessfullyEstablished
F2.9 MoRC_Main	sessionStatus
F2.9 MoRC_Main	MessageToRBC
F2.9 MoRC_Main	msgBus_out
F2.9 MoRC_Main	ready
Driver	Output1
Configuration1	Output1
ManageLevelAndMode	Service_Brake_Command
ManageLevelAndMode	EB_Requested
ManageLevelAndMode	Compatible_Mode_And_Level
ManageLevelAndMode	Data_To_BG_Management
ManageLevelAndMode	announcedLevel
ManageLevelAndMode	Data_To_DMI_Ack
Input	train_standstill
Input	levelAck
Input	outStartOfMissionEnded
Input	driver_level_transition
Input	currentPosition
Input	ERTMS_capabilities
Input	Data_From_Track_to_Level

Owner	Port
Input	Cab
Input	Data_From_DMI_To_Mode
Input	Data_From_F2_Functions_to_Mode
Input	Data_From_Localisation_To_Mode
Input	Data_From_Speed_and_Supervision_To_Mode
Input	Data_From_STM_to_Mode
Input	Data_From_TIU_To_Mode
Input	Data_From_Track_To_Mode
ManageLevels	TripTrainRequested
ManageLevels	needsAckFromDriver
ManageLevels	serviceBrakeRequested
ManageLevels	nextLevel
ManageLevels	announced_level_transition
ManageLevels	positionReportNeeded
ManageLevels	levellsNew
ManageLevels	isAvailableForUse
ManageLevels	announcedLevelTransition
ManageLevels	connectionToRBCRequested
CheckLevelAndMode	Level_Mode_Compatible
ManageModes	EB_Requested
ManageModes	Service_Brake_Command
ManageModes	currentMode
ManageModes	Data_To_DMI
ManageModes	Data_To_BG_Management
Output	Service_Brake_Command
Output	EB_Requested
Output	transitionPositionPassed
Output	Compatible_Mode_And_Level
Output	Data_To_DMI
Output	Data_To_BG_Management
ETCS OBU	DriverOut
ETCS OBU	RBCOut
ETCS OBU	TrainOut
F2 ETCS Kernel	resetOut
F2 ETCS Kernel	debugTrainPositionNominal
F2 ETCS Kernel	debugTrainPositionDeltaMax
F2 ETCS Kernel	debugTrainPositionDeltaMin
F2 ETCS Kernel	debugPermittedSpeed
F2 ETCS Kernel	debugInterventionSpeed
F2 ETCS Kernel	debugCurrentMode

Owner	Port
F2 ETCS Kernel	debugCurrentLevel
CheckBGConsistency	badBaliseMessageToDMI
CheckBGConsistency	errorLinkedBG
CheckBGConsistency	errorUnlinkedBG
CheckBGConsistency	incompatibleVersion
CaseLinkingNotInUse1	badBaliseMessageToDMI
InformationFilter	outAcceptedMessage
CheckEuroRadioMessage	radioSequenceError
CheckEuroRadioMessage	tNvContactError
CheckEuroRadioMessage	otherTimingError
CheckEuroRadioMessage	radioMessageConsistencyError
F2.10 manageDMI_Input	fromDMI_Identifier
F2.10 manageDMI_Input	fromDMI_DriverIdentifier
F2.10 manageDMI_Input	fromDMI_RadioNetData
F2.10 manageDMI_Input	fromDMI_Icon_Ack
F2.10 manageDMI_Input	fromDMI_AdhesionFactor
changeLevelByDiver1	ML_levelTransition
changeLevelByDiver1	updatedNTC
doDriverRequests1	outDriverRequestToModes
doDriverRequests1	outDriverRequestToLevels
receiveRequestsModesAndLevel1	forModesAndLevel
receiveRequestsModesAndLevel1	outStatusList
receiveRequestsModesAndLevel1	outDriverRequestToLevels
triggerForMA1	outForMA
updateDMIStatus1	newStatus
getTIUStatusFromData	outStatus
mergeTIU_Info	updatedInfo
selectTrainData	outTrainData
F2.2 Manage_ETCS_Procedures	request_MA_FS_SR_OS_LS_SH_to_MA_L2_Management
F2.2 Manage_ETCS_Procedures	request_Mode_Change_SB_to_FS_to_Level_and_Mode_Management
F2.2 Manage_ETCS_Procedures	start_ack_to_TIU
SoM_NTC_SN	start_ack_to_TIU
SoM_SR_FS_OS_LS_SH_SN_UN	request_MA_FS_SR_OS_LS_SH_to_MA_L2_Management
SoM_SR_FS_OS_LS_SH_SN_UN	request_Mode_Change_SB_to_FS_to_Level_and_Mode_Management
SoM_SR_FS_OS_LS_SH_SN_UN	start_ack_to_TIU
F2.9 MoRC_HO	radioStatus_2
F2.9 MoRC_HO	mobileConnectionCmd_2
F2.9 MoRC_HO	mobileRegistrationCmd_2
F2.9 MoRC_HO	safeRadioIndication
F2.9 MoRC_HO	bufferInformationFromAcceptingRBC

Owner	Port
F2.9 MoRC_HO	trainPassesA_RBC_RBC_border_WithItsFrontEnd
F2.9 MoRC_HO	msgBus_2_RBC_1
F2.9 MoRC_HO	msgBus_2_RBC_2
F2.9 MoRC_HO	triggerPositionReport
F2.9 MoRC_HO	triggerTrainData
F2.9 MoRC_HO	rejectOrderToContactRBC_or_RIU
F2.9 MoRC_HO	infomDriverNoCompatibleVersionSupported
F2.9 MoRC_HO	memorizeTheLastRadioNetworkID
F2.9 MoRC_HO	lastReceivedRadioNetworkID
processHandingOver	sessionCmds_2_MoRC_1
processHandingOver	sessionCmds_2_MoRC_2
processHandingOver	sendPositionReport_2_handingOverRBC
processHandingOver	sendPositionReport_2_acceptingRBC
processHandingOver	sendTrainData_2_acceptingRBC
processHandingOver	bufferInformationFromAcceptingRBC
processHandingOver	supervisingRBC
processHandingOver	useInformationFromAcceptingRBC
processHandingOver	handingOverMobile_is_mobile_1
processHandingOver	trainPassesA_RBC_RBC_border_WithItsFrontEnd
processHandingOver	notReady
MoRC_Main_v21	msgToRBC
MoRC_Main_v21	sendAPositionReport
MoRC_Main_v21	rejectOrderToContactRBC_or_RIU
MoRC_Main_v21	infomDriverNoCompatibleVersionSupported
MoRC_Main_v21	status
MoRC_Main_v21	safeRadioIndication
MoRC_Main_v21	mobileConnectionCmd
MoRC_Main_v21	mobileRegistrationCmd
MoRC_Main_v21	memorizeTheLastRadioNetworkID
MoRC_Main_v21	lastReceivedRadioNetworkID
MoRC_Main_v21	notReady
MoRC_Main_v22	msgToRBC
MoRC_Main_v22	sendAPositionReport
MoRC_Main_v22	rejectOrderToContactRBC_or_RIU
MoRC_Main_v22	infomDriverNoCompatibleVersionSupported
MoRC_Main_v22	status
MoRC_Main_v22	safeRadioIndication
MoRC_Main_v22	mobileConnectionCmd
MoRC_Main_v22	mobileRegistrationCmd
MoRC_Main_v22	memorizeTheLastRadioNetworkID



Owner	Port
MoRC_Main_v22	lastReceivedRadioNetworkID
MoRC_Main_v22	notReady
mobileDataRouter_out	data_2_RBC_1
mobileDataRouter_out	data_2_RBC_2
F2.7 SpeedSupervision_Integration	target
F2.7 SpeedSupervision_Integration	sdmCommands
F2.7 SpeedSupervision_Integration	EOA_overpassed
F2.7 SpeedSupervision_Integration	Target_Speed_Reached
F2.8 ProvidePositionReport	out_reportedBGs
AggregatePackets	outPackets
F2.13 manageTIU_output	outCommandStatusforEVC
bothBrakesActive	brakeCommand
getTIUStatusFromCommand	outStatus
handleTraction	outTrainCommands
mapModeToTractionCutOff	tractionCutOff
TIU_OutputIntegration	outTIU_to_API
TIU_OutputIntegration	outCommandStatusforEVC
calcDistances1	outLocationKP_Balise_Track
calcDistances1	ouDistanceKP_Balise
calcDistances1	outDistance_ToTSA
collectDMIPackets1	to_DMI
convert_cm_s_km_h1	km_h
copyGradientElement1	continue
copyGradientElement1	toDMI
copySpeedProfileElement1	continue
copySpeedProfileElement1	toDMI
copyTrackDescription1	toDMI
cyclicReportToDMI1	packetDynamic
doEntryRequest1	new_menuRequest
doEntryRequest1	new_entryRequest
doEntryRequest1	sendTrainDataToDMI
doEntryRequest1	outLevelsNeeded
doIdentifierRequest1	identifierRequest
isSendingNeeded1	sendingNeeded
mapEntryForLevel1	new_entryRequest
mapMoRCtoRadio_CS1	outBMI_CS
sendBrakesToDMI1	dmi_iconRequest
sendDynamic1	packetDynamic
sendLevelListPkg1	levelDataPkg
sendTrainData1	trainData_ForDMI

Owner	Port
sendVersion1	VersionPkg
synchWithDMI1	send_dmi_identifierRequest
synchWithDMI1	updatedOutputStatus
F2.3 trainData	triggerFromTrainData
trainDataStorage	updatedStatus
sendAcknowledgementRBC	updatedStatus
checkRadioMessages	ackReceived
checkRadioMessages	ackRequested
sendValidTrainDataRBC	updatedStatus
linkedBG_missed	missed
linkedBG_missed	indexOfBG
linkedBG_missed	BG
linkedBG_missed	BGs_out
twoConsecutiveLinkedBGs_missed	secondConsecutiveBG_missed
addAnnouncedBGs	BGs_out
addAnnouncedBGs	overrun
calculateBGLocations	BGs
calculateBGLocations	errors
calculateBGLocations	passedPositionedBG
calculateTrainpositionAttributes	trainPosition
calculateTrainPositionInfo	trainPositionInfo
calculateTrainPositionInfo	positionCalculationNotConsistent
delDispensableBGs	BGs_out
msg_2_passedBG	passedBG
msg_2_passedBG	BG_passed
msg_2_passedBG	onlyBGsAnnouncedViaRadio
F2.5 ManageLevelAndMode	Data_To_BG_Management
Input	train_standstill
Input	driver_level_transition
Input	levelAck
Input	currentPosition
Input	ERTMS_capabilities
Input	outStartOfMissionEnded
Input	Data_From_Track_to_Level
Input	Cab
Input	Data_From_DMI_To_Mode
Input	Data_From_F2_Functions_to_Mode
Input	Data_From_Localisation_To_Mode
Input	Data_From_Speed_and_Supervision_To_Mode
Input	Data_From_STM_to_Mode

Owner	Port
Input	Data_From_TIU_To_Mode
Input	Data_From_Track_To_Mode
ManageLevels	nextLevel
ManageLevels	TripTrainRequested
ManageLevels	needsAckFromDriver
ManageLevels	announcedLevelTransition
ManageLevels	serviceBrakeRequested
ManageLevels	connectionToRBCRequested
ManageLevels	positionReportNeeded
ManageLevels	levellsNew
ManageLevels	isAvailableForUse
CheckLevelAndMode	Level_Mode_Compatible
ManageModes	currentMode
ManageModes	EB_Requested
ManageModes	Service_Brake_Command
ManageModes	Data_To_DMI
ManageModes	Data_To_BG_Management
Output	Compatible_Mode_And_Level
Output	Data_To_DMI
Output	Data_To_BG_Management
Output	Service_Brake_Command
Output	EB_Requested
Output	transitionPositionPassed
F2.4 TrackAtlas	NV_raw_out
F2.4 TrackAtlas	MA_onboard_out
F2.4 TrackAtlas	MRSP
F2.4 TrackAtlas	message147
F2.4 TrackAtlas	ces_accepted
F2.4 TrackAtlas	ces_revoked
F2.4 TrackAtlas	trip_train
TrackAtlasETCS	SSP_available
TrackAtlasETCS	NV_raw_out
TrackAtlasETCS	To_ModeAndLevel
TrackAtlasETCS	to_DMI
TrackAtlasETCS	to_Supervision
TrackAtlasETCS	MA_onboard_out
TrackAtlasETCS	MA_request_out
TrackAtlasETCS	bus_out
TrackAtlasETCS	message147
TrackAtlasETCS	ces_accepted

Owner	Port
TrackAtlasETCS	ces_revoked
TrackAtlasETCS	trip_train
F2.9 MoRC_Main	ignoreMessagesFromRBC_except_m39_AckOfTerminationOfC
F2.9 MoRC_Main	sendAPositionReport
F2.9 MoRC_Main	cmdsToMobile
F2.9 MoRC_Main	memorizeTheLastRadioNetworkID
F2.9 MoRC_Main	currentRadioNetworkID
F2.9 MoRC_Main	orderTheRegistrationOfItsConnectedMobiles
F2.9 MoRC_Main	rejectOrderToContactRBC_or_RIU
F2.9 MoRC_Main	InformTheDriverThatNoConnectionWasSetup
F2.9 MoRC_Main	safeRadioConnectionStatus_toDriver
F2.9 MoRC_Main	mobileSWStatus
F2.9 MoRC_Main	requestTheSetupOfASafeRadioConnection
F2.9 MoRC_Main	requestReleaseOfSafeRadioConnectionWithTrackside
F2.9 MoRC_Main	sessionSuccessfullyEstablished
F2.9 MoRC_Main	sessionStatus
F2.9 MoRC_Main	MessageToRBC
F2.9 MoRC_Main	msgBus_out
F2.9 MoRC_Main	ready
Driver	Output1
Configuration1	Output1
MoRC_HO	radioStatus_2
MoRC_HO	mobileConnectionCmd_1
MoRC_HO	mobileConnectionCmd_2
MoRC_HO	mobileRegistrationCmd_1
MoRC_HO	mobileRegistrationCmd_2
MoRC_HO	safeRadioIndication
MoRC_HO	supervisingRBC
MoRC_HO	bufferInformationFromAcceptingRBC
MoRC_HO	trainPassesA_RBC_RBC_border_WithItsFrontEnd
MoRC_HO	msgBus_2_RBC_1
MoRC_HO	msgBus_2_RBC_2
MoRC_HO	triggerPositionReport
MoRC_HO	triggerTrainData
MoRC_HO	rejectOrderToContactRBC_or_RIU
MoRC_HO	infomDriverNoCompatibleVersionSupported
MoRC_HO	memorizeTheLastRadioNetworkID
MoRC_HO	lastReceivedRadioNetworkID
MoRC_HO	ready
processHandingOver	sessionCmds_2_MoRC_1

Owner	Port
processHandingOver	sessionCmds_2_MoRC_2
processHandingOver	sendPositionReport_2_handingOverRBC
processHandingOver	sendPositionReport_2_acceptingRBC
processHandingOver	sendTrainData_2_acceptingRBC
processHandingOver	bufferInformationFromAcceptingRBC
processHandingOver	supervisingRBC
processHandingOver	useInformationFromAcceptingRBC
processHandingOver	handingOverMobile_is_mobile_1
processHandingOver	trainPassesA_RBC_RBC_border_WithItsFrontEnd
processHandingOver	notReady
MoRC_Main_v21	msgToRBC
MoRC_Main_v21	sendAPositionReport
MoRC_Main_v21	rejectOrderToContactRBC_or_RIU
MoRC_Main_v21	infomDriverNoCompatibleVersionSupported
MoRC_Main_v21	status
MoRC_Main_v21	safeRadioIndication
MoRC_Main_v21	mobileConnectionCmd
MoRC_Main_v21	mobileRegistrationCmd
MoRC_Main_v21	memorizeTheLastRadioNetworkID
MoRC_Main_v21	lastReceivedRadioNetworkID
MoRC_Main_v21	notReady
MoRC_Main_v22	msgToRBC
MoRC_Main_v22	sendAPositionReport
MoRC_Main_v22	rejectOrderToContactRBC_or_RIU
MoRC_Main_v22	infomDriverNoCompatibleVersionSupported
MoRC_Main_v22	status
MoRC_Main_v22	safeRadioIndication
MoRC_Main_v22	mobileConnectionCmd
MoRC_Main_v22	mobileRegistrationCmd
MoRC_Main_v22	memorizeTheLastRadioNetworkID
MoRC_Main_v22	lastReceivedRadioNetworkID
MoRC_Main_v22	notReady
mobileDataRouter_out	data_2_RBC_1
mobileDataRouter_out	data_2_RBC_2
CheckBGConsistency	passedBG_out
CheckBGConsistency	applyServiceBrake
CheckBGConsistency	badBaliseMessageToDMI
CheckBGConsistency	errorLinkedBG
CheckBGConsistency	errorUnlinkedBG
CheckBGConsistency	incompatibleVersion

Owner	Port
CaseLinkingNotInUse1	badBaliseMessageToDMI
ProvidePositionReport	posRep
ProvidePositionReport	out_reportedBGs
ProvidePositionReport	packet0
ProvidePositionReport	packet1
ProvidePositionReport	posReport
AggregatePackets	outPackets
manageDMI_Output	to_DMI
manageDMI_Output	outStatusList
calcDistances1	outLocationKP_Balise_Track
calcDistances1	ouDistanceKP_Balise
calcDistances1	outDistance_ToTSA
collectDMIPackets1	to_DMI
convert_cm_s_km_h1	km_h
copyGradientElement1	continue
copyGradientElement1	toDMI
copySpeedProfileElement1	continue
copySpeedProfileElement1	toDMI
copyTrackDescription1	toDMI
cyclicReportToDMI1	packetDynamic
doEntryRequest1	new_menuRequest
doEntryRequest1	new_entryRequest
doEntryRequest1	sendTrainDataToDMI
doEntryRequest1	outLevelsNeeded
dolIdentifierRequest1	identifierRequest
isSendingNeeded1	sendingNeeded
mapEntryForLevel1	new_entryRequest
mapMoRCtoRadio_CS1	outBMI_CS
sendBrakesToDMI1	dmi_iconRequest
sendDynamic1	packetDynamic
sendLevelListPkg1	levelDataPkg
sendTrainData1	trainData_ForDMI
sendVersion1	VersionPkg
synchWithDMI1	send_dmi_identifierRequest
synchWithDMI1	updatedOutputStatus
F2 ETCS Kernel	resetOut
F2 ETCS Kernel	debugPermittedSpeed
F2 ETCS Kernel	debugInterventionSpeed
F2 ETCS Kernel	API_toEuroradio
F2 ETCS Kernel	API_toDMI

Owner	Port
F2 ETCS Kernel	API_toTIU
F2 ETCS Kernel	debugTrainPositionNominal
F2 ETCS Kernel	debugTrainPositionDeltaMax
F2 ETCS Kernel	debugTrainPositionDeltaMin
F2 ETCS Kernel	debugCurrentMode
F2 ETCS Kernel	debugCurrentLevel
F2 ETCS Kernel	API_persistentDataOut
CheckBGConsistency	badBaliseMessageToDMI
CheckBGConsistency	errorLinkedBG
CheckBGConsistency	errorUnlinkedBG
CheckBGConsistency	incompatibleVersion
CaseLinkingNotInUse1	badBaliseMessageToDMI
InformationFilter	outAcceptedMessage
CheckEuroRadioMessage	radioSequenceError
CheckEuroRadioMessage	tNvContactError
CheckEuroRadioMessage	otherTimingError
CheckEuroRadioMessage	radioMessageConsistencyError
F2.10 manageDMI_Input	fromDMI_Identifier
F2.10 manageDMI_Input	fromDMI_DriverIdentifier
F2.10 manageDMI_Input	fromDMI_RadioNetData
F2.10 manageDMI_Input	fromDMI_Icon_Ack
F2.10 manageDMI_Input	fromDMI_AdhesionFactor
changeLevelByDiver1	ML_levelTransition
changeLevelByDiver1	updatedNTC
doDriverRequests1	outDriverRequestToLevels
doDriverRequests1	outDriverRequestToModes
receiveRequestsModesAndLevel1	outDriverRequestToLevels
receiveRequestsModesAndLevel1	forModesAndLevel
receiveRequestsModesAndLevel1	outStatusList
triggerForMA1	outForMA
updateDMIStatus1	newStatus
F2.12 manageTIU_input	tractionCutOff
getTIUStatusFromData	outStatus
mergeTIU_Info	updatedInfo
selectTrainData	outTrainData
F2.2 Manage_ETCS_Procedures	request_MA_FS_SR_OS_LS_SH_to_MA_L2_Management
F2.2 Manage_ETCS_Procedures	request_Mode_Change_SB_to_FS_to_Level_and_Mode_Management
F2.2 Manage_ETCS_Procedures	start_ack_to_TIU
SoM_NTC_SN	start_ack_to_TIU
SoM_SR_FS_OS_LS_SH_SN_UN	request_MA_FS_SR_OS_LS_SH_to_MA_L2_Management

Owner	Port
SoM_SR_FS_OS_LS_SH_SN_UN	request_Mode_Change_SB_to_FS_to_Level_and_Mode_Manage
SoM_SR_FS_OS_LS_SH_SN_UN	start_ack_to_TIU
F2.9 MoRC_HO	bufferInformationFromAcceptingRBC
F2.9 MoRC_HO	trainPassesA_RBC_RBC_border_WithItsFrontEnd
F2.9 MoRC_HO	triggerPositionReport
F2.9 MoRC_HO	triggerTrainData
F2.9 MoRC_HO	rejectOrderToContactRBC_or_RIU
F2.9 MoRC_HO	informDriverNoCompatibleVersionSupported
F2.9 MoRC_HO	memorizeTheLastRadioNetworkID
F2.9 MoRC_HO	radioStatus_2
F2.9 MoRC_HO	mobileConnectionCmd_2
F2.9 MoRC_HO	mobileRegistrationCmd_2
F2.9 MoRC_HO	safeRadioIndication
F2.9 MoRC_HO	msgBus_2_RBC_1
F2.9 MoRC_HO	msgBus_2_RBC_2
F2.9 MoRC_HO	lastReceivedRadioNetworkID
processHandingOver	sendPositionReport_2_handingOverRBC
processHandingOver	sendPositionReport_2_acceptingRBC
processHandingOver	sendTrainData_2_acceptingRBC
processHandingOver	bufferInformationFromAcceptingRBC
processHandingOver	supervisingRBC
processHandingOver	useInformationFromAcceptingRBC
processHandingOver	handingOverMobile_is_mobile_1
processHandingOver	trainPassesA_RBC_RBC_border_WithItsFrontEnd
processHandingOver	notReady
processHandingOver	sessionCmds_2_MoRC_1
processHandingOver	sessionCmds_2_MoRC_2
MoRC_Main_v21	sendAPositionReport
MoRC_Main_v21	rejectOrderToContactRBC_or_RIU
MoRC_Main_v21	informDriverNoCompatibleVersionSupported
MoRC_Main_v21	memorizeTheLastRadioNetworkID
MoRC_Main_v21	notReady
MoRC_Main_v21	msgToRBC
MoRC_Main_v21	status
MoRC_Main_v21	safeRadioIndication
MoRC_Main_v21	mobileConnectionCmd
MoRC_Main_v21	mobileRegistrationCmd
MoRC_Main_v21	lastReceivedRadioNetworkID
MoRC_Main_v22	sendAPositionReport
MoRC_Main_v22	rejectOrderToContactRBC_or_RIU



Owner	Port
MoRC_Main_v22	infomDriverNoCompatibleVersionSupported
MoRC_Main_v22	memorizeTheLastRadioNetworkID
MoRC_Main_v22	notReady
MoRC_Main_v22	msgToRBC
MoRC_Main_v22	status
MoRC_Main_v22	safeRadioIndication
MoRC_Main_v22	mobileConnectionCmd
MoRC_Main_v22	mobileRegistrationCmd
MoRC_Main_v22	lastReceivedRadioNetworkID
mobileDataRouter_out	data_2_RBC_1
mobileDataRouter_out	data_2_RBC_2
F2.7 SpeedSupervision_Integration	EOA_overpassed
F2.7 SpeedSupervision_Integration	Target_Speed_Reached
F2.7 SpeedSupervision_Integration	target
F2.7 SpeedSupervision_Integration	sdmCommands
F2.8 ProvidePositionReport	out_reportedBGs
AggregatePackets	outPackets
PosReport_Supervision	out_reportedBGs
PosReport_Supervision	posRep
ReceiveReportParameters	posRep
F2.13 manageTIU_output	outCommandStatusforEVC
bothBrakesActive	brakeCommand
getTIUStatusFromCommand	outStatus
handleTraction	outTrainCommands
mapModeToTractionCutOff	tractionCutOff
TIU_OutputIntegration	outTIU_to_API
TIU_OutputIntegration	outCommandStatusforEVC
calcDistances1	outLocationKP_Balise_Track
calcDistances1	ouDistanceKP_Balise
calcDistances1	outDistance_ToTSA
collectDMIPackets1	to_DMI
convert_cm_s_km_h1	km_h
copyGradientElement1	to_DMI
copyGradientElement1	outStatusList
copyGradientElement1	continue
copyGradientElement1	toDMI
copySpeedProfileElement1	fromDMI_TrainDataAck
copySpeedProfileElement1	continue
copySpeedProfileElement1	toDMI
copyTrackDescription1	toDMI

Owner	Port
cyclicReportToDMI1	packetDynamic
doEntryRequest1	sendTrainDataToDMI
doEntryRequest1	new_menuRequest
doEntryRequest1	new_entryRequest
doEntryRequest1	outLevelsNeeded
doIdentifierRequest1	identifierRequest
isSendingNeeded1	sendingNeeded
mapEntryForLevel1	new_entryRequest
mapMoRCtoRadio_CS1	outBMI_CS
sendBrakesToDMI1	dmi_iconRequest
sendDynamic1	packetDynamic
sendLevelListPkg1	levelDataPkg
sendTrainData1	trainData_ForDMI
sendVersion1	VersionPkg
synchWithDMI1	updatedOutputStatus
synchWithDMI1	send_dmi_identifierRequest
F2.3 trainData	triggerFromTrainData
trainDataStorage	updatedStatus
sendAcknowledgementRBC	updatedStatus
checkRadioMessages	ackReceived
checkRadioMessages	ackRequested
sendValidTrainDataRBC	updatedStatus
linkedBG_missed	missed
linkedBG_missed	indexOfBG
linkedBG_missed	BG
linkedBG_missed	BGs_out
twoConsecutiveLinkedBGs_missed	secondConsecutiveBG_missed
addAnnouncedBGs	overrun
addAnnouncedBGs	BGs_out
calculateBGLocations	BGs
calculateBGLocations	errors
calculateBGLocations	passedPositionedBG
calculateTrainpositionAttributes	trainPosition
calculateTrainPositionInfo	positionCalculationNotConsistent
calculateTrainPositionInfo	trainPositionInfo
delDispensableBGs	BGs_out
msg_2_passedBG	BG_passed
msg_2_passedBG	passedBG
msg_2_passedBG	onlyBGsAnnouncedViaRadio
F2.5 ManageLevelAndMode	Data_To_BG_Management

Owner	Port
Input	train_standstill
Input	levelAck
Input	outStartOfMissionEnded
Input	driver_level_transition
Input	currentPosition
Input	ERTMS_capabilities
Input	Data_From_Track_to_Level
Input	Cab
Input	Data_From_DMI_To_Mode
Input	Data_From_F2_Functions_to_Mode
Input	Data_From_Localisation_To_Mode
Input	Data_From_Speed_and_Supervision_To_Mode
Input	Data_From_STM_to_Mode
Input	Data_From_TIU_To_Mode
Input	Data_From_Track_To_Mode
ManageLevels	TripTrainRequested
ManageLevels	needsAckFromDriver
ManageLevels	serviceBrakeRequested
ManageLevels	nextLevel
ManageLevels	announced_level_transition
ManageLevels	positionReportNeeded
ManageLevels	levellsNew
ManageLevels	isAvailableForUse
ManageLevels	announcedLevelTransition
ManageLevels	connectionToRBCRequested
CheckLevelAndMode	Level_Mode_Compatible
ManageModes	EB_Requested
ManageModes	Service_Brake_Command
ManageModes	currentMode
ManageModes	Data_To_DMI
ManageModes	Data_To_BG_Management
Output	Service_Brake_Command
Output	EB_Requested
Output	transitionPositionPassed
Output	Compatible_Mode_And_Level
Output	Data_To_DMI
Output	Data_To_BG_Management
F2.4 TrackAtlas	MA_onboard_out
F2.4 TrackAtlas	MRSP
F2.4 TrackAtlas	ces_accepted

Owner	Port
F2.4 TrackAtlas	ces_revoked
F2.4 TrackAtlas	trip_train
F2.4 TrackAtlas	NV_raw_out
F2.4 TrackAtlas	message147
TrackAtlasETCS	To_ModeAndLevel
TrackAtlasETCS	to_DMI
TrackAtlasETCS	to_Supervision
TrackAtlasETCS	MA_onboard_out
TrackAtlasETCS	ces_accepted
TrackAtlasETCS	ces_revoked
TrackAtlasETCS	trip_train
TrackAtlasETCS	NV_raw_out
TrackAtlasETCS	MA_request_out
TrackAtlasETCS	message147
TrackAtlasETCS	SSP_available
TrackAtlasETCS	bus_out
F2.9 MoRC_Main	ignoreMessagesFromRBC_except_m39_AckOfTerminationOfC
F2.9 MoRC_Main	sendAPositionReport
F2.9 MoRC_Main	cmdsToMobile
F2.9 MoRC_Main	memorizeTheLastRadioNetworkID
F2.9 MoRC_Main	orderTheRegistrationOfItsConnectedMobiles
F2.9 MoRC_Main	rejectOrderToContactRBC_or_RIU
F2.9 MoRC_Main	InformTheDriverThatNoConnectionWasSetup
F2.9 MoRC_Main	safeRadioConnectionStatus_toDriver
F2.9 MoRC_Main	mobileSWStatus
F2.9 MoRC_Main	requestTheSetupOfASafeRadioConnection
F2.9 MoRC_Main	requestReleaseOfSafeRadioConnectionWithTrackside
F2.9 MoRC_Main	sessionSuccessfullyEstablished
F2.9 MoRC_Main	ready
F2.9 MoRC_Main	currentRadioNetworkID
F2.9 MoRC_Main	sessionStatus
F2.9 MoRC_Main	MessageToRBC
F2.9 MoRC_Main	msgBus_out
MoRC_HO	bufferInformationFromAcceptingRBC
MoRC_HO	trainPassesA_RBC_RBC_border_WithItsFrontEnd
MoRC_HO	triggerPositionReport
MoRC_HO	triggerTrainData
MoRC_HO	rejectOrderToContactRBC_or_RIU
MoRC_HO	infomDriverNoCompatibleVersionSupported
MoRC_HO	memorizeTheLastRadioNetworkID

Owner	Port
MoRC_HO	radioStatus_1
MoRC_HO	radioStatus_2
MoRC_HO	mobileConnectionCmd_1
MoRC_HO	mobileConnectionCmd_2
MoRC_HO	mobileRegistrationCmd_1
MoRC_HO	mobileRegistrationCmd_2
MoRC_HO	safeRadioIndication
MoRC_HO	supervisingRBC
MoRC_HO	msgBus_2_RBC_1
MoRC_HO	msgBus_2_RBC_2
MoRC_HO	lastReceivedRadioNetworkID
processHandingOver	sendPositionReport_2_handingOverRBC
processHandingOver	sendPositionReport_2_acceptingRBC
processHandingOver	sendTrainData_2_acceptingRBC
processHandingOver	bufferInformationFromAcceptingRBC
processHandingOver	supervisingRBC
processHandingOver	useInformationFromAcceptingRBC
processHandingOver	handingOverMobile_is_mobile_1
processHandingOver	trainPassesA_RBC_RBC_border_WithItsFrontEnd
processHandingOver	notReady
processHandingOver	sessionCmds_2_MoRC_1
processHandingOver	sessionCmds_2_MoRC_2
MoRC_Main_v21	sendAPositionReport
MoRC_Main_v21	rejectOrderToContactRBC_or_RIU
MoRC_Main_v21	infomDriverNoCompatibleVersionSupported
MoRC_Main_v21	memorizeTheLastRadioNetworkID
MoRC_Main_v21	notReady
MoRC_Main_v21	msgToRBC
MoRC_Main_v21	status
MoRC_Main_v21	safeRadioIndication
MoRC_Main_v21	mobileConnectionCmd
MoRC_Main_v21	mobileRegistrationCmd
MoRC_Main_v21	lastReceivedRadioNetworkID
MoRC_Main_v22	sendAPositionReport
MoRC_Main_v22	rejectOrderToContactRBC_or_RIU
MoRC_Main_v22	infomDriverNoCompatibleVersionSupported
MoRC_Main_v22	memorizeTheLastRadioNetworkID
MoRC_Main_v22	notReady
MoRC_Main_v22	msgToRBC
MoRC_Main_v22	status

Owner	Port
MoRC_Main_v22	safeRadioIndication
MoRC_Main_v22	mobileConnectionCmd
MoRC_Main_v22	mobileRegistrationCmd
MoRC_Main_v22	lastReceivedRadioNetworkID
mobileDataRouter_out	data_2_RBC_1
mobileDataRouter_out	data_2_RBC_2
SpeedSupervision_Integration	sdmToDMI
SpeedSupervision_Integration	target
SpeedSupervision_Integration	sdmCommands
SpeedSupervision_Integration	brakeCmd
SpeedSupervision_Integration	EOA_overpassed
SpeedSupervision_Integration	Target_Speed_Reached
manageTIU_input	outTIUStatus
manageTIU_input	outTIUCurrentInfo
getTIUStatusFromData	outStatus
mergeTIU_Info	updatedInfo
selectTrainData	outTrainData
Master_Procedure	DMI_Entry_Request_to_DMI
Master_Procedure	request_Start_Mobile_Terminal_and_RBC_Registration_to_Mo
Master_Procedure	powerUp_to_MoRC
Master_Procedure	statusstartofmissionongoing_to_MoRC
Master_Procedure	powerOff_to_MoRC
Master_Procedure	request_MA_FS_SR_OS_LS_SH_to_MA_L2_Management
Master_Procedure	request_Mode_Change_SB_to_FS_to_Level_and_Mode_Mana
Master_Procedure	start_ack_to_TIU
SoM_NTC_SN	start_ack_to_TIU
SoM_SR_FS_OS_LS_SH_SN_UN	request_MA_FS_SR_OS_LS_SH_to_MA_L2_Management
SoM_SR_FS_OS_LS_SH_SN_UN	request_Mode_Change_SB_to_FS_to_Level_and_Mode_Mana
SoM_SR_FS_OS_LS_SH_SN_UN	start_ack_to_TIU
manageDMI_Input	fromDMI_Identifier
manageDMI_Input	fromDMI_DriverIdentifier
manageDMI_Input	fromDMI_RadioNetData
manageDMI_Input	fromDMI_Icon_Ack
manageDMI_Input	fromDMI_AdhesionFactor
manageDMI_Input	forModesAndLevel
manageDMI_Input	ML_levelTransition
manageDMI_Input	outDriverRequest
manageDMI_Input	outForMA
changeLevelByDiver1	ML_levelTransition
changeLevelByDiver1	updatedNTC

Owner	Port
doDriverRequests1	outDriverRequestToLevels
doDriverRequests1	outDriverRequestToModes
receiveRequestsModesAndLevel1	outDriverRequestToLevels
receiveRequestsModesAndLevel1	forModesAndLevel
receiveRequestsModesAndLevel1	outStatusList
triggerForMA1	outForMA
updateDMIStatus1	newStatus
CheckBGConsistency	applyServiceBrake
CheckBGConsistency	badBaliseMessageToDMI
CheckBGConsistency	errorLinkedBG
CheckBGConsistency	errorUnlinkedBG
CheckBGConsistency	incompatibleVersion
CheckBGConsistency	passedBG_out
CaseLinkingNotInUse1	badBaliseMessageToDMI
manageDMI_Output	to_DMI
calcDistances1	outLocationKP_Balise_Track
calcDistances1	ouDistanceKP_Balise
calcDistances1	outDistance_ToTSA
collectDMIPackets1	to_DMI
convert_cm_s_km_h1	km_h
copyGradientElement1	to_DMI
copyGradientElement1	outStatusList
copyGradientElement1	continue
copyGradientElement1	toDMI
copySpeedProfileElement1	fromDMI_TrainDataAck
copySpeedProfileElement1	continue
copySpeedProfileElement1	toDMI
copyTrackDescription1	toDMI
cyclicReportToDMI1	packetDynamic
doEntryRequest1	sendTrainDataToDMI
doEntryRequest1	new_menuRequest
doEntryRequest1	new_entryRequest
doEntryRequest1	outLevelsNeeded
dolIdentifierRequest1	identifierRequest
isSendingNeeded1	sendingNeeded
mapEntryForLevel1	new_entryRequest
mapMoRCtoRadio_CS1	outBMI_CS
sendBrakesToDMI1	dmi_iconRequest
sendDynamic1	packetDynamic
sendLevelListPkg1	levelDataPkg

Owner	Port
sendTrainData1	trainData_ForDMI
sendVersion1	VersionPkg
synchWithDMI1	updatedOutputStatus
synchWithDMI1	send_dmi_identifierRequest
ManageLevelAndMode	Compatible_Mode_And_Level
ManageLevelAndMode	Data_To_BG_Management
ManageLevelAndMode	Service_Brake_Command
ManageLevelAndMode	EB_Requested
ManageLevelAndMode	announcedLevel
ManageLevelAndMode	Data_To_DMI_Ack
Input	train_standstill
Input	driver_level_transition
Input	levelAck
Input	currentPosition
Input	ERTMS_capabilities
Input	outStartOfMissionEnded
Input	Data_From_Track_to_Level
Input	Cab
Input	Data_From_DMI_To_Mode
Input	Data_From_F2_Functions_to_Mode
Input	Data_From_Localisation_To_Mode
Input	Data_From_Speed_and_Supervision_To_Mode
Input	Data_From_STM_to_Mode
Input	Data_From_TIU_To_Mode
Input	Data_From_Track_To_Mode
ManageLevels	nextLevel
ManageLevels	TripTrainRequested
ManageLevels	needsAckFromDriver
ManageLevels	announcedLevelTransition
ManageLevels	serviceBrakeRequested
ManageLevels	connectionToRBCRequested
ManageLevels	positionReportNeeded
ManageLevels	levellsNew
ManageLevels	isAvailableForUse
CheckLevelAndMode	Level_Mode_Compatible
ManageModes	currentMode
ManageModes	EB_Requested
ManageModes	Service_Brake_Command
ManageModes	Data_To_DMI
ManageModes	Data_To_BG_Management



Owner	Port
Output	Compatible_Mode_And_Level
Output	Data_To_DMI
Output	Data_To_BG_Management
Output	Service_Brake_Command
Output	EB_Requested
Output	transitionPositionPassed
manageTIU_input	tractionCutOff
manageTIU_input	outTIUStatus
manageTIU_input	outTIUCurrentInfo
getTIUStatusFromData	outStatus
mergeTIU_Info	updatedInfo
selectTrainData	outTrainData
TrackAtlas	NV_raw_out
TrackAtlas	To_ModeAndLevel
TrackAtlas	to_DMI
TrackAtlas	to_Supervision
TrackAtlas	MA_onboard_out
TrackAtlas	MRSP
TrackAtlas	MA_request_out
TrackAtlas	message147
TrackAtlas	ces_accepted
TrackAtlas	ces_revoked
TrackAtlas	trip_train
TrackAtlas	bus_out
TrackAtlasETCS	SSP_available
TrackAtlasETCS	NV_raw_out
TrackAtlasETCS	To_ModeAndLevel
TrackAtlasETCS	to_DMI
TrackAtlasETCS	to_Supervision
TrackAtlasETCS	MA_onboard_out
TrackAtlasETCS	MA_request_out
TrackAtlasETCS	bus_out
TrackAtlasETCS	message147
TrackAtlasETCS	ces_accepted
TrackAtlasETCS	ces_revoked
TrackAtlasETCS	trip_train
Master_Procedure	powerUp_to_MoRC
Master_Procedure	statusstartofmissionongoing_to_MoRC
Master_Procedure	powerOff_to_MoRC
Master_Procedure	request_MA_FS_SR_OS_LS_SH_to_MA_L2_Management

Owner	Port
Master_Procedure	request_Mode_Change_SB_to_FS_to_Level_and_Mode_Management
Master_Procedure	start_ack_to_TIU
Master_Procedure	DMI_Entry_Request_to_DMI
Master_Procedure	request_Start_Mobile_Terminal_and_RBC_Registration_to_Mo
SoM_NTC_SN	start_ack_to_TIU
SoM_SR_FS_OS_LS_SH_SN_UN	request_MA_FS_SR_OS_LS_SH_to_MA_L2_Management
SoM_SR_FS_OS_LS_SH_SN_UN	request_Mode_Change_SB_to_FS_to_Level_and_Mode_Management
SoM_SR_FS_OS_LS_SH_SN_UN	start_ack_to_TIU
manageTIU_output	outTIU_to_API
manageTIU_output	outCommandStatusforEVC
bothBrakesActive	brakeCommand
getTIUStatusFromCommand	outStatus
handleTraction	outTrainCommands
mapModeToTractionCutOff	tractionCutOff
TIU_OutputIntegration	outTIU_to_API
TIU_OutputIntegration	outCommandStatusforEVC
SpeedSupervision_Integration	EOA_overpassed
SpeedSupervision_Integration	Target_Speed_Reached
SpeedSupervision_Integration	sdmToDMI
SpeedSupervision_Integration	target
SpeedSupervision_Integration	sdmCommands
SpeedSupervision_Integration	brakeCmd
manageTIU_output	outTIU_to_API
manageTIU_output	outCommandStatusforEVC
bothBrakesActive	brakeCommand
getTIUStatusFromCommand	outStatus
handleTraction	outTrainCommands
mapModeToTractionCutOff	tractionCutOff
TIU_OutputIntegration	outTIU_to_API
TIU_OutputIntegration	outCommandStatusforEVC
Manage_TrackSideInformation_Integration	ApplyServiceBrake
Manage_TrackSideInformation_Integration	BadBaliseMessageToDMI
Manage_TrackSideInformation_Integration	forLevelManagement
Manage_TrackSideInformation_Integration	outputMessageForRadioAck
Manage_TrackSideInformation_Integration	Data_to_From_Track_Packets_at_ML
CheckBGConsistency	badBaliseMessageToDMI
CheckBGConsistency	errorLinkedBG
CheckBGConsistency	errorUnlinkedBG
CheckBGConsistency	incompatibleVersion
CaseLinkingNotInUse1	badBaliseMessageToDMI

Owner	Port
InformationFilter	outAcceptedMessage
CheckEuroRadioMessage	radioSequenceError
CheckEuroRadioMessage	tNvContactError
CheckEuroRadioMessage	otherTimingError
CheckEuroRadioMessage	radioMessageConsistencyError
trainData	triggerFromTrainData
trainData	updatedAtStatus
trainData	outMessageBus
trainDataStorage	updatedAtStatus
sendAcknowledgementRBC	updatedAtStatus
checkRadioMessages	ackReceived
checkRadioMessages	ackRequested
sendValidTrainDataRBC	updatedAtStatus
TrackAtlas	To_ModeAndLevel
TrackAtlas	to_DMI
TrackAtlas	to_Supervision
TrackAtlas	MA_onboard_out
TrackAtlas	MRSP
TrackAtlas	ces_accepted
TrackAtlas	ces_revoked
TrackAtlas	trip_train
TrackAtlas	NV_raw_out
TrackAtlas	MA_request_out
TrackAtlas	message147
TrackAtlas	bus_out
TrackAtlasETCS	To_ModeAndLevel
TrackAtlasETCS	to_DMI
TrackAtlasETCS	to_Supervision
TrackAtlasETCS	MA_onboard_out
TrackAtlasETCS	ces_accepted
TrackAtlasETCS	ces_revoked
TrackAtlasETCS	trip_train
TrackAtlasETCS	NV_raw_out
TrackAtlasETCS	MA_request_out
TrackAtlasETCS	message147
TrackAtlasETCS	SSP_available
TrackAtlasETCS	bus_out
calculateTrainPosition	trainPosition
calculateTrainPosition	BGs
linkedBG_missed	missed

Owner	Port
linkedBG_missed	indexOfBG
linkedBG_missed	BG
linkedBG_missed	BGs_out
twoConsecutiveLinkedBGs_missed	secondConsecutiveBG_missed
addAnnouncedBGs	overrun
addAnnouncedBGs	BGs_out
calculateBGLocations	BGs
calculateBGLocations	errors
calculateBGLocations	passedPositionedBG
calculateTrainpositionAttributes	trainPosition
calculateTrainPositionInfo	positionCalculationNotConsistent
calculateTrainPositionInfo	trainPositionInfo
delDispensableBGs	BGs_out
msg_2_passedBG	BG_passed
msg_2_passedBG	passedBG
msg_2_passedBG	onlyBGsAnnouncedViaRadio
Abstract definition	Train position
Abstract definition	BGs
ProvidePositionReport	out_reportedBGs
ProvidePositionReport	posRep
ProvidePositionReport	packet0
ProvidePositionReport	packet1
ProvidePositionReport	posReport
AggregatePackets	outPackets
PosReport_Supervision	out_reportedBGs
PosReport_Supervision	posRep
ReceiveReportParameters	posRep