

spirit[®]

TECH OPS TRAINING

A-320 FAMILY V2500 & PW1100G ENGINE RUN / TAXI & EMERGENCY CHECKLISTS



TABLE OF CONTENTS

TOWING / ENGINE RUN-UP / TAXI CHECKLIST

CONTROL SAFETY.....	PG. 1
EXTERNAL POWER.....	PG. 2
APU START ON EXTERNAL POWER.....	PG. 2
APU START ON BATTERIES.....	PG. 2
COCKPIT PREPARATION.....	PG. 3
BEFORE PUSHBACK / AFTER PUSH BACK.....	PG. 4
BEFORE ENGINE START / STARTER DUTY LIMITS....	PG. 5 / 14
AUTOMATIC START.....	PG. 6 / 15
MANUAL START.....	PG. 7 / 16
CROSSBLEED START.....	PG. 8 / 17
PNEUMATIC ASSIST START.....	PG. 9 / 18
AFTER ENGINE START.....	PG. 10 / 19
ENGINE SHUTDOWN.....	PG. 11 / 20
DRY-MOTORING.....	PG. 12 / 21
WET-MOTORING.....	PG. 13 / 22
TAXI.....	PG. 23
TOWING WITHOUT ENGINE RUN.....	PG. 24
TOWING WITH BATTERY POWER ONLY.....	PG. 25
LEAVING THE AIRCRAFT.....	PG. 26

EMERGENCY CHECKLIST

ENGINE FIRE ON GROUND.....	PG. 27
ENGINE TAILPIPE FIRE.....	PG. 28
APU FIRE.....	PG. 29
LOSS OF BRAKING.....	PG. 30
SMOKE / AVIONICS SMOKE.....	PG. 31
CARGO SMOKE.....	PG. 32

SUPPLEMENTAL INFORMATION

MARSHALLING HAND SIGNALS.....	PG. 34 - 38
AIRPORT LIGHTS, SIGNS, & MARKINGS.....	PG. 39 - 41
FUTURE USE.....	PG. 42 - 45
NOTES.....	PG. 46 - 48

CONTROL SAFETY

- FOLLOW LOCAL STATION ENGINE RUN SOP.
- USE OF THIS CHECKLIST IS REQUIRED FOR ALL ENGINE RUN / TAXI PROCEDURES.
- TWO QUALIFIED PERSONS ARE REQUIRED WHEN PERFORMING AIRCRAFT TAXI.
- PASSENGERS ARE NOT ALLOWED ON A/C WHEN PERFORMING AN ENGINE RUN / TAXI.
- POSITIVE GROUND PERSONNEL COMMUNICATION REQUIRED AT ALL TIMES DURING ENGINE RUN VIA HEADSET.
- IF HEADSET OR AIRCRAFT INTERPHONE SYSTEM IS INOPERABLE, HAND SIGNALS ARE PERMITTED WITH 100% VISUAL CONTACT WITH FLIGHT DECK AT ALL TIMES.
- AIRPORT DIAGRAM IS REQUIRED DURING TAXI.
- MAINTENANCE RUN UPS & TAXIS REQUIRE A FLT NUMBER TO BE ENTERED IN MCDU. USE "MX01" WITH ADDITIONAL RUNS ON THE SAME AIRCRAFT NUMBERED "MX02, MX03" ETC.

AIRCRAFT WALK AROUND & LOGBOOK REVIEW.... PERFORM
WHEEL CHOCKS IN PLACE
C/B PANELS CHECKED
PARKING BRAKE ON
ATC TRANSPONDER (FOLLOW LOCAL AIRPORT REQ).....STBY
WEATHER RADAR SYSTEMOFF
ENG MODE SELECTOR..... NORM
ENG MASTER SWITCHES 1 & 2.....OFF
THRUST LEVERS..... IDLE / REVERSE STOWED
LANDING GEAR LEVER.....DOWN
GRAVITY GEAR EXTN RESET / STOWED
FUEL PUMPS OFF
BAT PUSH BUTTONS 1 & 2. OFF / VOLTAGE ABOVE 25.5V
BUS TIE..... AUTO

PROCEED TO EXTERNAL POWER OR APU START
(PG. 2)

EXTERNAL POWER

EXT PWR PUSHBUTTON	PRESS
BAT PUSHBUTTON 1 & 2.....	ON
GEN 1, 2, & APU PUSHBUTTONS.....	IN
VENTILATION PANEL.....	NO LIGHTS ILLUMINATED
ECAM.....	ADJUST BRIGHTNESS

PROCEED WITH APU START WITH EXT POWER

APU START WITH EXT POWER

**LIMIT APU FIRE TEST TO 3 SECONDS OR LESS TO PREVENT
INADVERTANT DISCHARGE OF APU FIRE BOTTLE**

APU FIRE PUSHBUTTON.....	IN / GUARDED
APU AUTO EXTIG GND TEST C/B (L40).....	PULL
APU FIRE TEST.....	PERFORM
APU AUTO EXTIG GND TEST C/B (L40).....	RESET
APU MASTER SWITCH.....	PRESS ON
APU START PUSHBUTTON.....	PRESS

PROCEED WITH COCKPIT PREPARATION (PG. 3)

APU START ON BATTERIES

**LIMIT APU FIRE TEST TO 3 SECONDS OR LESS TO PREVENT
INADVERTANT DISCHARGE OF APU FIRE BOTTLE**

BAT PUSHBUTTON 1 & 2.....	ON
APU MASTER SWITCH.....	PRESS ON
APU FIRE PUSHBUTTON.....	IN / GUARDED
APU AUTO EXTIG GND TEST C/B (L40).....	PULL
APU FIRE TEST.....	PERFORM
APU AUTO EXTIG GND TEST C/B (L40).....	RESET
APU GEN PUSHBUTTON.....	IN
APU START PUSHBUTTON.....	PRESS
ECAM.....	ADJUST BRIGHTNESS
VENTILATION PANEL	NO LIGHTS ILLUMINATED

PROCEED WITH COCKPIT PREPARATION (PG. 3)

COCKPIT PREPARATION

RMP 1 & 2.....CHECK ON
 ACP 1 & 2.....VHF 1/2 & INT
 ADIRUS.....ALIGN IN NAV
 MCDU 1 & 2.....ON / ADJUST BRIGHTNESS
 MCDU.... (INSERT AIRPORT CODE & FLT # MX01).....SELECT "INIT"
 COCKPIT LIGHTING.....AS REQUIRED
 ANN LIGHT TEST.....PERFORM
 EMERGENCY EXIT LIGHT SELECTOR..... AS REQUIRED
 ECAM CONTROL PANEL.....SELECT "PRESS"
 OUTFLOW VALVE.....VERIFY OPEN
 CABIN PRESS MODE PUSHBUTTON..... MAN (MANUAL)
 ECAM CONTROL PANEL..... SELECT "BLEED"
 BLEED STATUS.....VERIFY BEFORE APU BLEED ON
 APU BLEED PUSH BUTTON.....ON
 FUEL ON BOARD..... 7,000 LBS RECOMMENDED
 ECAM CONTROL PANEL.....SELECT "ENG"
 FADEC GND PWR.....ON
 ENGINE OIL QUANTITY – V2500..... 11 QTS MINIMUM
 ENGINE OIL QUANTITY – PW1100G..... 14 QTS MINIMUM
 OTHER ENG INDICATIONS.....NORMAL
 FADEC GND PWR.....OFF
 SPEED BRAKE LEVER.....RETRACTED / DISARMED
 FLAP LEVER POSITION.....CORRESPOND W/ FLAP POSITION
 RUDDER TRIM.....RESET / CHECK
 ECAM CONTROL.....SELECT "HYD"
 HYDRAULIC PAGE.....VERIFY CORRECT LEVEL / NO FAULTS
 ECAM CONTROL.....DE-SELECT "HYD"
 PARKING BRAKE.....ON
 BEACON.....ON
 NAV LIGHTS.....ON
 OTHER EXTERIOR LIGHTS.....AS REQUIRED
 ELEC HYD PUMP SWITCHAS REQUIRED
 FLIGHT DECK RESPONSIBILITIES.....DISCUSS & REVIEW

PROCEED TO BEFORE PUSHBACK IF TAXIING (PG. 4)

OR

BEFORE ENGINE START IF RUN-UP ONLY (PG. 5 - V2500)

(PG. 14 - PW1100G)

BEFORE PUSHBACK

NOTE 1: DISREGARD A/SKID & N/W STRG OFF WARNING

**NOTE 2: USE SPIRIT MAINTENANCE AND A/C TAIL NUMBER
AS CALL SIGN**

COCKPIT SEATSADJUST
SEAT BELTS WITH HARNESS.....ON
RUDDER PEDALS.....ADJUST
A/SKID & N/W STEERING SWITCH.....OFF
VERIFY WHEEL CHOCKS.....REMOVED
EXTERNAL POWER.....DISCONNECTED
JETWAY.....REMOVED
ATC / GROUND CONTROL CLEARANCE.....OBTAIN
GROUND CREW.....INFORM
PARKING BRAKE.....OFF

PROCEED TO AFTER PUSHBACK

AFTER PUSHBACK

PARKING BRAKE.....ON
CLEAR TO DISCONNECT AND SHOW THE PIN.....VERIFY
A/SKID & N/W STEERING SWITCH.....ON

**PROCEED TO BEFORE ENGINE START (PG. 5 - V2500)
(PG. 14 - PW1100G)**

BEFORE ENGINE START (V2500)

ENG FIRE PUSHBUTTONS.....IN / GUARDED
ENG 1 (2) FIRE TEST.....PERFORM
THRUST LEVERS.....IDLE
BEACON.....ON
FUEL PUMPS.....ON
GROUND CLEARANCE (CALL RAMP IF REQUIRED).....OBTAIN

STARTER DUTY-CYCLE LIMITATIONS (V2500)

**DO NOT ENGAGE STARTER AGAIN WITH ENGINE MOTORING
ABOVE 10% N2 – DOING SO WILL DAMAGE THE
STARTER SHAFT**

A) THREE ENGINE STARTING ATTEMPTS – STARTUP TO IDLE

- 1ST START ATTEMPT – IF FAIL, 15 SEC COOL DOWN
- 2ND START ATTEMPT – IF FAIL, 15 SEC COOL DOWN
- 3RD START ATTEMPT – IF FAIL, 30 MIN COOL DOWN

B) THREE ENGINE CRANKING SESSIONS – CRANKING ONLY

- 2 MINUTE CRANK – 15 SECOND COOL DOWN
AFTER N2 = 0%
- 2 MINUTE CRANK – 15 SECOND COOL DOWN
AFTER N2 = 0 %
- 1 MINUTE CRANK – 30 MINUTE COOL DOWN

C) ONE ENGINE CRANKING SESSION – CRANKING ONLY

- 4 MINUTE CRANK – 30 MIN COOL DOWN

PROCEED TO ENGINE START (PG. 6)

ENGINE AUTO START (V2500)

OBSERVE STARTER OPERATION GUIDELINES ON PAGE 5

**EEC STARTUP PROTECTIONS DISABLED AT 50% N2 WHEN
IN AUTOMATIC START – MONITOR ALL PARAMETERS**

ENGINE MODE SELECTOR.....IGN START
AIR PRESSURE AT START VALVE.....BETWEEN 30 & 40 PSI
ENGINE MASTER SWITCH 1(2).....ON
CHRONO.....START WHEN VALVE OPENS
N2 INDICATION.....OBSERVE AN INCREASE
OIL PRESSURE..... OBSERVE AN INCREASE
N1 INDICATION.....OBSERVE AN INCREASE AT 25 - 30 SECs
FUEL FLOW.....OBSERVE AN INCREASE AT 24 - 26% N2
ENGINE 1(2) IGNITER A or B..... OBSERVE AT 30 SECs
EGT RISE.....OBSERVE AN INCREASE (MAX 635°)
IGNITION / STARTER CUT-OUT.....OBSERVE AT 43% N2

AT IDLE CHECK FOR:

- EPR = 1.01
- N1 = 23%
- EGT = 410° C
- N2 = 58%
- FF = 880 LBS / HR

**NOTE: THESE VALUES ARE APPROXIMATE AND CAN VARY DUE TO
AGE OF ENGINE**

PROCEED TO AFTER ENGINE START (PG. 10)

ENGINE MANUAL START (V2500)

OBSERVE STARTER OPERATION GUIDELINES ON PAGE 5
EEC STARTUP PROTECTIONS DISABLED ENTIRELY WHEN IN
MANUAL STARTING MODE – MONITOR ALL PARAMETERS

ABORT START IF ANY OF THE FOLLOWING OCCUR

- The Oil pressure does not increase
- No N1 indication when N2 is greater than 34%
- Ignition System and/or Fuel Flow does not come online
- No increase in EGT 20 seconds after Fuel Flow increase
- More than 90 seconds after fuel flow to achieve Idle N2
- Fuel Flow or Ignition is stopped
- EGT approaches the startup limit / Loss of EGT indication
- Sluggish N2 acceleration with a fast increase in EGT
- Abnormal vibrations detected / Engine surge observed

ABORTED START MUST BE FOLLOWED UP BY A DRY-MOTOR
FOR 30 SECONDS OR UNTIL EGT IS LESS THAN 250° C

ENGINE MODE SELECTOR.....IGN START
AIR PRESSURE AT START VALVE.....BETWEEN 30 & 40 PSI
ENGINE MANUAL START PUSHBUTTON 1(2).....ON
CHRONO.....START WHEN VALVE OPENS
ENGINE DRY CRANK.....30 SECONDS
OIL PRESSURE.....OBSERVE AN INCREASE
ENGINE MASTER SWITCH 1(2).....ON
FUEL FLOW.....OBSERVE AN INCREASE
ENGINE 1(2) IGNITER A+B.....ON
EGT RISE.....OBSERVE AN INCREASE (MAX 635°)
IGNITION / STARTER CUT-OUT.....OBSERVE AT 43% N2
ENGINE MANUAL START PUSHBUTTON 1(2)OFF

AT IDLE CHECK FOR:

- EPR = 1.01
- N1 = 23%
- EGT = 410° C
- N2 = 58%
- FF = 880 LBS / HR

NOTE: THESE VALUES ARE APPROXIMATE AND CAN VARY DUE TO
AGE OF ENGINE

PROCEED TO AFTER ENGINE START (PG. 10)

ENGINE CROSSBLEED START (V2500)

OBSERVE STARTER OPERATION GUIDELINES ON PAGE 5

ENGINE MODE SELECTORIGN START
PACK 1 & 2.....OFF
APU BLEED.....OFF
X-BLEED VALVE SELECTOR.....OPEN
ENGINE BLEED (RUNNING ENGINE).....ON
ENGINE BLEED (OTHER ENGINE).....OFF
AIR PRESSURE AT START VALVE.....BETWEEN 30 & 40 PSI

NOTE: IT MAY BE NEEDED TO INCREASE POWER ON THE
OPPOSITE ENGINE TO OBTAIN 30 TO 40 PSI

GROUND CLEARANCE (CALL RAMP / ATC IF REQUIRED).....OBTAIN
ENGINE MASTER SWITCH 1(2).....ON
CHRONO.....START WHEN VALVE OPENS
N2 INDICATION.....OBSERVE AN INCREASE
OIL PRESSURE.....OBSERVE AN INCREASE
N1 INDICATION.....OBSERVE AT 25 – 30 SECs
FUEL FLOW.....OBSERVE AN INCREASE AT 24 - 26% N2 RPM
ENGINE 1(2) IGNITER A or B.....OBSERVE AT 30 SECs
EGT RISE.....OBSERVE AN INCREASE (MAX 635°)
IGNITION / STARTER CUT-OUT.....OBSERVE AT 43% N2
THRUST LEVERSIDLE
X-BLEED VALVE SELECTOR.....AUTO
ENGINE BLEED (STARTED ENGINE).....ON

AT IDLE CHECK FOR:

- EPR = 1.01
- N1 = 23%
- EGT = 410° C
- N2 = 58%
- FF = 880 LBS / HR

NOTE: THESE VALUES ARE APPROXIMATE AND CAN VARY
DUE TO AGE OF ENGINE

PROCEED TO AFTER ENGINE START (PG. 10)

ENGINE START WITH EXT PNEU POWER

(V2500)

OBSERVE STARTER OPERATION GUIDELINES ON PAGE 5

ECAM CONTROL PANEL.....SELECT "BLEED"
X-BLEED VALVE SELECTOR.....AS REQUIRED
APU BLEED PUSHBUTTON.....OFF
PACKS 1 & 2.....OFF
ENGINE BLEED.....OFF
EXT PNEUMATIC POWER.....ESTABLISH
GROUND CLEARANCE.....OBTAIN
BEACON.....ON
ENGINE MODE SELECTOR.....IGN START
ENGINE MASTER SWITCH 1(2).....ON
CHRONO.....START WHEN VALVE OPENS
N2 INDICATION.....OBSERVE AN INCREASE
OIL PRESSURE.....OBSERVE AN INCREASE
N1 INDICATION.....OBSERVE AT 25 – 30 SECs
FUEL FLOW.....OBSERVE AN INCREASE AT 24 - 26% N2 RPM
ENGINE 1(2) IGNITER A or B.....OBSERVE AT 30 SECs
EGT RISE.....OBSERVE AN INCREASE (MAX 635°)
IGNITION / STARTER CUT-OUT.....OBSERVE AT 43% N2

AT IDLE CHECK FOR:

- EPR = 1.01
- N1 = 23%
- EGT = 410° C
- N2 = 58%
- FF = 880 LBS / HR

NOTE: THESE VALUES ARE APPROXIMATE AND CAN VARY DUE TO AGE OF ENGINE

PROCEED WITH CROSSBLEED ENGINE START (PG. 8)
OR
PROCEED WITH AFTER ENGINE START (PG. 10)

AFTER ENGINE START (V2500)

ENGINE MODE SELECTOR..... NORM
APU BLEED PUSHBUTTON.....AS REQUIRED
ANTI-ICE...(BELOW 40° F & VISIBLE MOISTURE)AS REQUIRED
X-BLEED SELECTOR..... AUTO
PACKS 1 & 2..... AS REQUIRED
PARKING BRAKE PRESSURE CHECK

PROCEED TO TAXI (PG. 23)
OR
ENGINE SHUT DOWN (PG. 11)

ENGINE SHUTDOWN (V2500)

**OBEY 3 MINUTE MINIMUM IDLE-RUN TIME
BEFORE ENGINE SHUT DOWN**

**OBEY 15 MINUTE MINIMUM IDLE-RUN TIME IF OPERATED AT
MORE THAN 1.33 EPR FOR 5 MINUTES OR LONGER**

**MONITOR ALL PARAMETERS WHILE ENGINE
IS SPOOLING DOWN**

THRUST LEVERS.....	IDLE
PARKING BRAKE.....	ON
ANTI-ICE.....	OFF
APU / EXT POWER.....	AS REQUIRED
GROUND CONTACT.....	AS REQUIRED
ENGINE MASTER SWITCH 1 (2).....	OFF
YELLOW ELEC PUMP (IF SINGLE ENGINE TAXI).....	OFF

PROCEED WITH LEAVING THE AIRCRAFT (PG. 26)

ENGINE DRY MOTORING (V2500)

OBSERVE STARTER OPERATION GUIDELINES ON PAGE 5

MONITOR ALL PARAMETERS

ENGINE HPSOV C/B (ENG #1 A01) (ENG #2 A02).....PULL
ECAM CONTROL PANEL.....SELECT "FUEL"
FUEL PAGE.....VERIFY LP FUEL VALVE 1(2) INLINE / OPEN
FUEL PUMPSON
PACKS 1 & 2.....OFF
ECAM CONTROL PANEL.....SELECT "ENG"
GROUND CLEARANCE.....OBTAIN
ENGINE MODE SELECTOR.....CRANK
ENG MANUAL START PUSHBUTTON 1(2).....ON
CHRONO.....START WHEN VALVE OPENS

WHEN DRY-MOTORING COMPLETE:

ENGINE MANUAL START PUSHBUTTON 1(2).....OFF
ENGINE MODE SELECTOR.....NORM
ENGINE 1(2) HPSOV C/B (ENG #1 A01) (ENG#2 A02).....RESET
ECAM CONTROL PANEL.....SELECT "FUEL"
FUEL PAGE.....VERIFY LP FUEL VALVE 1(2) CLOSED
ECAM CONTROL PANEL.....DE-SELECT "FUEL"
FUEL PUMPS.....OFF
PACKS 1 & 2.....AS REQUIRED

Verify LP fuel valve 1(2) OPEN fault is NOT on upper ECAM

ENGINE DRY-MOTORING CHECKLIST COMPLETE

ENGINE WET MOTORING (V2500)

2 CHRONOS ARE NEEDED FOR THE WET MOTOR PROCESS:

1ST TO MONITOR STARTER DUTY TIME

2ND TO MONITOR ACTIVE FUEL-FLOW

ENG IGNITION C/B (ENG #1 A03 / P39 / P41) (ENG #2 A03 / P40 / P42).PULL
FUEL PUMPS.....ON
PACKS 1 & 2.....OFF
ENG MODE SELECTOR.....CRANK
GROUND CLEARANCE.....OBTAIN
ENG MANUAL START PUSHBUTTON 1(2).....ON
1st CHRONO.....START WHEN VALVE OPENS

WHEN N2 IS GREATER THAN 15%:

ENGINE MASTER SWITCH 1(2).....ON
2nd CHRONO.....START WHEN FUEL FLOW ON

ON ECAM CHECK:

- FUEL FLOW
- OIL PRESSURE / QUANTITY

AFTER 20 SECONDS ON SECOND CHRONO:

ENGINE MASTER SWITCH 1(2).....OFF
FUEL FLOW.....OBSERVE IMMEDIATE DECREASE

**THE EEC RE-ENGAGES STARTER VALVE AUTOMATICALLY
WHEN N2 SPEED IS BELOW 10% FOR ENGINE FUEL DRYING**

1ST CHRONO.....MONITOR STARTER DUTY LIMITS
90 SECONDS ON 1ST CHRONO.....MAN START P/BS 1(2) OFF
ENGINE MODE SELECTOR.....NORM
ENGINE 1(2) IGNITION C/B'S.....RESET
FUEL PUMPS.....OFF
PACKS 1 & 2.....AS REQUIRED
1ST CHRONO & 2ND CHRONO.....RESET

ENGINE WET-MOTORING CHECKLIST COMPLETE

BEFORE ENGINE START (PW1100G)

ENG FIRE PUSHBUTTON.....IN / GUARDED
ENG 1 (2) FIRE TEST.....PERFORM
THRUST LEVERS.....IDLE
BEACON.....ON
FUEL PUMPSON
DUAL COOLING PUSHBUTTON.....OFF
GROUND CLEARANCE (CALL RAMP IF REQUIRED).....OBTAIN

STARTER DUTY-CYCLE LIMITATIONS (PW1100G)

**DO NOT ENGAGE STARTER AGAIN WITH ENGINE MOTORING
ABOVE 1 % N2 – MUST REACH 0% N2**

**EEC WILL COMMAND STARTER AIR VALVE CLOSED IF DUTY
CYCLE IS EXCEEDED**

STARTER DUTY CYCLE:

- 3 START ATTEMPTS - 35 SECONDS COOLING PERIOD BETWEEN EACH, FOLLOWED BY A 15 MINUTE COOL DOWN
- 1 CONTINUOUS CRANK UP TO 15 MINUTES, FOLLOWED BY A 15 MINUTE COOL DOWN

ENGINE BOWED ROTOR PROTECTION (PW1100G)

COOLING TIME IS DISPLAYED ON UPPER ECAM IF EEC DETERMINES ENGINE MOTORING IS REQUIRED FOR BOWED ROTOR PROTECTION. ENGINE MOTORS FOR DISPLAYED TIME BEFORE START SEQUENCE BEGINS
(APPROX 8 - 10% N2)

PROCEED TO ENGINE START (PG. 15)

ENGINE AUTO START (PW1100G)

**OBSERVE STARTER OPERATION AND ENGINE BOWED
ROTOR PROTECTION GUIDELINES ON PAGE 14**

**EEC STARTUP PROTECTIONS ARE ENABLED DURING
AUTOMATIC START**

MONITOR ALL PARAMETERS

ENGINE MODE SELECTOR.....IGN START
AIR PRESSURE AT START VALVE.....BETWEEN 30 & 40 PSI
ENGINE MASTER SWITCH 1 (2).....ON
ENGINE START VALVE 1 (2).....OPENED
N2 INDICATION.....OBSERVE AN INCREASE
OIL PRESSURE.....OBSERVE AN INCREASE
ENGINE 1 (2) IGNITER A or B.....AT 18% N2
FUEL FLOW.....OBSERVE AN INCREASE
EGT RISE.....OBSERVE AN INCREASE (MAX 1084°)
IGNITION / STARTER CUT-OUT.....OBSERVE AT 55% N2

AT IDLE CHECK FOR:

- N1 = 19%
- EGT = 440° C
- N2 = 59%
- FF = 600 LBS / HR

**NOTE: THESE VALUES ARE APPROXIMATE AND CAN VARY DUE TO
AGE OF ENGINE**

PROCEED TO AFTER ENGINE START (PG. 19)

ENGINE MANUAL START (PW1100G)

OBSERVE STARTER OPERATION AND ENGINE BOWED ROTOR PROTECTION GUIDELINES ON PAGE 14

EEC STARTUP PROTECTIONS DISABLED DURING MANUAL STARTING MODE – MONITOR ALL PARAMETERS AND ABORT START IF ANY OF THE FOLLOWING OCCUR:

- The oil pressure does not increase
- N1 does not increase when N2 is greater than 48%
- Ignition system and/or Fuel Flow does not come online
- No increase in EGT 20 seconds after Fuel Flow increase
- More than 90 seconds after fuel flow to achieve Idle N2
- Fuel or Ignition is accidentally stopped
- Loss of EGT indication / EGT approaches startup limit
- Sluggish N2 acceleration with a fast increase in EGT
- Abnormal vibrations detected / Engine surge observed

ABORTED START MUST BE FOLLOWED UP BY A DRY-MOTOR FOR 30 SECONDS OR UNTIL EGT IS LESS THAN 250°C

ENGINE MODE SELECTOR.....IGN START
AIR PRESSURE AT START VALVE.....BETWEEN 30 & 40 PSI
ENGINE MANUAL START PUSHBUTTONS 1(2).....ON
CHRONO.....START WHEN START VALVE OPENS
ENGINE DRY CRANK.....30+ SECONDS
COOLING TIME (IF REQUIRED).....MONITOR
OIL PRESSURE.....OBSERVE AN INCREASE
N2 INDICATION.....MAX MOTORING (MIN 18%)
ENGINE MASTER SWITCH 1(2).....ON
FUEL FLOW.....OBSERVE AN INCREASE
ENGINE 1 (2) IGNITER A+B.....ON
EGT RISE.....OBSERVE AN INCREASE (MAX 1084°)
IGNITION / STARTER CUT-OUT.....OBSERVE AT 55% N2
ENGINE MANUAL START PUSHBUTTONS 1(2)OFF

AT IDLE CHECK FOR:

- N1 = 19%
- EGT = 440° C
- N2 = 59%
- FF = 600 LBS / HR

NOTE: THESE VALUES ARE APPROXIMATE AND CAN VARY DUE TO AGE OF ENGINE

PROCEED TO AFTER ENGINE START (PG. 19)

ENGINE CROSSBLEED START (PW1100G)

OBSERVE STARTER OPERATION AND ENGINE BOWED ROTOR PROTECTION GUIDELINES ON PAGE 14

ENGINE MODE SELECTOR.....IGN START
PACK 1 & 2.....OFF
APU BLEED.....OFF
X-BLEED VALVE SELECTOR.....OPEN
ENGINE BLEED (RUNNING ENGINE).....ON
ENGINE BLEED (OTHER ENGINE).....OFF
AIR PRESSURE AT START VALVE.....BETWEEN 30 & 40 PSI

NOTE: IT MAY BE NEEDED TO INCREASE POWER ON THE
OPPOSITE ENGINE TO OBTAIN 30 TO 40 PSI

GROUND CLEARANCE (CALL RAMP / ATC IF REQUIRED).....OBTAIN
ENGINE MASTER SWITCH 1 (2).....ON
CHRONO.....START WHEN VALVE OPENS
N2 INDICATION.....OBSERVE AN INCREASE
OIL PRESSURE.....OBSERVE AN INCREASE
FUEL FLOW.....OBSERVE AN INCREASE
ENGINE 1(2) IGNITER A or B.....AT 18% N2
EGT RISE.....OBSERVE AN INCREASE (MAX 1084°)
IGNITION / STARTER CUT-OUT.....OBSERVE AT 55% N2
THRUST LEVERS.....IDLE
X-BLEED VALVE SELECTOR.....AUTO
ENGINE BLEED (STARTED ENGINE).....ON

AT IDLE CHECK FOR:

- N1 = 19%
- EGT = 440° C
- N2 = 59%
- FF = 600 LBS / HR

NOTE: THESE VALUES ARE APPROXIMATE AND CAN VARY
DUE TO AGE OF ENGINE

PROCEED TO AFTER ENGINE START (PG. 19)

ENGINE START WITH EXT PNEU POWER

(PW1100G)

**OBSERVE STARTER OPERATION AND ENGINE BOWED
ROTOR PROTECTION GUIDELINES ON PAGE 14**

ECAM CONTROL PANELSELECT "BLEED"
X-BLEED VALVE SELECTOR.....AS REQUIRED
APU BLEED PUSHBUTTON.....OFF
PACKS 1 & 2.....OFF
ENGINE BLEED.....OFF
EXT PNEUMATIC POWER.....ESTABLISH
GROUND CLEARANCE.....OBTAIN
BEACON.....ON
ENGINE MODE SELECTOR.....IGN START
ENGINE MASTER SWITCH 1 (2).....ON
N2 INDICATION.....OBSERVE AN INCREASE
OIL PRESSURE.....OBSERVE AN INCREASE
FUEL FLOW.....OBSERVE AN INCREASE
ENGINE 1(2) IGNITER A or B.....AT 18% N2
EGT RISE.....OBSERVE AN INCREASE (MAX 1084°)
IGNITION / STARTER CUT-OUT.....OBSERVE AT 55% N2

AT IDLE CHECK FOR:

- N1 = 19%
- EGT = 440° C
- N2 = 59%
- FF = 600 LBS / HR

**NOTE: THESE VALUES ARE APPROXIMATE AND CAN VARY DUE TO
AGE OF ENGINE**

**PROCEED WITH CROSSBLEED
ENGINE START (PG.17)
OR
PROCEED WITH AFTER
ENGINE START (PG. 19)**

AFTER ENGINE START (PW1100G)

ENGINE MODE SELECTOR.....NORM
APU BLEED PUSHBUTTON.....AS REQUIRED
ANTI-ICE....(BELOW 40° F & VISIBLE MOISTURE).....AS REQUIRED
X-BLEED SELECTOR.....AUTO
PACKS 1 & 2.....AS REQUIRED
PARKING BRAKE PRESSURE.....CHECK

PROCEED TO TAXI (PG. 23)
OR
ENGINE SHUT DOWN (PG. 20)

ENGINE SHUTDOWN (PW1100G)

**OBEY 10 MINUTE MINIMUM IDLE-RUN TIME
BEFORE ENGINE SHUT DOWN**

**MONITOR ALL PARAMETERS WHILE ENGINE
IS SPOOLING DOWN**

THRUST LEVERS.....	IDLE
PARKING BRAKE.....	ON
ANTI-ICE.....	OFF
APU / EXT POWER.....	AS REQUIRED
GROUND CONTACT.....	AS REQUIRED
ENGINE MASTER SWITCH 1 (2).....	OFF
YELLOW ELEC PUMP (IF SINGLE ENGINE TAXI).....	OFF

PROCEED WITH LEAVING THE AIRCRAFT (PG. 26)

ENGINE DRY MOTORING (PW1100G)

OBSERVE STARTER OPERATION GUIDELINES ON PAGE 14

MONITOR ALL PARAMETERS

ENGINE HPSOV C/B (ENG #1 A01) (ENG #2 A02).....PULL
ECAM CONTROL PANEL.....SELECT "FUEL"
FUEL PAGE.....VERIFY LP FUEL VALVE 1(2) INLINE / OPEN
FUEL PUMPSON
PACKS 1 & 2.....OFF
ECAM CONTROL PANEL.....SELECT "ENG"
GROUND CLEARANCE.....OBTAIN
ENGINE MODE SELECTOR.....CRANK
ENG MANUAL START PUSHBUTTON 1(2).....ON
CHRONO.....START WHEN VALVE OPENS

WHEN DRY-MOTORING COMPLETE:

ENGINE MANUAL START PUSHBUTTON 1(2).....OFF
ENGINE MODE SELECTOR.....NORM
ENGINE HPSOV C/B (ENG #1 A01) (ENG #2 A02).....RESET
ECAM CONTROL PANEL.....SELECT "FUEL"
FUEL PAGE.....VERIFY LP FUEL VALVE 1(2) CLOSED
ECAM CONTROL PANEL.....DE-SELECT "FUEL"
FUEL PUMPS.....OFF
PACKS 1 & 2.....AS REQUIRED

Verify LP fuel valve 1(2) OPEN fault is NOT on upper ECAM

ENGINE DRY-MOTORING CHECKLIST COMPLETE

ENGINE WET MOTORING (PW1100G)

2 CHRONOS ARE NEEDED FOR THE WET MOTOR PROCESS:

1ST TO MONITOR STARTER DUTY TIME

2ND TO MONITOR ACTIVE FUEL-FLOW

ENG IGNITION C/B (#1 A03 / P41) (#2 A03 / P42) PULL
FUEL PUMPS ON
PACKS 1 & 2 OFF
ENG MODE SELECTOR CRANK
GROUND CLEARANCE OBTAIN
ENG MANUAL START PUSHBUTTON 1(2) ON
1st CHRONO START WHEN VALVE OPENS

WHEN N2 STABILIZES:

ENGINE MASTER SWITCH 1(2) ON
2nd CHRONO START WHEN FUEL FLOW ON

ON ECAM CHECK:

- FUEL FLOW
- OIL PRESSURE / QUANTITY

AFTER 15 SECONDS ON SECOND CHRONO:

ENGINE MASTER SWITCH 1(2) ... OFF
FUEL FLOW OBSERVE IMMEDIATE DECREASE
2nd CHRONO RESTART WHEN FUEL FLOW SHOWS ZERO

**CONTINUE TO OPERATE STARTER FOR 30 SECONDS
TO REMOVE ALL FUEL VAPORS**

1ST CHRONO MONITOR STARTER DUTY LIMITS
30 SECONDS ON 2ND CHRONO MANUAL P/BS 1(2) OFF
ENGINE MODE SELECTOR NORM
ENGINE 1(2) IGNITION C/B'S RESET
FUEL PUMPS OFF
PACKS 1 & 2 AS REQUIRED
1ST CHRONO & 2ND CHRONO RESET

ENGINE WET-MOTORING CHECKLIST COMPLETE

TAXI

**IF BRAKES FAIL DURING GROUND OPERATION,
IMMEDIATELY SET A/SKID & N/W STRG SWITCH OFF AND
OPERATE BRAKE PEDALS TO STOP AIRCRAFT**

**APPROXIMATELY 7 BRAKE APPLICATIONS AVAILABLE WITH
EMERGENCY BRAKE ACCUMULATOR
IN EMERGENCY BRAKING SITUATIONS, THRUST
REVERSERS CAN BE USED TO SLOW AIRCRAFT IF NEEDED
PRIOR TO SETTING PARKING BRAKE**

**IN EXTREME EMERGENCIES AND ONLY IF PEDALS ARE
INEFFECTIVE WITH A/SKID SELECTED OFF, AIRCRAFT MAY
BE STOPPED USING PARKING BRAKE – NOTE: IMMEDIATE
FULL BRAKE PEDAL APPLICATION WILL OCCUR**

**APU MUST BE RUNNING FOR SINGLE ENGINE TAXI. GOOD
JUDGMENT MUST BE EXERCISED. USE CAUTION TO AVOID
EXCESSIVE GENERATION OF JET BLAST. SINGLE ENGINE
TAXI NOT PERMITTED IN ICE & SNOW.**

**PTU (IF SINGLE ENGINE TAXI).....AUTO
YELLOW ELEC PUMP (IF SINGLE ENGINE TAXI).....ON
ECAM CONTROL PANELSELECT “DOORS”
ECAM DOOR PAGE..... DOORS CLOSED
ECAM CONTROL PANELDE-SELECT “DOORS”
NOSE LIGHT.....TAXI
OTHER LIGHTS.....AS REQUIRED
ATC / GROUND CONTROL CLEARANCE.....OBTAIN
PARKING BRAKE.....OFF
BRAKE EFFICIENCY.....CHECK
STEERING EFFICIENCY.....CHECK**

FOLLOW ATC INSTRUCTION & PROCEED WITH TAXI

PRE-TOWING (WITHOUT ENGINE RUN)

NOTE 1: C/W CONTROL SAFETY CHECKLIST

NOTE 2: MAX TOWING SPEED 6 MPH WITH DOORS FULLY OPEN

NOTE 3: DO NOT TOW / MOVE AIRCRAFT WITH COWLS OPEN

**NOTE 4: WITH DOORS CLOSED AND LOCKED, MAXIMUM
TOWING SPEED: TOWBAR & TUG 15 MPH
TOWBARLESS TUG 20 MPH**

NOTE 5: DISREGARD A/SKID & N/W STRG OFF WARNING

YELLOW BRAKE PRESSUREVERIFY 3000PSI
A/SKID & N/W SWITCHOFF
BYPASS PIN.....INSTALL
TOW BAR AND TUG.....CONNECTED
CHOCKS.....REMOVED
EXTERNAL POWER.....DISCONNECT
BEACON.....ON
GROUND CREW.....INFORM
PARKING BRAKE.....OFF

AIRCRAFT READY TO TOW

POST-TOWING (WITHOUT ENGINE RUN)

YELLOW BRAKE PRESSURE.....VERIFY 3000 PSI
PARKING BRAKE.....ON
CHOCKS.....INSTALL
BEACON.....OFF
TOW BAR AND TUG..... DISCONNECTED
BYPASS PIN.....REMOVED
A/SKID & N/W SWITCH.....ON

PROCEED TO LEAVING THE AIRCRAFT (PG. 26)

PRE-TOWING (WITH BATT PWR ONLY)

NOTE 1: C/W CONTROL SAFETY CHECKLIST

NOTE 2: MAX TOWING SPEED 6 MPH WITH DOORS FULLY OPEN

NOTE 3: DO NOT TOW / MOVE AIRCRAFT WITH COWLS OPEN

NOTE 4: MAX TOWING TIME IS 1 HR WITH BATTERY POWER

NOTE 5: VHF 1 ONLY AVAILABLE ON BATTERY POWER

NOTE 6: WHEN TOWING IS COMPLETE, ATTACH GPU & BRING BATTERIES BACK TO FULL POWER

BAT PUSHBUTTONS.....ON
YELLOW BRAKE PRESSUREVERIFY 3000 PSI
RMP 1.....CHECK ON / FREQ SET
ACP 1VHF 1
BYPASS PIN.....INSTALL
TOW BAR AND PUSHBACK.....CONNECTED
CHOCKS.....REMOVED
EXTERNAL POWER.....DISCONNECT
GROUND CREW.....INFORM
PARKING BRAKE.....OFF

AIRCRAFT READY TO TOW

POST-TOWING (WITH BATT PWR ONLY)

YELLOW BRAKE PRESSURE.....VERIFY APPROX 2100 PSI
PARKING BRAKE.....ON
CHOCKS.....INSTALL
TOW BAR AND TUG..... DISCONNECTED
BYPASS PIN.....REMOVED
BAT PUSHBUTTONS.....OFF

PROCEED TO LEAVING THE AIRCRAFT (PG. 26)

LEAVING THE AIRCRAFT

WHEEL CHOCKS IN PLACE
YELLOW BRAKE PRESSURE VERIFY 3000 PSI
PARKING BRAKE (IF BRAKE TEMPS BELOW 300°C) ON
(IF BRAKE TEMPS ABOVE 300°C) OFF
CREW O2 SUPPLY OFF
ADIRS ROTARY SELECTORS OFF
EXTERIOR LIGHTS OFF
EMERGENCY EXIT LIGHT OFF
CABIN PRESS MODE PUSHBUTTON AUTO
EXT POWER AS REQUIRED
FUEL PUMPS OFF
APU BLEED PUSHBUTTON OFF
MCDU FULL DIM
APU MASTER SWITCH OFF

AFTER APU SHUTDOWN:

ECAM FULL DIM
RMP 1 & 2 OFF
ACP 1 & 2 OFF
BAT PUSHBUTTONS OFF WHEN APU FLAP CLOSES
EXT POWER OFF

**YOU MUST WAIT 90 SECONDS BEFORE TURNING OFF
BATTERY PUSHBUTTONS TO ALLOW PROPER TIME
FOR APU INLET TO CLOSE**

MECHANICS A320 FAMILY EMERGENCY

QUICK REFERENCE CHECKLIST

ENGINE FIRE ON GROUND

THRUST LEVERS.....IDLE
AIRCRAFT.....STOP / HOLD POSITION
PARKING BRAKE.....ON
MASTER WARNING PUSHBUTTON.....PRESS
ENG MASTER SWITCH (AFFECTED ENGINE)OFF
ENG FIRE PUSHBUTTON (AFFECTED ENGINE).....RELEASE
WAIT 10 SECs FOR FIRE TO EXTINGUISH.....OBSERVE

IF ENGINE FIRE CONTINUES:

AGENT 1.....DISCH
ATC / GROUND CONTROL.....NOTIFY
WAIT 30 SECs FOR FIRE TO EXTINGUISH.....OBSERVE

IF ENGINE FIRE CONTINUES:

AGENT 2.....DISCH
WAIT 30 SECs FOR FIRE TO EXTINGUISH.....OBSERVE

IF ENGINE FIRE IS UNEXTINGUISHABLE, AND AIRCRAFT EVACUATION REQUIRED:

ATC / GROUND CONTROL..... NOTIFY
ENGINE MASTER SWITCH (OPPOSITE SIDE).....OFF
FUEL PUMPS.....OFF
APU MASTER SWITCH.....OFF
BAT PUSHBUTTONS 1+2 (IF TIME PERMITS).....OFF
EVACUATION PROCEDURES.....INITIATE

CHECKLIST COMPLETE

MECHANICS A320 FAMILY EMERGENCY

QUICK REFERENCE CHECKLIST

ENGINE TAILPIPE FIRE

THRUST LEVERS.....IDLE
AIRCRAFT.....STOP / HOLD POSITION
PARKING BRAKE.....ON
ENG MASTER SWITCH (AFFECTED ENG).....OFF
ATC / GROUND CONTROL.....NOTIFY

IF APU AVAILABLE:

APU BLEED.....ON
ENG MODE SELECTOR.....CRANK
ENG MAN START PUSHBUTTON (AFFECTED ENG).....ON

AFTER CONFIRMATION OF FIRE EXTINGUISHED:

ENG MAN START PUSHBUTTON (AFFECTED ENG).....OFF

IF APU NOT AVAILABLE:

X-BLEED VALVE SELECTOR.....OPEN
ENGINE BLEED (RUNNING ENGINE).....VERIFY ON
ENG MODE SELECTOR.....CRANK
ENG MAN START PUSHBUTTON (AFFECTED ENG).....ON

AFTER CONFIRMATION OF FIRE EXTINGUISHED:

ENG MAN START PUSHBUTTON (AFFECTED ENG).....OFF

***IF FIRE WILL NOT EXTINGUISH WITH MOTORING
ENGINE, OR IF MOTORING IS NOT POSSIBLE:***

ENGINE FIRE 1(2) PUSHBUTTON.....RELEASE
ECAM CONTROL PANEL.....SELECT "FUEL"
FUEL PAGE.....VERIFY LP FUEL VALVE 1(2) CLOSED
GROUND.....EXTINGUISH FIRE WITH GROUND EQUIPMENT

CHECKLIST COMPLETE

MECHANICS A320 FAMILY EMERGENCY

QUICK REFERENCE CHECKLIST

APU FIRE

EVEN THOUGH AUTOMATIC SYSTEM WILL OPERATE IN
CASE OF AN APU FIRE ON GROUND, ALL ACTIONS
MUST BE PERFORMED

THRUST LEVERS.....IDLE
AIRCRAFT.....STOP / HOLD POSITION
PARKING BRAKE.....ON
MASTER WARNING PUSHBUTTON.....PRESS
APU FIRE PUSHBUTTON.....RELEASE
AGENT PUSHBUTTON.....PRESS
ATC / GROUND CONTROL..... NOTIFY

IF APU FIRE CONTIUES:

ATC / GROUND CONTROL..... NOTIFY
ENGINE MASTER SWITCH (BOTH - ONE AT A TIME).....OFF
APU MASTER SWITCH.....OFF
EXT POWER PUSHBUTTON.....OFF
BATTERY PUSHBUTTONS.....OFF
EVACUTION PROCEDURES.....INITIATE

CHECKLIST COMPLETE

MECHANICS A320 FAMILY EMERGENCY

QUICK REFERENCE CHECKLIST

LOSS OF BRAKING

**IF BRAKES FAIL DURING GROUND OPERATION,
IMMEDIATELY SET A/SKID & N/W STRG SWITCH TO OFF AND
OPERATE BRAKE PEDALS TO STOP AIRCRAFT**

**APPROXIMATELY 7 BRAKE APPLICATIONS AVAILABLE WITH
EMERGENCY BRAKE ACCUMULATOR**

**IN EMERGENCY BRAKING SITUATIONS, THRUST
REVERSERS CAN BE USED TO SLOW AIRCRAFT IF NEEDED
PRIOR TO SETTING PARKING BRAKE**

**IN EXTREME EMERGENCIES AND ONLY IF PEDALS ARE
INEFFECTIVE WITH A/SKID SELECTED OFF, AIRCRAFT MAY
BE STOPPED USING PARKING BRAKE – NOTE: IMMEDIATE
FULL BRAKE PEDAL APPLICATION WILL OCCUR**

**BRAKE PEDALS.....RELEASE
A/SKID & N/W.....OFF
BRAKE PEDALS.....APPLY**

IF STILL NO BRAKING:

**THRUST REVERSERS.....AS REQUIRED
PARKING BRAKE.....ON**

CHECKLIST COMPLETE

MECHANICS A320 FAMILY EMERGENCY

QUICK REFERENCE CHECKLIST

SMOKE / AVIONICS SMOKE

THRUST LEVERS.....IDLE
AIRCRAFT.....STOP / HOLD POSITION
PARKING BRAKE.....ON
ATC / GROUND CONTROL..... NOTIFY
ENGINE MASTER SWITCH (BOTH - ONE AT A TIME).....OFF
ADIRS ROTARY SWITCHES.....OFF
APU BLEED PUSHBUTTONS.....OFF
APU GEN SWITCH.....OFF
APU MASTER SWITCH.....OFF
EXT POWER PUSHBUTTON.....OFF
BATTERY PUSHBUTTONS.....OFF

CHECKLIST COMPLETE

MECHANICS A320 FAMILY EMERGENCY

QUICK REFERENCE CHECKLIST

CARGO SMOKE

THRUST LEVERS.....IDLE
AIRCRAFT.....STOP / HOLD POSITION
PARKING BRAKE.....ON
MASTER WARNING PUSHBUTTON.....PRESS
AGENT (AFFECTED COMPARTMENT).....PRESS
ATC / GROUND CONTROL.....NOTIFY

**NOTE 1: FWD & AFT LIGHTS ILLUMINATE WHEN
DISCHARGE IS COMPLETE**

**NOTE 2: SMOKE WARNINGS WILL REMAIN ON UNTIL SMOKE
AND EXTINGUISHING AGENT ARE NO LONGER
PRESENT**

ENGINE MASTER SWITCH (BOTH – ONE AT A TIME).....OFF
ADIRS ROTARY SWITCHES.....OFF
APU BLEED PUSHBUTTON.....OFF
APU GEN SWITCH.....OFF
APU MASTER SWITCH.....OFF
EXT POWER PUSHBUTTON.....OFF
BATTERY PUSHBUTTONS.....OFF

CHECKLIST COMPLETE

SUPPLEMENTAL INFORMATION

MARSHALLING HAND SIGNALS

PAGE 36 - 40



AIRPORT LIGHTS, SIGNS, & MARKINGS

PAGE 41 - 43



FUTURE USE

PAGE 44 - 47

NOTES

PAGE 48 - 50




MARSHALLING HANDSIGNALS

AIRCRAFT ALIGNMENT



STRAIGHT AHEAD



TURN LEFT (PILOT'S POV)




TURN RIGHT (PILOT'S POV)



SLOW DOWN



STOP



ONLY TO BE USED WHEN HEADSET OR INTERPHONE IS INOPERABLE

MARSHALLING HANDSIGNALS

CHOCKS IN

WANDS ABOVE
HEAD & THEN
MOVE INWARD
IN A "JABBING"
MOTION



CHOCKS REMOVED

WANDS ABOVE
HEAD & THEN
MOVE OUTWARD
IN A "JABBING"
MOTION




GPU CONNECT

LEFT HAND
OPENED ABOVE
HEAD & MOVE
RIGHT HAND UP
TO CREATE A "T"




GPU DISCONNECT

LEFT & RIGHT
HANDS ABOVE
HEAD MAKING
A "T", THEN
MOVE HANDS
AWAY FROM
EACH OTHER




AIR START CONNECT



LEFT HAND OPENED ABOVE HEAD
& MOVE RIGHT HAND INWARDS
TO CREATE A "SIDEWAYS T"

AIR START DISCONNECT



LEFT & RIGHT HANDS ABOVE HEAD
MAKING A SIDEWAYS "T", MOVE
HANDS AWAY FROM EACH OTHER

ONLY TO BE USED WHEN HEADSET OR INTERPHONE IS INOPERABLE

MARSHALLING HANDSIGNALS

WING WALKER – LEFT WING CLEAR

RIGHT ARM
EXTENDED
UPWARDS,
WHILE LEFT
ARM POINTS
45° DOWN




WING WALKER – RIGHT WING CLEAR

LEFT ARM
EXTENDED
UPWARDS,
WHILE RIGHT
ARM POINTS
45° DOWN



TRANSFER TO NEXT MARSHALLER



ARMS STRAIGHT ABOVE HEAD WITH WANDS POINTING UP, THEN
DIRECT WANDS TO MARSHALLER TAKING OVER

HOLD

ARMS
EXTENDED
DOWN



END MARSHALLING

RIGHT
HAND TO
EYEBROW
& FORM A
SALUTE



ONLY TO BE USED WHEN HEADSET OR INTERPHONE IS INOPERABLE

MARSHALLING HANDSIGNALS

SHUT DOWN ENGINE

EXTEND LEFT
ARM UP AND
THEN USING
RIGHT HAND OR
WAND MAKE A
“SLICING
MOTION”
ACROSS THROAT



CLEAR TO START ENGINE

CIRCULAR
MOTION OF
RIGHT HAND
@ HEAD
LEVEL WITH
LEFT ARM
POINTING TO
ENGINE



BRAKES SET

WITH RIGHT
HAND, OPEN
PALM, THEN
CLOSE INTO FIST



BRAKES OFF

RIGHT
HAND
CLOSED
FIST, THEN
OPEN PALM



INTERPHONE

CUP EARS
WITH
HANDS



CLEAR FOR TAXI


RIGHT
WAND &
ARM
POINTED
UP & LEFT
POINTED
DOWN




ONLY TO BE USED WHEN HEADSET OR INTERPHONE IS INOPERABLE

EMERGENCY HANDSIGNALS

ENGINE FIRE




TAILPIPE FIRE



BRAKE FIRE



EMERGENCY STOP



ONLY TO BE USED WHEN HEADSET OR INTERPHONE IS INOPERABLE

AIRFIELD LIGHTING

TAXIWAY EDGE

BLUE LIGHT
INDICATES THE
EDGE OF THE
TAXIWAY



TAXIWAY CENTERLINE

GREEN
LIGHT
INDICATES
TAXIWAY
CENTERLINE
(NOT ON ALL
TAXIWAYS)



RUNWAY EDGE

WHITE OR
WHITE &
YELLOW LIGHT
INDICATE THE
EDGE OF THE
RUNWAY



RUNWAY CENTERLINE

RED, RED &
WHITE, OR
WHITE LIGHT
INDICATES
THE RUNWAY
CENTERLINE



RUNWAY GUARD LIGHT












YELLOW ALTERNATING FLASHING LIGHT
INDICATE A RUNWAY AHEAD (MAY BE
INSTALLED IN, AND/OR ABOVE GROUND)

RUNWAY THRESHOLD



RED & GREEN
LIGHT
MARKS THE
END OR
BEGINNING
OF RUNWAY

AIRPORT SIGNS







B 4-22	TWY/RWY HOLDING POSITION: Hold short of intersecting runway		RUNWAY BOUNDARY: Exit boundary from runway protected area
25-7	RWY/RWY HOLD POSITION: Hold short of intersecting runway		ILS CRITICAL AREA BOUNDARY: Exit boundary of ILS critical area
8-APCH	RWY APCH HOLD POSITION: Hold short of protected area when instructed by ATC		RUNWAY EXIT: Defines direction & designation of exit taxiway from runway
ILS	ILS HOLD POSITION: Hold short of ILS critical area when instructed by ATC		TWY DIRECTION: Defines direction & designation of intersecting taxiway(s)
	NO ENTRY: Identifies paved areas where aircraft entry is prohibited		OUTBOUND DESTINATION: Defines direction to take-off runway
B	TAXIWAY LOCATION: Identifies taxiway on which aircraft is located		INBOUND DESTINATION: Indicates direction of destination, i.e. terminal or military area
22	RUNWAY LOCATION: Identifies runway on which aircraft is located		TAXIWAY ENDING MARKER: Indicates that taxiway does not continue beyond this point
4	RUNWAY DISTANCE REMAINING: Identifies runway length remaining		DIRECTION SIGN ARRAY: Identifies location in conjunction with multiple intersecting taxiways

Line Up and Wait
has replaced
"Taxi Into Position
and Hold".

The new language
permits entry onto the
runway to await further
instructions, but is not
a take-off clearance.

If ever in doubt about
a clearance or taxi
instruction, do not
hesitate to
ASK FOR HELP!

ATCT LIGHT GUN SIGNALS

Color and Type of Signal	Aircraft on the Ground
STEADY GREEN 	Cleared for Takeoff
FLASHING GREEN 	Cleared to Taxi
STEADY RED 	STOP
FLASHING RED 	Taxi Clear of the Runway in Use
FLASHING WHITE 	Return to Starting Point on Airport
ALTERNATING RED/GREEN 	Exercise Extreme Caution

Elevated
Guard Lights
Hold Short



In-Pavement
Guard Lights
Hold Short


AIRFIELD MARKINGS



HOLDING POSITION:
Hold short of intersecting rwy;
also a land-and-hold-short marking



MOVEMENT AREA BOUNDARY:
Defines boundary of movement
area and non-movement area




**HOLDING POSITION WITH
ENHANCED TAXIWAY
CENTERLINE:** Alerts of an
approaching runway




**TAXIWAY/TAXIWAY HOLDING
POSITION:** Hold short of intersecting
taxiway when directed by ATC




SOLID TAXIWAY EDGE: Defines edge
of usable, full-strength taxiway
pavement; adjoining pavement
NOT usable



ILS CRITICAL AREA: Hold short
when instructed by ATC



DASHED TAXIWAY EDGE: Defines
edge of taxiway where adjoining
pavement or apron IS available
for taxi



**SURFACE PAINTED HOLDING
POSITION:** Designates runway ahead in
conjunction with yellow holding position marking

**SURFACE PAINTED TAXIWAY
DIRECTION:** Direction &
designation of intersecting twy

**SURFACE PAINTED TAXIWAY
LOCATION:** Identifies twy
on which aircraft is located

THIS PAGE INTENTIONALLY LEFT BLANK
FOR FUTURE USE

THIS PAGE INTENTIONALLY LEFT BLANK
FOR FUTURE USE

THIS PAGE INTENTIONALLY LEFT BLANK
FOR FUTURE USE

THIS PAGE INTENTIONALLY LEFT BLANK
FOR FUTURE USE

[illegible]

[illegible]

NOTES

