

## SCB I2C: Slave Mode

---

### › **Description:**

- This example demonstrates SCB-I2C in Slave Mode, MCU is set as slave and PC/Aardvark in master Mode.

### › **Target Device:**

- Traveo-II CYT2B6x devices

### › **Hardware:**

- CYTVII-B-E-1M-100-CPU REV 1.0
- TVII Base Board (BB)

## SCB I2C: Slave Mode


### › **Dependency:**

- Any example could be copied to the main “src” based on the interested core
- Aardvark SCL/0 – JP2/12 on BB
- Aardvark SDA/2 – JP2/10 on BB
- Aardvark GND/1 to any GND on the CPU/BB

### › **Expectation:**

- MCU is set in Slave Mode, Aardvark shall be set in Master mode and click start.
- PC/Aardvark sends data to MCU. Aardvark will show the sent data and received data.

# SCB I2C: Slave Mode



- › **Legend:**
- **Red block** for power, debug and USB (Mandatory)
  - **Yellow block** for the example specific connections