

SCB SPI: High Level Driver Master

› **Description:**

- This example demonstrates SCB-SPI in Master Mode (High level), MCU is set as master and PC/Aardvark set in slave Mode.

› **Target Device:**

- Traveo-II CYT2B9x devices

› **Hardware:**

- CYTVII-B-E-176-CPU BOARD REV.C (REV_C)
- TVII Base Board (BB)

SCB SPI: High Level Driver Master


› **Dependency:**

- Any example could be copied to the main “src” based on the interested core
- Aardvark to be configured as a slave
- Aardvark MOSI/8 - JP6/14 on BB
- Aardvark MISO/5 - JP6/15 on BB
- Aardvark SCLK/7 - JP6/9 on BB
- Aardvark SS/9 - JP6/8 on BB
- Aardvark GND/1 to any GND on the CPU/BB board

› **Expectation:**

- MCU is set in Master Mode, Aardvark shall be set in slave mode and click start.
- MCU prepares data and sends it to the PC. The screen of Aardvark will show the data from MCU.

SCB SPI: High Level Driver Master



› Legend:

- Red block for power, debug and USB (Mandatory)
- Yellow block for the example specific connections