

Helpfiles > "Animal" menu > "Animal list" window > Animal card > Animal card - "AMS settings" > "Monitoring" > "Conductivity"

"Conductivity"

"Conductivity"

Item	Description
<i>"Conductivity counter in cow monitoring":</i>	Check the box if conductivity counters should be shown for the animal in <i>"Health Cow monitoring"</i> .
<i>"Increase when absolute conductivity of any teat is above":</i>	Enter a threshold. If the conductivity value of a quarter is higher than this threshold, the counter will be increased.
<i>"Increase when relative conductivity is above":</i>	<p>Enter a threshold. If the relative conductivity value of a quarter is higher than this threshold, the counter will be increased.</p> <p>Relative conductivity compares the conductivity value of a quarter with the average value of the two quarters with the lowest conductivity. For example, if the two lowest quarters have 4000 and 4500 $\mu\text{S/cm}$, the average is 4250 $\mu\text{S/cm}$. If the threshold is 125%, the counter will increase if the conductivity value of another quarter is higher than 5312 $\mu\text{S/cm}$ (4250×1.25).</p>
<i>"Lower limit for relative counter":</i>	Enter a threshold. If the conductivity value of a quarter is lower than this threshold, the quarter will not be included in the relative conductivity calculation.