



Hi3536D V100 U-Boot Porting
Development Guide

Issue	00B02
Date	2017-11-20

Copyright © HiSilicon Technologies Co., Ltd. 2017. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of HiSilicon Technologies Co., Ltd.

Trademarks and Permissions



HISILICON, and other HiSilicon icons are trademarks of HiSilicon Technologies Co., Ltd.

All other trademarks and trade names mentioned in this document are the property of their respective holders.

Notice

The purchased products, services and features are stipulated by the contract made between HiSilicon and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

HiSilicon Technologies Co., Ltd.

Address: Huawei Industrial Base
Bantian, Longgang
Shenzhen 518129
People's Republic of China

Website: <http://www.hisilicon.com>

Email: support@hisilicon.com



About This Document

Purpose

This document describes how to port and burn the U-Boot (that is, bootloader of the Hi3536D V100 board) on the Hi3536D V100 board, and how to use ARM debugging tools.

Related Version

The following table lists the product version related to this document.

Product Name	Version
Hi3536D	V100

Intended Audience

This document is intended for:

- Technical support personnel
- Software development engineers

Change History

Changes between document issues are cumulative. Therefore, the latest document issue contains all changes made in previous issues.

Issue 00B02(2017-11-20)

This issue is the second draft release, which incorporates the following changes:

Chapter 2 Porting the U-Boot

Section 2.5 is updated.

Issue 00B01 (2017-09-08)

This issue is the first draft release.



Contents

1 Overview.....	1
1.1 Description	1
1.2 U-Boot Directory Structure	1
2 Porting the U-Boot	2
2.1 U-Boot Hardware Environment	2
2.2 Compiling the U-Boot.....	2
2.3 Configuring the DDR.....	3
2.4 Configuring Pin Multiplexing	3
2.5 Generating the Final U-Boot Image	3
3 Burning the U-Boot.....	4
3.1 Overview	4
3.2 Burning the U-Boot by Using the BOOTROM.....	4
3.3 Burning the U-Boot to Two Types of Flash Memories	4
3.3.1 Burning the U-Boot to the SPI NOR Flash	4
3.3.2 Burning the U-Boot to the SPI NAND Flash.....	5
4 Using ARM Debugging Tools.....	6
4.1 Overview	6
4.2 ARM Debugging Tools	6
4.2.1 DS-5 Eclipse	6
4.2.2 DS-5 Debug	6
4.3 Using ARM Debugging Tools	7
4.3.1 Installing the DS-5	7
4.3.2 Creating a Configuration Database for the Target Platform.....	8
4.3.3 Connecting the DS-5 to the Target Platform	14
4.4 Burning Images to a Flash Memory by Using the Simulator	17
4.4.1 Initializing the Memory	17
4.4.2 Downloading the U-Boot Image	19
4.4.3 Burning the U-Boot Image.....	21
5 Appendix	22
5.1 U-Boot Commands.....	22
5.1.1 Block Protection Command for the SPI NOR Flash.....	22



Figures

Figure 4-1 Startup GUI of the DS-5 Eclipse	8
Figure 4-2 Platform configuration window	9
Figure 4-3 Config IP window	9
Figure 4-4 Config IP scan window	10
Figure 4-5 Window for setting the IP address of the simulator	10
Figure 4-6 Window for creating the platform database	11
Figure 4-7 Window for creating the platform database	11
Figure 4-8 Window for creating the platform database	12
Figure 4-9 Window for creating the platform database	12
Figure 4-10 Window for creating the platform database	13
Figure 4-11 Window for creating the platform database	13
Figure 4-12 Window for creating the platform database	14
Figure 4-13 End Debug Configuration window	15
Figure 4-14 Debug Configuration window	15
Figure 4-15 Debug Configuration window	16
Figure 4-16 DS-5 Debug – Eclipse Platform window	17
Figure 4-17 Scripts window	18
Figure 4-18 Memory window	19
Figure 4-19 Memory window	19
Figure 4-20 Memory Import window	20
Figure 4-21 Registers window	21
Figure 5-1 Viewing current BP information	24
Figure 5-2 Locking the entire component	25
Figure 5-3 Clearing the current locking status	25
Figure 5-4 Locking the specified area by setting the level	25



Tables

Table 1-1 Main directory structure of the U-Boot	1
Table 5-1 Mapping between the BP levels and BP lock areas of components of different vendors	23



1 Overview

1.1 Description

The bootloader of the Hi3536D V100 board uses the U-Boot. When the types of the selected peripheral components are different from the types of the components on the board, you need to modify the U-Boot configuration file including the information about memory configuration and pin multiplexing.

1.2 U-Boot Directory Structure

[Table 1-1](#) shows the main directory structure of the U-Boot. For details, read the **readme** file in the **U-Boot** folder.

Table 1-1 Main directory structure of the U-Boot

Directory	Description
arch	Indicates the code of the chip architecture and the entry code of the U-Boot.
board	Indicates the code of boards, such as the memory driver code.
board/Hi3536dv100	Indicates the code of the Hi3536D V100 board.
arch/xxx/lib	Indicates the code of architecture, such as the common code of ARM and microprocessor without interlocked pipeline stages (MIPS) architecture.
include	Indicates header files.
include/configs	Indicates the configuration files of boards.
common	Indicates the implementation files of functions or commands.
drivers	Indicates the driver code of Ethernet ports, flash memories, and serial ports.
net	Indicates the implementation files of network protocols.
fs	Indicates the implementation files of file systems.



2 Porting the U-Boot

2.1 U-Boot Hardware Environment

Peripheral components on the Hi3536D V100 demo board include the DDR SDRAM, SPI NOR flash, and SPI NAND flash. For details, see the *Hi3536D V100 Component Compatibility List*.

2.2 Compiling the U-Boot

After preceding operations are complete, you can compile the U-Boot by running the following commands:

Step 1 Configure the compilation environment.

```
make ARCH=arm CROSS_COMPILE=arm-hisivXXX-linux- hi3536dv100_config
```



NOTE

hi3536dv100_config is used for the configuration of the SPI NOR flash and SPI NAND flash.

Step 2 Compile the U-Boot.

```
make ARCH=arm CROSS_COMPILE=arm-hisivXXX-linux-
```

If the compilation is successful, the **u-boot.bin** file will be generated in the **u-boot** directory.



NOTE

The **CROSS_COMPILE** parameter indicates the tool chain. In this document, the **CROSS_COMPILE** = **arm-hisivXXX-linux-** parameter indicates the following two situations:

- Hi3536D_V100R001C01SPCxxx corresponds to uclibc. If the uclibc tool chain is used, the **CROSS_COMPILE** parameter is set to **arm-hisiv510-linux-**.
- Hi3536D_V100R001C02SPCxxx corresponds to glibc. If the glibc tool chain is used, the **CROSS_COMPILE** parameter is set to **arm-hisiv610-linux-**.



CAUTION

The **u-boot.bin** file is not the final U-Boot image.



----End

2.3 Configuring the DDR

On Windows, open the configuration table in **osdrv/tools/pc/uboot_tools** of the SDK. If different DDR SDRAMs are used, modify the **mddrc_dmc0**, **mddrc_dmc1**, **mddrc_phy0**, and **mddrc_phy1** sheets in the configuration table based on DDR features.

2.4 Configuring Pin Multiplexing

If the pin multiplexing relationship changes, modify the **muxctrl_reg** sheet in the configuration table.

2.5 Generating the Final U-Boot Image


Perform the following steps:

- Step 1** Save settings after the configuration sheet is modified.
- Step 2** Click **Generate reg bin file** on the first tab page of the configuration sheet or use the hiregbin tool (for details, see the readme file in **osdrv/tools/pc/uboot_tools/hiregbin-v5.0.0.tgz**) to generate the temporary file **reg_info.bin**.
- Step 3** Copy **u-boot.bin** (generated after the U-Boot is compiled) and **reg_info.bin** to **osdrv/tools/pc/uboot_tools** of the SDK, and run the following command:

```
./mkboot.sh reg_info.bin u-boot-hi3536dv100.bin
```

u-boot-hi3536dv100.bin is the final U-Boot image that can run on the board.

----End





CAUTION

In the current issue, **sf lock** can be used to protect blocks of the SPI NOR Flash. If a block of the SPI NOR Flash is protected, the block becomes read-only, the **erase** and **write** commands do not take effect, and the block is still protected even after power outage. In this case, the erase and write commands are valid only after the **sf lock 0** command is executed. For details, see section 5.1.1 "Block Protection Command for the SPI NOR Flash."

3.3.2 Burning the U-Boot to the SPI NAND Flash

Perform the following steps:

Step 1 Run the following commands in the HyperTerminal after the U-Boot runs in the memory:

```
hisilicon# nand erase 0x0 0x100000 /*Erase 1 MB capacity of the NAND flash.*/  
hisilicon# mw.b 0x82000000 ff 0x100000 /*Initialize the memory.*/  
hisilicon# tftp 0x82000000 u-boot-hi3536dv100.bin /*Download the u-boot  
to the memory.*/  
hisilicon# nand write 0x82000000 0x0 0x100000 /*Write the U-Boot from the  
memory to the SPI NAND flash.*/
```

Step 2 Restart the system. The U-Boot is burnt successfully.

----End



4 Using ARM Debugging Tools

4.1 Overview

The ARM Development Studio 5 (DS-5) is an end-to-end software development toolkit used on the Linux and Android platforms. It covers the development of the startup code, kernel porting, application, and bare board debugging. The DS-5 provides the kernel space debugger and the application with the tracking function, system-wide performance analyzer, real-time system simulator, and compiler. These functions are included in the customized, powerful, and friendly Eclipse-based integrated development environment (IDE). The DS-5 can help engineers to develop and optimize systems based on Linux for platforms supported by ARM, shorten the development and test cycles, and develop highly efficient software.

The DS-5 includes:

- DS-5 Eclipse: An IDE which integrates the compilation tools with the debugging tools.
- DS-5 Debug
- Real-time system models (RTSM)
- ARM pipeline performance analyzer

This chapter describes how to use the following tools to debug the ARM processor:

- DS-5 Eclipse
- DS-5 Debug

4.2 ARM Debugging Tools

4.2.1 DS-5 Eclipse

The DS-5 Eclipse is an Eclipse-based IDE. It integrates the compilation tools and debugging tools of ARM, and ARM Linux GNU tool chain for ARM Linux target board development. The DS-5 Eclipse provides project management, editor, and view.

4.2.2 DS-5 Debug

The DS-5 Debug is a graphical debugger which supports software development debugging on the ARM target board and RTSM. Because of its comprehensive and direct view, you can easily debug Linux and bare board programs, including source program synchronization and



disassembling, stack calling management, operations of the memory, register, expression, variable, thread, and breakpoint, as well as code tracking.

The DS-5 Debug management window can be used to execute source codes or instructions step by step, and view the latest data in other views after code running. You can also set breakpoints or checkpoints to pause the application to learn the status after application execution. The tracking view can be used on some target boards to track function execution in the application in the sequence of program running.

4.3 Using ARM Debugging Tools

To use the DS-5 to debug the program or burn the U-Boot to the development board, you must create a configuration database for the target platform, and then connect the DS-5 to the target platform.

For details about how to use ARM debugging tools, see the documents provided by ARM. To use the DS-5, perform the following steps:

- Step 1** Install the DS-5.
- Step 2** Create a configuration database for the target platform.
- Step 3** Create a new connection to connect the DS-5 to the target platform by using the configuration database for the target platform.


----End

4.3.1 Installing the DS-5

The DS-5 is the setup program of the DS-5 Eclipse provided by ARM. Before installation, read relevant documents provided by ARM. After installation, start the DS-5 Eclipse. See [Figure 4-1](#).



Figure 4-1 Startup GUI of the DS-5 Eclipse




4.3.2 Creating a Configuration Database for the Target Platform

Perform the following steps:

- Step 1** Choose **File > New > Other**. In the displayed dialog box, select **Platform Configuration** under **DS-5 Configuration Database**, and then click **Next >**, as shown in Figure 4-2.



Figure 4-2 Platform configuration window



Step 2 Connect to the simulator. Choose **ARM DS-5 v5.24.1 > Debug Hardware > Debug Hardware Config IP(5.24.1)** from the menu. In the displayed software window, click **scan**. After the simulator is found, set an IP address that is in the same network segment as the current PC, as shown in [Figure 4-3](#) and [Figure 4-5](#).

Figure 4-3 Config IP window






Figure 4-4 Config IP scan window





Figure 4-5 Window for setting the IP address of the simulator



- Step 3** Go back to the **DS-5 Eclipse** window. Select **Automatic/simple platform detection(Recommended)**, and click **Next >**. The system performs the scan. Enter the IP address of the simulator in **Connection Address:** and click **Next >**. Select **Debug target after saving configuration**, and click **Next >**. Click **Create New Database**. Enter the database name and click **OK**. Then, click **Next >**. Set **Platform Manufacturer** to **Hisilicon**, set **Platform Name** to **Hi3536D V100**, and click **Finish**, as shown in [Figure 4-6](#) to [Figure 4-12](#).



Figure 4-6 Window for creating the platform database




Figure 4-7 Window for creating the platform database






Figure 4-8 Window for creating the platform database




Figure 4-9 Window for creating the platform database






Figure 4-10 Window for creating the platform database




Figure 4-11 Window for creating the platform database






Figure 4-12 Window for creating the platform database

----End

4.3.3 Connecting the DS-5 to the Target Platform

Perform the following steps:

- Step 1** In the displayed dialog box after **Finish** is clicked, right-click **DS-5 Debugger**, choose **New** from the shortcut menu, and select the created **Hisilicon-Hi3536D V100**, as shown in [Figure 4-13](#).
- Step 2** On the **Connection** tab page, click **Hisilicon**, **Hi3536D V100**, **Bare Metal Debug**, and **Cortex-A7**, and enter the IP address of the DS-5 device in the text box, as shown in [Figure 4-14](#).
- Step 3** Select **Connect Only** on the **Debugger** tab page, as shown in [Figure 4-15](#).
- Step 4** Click **Debug** to connect to the target platform. The window shown in [Figure 4-16](#) is displayed.



Figure 4-13 End Debug Configuration window




Figure 4-14 Debug Configuration window






Figure 4-15 Debug Configuration window







Figure 4-16 DS-5 Debug – Eclipse Platform window



----End

4.4 Burning Images to a Flash Memory by Using the Simulator

4.4.1 Initializing the Memory





In the **Scripts** window, click  to import the memory initialization script, and click  to run the memory initialization script (if the simulator is running, click  in the **Debug Control** window to stop it). See [Figure 4-17](#).



Figure 4-17 Scripts window




Use the following method to check whether the memory is successfully initialized.

Enter the memory address such as **0x82000000** in the **Memory** window. Press **Enter** to view whether the memory value is displayed in the window shown in [Figure 4-18](#). If values are displayed and can be changed, the memory is successfully initialized. To change a memory value such as **0x82000000**, double-click the value, enter a new value such as **0x12345678**, and press **Enter**. See [Figure 4-18](#).



Figure 4-18 Memory window



CAUTION


The script for memory initialization is the file in .ds, .py or .txt format in the `osdrv/tools\pc\uboot_tools` directory.

4.4.2 Downloading the U-Boot Image

Perform the following steps:

Step 1 Click  in the **Memory** window, see Figure 4-19.


Figure 4-19 Memory window





Step 2 Select **Import Memory**. The image download window is displayed. Download the U-Boot image to the memory address such as **0x82000000**. See [Figure 4-20](#).


Figure 4-20 Memory Import window




Step 3 In the **Registers** window, change the PC value to **0x82000000**. See [Figure 4-21](#).



Figure 4-21 Registers window



Step 4 Click  in the **Debug Control** window to start the U-Boot, and view the U-Boot start information over the serial port.

----End

4.4.3 Burning the U-Boot Image

After the U-Boot starts, burn the U-Boot image in the memory to a flash memory over the serial port.

Taking SPI NOR flash as an example, the burning commands are as follows:

```
hisilicon# sf probe 0 /* Detect and initialize the
SPI flash. */
hisilicon# sf erase 0x0 0x100000 /* Erase 1 MB capacity of the
SPI flash. */
hisilicon# sf write 0x82000000 0x0 0x100000 /* Write the U-Boot from the
memory to the SPI flash. */
hisilicon# reset /* Restart the board. */
```



5 Appendix

5.1 U-Boot Commands

5.1.1 Block Protection Command for the SPI NOR Flash

The SPI NOR flash provides the block protection (BP) bits to ensure data security.

A corresponding block in the component enters the write protection status by setting the BP0, BP1, BP2, or BP3 (the status register of some chips may have BP4 but not BP3) bit in the status register (SR) to **1** (enabled). These BP bits are non-volatile and can retain the configured status during power-off.

Some vendors provide the function of configuring the BP direction, that is, whether to enable the BP function of blocks from the top of the component or from the bottom of the component can be configured. Whether the start address for write protection locking starts from the low address (bottom) or high address (top) is configured in the TBPROT bit (for the chips of some vendors, the TBPROT bit is located in the SR) of the configuration register (CR). Typically this configuration bit is the one-time programmable (OTP) type. The default bit value is 0, indicating that the BP starts from the top (high address). Once this bit is set to 1, indicating that the BP starts from the bottom (low address), the status cannot be changed any more.

Based on actual applications, the TBPROT is set to 1 since initialization of the controller, that is, BP starts from the bottom (low address).

All the BP bits in the SRs for SPI NOR components are 0 (disabled) by default. The BP for all the blocks in the components is disabled and the blocks can be erased or written.

When all the BP bits are set to 1 (enabled), all the blocks in the components are in write protection status and the erase and write operations have no effect.

The BP is implemented based on the unit of block. The hexadecimal value of each BP bit is converted into the decimal level value based on the enable status of the BP bits to configure the range of locked BP. For the components with three BP bits, the value range of level is 0–7 for BP[0:0:0] to BP[1:1:1]. For the components with four BP bits, the value range of level is 0–10 (or 0–9 because the minimum locked area cannot be less than one block) for BP[0:0:0:0] to BP[1:1:1:1].

The BP lock area varies according to the components of different vendors, as shown in [Table 5-1](#).



Table 5-1 Mapping between the BP levels and BP lock areas of components of different vendors

Level	MXIC MX25L-					ESMT F25L-
	12835F	25635F	25735F	6406E	1606E	64QA
0	Unlocked	Unlocked	Unlocked	Unlocked	Unlocked	Unlocked
1	0–64 KB	0–64 KB	0–64 KB	0–4 MB (64 blocks)	All-locked 2 MB (32 blocks)	0–4 MB (64 blocks)
2	0–128 KB	0–128 KB	0–128 KB	0–6 MB (96 blocks)	0–1 MB (16 blocks)	0–6 MB (96 blocks)
3	0–256 KB	0–256 KB	0–256 KB	0–7 MB (112 blocks)	0–1.5 MB (24 blocks)	0–7 MB (112 blocks)
4	0–512 KB	0–512 KB	0–512 KB	0–7.5 MB (120 blocks)	0–1.75 MB (28 blocks)	0–7.5 MB (120 blocks)
5	0–1 MB	0–1 MB	0–1 MB	0–7.75 MB (124 blocks)	0–1.875 MB (30 blocks)	0–7.75 MB (124 blocks)
6	0–2 MB	0–2 MB	0–2 MB	0–7.875 MB (126 blocks)	0–1.9375 MB (31 blocks)	0–7.875 MB (126 blocks)
7	0–4 MB	0–4 MB	0–4 MB	All-locked 8 MB (128 blocks)	All-locked 2 MB (32 blocks)	All-locked 8 MB (128 blocks)
8	0–8 MB	0–8 MB	0–8 MB	-	-	-
9	All-locked 16 MB	0–16 MB	0–16 MB	-	-	-
10	-	All-locked 32 MB	All-locked 32 MB	-	-	-
Level	SPANSION S25FL-		WINBOND W25Q-			
	127S	256S	128FV	128BV	256FV	64FV
0	Unlocked	Unlocked	Unlocked	Unlocked	Unlocked	Unlocked
1	0–256 KB	0–512 KB	0–256 KB	0–256 KB	0–64 KB	0–128 KB
2	0–512 KB	0–1 MB	0–512 KB	0–512 KB	0–128 KB	0–256 KB
3	0–1 MB	0–2 MB	0–1 MB	0–1 MB	0–256 KB	0–512 KB
4	0–2 MB	0–4 MB	0–2 MB	0–2 MB	0–512 KB	0–1 MB
5	0–4 MB	0–8 MB	0–4 MB	0–4 MB	0–1 MB	0–2 MB
6	0–8 MB	0–16 MB	0–8 MB	0–8 MB	0–2 MB	0–4 MB
7	All-locked 16 MB	All-locked 32 MB	All-locked 16 MB	All-locked 16 MB	0–4 MB	All-locked 8 MB



8	-	-	-	-	0–8 MB	-
9	-	-	-	-	0–16 MB	-
10	-	-	-	-	All-locked 32 MB	-
Level	GD GD25Q-			CFEON EN25Q-		
	128C	64	32	128	64	
0	Unlocked	Unlocked	Unlocked	Unlocked	Unlocked	
1	0–256 KB	0–128 KB	0–64 MB	0–15.9375 MB (255 blocks)	0–7.9375 MB (127 blocks)	
2	0–512 KB	0–256 KB	0–128 MB	0–15.875 MB (254 blocks)	0–7.875 MB (126 blocks)	
3	0–1 MB	0–512 KB	0–256 MB	0–15.75 MB (252 blocks)	0–7.75 MB (124 blocks)	
4	0–2 MB	0–1 MB	0–512 MB	15.5 MB(248 blocks)	0–7.5 MB (120 blocks)	
5	0–4 MB	0–2 MB	0–1 MB	0–15 MB(240 blocks)	0–7 MB (112 blocks)	
6	0–8 MB	0–4 MB	0–2 MB	0–14 MB(224 blocks)	0–6 MB (96 blocks)	
7	All-locked 16 MB	All-locked 8 MB	All-locked 4 MB	All-locked 16 MB (256 blocks)	All-locked 8 MB (128 blocks)	

The **lock** BP command is added for SPI NOR components in U-Boot based on the BP mechanism for the SPI NOR flash. The command formats are as follows:

- **sf lock**

This command can be used to view the configured BP level, value range of the level, and the range of locked areas. At the same time, the command description information is displayed. See [Figure 5-1](#).

Figure 5-1 Viewing current BP information

```
hisilicon # sf lock
Get spi lock information
level: 5
Spi is locked. lock address[0 => 0x100000]

sf lock level/all
Usage:
all: level(10), lock all blocks.
level(0): unlock all blocks.
set spi nor chip block protection level(0 - 10).
As usual: lock_len = chipsize >> (10 - level)
hisilicon #
```

- **sf lock all**



This command is used to lock all the blocks (of the entire component). As shown in [Table 5-1](#), running this command is equivalent to setting the level to the maximum value. See [Figure 5-2](#).

Figure 5-2 Locking the entire component

```
hisilicon # sf lock all
lock all blocks.
Spi is locked. lock address[0 => 0x2000000]
hisilicon #
```

- sf lock 0

This command is used to clear the current BP locking status. In this case, all the blocks in the component are not protected, and can be erased. See [Figure 5-3](#).

Figure 5-3 Clearing the current locking status

```
hisilicon # sf lock 0
unlock all block.
hisilicon #
```

- sf lock <level>

This command is used to set the BP level. The corresponding areas are protected based on the level, as described in [Table 5-1](#). In this way, the blocks in the BP area cannot be normally erased. See [Figure 5-4](#).

Figure 5-4 Locking the specified area by setting the level

```
hisilicon # sf lock 4
lock level: 4
Spi is locked. lock address[0 => 0x80000]
hisilicon #
```