


Derived from https://cdn-shop-adafruit.com/product-files/412/solenoid_driver.pdf



Solenoid circuit connects when ready to fire,
disconnects when pulled out for loading.


Sheet: /Solenoid/
File: Solenoid.sch

Title: Detail: Solenoid Driver

Size: A4 Date: 2020-09-07


KiCad E.D.A. eeschema (5.1.5)-3

Rev:
Id: 2/4



Only connect Programming Arduino
when programming KCX_BT_EMITTER
Bluetooth Audio Module

Programming Arduino does not need to be a Nano.
It must be an Arduino with 5V interfaces
Power via USB and use Serial Monitor to control



These 3 connectors should be male jumper wires.
Use the color code suggested to avoid connection errors.
Matching labels to female jumpers suggested:
GND
2 RX
9 TX

Programs the KCX_BT_EMITTER Bluetooth Module

Sheet: /Programming Arduino/
File: ProgArd.sch

Title: Programming Arduino

Size: A4 Date: 2020-09-07

KiCad E.D.A. eeschema (5.1.5)-3

Rev:
Id: 4/4