

Overview

The CBUS protocol provides commands to allow the configuration of a module by a networked computer. These commands allow the read & write functionality of numbered variables, but doesn't describe what those variables do – as this is different across different modules

Thus, modifying a computer program to allow users to configure new modules has been a very time-consuming process, and typically not possible by the module developer

This document aims to provide a way to describe what these variables mean, in a form that can be digested by a computer program to provide a meaningful user interface, without changing the software programming, thus available to all module developers

This is intended to describe what the module variables mean, not dictate how the user interface is implemented. However, pragmatically some things are best described in user interface terms

General

CBUS Modules are identified by manufacturer/model numbers, which are stored in the firmware. So the module actually refers to the firmware, and not the physical board the firmware resides on, although most of the firmware has been written for a specific type of board. There is, however, some firmware that will run on different hardware, and will report the same module identification irrespective of which hardware they are running on. Equally, there is specific hardware that have had different variants of firmware written for them, so such hardware will report a different module ID depending which variant of firmware is loaded

In this file the module is described using key-value pairs, the key identifies the data, and the value is the data content, which can be various types of literal (fixed) data, such as string, numeric or an array to 'nest' further key-value pairs

Key-value pairs can be represented in many data formats, with JSON being the preferred format widely supported by many languages

Camel case is the preferred naming format for keys, unless specified otherwise

Camel case is the practice of starting each word with a capital letter, except for the first word.

There is no direct support for comments, but a key-value pair can be used where necessary

E.g. "comment": "comment added for clarity"

File naming convention

The filename is generated from the module name, the manufacturer/module identification and the firmware version. Leading with the module name makes the files a little easier to sort by eye. Kebab case formatting (- sign separator) is used to separate the 3 items.

Note the firmware version is kept in the same format as used in firmware documentation, i.e. number followed by character.

`AAAAAAA-BBCC-DE<Options>`

Where

`AAAAAAA` : variable length module name registered against the manufacturer ID & Module ID

`BB` : Manufacturer ID in hexadecimal - two hex digits

`CC` : Module ID in hexadecimal - two hex digits

`D` : Firmware major version in decimal - 1 to 3 digits

`E` : Firmware minor version in single ascii character

`<Options>` : not mandatory - described below

Example (without options):

`CANACC4-A501-2q.json`

Module name, Manufacturer ID & Module ID

The module name is registered against the manufacturer ID & Module ID in CbusDefs, and as the manufacturer & module ID is also present, is just included for human readability.

For personal development of modules, it is recommended that the NMRA Manufacturer ID of '13' (development) is used, with a module ID & module name of personal choice, thus avoiding the need to have a module added to 'CbusDefs' – avoiding conflict with other modules would then be the responsibility of the user of that module.

Options

The use of different microprocessor devices in the same module allows for different capabilities of that module. To reflect this, an optional suffix can be added to the file name to identify the processor type.

The option format for processor type is two hyphens, followed by a capital P then the 'processor type number' as defined by "CbusDefs" – e.g. `—P13`

For the majority of modules, that do not support multiple devices, or that have the same capabilities irrespective of processor type, then this option would be omitted – i.e. the option would only be used in a limited number of cases.

For a recent version of CANMIO-Universal firmware, one example would be

`CANMIO-A520-3d—P13.json`

Where the `—P13` indicates it's for a module with the P18F25K80 microprocessor.

Why use a 'double hyphen' ?

As we cannot dictate that a hyphen cannot be in the module name, then a hyphen may appear in that, so in order to be able to identify the optional segment, the 'double hyphen' is used, as this is most unlikely to appear in the name

Using the filename

It is recommended that a file match for a stored module descriptor file is initially performed with the processor option, falling back to matching the filename without the processor option

The filename to match would be created from the data provided from the module itself – as all items are read from 'Node Parameters', with the exception of the module NAME

The CBUS protocol only provides for the reading of the module NAME when in setup mode, so it is pragmatic to consider alternatives to reading the NAME

1. Match the filename without the NAME portion, and use the NAME from the matching filename for display purposes
2. Have a lookup table for the name, using the manufacturer & module ID, based on CbusDefs. To cater for development module names (manufacturer ID 13), a method to add those should be provided in that case

As already mentioned, it should be assumed the module name could contain a single hyphen

File Format:

Style

Whilst not mandatory, for readability it is strongly recommended that the title & subtitle properties are the first in any element, followed by the type property.

```
{
  "displayTitle": "Time delay between response messages",
  "displaySubTitle": "1 millisecond steps",
  "type": "NodeVariableSlider",
  "nodeVariableIndex": 5,
  "displayUnits": "milliseconds"
},
```

Unfortunately, early examples do not follow this convention

top-level section

moduleDescriptorName

This property is the filename described above without the extension. This is an important property that is used to identify the descriptor when the content of the file is being as a data object programmatically (i.e. not as a file with a filename)

moduleName

This optional property in the root section is the name registered against the manufacturer ID & Module ID for this specific module. The value returned from the CBUS command NAME is typically a subset of this module name due to data restrictions

NVsetNeedsLearnMode

One family of firmware based on original CANSERVO8 code needs to be put into 'learn' mode before node variables can be programmed. Setting the [NVsetNeedsLearnMode](#) key to a value of [true](#) in the root section will indicate if this is required for this specific module. The processing application is expected to assume [false](#) if this property is not present, so it's only required if set to true

nodeVariables & eventVariables sections

These sections are the descriptors for node & event variables. Both of these have types and properties that work in the same way.

The major difference between the two is that there is only one instance of the node variables for each module, where there can be multiple instances of the event variables, so the actual types reflect that difference, but share the same properties

A group type element is defined to allow the grouping of elements using an array

For many modules, the meaning of certain variables change depending on the value of another variable. To cater for this, a [visibilityLogic](#) property has been created. This allows more than one descriptor for a single variable to be created, but controls which of these descriptors actually gets displayed by the result 'visibilityLogic' element (only display is logic returns true), this should be supported on all types

Another option is [Overloaded Labels](#), which allows different labels to be presented depending on another variable, all within a single descriptor. Note this is only available on certain types

Types

The type property indicates what the variable represents and how should be handled

Note not all types duplicated for both, as created on an 'as needed' basis

EventVariableBitArray NodeVariableBitArray	Represents an 8 bit node variable where each bit can be selected independently - also known as flags, bitfield or multi-select Uses bitCollection to define the bits & their labels Uses displayTitle , displaySubTitle Supports Overloaded labels
EventVariableBitSingle NodeVariableBitSingle	Represent a single bit in a node variable Uses the bitPosition property to identify which bit Uses displayTitle , displaySubTitle
NodeVariableDual	Represents a two byte variable as a simple numeric input value

	<p>Uses displayTitle, displaySubTitle</p> <p>Note that the lower index number variable is the most significant byte</p>
EventVariableGroup NodeVariableGroup	<p>Allows a collection of types to be logically grouped together, differs from Tabs in that multiple groups can be visible at the same time, and expected to have less content</p> <p>Uses the groupItems property, which can contain any of the other types including the 'Tabs' types</p> <p>Doesn't use any other properties</p>
EventVariableNumber NodeVariableNumber	<p>Represents a variable as a simple numeric input value</p> <p>Option to use min & max to limit user input</p> <p>Option to use startBit & endBit to use a subset of the bits in a variable</p> <p>Option to use displayOffset to adjust displayed values</p> <p>Uses displayTitle, displaySubTitle</p> <p>Doesn't use displayScale or displayUnits</p>
EventVariableSlider NodeVariableSlider	<p>Represents a variable as a slider control</p> <p>Option to use description to show more information</p> <p>Option to use displayScale, displayUnits and displayOffset to adjust displayed values</p> <p>Uses displayTitle, displaySubTitle</p> <p>Option to use min & max to limit user input</p> <p>Option to use startBit & endBit to use a subset of the bits in a variable</p> <p>NodeVariableSlider supports the option to use outputOnWrite to show output is set immediately on a write (can implement a 'test' feature)</p>
EventVariableSelect NodeVariableSelect	<p>Represents a control to select a single value from the array of options</p> <p>Option to use bitMask to define a subset of the bits to use</p> <p>Option to use displayScale to adjust displayed values</p> <p>Option to use displayUnits to display units of measure</p> <p>Uses displayTitle, displaySubTitle</p> <p>Supports Overloaded labels</p>
EventVariableTabs NodeVariableTabs	<p>Defines the logical grouping of a set of variables, differs from 'groups' in that only the contents of one tab (tabPanel) is visible at a time, typically the full width of the display area, and would typically have more content than a group</p> <p>Uses the tabPanels property to define a set of tabs and the content of the associated tab panels, the content is any of the other types including the 'group' types.</p> <p>Doesn't use any other properties</p>

Properties for nodeVariable & eventVariable

property (key)	type	requirement	default
type	string	mandatory	Not Applicable
nodeVariableIndex eventVariableIndex	numeric	mandatory	Not Applicable
bitPosition	numeric	Mandatory for some types	Not Applicable
bitCollection	array	Mandatory for some types	Not Applicable
bitMask	numeric	optional	255
min	numeric	optional	0
max	numeric	optional	maximum size of the variable type
startBit	numeric	optional	0
endBit	numeric	optional	8
groupItems	array	Mandatory for some types	Not Applicable
displayTitle	string	Mandatory for some types	Not Applicable
displaySubTitle	string	optional	Not Applicable
displayScale	numeric	optional	1
displayUnits	string	optional	blank
displayOffset	numeric	optional	0
options	array	optional	Not Applicable
outputOnWrite	boolean	optional	false
tabPanels	array	Mandatory for some types	Not Applicable
visibilityLogic	Logic element	optional	Not Applicable

bitCollection

An array of bitPositions and associated labels used to define a collection of a variable number of bits and their labels used in the BitArray types. bitPositions start from 0

Each array entry of the form `{“bitPosition”: 1, “label”: “bit description”}`

bitMask

A bit value of 1 in the bitMask indicates that the corresponding bit position in the variable should be modified, a value of 0 shows the corresponding bit position in the variable should keep its original value. This allows a type to modify just part of a variable, and leave the remainder for another type to modify. See [options](#) description for an example of how it can be used

min/max

This pair usually relates to the raw value in the node variable, not the display value, unless stated otherwise in the type description above

startBit/endBit

Describes the starting and ending bits of a value that doesn't use all 8 bits of a variable. Typically used to create a bit mask to use to ensure that unused bits are not modified when this value is updated

displayScale & displayUnits

For numeric values, this pair allows the variable to be displayed in a 'friendly' fashion, e.g. a time delay in 100mS intervals would have a displayScaling of 100 and a displayUnits of 'mS'. These do not affect the underlying 'raw' variable

displayOffset

Used in special circumstances where the value the variable represents doesn't start at 0. E.g. a time delay may have a minimum of 500mS (i.e. the variable value of 0 represents 500mS), but intervals of 100mS could have a display offset of 500. Another example would be to use an offset of 1 to display channel numbers 1 to 8, that's stored in 3 bits which have a range of 0 to 7. Can also be used to display negative starting values, whilst keeping the raw value unsigned, e.g. using an offset of -100 to display -100 to +100 with the raw value in the variable being 0 to 200 - however, probably less useful in this application

displayTitle

The main description of the item

displaySubTitle

An optional element that can be used to add further information about the item - e.g. "Range 50 to 25500 mS"

groupItems

An array used by the [NodeVariableGroup](#) type to logically group other types together, e.g. to group more than one node variable to a single channel

options

Array of labels with values to be used in the [NodeVariableSelect](#) type.

Each array entry of the form {"label": "Options 1", "value": 0}

The value field maps onto the bits in the variable, for example, if the top 2 bits are used (bits 6 & 7), then the array will take the form

```
{"label": "event sent at ON end", "value": 0},      – bits 6 & 7 clear
{"label": "event sent when at OFF end", "value": 64}, – bit 6 set, 7 clear
{"label": "event sent at mid travel", "value": 128}, – bit 6 clear, bit 7 set
{"label": "Start of Day (SoD) event", "value": 192} – bits 6 & 7 set
```

The [bitMask](#) option can be used to limit modifications to the specific bits, in this case a value of 192 would be used (bits 6 & 7 set to only allow those to be modified)

outputOnWrite

If true, this indicates that when this variable is written to, the associated output immediately takes on this new value.

In some modules this is seen in the servo position variables, and has been used to provide a 'test' feature by re-writing the current variable value, e.g. to move the servo to the 'on' position. Currently only supported in the [NodeVariableSlider](#) type.

tabPanels

An array used by the [NodeVariableTabs](#) & [EventVariableTabs](#) types to logically group other types together in tabbed panels

Each entry in the array contains the displayTitle of the tab, and a further array of items that form the content of the tab panel

```
{ "displayTitle": "Tab number one",
  "items": [
    {
      "type": "EventVariableNumber",
      "eventVariableIndex": 1,
      "displayTitle": "Output 1-1"
    }
  ]
}
```

visibilityLogic

This optional property uses a [logic element](#) (see below for more detail) to only display the descriptor if the logic returns true.

This is typically used where the meaning of a variable changes depending on another variable - e.g. on some modules, event variables change meaning (or not used) if the event is marked as a 'produced' event, or 'consumed' event

Having this "visibilityLogic" property allows multiple descriptors to be defined for the same variable, but then select which one gets displayed depending on the result of the logic element

Overloaded labels

In more complex modules, the same variable has different meaning depending on another variable - an example being the following partial extract for a configuration for EV#1

Produced(EV#1)									
Happening Id		I/O	TYPE						
Hex	Decimal		INPUT	OUTPUT	SERVO	BOUNCE	MULTI	ANALOGUE	MAGNET
0	0	Global	No Happening is mapped to the event.						
1	1		Produced startup event						
2	2								
3	3								
4	4								
5	5								
6	6								
7	7								
8	8	1	Changed	Changed	Reached OFF	Changed	AT1		
9	9		TWO_ON		Reached MID		AT2		
A	10				Reached ON		AT3		
B	11						AT4		
C	12	2	Changed	Changed	Reached OFF	Changed	AT1		
D	13		TWO_ON		Reached MID		AT2		
E	14				Reached ON		AT3		
F	15						AT4		

Where the variable is an encoding (i.e. each value has a different meaning), then only the label needs to be changed to describe a different meaning for that value

This isn't suitable for variables that aren't encodings, hence only certain types support it

The following element describes how to 'overload' the label in types that support it

`"overload":{"nv",labels["value":0, "label": "first label", "value":1, "label": "2nd label",.....]}`

For example, the following shows how the table above is represented

```
{
  "type": "EventVariableSelect",
  "eventVariableIndex": 1,
  "displayTitle": "Produced event",
  "displaySubTitle": "EV1",
  "options": [
    {"value": 0, "label": "no event (0)"},
    {"value": 1, "label": "Startup event (1)"},
    {"value": 8, "overload":{"nv": "16", "labels": [
      {"value": 0, "label": "CH1 - Input Changed"},
      {"value": 1, "label": "CH1 - Input Changed"},
      {"value": 2, "label": "CH1 - Reached OFF"},
      {"value": 3, "label": "CH1 - Input Changed"},
      {"value": 4, "label": "CH1 - AT1"}
    ]}
  ]
},
{"value": 9, "overload":{"nv": "16", "labels": [
  {"value": 0, "label": "CH1 - TWO_ON"},
  {"value": 2, "label": "CH1 - Reached MID"},
  {"value": 4, "label": "CH1 - AT2"}
]
}
```

```
    }  
  },  
  ...  
}
```

Logic elements

A logic element allows simple logic to be embedded into the descriptor

The logic returns a true or false condition for the named property, and can be used for more than one named property

The logic follows the syntax

```
"Named Property":{ "argument", "condition"}
```

The intent is that the "argument" always evaluates to a simple numeric value, and the condition just needs to compare two simple values

For example, in the following property, "visibilityLogic", the result of the logic element is used to control if a variable is displayed or not

And in this case, the variable would only be displayed if the value of ev3 bit 7 is equal to 1

```
"visibilityLogic":{  
  "evBit": {"index":3, "bit": 7}  
  "equals": 1  
},
```

Logic conditions

condition	description
"equals":<value>	Equal to, with numerical value, will return true or false
"in":<[value>,...]	Equal to any value in the array, will return true or false

Logic arguments

item	description
"evBit": { "index":<ev index>, "bit": <0 to 7> }	Describes a single event variable bit with numerical values for event index and bit position (0 to 7). Will evaluate to 0 or 1
"nv":<nv index>	Describes a node variable by it's index number, will evaluate to a number 0 to 255