

# RF Survey Toolkit

LRWAN-Disco

NRF52

Android Application

Parse ALP  
& query GWs

BLE interrupt:  
Forward over UART

START survey  
(default parameters)

Generate ALP  
command  
Send over BLE  
(periodically)

After timeout:  
No GW responded

UART interrupt:  
Forward over BLE

Parse ALP response  
& store with location

STOP survey:  
Discard/  
Save data to JSON

LPWAN

UART

BLE

