


Last change: 10.9.2020

Header

If the interface „Beckhoff.App.Core.Interfaces.IBAHeader“ is defined in [Unity](#), it will be used to display a header and all older Header versions are disabled.


This allows the user to implement their own headers.

By default "Beckhoff.App.Header.HeaderCtrl" stored in "Beckhoff.App.Header.dll" implements "IBAHeader". This is defined in the unity configuration file "Header.config.xml" in folder "System\locConfig".



Doubleclick on error line opens a detailed error description.

Click on „State TwinCAT/SPS“ opens a window to choose the target system:



Beckhoff Automation
GmbH & Co. KG
Hülshorstweg 20
33415 Verl, Germany

Postfach 11 42
33398 Verl

Telefon: +49 5246 963-0
Vertrieb: +49 5246 963-1000
Service: +49 5246 963-460
Support: +49 5246 963-157

Fax Zentrale: - 149
Fax Vertrieb: - 198

www.beckhoff.de
info@beckhoff.de
vertrieb@beckhoff.de
service@beckhoff.de
support@beckhoff.de
international-sales@beckhoff.de
engineering@beckhoff.de

Geschäftsführer:
Dipl.-Phys. Hans Beckhoff

Registergericht:
Gütersloh HRA 7075

Ust.-Id.-Nr.: DE 815529334

Kreissparkasse Wiedenbrück
BIC: WELADED1WDB
IBAN: DE24 4785 3520 0000 0600 04 (EUR)
IBAN: DE02 4785 3520 0000 0600 12 (USD)
Deutsche Bank (EUR, USD)
BIC: DEUTDE33489
IBAN: DE95 4807 0043 0373 6014 00

Click on question mark opens detailed error description.

Click on „#“ opens the editor at error location where the error occurs.

In settings in section “Messageline” exists some settings for behavior and design:

- „CNC DignosisManual English/German“ define the location of the .chm help files of the appropriate language.
- „EditButtonVisible“: if this is switched off, the button for editing “#” will never be displayed.
- „Font“: Type and size of error text line.
- „FormToShowOnDoubleClick“: Instance name of form which is shown on double click.
- „ShowOnlyHighestStatus“: Only the most important messages are displayed. For example, if there are errors and warnings, “TRUE” displays only errors.
- „TimerIntervall“: Interval with which the next message is displayed for several pending messages.

Interface IBAHeader

The IBAHeader interface is defined as follows:

```

namespace Beckhoff.App.Core.Interfaces
{
    public interface IBAHeader
    {
        Control HeaderControl { get; }
        /// <summary>
        /// additional Control, only displayed if != null
        /// </summary>
        void AddControl(System.Windows.Controls.UserControl control);
        /// <summary>
        /// additional Control, only displayed if != null
        /// </summary>
        void RemoveControl(System.Windows.Controls.UserControl control);
    }
}

```

The two methods "AddControl" and "RemoveControl" allow adding or removing additional WPF UserControls for the header at runtime.

Use Unity to query and use IBAHeader.

Example:

```

public FormDemo(IBAHeader header, string instanceName) : this()
{
    header = header;
    headerVM = new HeaderControlVM(instanceName);
    _headerControl = new ucHeaderControl {DataContext = _headerVM};
    _header.AddControl(_headerControl);
}

```

