

○ *Case No: 3*

Groupmate: Alex

- ***The cause of low pressure is*** due to the proportional heaters not activating, even though the CV is down to 16 pct. which is caused by the fact that CHTRC control is turned off manually.
- ***Indicators I used are*** the value shown for CV at PK-444A
- ***In this scenario, the operator should*** turn on the CHTRC control manually, continuously monitor the temperatur changes, and maybe think of turning on a backup heater manually in the start.