

# E3631A 可编程直流电源测试程序使用说明

谢承臻

日期：2023 年 10 月 10 日

## 1 设备参数

E3631A<sup>1</sup>只有后面的一个 USB 接口，三个通道的输出电压电流范围如下：

- CH1: V(0V, 6.18V), \*RST<sup>2</sup> = 0V; I(0.001A, 5.15A), \*RST = 5A.
- CH2: V(0V, 25.75V), \*RST = 0V; I(0.001A, 1.03A), \*RST = 1A.
- CH3: V(-25.75V, 0V), \*RST = 0V; I(0.001A, 1.03A), \*RST

## 2 测试代码说明

测试程序为 [ES3631A.py](#)，使用时根据以下步骤进行：

1. 修改 `resource_name` 的值，这是仪器 I/O 接口的参数，在设备前面板按照 Utilities → I/O Config → USB Status 的按键顺序查看。实验室里一台是 MY61003060，另一台是 MY61002637；

2. 初始化设置，一般不用改；

3. 主体部分<sup>3</sup>，要干啥任务在这设置。这块用的库是 `keysight_kte36000`，有啥函数要用点[这里](#)找说明。下面是一些常用的函数：

```
set_voltage_level(self: keysight\_kte36000.keysight\_kte36000.KtE36000Output, voltage: float, channel_list: str) → None
Specifies the output voltage level.

Parameters:: • voltage (float) – The Voltage level.
              • channel_list (str) – Channel List. e.g. (@1) for channel 1 or (@1,2) for channel 1 and 2 or (@1:3) for channel 1 to 3 etc.

Returns::    None
```

图 1: 设置输出电压

```
set_current_limit(self: keysight\_kte36000.keysight\_kte36000.KtE36000Output, current: float, channel_list: str) → None
Programs the immediate current level of the power supply in amperes.

Parameters:: • current (float) – Current level.
              • channel_list (str) – Channel List. e.g. (@1) for channel 1 or (@1,2) for channel 1 and 2 or (@1:3) for channel 1 to 3 etc.

Returns::    None
```

图 2: 设置输出电流

---

<sup>1</sup>具体的编程指南和用户指南见 `./manual`

<sup>2</sup>默认值

<sup>3</sup>位置在第一个 bookmark 后

`set_enabled(self: keysight\_kte36000.keysight\_kte36000.KtE36000Output, enabled: bool, channel_List: str) → None`

Enables or Disables the selected power supply output.

**Parameters::**

- enabled (bool) – The output enable state for the specified channels.
- channel\_list (str) – Channel List. e.g. (@1) for channel 1 or (@1,2) for channel 1 and 2 or (@1:3) for channel 1 to 3 etc.

**Returns::** None

图 3: 使能设置

`measure(self: keysight\_kte36000.keysight\_kte36000.KtE36000Measurement, measure_type: keysight\_kte36000.keysight\_kte36000.FetchType, channel_List: str) → float`  
Returns the measured value.

**Parameters::**

- measure\_type ([FetchType](#)) – The measure type.
- channel\_list (str) – Channel List. e.g. (@1) for channel 1 or (@1,2) for channel 1 and 2 or (@1:3) for channel 1 to 3 etc.

**Returns::** Measured value.

**Return type::** [float](#)

**Remarks::**

- MEAS:ARR:CURR – Queries return an array containing the instantaneous input current.
- MEAS:ARR:VOLT – Queries return an array containing the instantaneous input voltage.
- MEAS:ARR:POW – Queries return an array containing the instantaneous input power.

图 4: 返回测量结果

**class FetchType**

Select the Fetch Type.

Members:

CURRENT : The current.

VOLTAGE : The Voltage.

POWER : The Power.

CURRENT\_ACDC : The total rms(AC+DC) measurement.

CURRENT\_MAX : The maximum current.

CURRENT\_MIN : The minimum current.

VOLTAGE\_ACDC : The total rms(AC+DC) measurement.

VOLTAGE\_MAX : The maximum voltage.

VOLTAGE\_MIN : The minimum voltage.

POWER\_MAX : The maximum power.

POWER\_MIN : The minimum power.

图 5: FetchType 类

4. 检查报错，用的函数是 `utility.error_query`。一般不用改，报的啥错看打印结果就好。

5. 打开终端到程序所在目录下运行程序即可。