

Enabled Mirror / Puddle Lights When Mirrors Are Closed

Allows the puddle light to operate, even when the mirrors are closed

Select Modules 42 and 52

Coding – Byte 01

Bit 05 – Deactivated

Enable Traffic Information (TMC) on Headunit

This enables the ‘Traffic’ button to work on the headunit, and will use radio frequency data to display nearby traffic information. Once activated, it may take over an hour for the initial messages to appear.

Select Control Unit 5F (Information Control Unit)

Adaptations

Change Fee Based Traffic Information (TMC) value to ‘1024’

**Next, in the normal radio settings, enable ‘Traffic Programme (TP)’ and RDS
If you get an error, turn the headunit OFF and try again.**

Disable ‘Ignition On’ Alarm

This disabled the ignition on alarm which is activated when the drivers door is opened.

Module 17

Adaptation

Search ‘Ignition’

Select “Ignition Active Message, Actuator”

Set to ‘No Display’

Heated Seat Memory

Heated seats will resume last setting upon re-entering the vehicle.

Select Control Unit 08 – HVAC

Adaptation

Change “Retention of the seat heater level driver” to active

Change “Retention of the seat heater level passenger” to active

Starting Vibration Reduction

In wheel slip scenarios, where wheel hop is typically induced, this tweak will stop the intervention of the braking system, allowing you to continue spinning the wheels. Assist with launching the vehicle, and stops the car from ‘bogging down’.

Select Control Unit 03 – Brake

Adaptation

Starting Vibration Reduction

Set to Starting Vibration Reduction and Torque Limitation to ‘Deactivated’

Haldex All-Wheel-Drive Adjust Traction

Reports indicate that changing this setting to ‘Increased Traction’ improves the handling and makes the car feel like a permanent AWD system.

Select AWD Control Unit

Adaptation

Acoustic Measure, Wiring Logic

Choose from ‘Standard, Increased Traction, Less Noise’

Enable Auto High Beam (Light Assist)

Enables the Auto High Beam for Highline Models Only.

Select Control unit 09 (Central Electrics)

Security access

Access Code 31347

Adaptation

1. Fernlicht_assistent – Menuesteuerung Fernlichtassistent – Change to ‘Present’

2. Fernlicht_assistent – Erweiterte_Fernlichtsteuerung – Change to ‘AFS, FLA, Fernlicht ueber AFS’

Enter Coding

Byte 2 – Tick Bit 0 and Bit 1

Select Control Unit Front Sensor Driver Assist System (A5)

Enter Coding

Byte 21 – Tick Bit 5

Reboot Headunit. Option will now appear under ‘Light Settings’ and pushing the high beam stalk forward will reveal the symbol with an ‘A’ within it.

Enable Adaptive Lane Guidance (Holds Vehicle in Centre of Lane)

This tweak will enable ALG, which holds the vehicle in the centre of the lane.

Can also be used to adjust sensitivity

Select Module A5

Coding

Security Key: 20103

**Change ‘Point of Intervention’ to desired value e.g ‘Early’
This will now appear as a menu option under ‘Driver Assistance’**

Disable Sat Nav Safety Warning

This tweak disabled the safety warning which appears each time you turn the car on

**Select 5F
Coding
Byte 23
Initial Disclaimer – Off
Legal Disclaimer – Off**

Oil Temperature Display in Cluster

Displays the engine oil temperature in the cluster.

**Select Control unit 17
Control unit long coding
Byte 10
Bit 01 Activate**

Disable Start / Stop (Voltage Method)

Disable engine Start / Stop functionality.

**Select Control unit 19
Adaptation
Start Stop Limit voltage
Value=12**

XDS Differential Lock Adjustment

XDS is an electronic differential lock, and lets you grip the road when cornering fast. It improves responses to ensure an even safer drive. In moments of fast cornering XDS lightly brakes the inside wheel to prevent wheel spinning. The result is better traction and a reduction of any tendency to under steer. This tweak will vary the aggressiveness of XDS.

**Select Control unit 03 (ABS)
Adaptation
Select: Expanded Electronic Differential Lock
Options: Weak – Normal – Hard**

Brake Drying System

This function increases safety in heavy rain, by applying the brake pads to the brake discs at prescribed intervals, in order to wipe away the unwanted film of water. Most drivers won't even feel the system operating.

Select Control unit 03 (ABS)

Adaptation

Select: Disc Drying

Options: Weak-Normal-Hard

Auto Close Windows When Raining

When rain is detected on the rain sensor, the windows will automatically close.

Select Control unit 09 (Central Electrics)

Security access

Access code 31347

Adaptation

(15) Access Control 2-Regenschliessen_ein_aus

Value: Permanent

(16) Access Control 2-Regenschliessen_art

Value: Permanent

(28) Zugriffskontrolle 2-Menuesteuerung Regenschliessen

Value:Aktif

Select Control unit 09 (Central Electrics)

Control unit Long Coding

Subsystem: Rain / Light Sensor (RLS)

Byte 0

Bit 1-Bit 2 DeActivate

Fan Speed Display on Auto Mode

Show the A/C fan speed when operating in auto mode.

Select Control unit 08 (Air condition A/C)

Control unit Long Coding

Byte 11

Bit 6 Activate

Cornering Fog Light Activation

Left or right fog light will turn on when indicating. Fog lights must be fitted.

Select Control unit 09 (Central Electrics)

Security access

Access Code 31347

Adaptation

(5) Leuchte12NL LB45-Lichtfunktion B12 auswählen

Select: Abbiegelicht links

(5) Leuchte13NL RB5-Lichtfunktion B13 auswählen

Select: Abbiegelicht rechts

Adjusting Cornering Fog Light Sensitivity (Speed Threshold)

With the above tweak enabled, this will adjust the speed in which cornering fog lights will turn on. Fog lights must be fitted.

Select Control unit 09 (Central Electrics)

Security access

Security Code 31347

Adaptation

(3) Static cornering light lower speed threshold

New Value = 0

(4) Static cornering light upper speed threshold

New Value = 50

Hill Hold Assist Duration

Adjust how long the brakes ‘hold’ the vehicle when taking off on a steep hill.

Select Control unit 03 (Brakes)

Adaptation

Select Hill-start Assistant

Adjust as you wish. (default: Normal)

Refuel Amount in Cluster

After refuelling, the amount in litres will be displayed in the cluster.

Select Control unit 17 (Dashboard)

Control unit long coding

Byte 10

Bit 4 Activate

Lock Acknowledge with Horn

The horn will beep when locking the vehicle.

Select Control unit 09 (Central Electrics)

Security access

Access code 31347

Adaptation

(1) feedback signals-Acoustic feedback

Value=Yes

(2) Lock feedback signals-Acoustic feedback

Value=Yes

(8) feedback signals-Acoustic feedback global

Value=Aktive

(7) feedback signals-Acoustic feedback

Value=Active

(8) feedback signals-Acoustic feedback duration

Value=Short(kurz)

Deactivate Warning Tone for Parking System

Disables the sounder for the parking sensors.

Select Control unit 03 (Brakes)

Adaptation

Park Assist Activation Tone

Value = OFF

Parking Warning Speed Change

Sets the speed where the parking sensors will be disabled.

Select Control unit 03 (Brakes)

Adaptation

Shutdown parking aid

Value = 20km/h

Hide Optical Parking System Warning Line

Disables the 'Please check surroundings' message that appears on the headunit when parking.

Select Control unit 03 (Brakes)

Security access

Access code:71679

Control unit Coding

Byte 1

Bit 5 DeActivate

Change Cluster Graphics

Change the cluster background visuals to different models

Select Dashboard (17)

Adaptation

Tube_Version

Variant_2 = Default

Variant_3 = Golf GTI

Variant_4 = Golf R

Seat Belt Warning Deactivation

Disables the audible seat belt warning.

Select Control unit 17 (Dashboard)

Adaptation

Select:Disable channel belt warning

Value:Yes

Control unit long coding

Byte 0

Bit 2-4 Deactivate

De-Fogger Timer

Adjust the operating time of the rear window de-fogger

Select Control unit 09 (Central Electrics)

Security access

Access Code 31347

Adaptation

(3) Window Air condition A/C condition A/C rear window heating value

Enter desired value

Tap to Indicate – Number of Blinks

When tapping the indicator to turn, this tweak will change the number of times the indicator blinks.

Select Control unit 09 (Central Electrics)

Security access

Access Code 31347

Adaptation

Aussenlicht_Bling

Komfortblinken Blinkzyklen

Value: 1-5 Value 3 (Standard – 3x blinking)

Traffic Sign Assist Activation (Car must be fitted with Camera)

Vehicle camera will read traffic signs and display the posted speed in the cluster.

Select Control unit 5F (Information Electrical)

Adaptation

Select Car_Function_List_BAP_Gen2 traffic_sign_recognition_0x21

Değer=Active

Select Car_Function_Adaptations_Gen2-menu

menu_display_road_sign_identification

Değer=Active

Go to Long Coding

Byte 24, Activate Bit 6

Control unit A5 (front / advance camera)

Security access

Access Code 20103

Control unit Long Coding

Byte 16, Activate Bit 4

Select Control unit 17 (Dashboard)

Control unit Long Coding

Byte 5

Activate Bit 2

Control unit A5 (front / advance camera)

Adaptation

Road Sign Detection Fusion Mode

Change to 'Road Sign Detection'

Reboot Infotainment

Lane Assist Activation (Car must be fitted with Camera)

Vehicle camera will attempt to keep the vehicle within the current lane.

Select Control unit 17 (Dashboard)

Control unit Long Coding

Byte 4

Bit 6 Activate

Byte 11

Bit 1 Activate

Select Control unit A5 (front / advance camera)

Control unit Long Coding

Bye 0

Bit 0 Activate

Select Control unit A5 (front / advance camera)

Security access

Access Code 20103

Adaptation

Channel – Seçim HCA_On_State

Put emphasis on menu

Channel – Seçim HCA_Warning_intensity

Put emphasis on menu

Channel – Seçim BAP_Personalisierung

Put emphasis on not activated

Select the time of engagement

Set adjustment via menu – emphasis on late

Select Personalization spurt holding an assistant to a terminal 15 – channel

Set value to last setting

Select Control unit 44 (power steering)

Control unit Long Coding

Bye 0

Bit 0 Aktif

Select Control unit 5F (Informationselektronik)

Adaptation

(49) function -Vehicle list BAP LDW_HCA_0x19

Activate

(21) vehicle menu operation-menu_display_Lane_Departure_Warning

Activate

(23) vehicle menu

Bedienung_menu_display_Lane_Departure_Warning_over_threshold_high – channel

Activate

Lane Assist Adjustments (Car must be fitted with Camera)

Adjust the point in which the steering wheel will vibrate to indicate the vehicle is drifting out of the lane.

Steering Wheel Vibration

Select Control unit A5 (camera)

Security access

Enter unlock code 20103

Adaptation

Select channel intensity steering wheel vibration

Value adjust accordingly Default: medium options: early, middle, late

Drivers Reaction Adjustment (Car must be fitted with Camera)

Adjusts the sensitivity in which the car will alert the driver due to lack of steering input.

Select Control unit A5 (camera)

Security access

Enter unlock code 20103

Adaptation

Select channel deactivation threshold driver activity

Value adjust accordingly Default: medium options: early, middle, late

Lap Timer Activation

Enable the Lap Timer in the cluster.

Select Control unit 17 (Dashboard)

Control unit Long Coding

Byte 1

Bit 3 Activate

Disable Overtaking on Right Prevention (Undertaking)

Allows ACC equipped RHD vehicles to overtake on the left side, which is blocked by default.

Adaptive Cruise Control (Module 13)

Long Coding

Overtaking_right_prevention

New Value Deactivated

Security code 20103

Changing the Headunit Boot Screen

Change the boot screen picture to different models

Select Control unit 5F (infotainment)

Coding

Byte_18_Screenings

0 = None

1 = Hybrid

2 = Golf GTD
3 = Golf GTI
4 = Golf Bluemotion
5 = E-Golf
6 = R Line
7 = Golf R

Gauge Needle Sweep

When starting the vehicle, the cluster needles will ‘sweep’ their entire range.

Select Control unit 17 (Dashboard)
Control unit long coding
Byte 1
Bit 0 Activate (Ignore Bit 1, it will not work)

Adjusting Microphone Sensitivity

Adjusts the microphone gain for handsfree usage.

Select Control unit 5F (infotainment)
Adaptation
Select Mikrofonempfindlichkeit (Microphone Sensitivity)
Adjust value as you wish.

Sunroof Opening With Remote Control

Sunroof opens when holding down the unlock button on the key fob. Also closes when holding lock button.

Select Control unit 09 (Central Electrics)
Security access
Access Code 31347
Adaptation
(9) – Zugangskontrolle 2 – SAD Richtung Komfortöffnen auswählen
Change to Active

DRL Control on Car Menu

Enables a setting on your headunit which allows you to completely disable the Daytime Running Lights.

Select Control unit 09 (Central Electrics)
Security access
Access Code 31347
Adaptation

(2) Daytime running light activation by BAP or Operating sequence possible
Value = Aktif

Enable Trailer Assist

Enables 'Trailer Assist' option under the headunit settings.

Select Park Assist Module (76)

Coding

Byte 0, Tick Bit 3

Select Instruments Module

Coding

Byte 12, Tick Bit 5

Select Reversing Camera Module

Coding

Byte 10, Tick Bit 3