


Pocket

Start Up

Quick Instructions
for initial start-up of

UNIDRIVE




WARNING: This is a brief guide only. It does not give safety information. Incorrect installation or operation of the drive could cause personal injury or equipment damage. Refer to Unidrive  User Guide for essential safety information.




**CONTROL
TECHNIQUES**
www.controltechniques.com

Power Wiring


DC Connections




WARNING

For complete wiring and fusing instructions, refer to the Unidrive  User Guide



*Thermal overload for external braking resistor to protect against fire risk. This must be wired to interrupt the AC supply in event of a fault



AC Connections



Heatsink mounted braking resistor

A resistor has been especially designed to be mounted within the heatsink of the Unidrive  (sizes 1 and 2). The design of the resistor is such that no thermal protection circuit is required, as the device will fail safely under fault conditions. On Unidrive  sizes 1 and 2, the in built software overload protection is set up at default for the designated heatsink mounted resistor. If an external brake resistor is used, a thermal overload device is required, refer to User Guide.





NOTE The heatsink mounted resistor is suitable for applications with a low level of regen energy only.

Control Wiring

Wire the Unidrive **SD** control circuits in accordance with drawing below.


Terminal Strips

Default Terminal Functions



Encoder Wiring


Closed Loop Vector



Terminal	Connections
1	A
2	A\
3	B
4	B\

Terminal	Connections
5	Z
6	Z\
13	+V
14	0V

Servo



Terminal	Connections
1	A
2	A\
3	B
4	B\
5	Z
6	Z\
7	U
8	U\
9	V
10	V\
11	W
12	W\
13	+V
14	0V
15	Th

- Z - Marker pulse is optional.
- Encoder screening connected to drive 0V and encoder 0V.
- Connections shown are for default Quadrature Incremental Encoder, for other encoder types please refer to User Guide.

Keypad & Display

Upper Display


Parameter number
or drive status

Control buttons

Fwd/Rev (blue) button

Stop/Reset (red) button

Start (green) button



Lower Display

Parameter value
or trip code

Mode (black) button

changes between
parameter edit and
monitor mode

Joypad

Used to select a parameter
and change its value

Display Modes

Status Mode
(Display not
flashing)



To enter Parameter
Mode, press **M** key or



Timeout


Parameter Mode
(Upper display
flashing)



Use  keys
to select parameter for editing



To enter Edit Mode,
press **M** key

When returning
to Parameter
Mode use the
 keys to select
another parameter
to change, if
required



Edit Mode

(Character to be edited in lower line of display flashing)

Change parameter values using  keys.


To return to
Status Mode,
press **M** key

Timeout

**Temporary
Parameter
Mode**
(Upper display
flashing)

To exit Edit Mode,
press **M** key

Reset to Factory Defaults

Enter the appropriate value shown below into Pr 0.00 and
then press the  button.

Lower Display Function


1233

Resets parameters to 50Hz supply default

1244

Resets parameters to 60Hz supply default

Open Loop start-up

The Unidrive  default operating mode is Open Loop. See Control Wiring diagram for default connections.

Before power-up

Ensure:

- The drive enable signal is not given (terminal 31)
- Run signal is not given (terminal 26)
- Motor is connected

Power-up the drive



Ensure:

- Drive displays 'inh'

If the drive trips, see Trip Codes.

Enter motor nameplate details

Enter:

- Motor rated frequency in Pr 0.47 (Hz)
- Motor rated current in Pr 0.46 (A)
- Motor rated speed in Pr 0.45 (rpm)
- Motor rated voltage in Pr 0.44 (V) -
check if  or  connection

Set maximum frequency

Enter:

- Maximum frequency in Pr 0.02 (Hz)

Set acceleration/deceleration rates

Enter:

- Acceleration rate in Pr 0.03 (s/100Hz)
- Deceleration rate in Pr 0.04 (s/100Hz) (If braking resistor fitted, set Pr 0.15 = FAST.)

Open Loop start-up continued

Autotune

Unidrive SP is able to perform either a stationary or a rotating autotune. The motor must be at a standstill before an autotune is enabled. A rotating autotune should be used whenever possible.



WARNING: A rotating autotune will cause the motor to accelerate up to 2/3 base speed in the direction selected regardless of the reference provided. Once complete the motor will coast to a stop. The run signal must be removed before the drive can be made to run at the required reference. The drive can be stopped at any time by removing the run signal or removing the drive enable.

- A stationary autotune can be used when the motor is loaded and it is not possible to remove the load from the motor shaft. A stationary autotune does not measure the power factor of the motor so the value on the motor nameplate must be entered into Pr 0.43
- A rotating autotune should only be used if the motor is unloaded or the load is uncoupled

To perform an autotune:

- Set Pr 0.40 = 1 for a stationary autotune or set Pr 0.40 = 2 for a rotating autotune
- Close the Drive Enable signal (terminal 31). The drive will display 'rdY'
- Close the run signal (terminal 26 or 27). The lower display will flash 'Auto' and 'tunE' alternatively, while the drive is performing the autotune
- Wait for the drive to display 'rdY' and for the motor to come to a standstill

Remove the run signal from the drive.

Run

- Drive is now ready to run

Closed Loop start-up

See **Control Wiring** section for default connections.

Step	Description	Actions	Display
Allow drive operating mode to be changed	Go to Parameter 0.00 Enter 1253 EUR Enter 1254 USA Finish Step	 	Upper = 0.00 Lower = 1253
Select Closed Loop Vector Operation	Go to Parameter 0.48 Select CL.VECT Finish Step	 	Upper = 0.48 Lower = CL VECT

Before power-up

Ensure:

- Drive Enable signal is not given (terminal 31)
- Run signal is not given (terminal 26)
- Motor and encoder are connected

Power-up the drive

Ensure:

- Drive displays 'inh'

If the drive trips, see Trip Codes.

Set motor feedback parameters

Incremental encoder basic set-up

Enter:

- Drive encoder Lines Per Revolution in Pr 0.27 (set according to encoder)

Enter motor nameplate details

Enter:

- Motor rated frequency in Pr 0.47 (Hz)
- Motor rated current in Pr 0.46 (A)
- Motor rated full load speed (base speed - slip speed) in Pr 0.45 (rpm)
- Motor rated voltage in Pr 0.44 (V) - check if or connection

Set maximum speed

Enter:


- Maximum speed in Pr 0.02 (rpm)

Closed Loop start-up continued

Set acceleration/deceleration rates

- Acceleration rate in Pr 0.03 (s/1000rpm)
- Deceleration rate in Pr 0.04 (s/1000rpm) (If braking resistor fitted, set Pr 0.15 = FAST.)

Autotune

Unidrive  is able to perform either a stationary or a rotating autotune. The motor must be at a standstill before an autotune is enabled. A rotating autotune should be used wherever possible.



WARNING: A rotating autotune will cause the motor to accelerate up to 2/3 base speed in the direction selected regardless of the reference provided. Once complete the motor will coast to a stop. The run signal must be removed before the drive can be made to run at the required reference. The drive can be stopped at any time by removing the run signal or removing the drive enable.

- A stationary autotune can be used when the motor is loaded and it is not possible to remove the load from the motor shaft. A stationary autotune does not measure the power factor of the motor so the value on the motor nameplate must be entered into Pr 0.43
- A rotating autotune should only be used if the motor is unloaded or the load is uncoupled

To perform an autotune:

- Set Pr 0.40 = 1 for a stationary autotune or set Pr 0.40 = 2 for a rotating autotune
- Close the Drive Enable signal (terminal 31). The drive will display 'rdY'
- Close the run signal (terminal 26 or 27). The lower display will flash 'Auto' and 'tunE' alternatively, while the drive is performing the autotune.
- Wait for the drive to display 'rdY' and for the motor to come to a standstill










Remove the run signal from the drive.

Run

- Drive is now ready to run

Servo start-up

See **Control Wiring** section for default connections.

Step	Description	Actions	Display
Allow drive operating mode to be changed	Go to Parameter 0.00 Enter 1253 EUR Enter 1254 USA Finish Step	   	Upper = 0.00 Lower = 1253
Select Servo Operation	Go to Parameter 0.48 Select SErVO Finish Step	    	Upper = 0.48 Lower = SErVO

Before power-up

Ensure:

- Drive Enable signal is not given (terminal 31)
- Run signal is not given (terminal 26)
- Motor is connected
- Encoder is connected

Power-up the drive

Ensure:

- Drive displays 'inh'

If the drive trips, see Trip Codes.

Set motor feedback parameters

Incremental encoder basic set-up

Enter:

- Drive encoder Pulses Per Revolution in Pr. 0.27
(set according to encoder)

Enter motor nameplate details

Enter:

- Motor rated current in Pr 0.46 (A)
- Motor rated voltage in Pr 0.44 (V)
- Number of poles in Pr 0.42 (if Pr 0.42 is set to Auto, then the number of poles is 6)

Set maximum speed

Enter:

- Maximum speed in Pr 0.02 (rpm)

Servo start-up continued

Set acceleration/deceleration rates

- Acceleration rate in Pr 0.03 (s/1000rpm)
- Deceleration rate in Pr 0.04 (s/1000rpm) (If braking resistor fitted, set Pr 0.15 = FAST.)

Autotune

The load must be removed from the shaft before an Autotune is performed.



WARNING: The normal low speed test will rotate the motor by up to 2 revolutions in the direction selected, regardless of the reference provided. Once complete the motor will come to a standstill. The run signal must be removed before the drive can be made to run at the required reference. The drive can be stopped at any time by removing the run signal or removing the Drive Enable.

To perform an autotune:

- Set Pr 0.40 = 2
- Close the run signal (terminal 26 or 27).
- Close the Drive Enable signal (terminal 31). The lower display will flash 'Auto' and 'tunE' alternatively, while the drive is performing the test.
- Wait for the drive to display 'StoP' and for the motor to come to a standstill.

If the drive trips, see Trip Codes.

Remove the run signal from the drive.

Run

- Drive is now ready to run

Display Messages

Status Messages

Upper Display Description

Auto tUnE	Autotune in progress. The autotune procedure has been initialised. 'Auto' and 'tunE' will flash alternatively on the display.
dEC	Decelerating. The drive is decelerating the motor.
inh	Inhibit. The drive is inhibited and cannot be run. The drive enable signal is not applied to terminal 31 or Pr 6.15 is set to 0.
rdY	Ready. The drive is ready to be run.
run	Running. The drive is running.
Stop	Stop or holding zero speed. The drive is holding zero speed.
trIP	Trip condition. The drive has tripped and is no longer controlling the motor. The trip code appears on the upper display.
OVLd	Motor overload alarm. The motor I ² t accumulator in the drive has reached 75% of the value at which the drive will be tripped and the load on the drive is >100%.

Trip Codes

Lower Display Function

UU	Undervoltage
OU	Overvoltage
0 IAC	Instantaneous Overcurrent
Et	External Trip
IE.AC	Motor Overload
Et	Motor Overtemp or Thermistor circuit open
Ph	Input Power Phase Loss
Enc2	Encoder wire break
IE.br	Braking resistor trip

For other status messages and trip codes please refer to User Guide.

Basic Parameters (Menu 0)

Parameter			Range(↕)			Default(↔)		
			OL	VT	SV	OL	VT	SV
0.00	xx.00	{x.00}	0 to 32,767			0		
0.01	Minimum reference clamp	{1.07}	±3,000.0Hz	±Speed_limit_max rpm		0.0		
0.02	Maximum reference clamp	{1.06}	0 to 3,000.0Hz	Speed limit_max rpm		EUR> 50.0 USA> 60.0	EUR> 1,500.0 USA> 1800.0	3,000.0
0.03	Acceleration rate	{2.11}	0.0 to 3,200.0 s/100Hz	0.000 to 3,200.000 s/1,000rpm		5.0	2.000	0.200
0.04	Deceleration rate	{2.21}	0.0 to 3,200.0 s/100Hz	0.000 to 3,200.000 s/1,000rpm		10.0	2.000	0.200
0.05	Reference select	{1.14}	A1.A2 (0), A1.Pr (1), A2.Pr (2), Pr (3), Pad (4), PrC (5)			A1.A2 (0)		
0.06	Current limit	{4.07}	0 to Current_limit_max %			165.0	175.0	
0.07	OL> Voltage mode select	{5.14}	Ur_S (0), Ur (1), Fd (2), Ur_Auto (3), Ur I (4), SrE (5)			Ur_I (4)		
	CL> Speed controller P gain	{3.10}	0.0000 to 6.5535 1/rad s ⁻¹			0.0100		
0.08	OL> Voltage boost	{5.15}	0.0 to 25.0% of motor rated voltage			3.0		
	CL> Speed controller I gain	{3.11}	0.00 to 655.35 1/rad			1.00		
0.09	OL> Dynamic V/F	{5.13}	OFF (0) or On (1)			0		
	CL> Speed controller D gain	{3.12}	0.00000 to 0.65535 (s)			0.00000		
0.10	OL> Estimated motor speed	{5.04}	±180,000 rpm					
	CL> Motor speed	{3.02}	±Speed_max rpm					
0.11	OL & VT> Drive output frequency	{5.01}	±Speed_freq_max Hz					
	SV> Drive encoder position	{3.29}	0 to 65,535 1/2 ¹⁶ ths of a revolution					
0.12	Total motor current	{4.01}	0 to Drive_current_max A					
0.13	OL & VT> Motor active current	{4.02}	±Drive_current_max A					
	SV> Analog input 1 offset trim	{7.07}	±10.000 %			0.000		
0.14	Torque mode selector	{4.11}	0 to 1	0 to 4		Speed control mode (0)		
0.15	Ramp mode select	{2.04}	FAST (0) Std (1) Std.hV (2)	FAST (0) Std (1)		Std (1)		
0.16	OL> T28 and T29 auto- selection disable	{8.39}	OFF (0) or On (1)			0		
	CL> Ramp enable	{2.02}	OFF (0) or On (1)			On (1)		
0.17	OL> T29 digital input destination	{8.26}	Pr 0.00 to Pr 21.51			Pr 6.31		
	CL> Current demand filter time constant	{4.12}	0.0 to 25.0 ms			0.0		
0.18	Positive logic select	{6.29}	OFF (0) or On (1)			On (1)		
0.19	Analog input 2 mode	{7.11}	0-20 (0), 20-0 (1), 4-20tr (2), 20-4tr (3), 4-20 (4), 20-4 (5), VOLT (6)			VOLT (6)		
0.20	Analog input 2 destination	{7.14}	Pr 0.00 to Pr 21.51			Pr 1.37		
0.21	Analog input 3 mode	{7.15}	0-20 (0), 20-0 (1), 4-20tr (2), 20-4tr (3), 4-20 (4), 20-4 (5), VOLT (6), th.SC (7), th (8), th.diSp (9)			VOLT (6)		
0.22	Bipolar reference select	{1.10}	OFF (0) or On (1)			OFF (0)		
0.23	Jog reference	{1.05}	0 to 400.0 Hz	0 to 4000.0 rpm		0.0		
0.24	Pre-set reference 1	{1.21}	±Speed_limit_max rpm			0.0		
0.25	Pre-set reference 2	{1.22}	±Speed_limit_max rpm			0.0		
0.26	OL> Pre-set reference 3	{1.23}	±Speed_freq_max Hz/rpm			0.0		
	CL> Overspeed threshold	{3.08}	0 to 40,000 rpm			0		
0.27	OL> Pre-set reference 4	{1.24}	±Speed_freq_max Hz/rpm			0.0		
	CL> Drive encoder lines per revolution	{3.34}	0 to 50,000				1024	4096
0.28	Keypad fwd/rev key enable	{6.13}	OFF (0) or On (1)			OFF (0)		

Basic Parameters (Menu 0) cont.

Parameter			Range(↕)			Default(↔)		
			OL	VT	SV	OL	VT	SV
0.29	SMARTCARD parameter data	{11.36}	0 to 999			0		
0.30	Parameter cloning	{11.42}	nonE (0), rEAd (1), Prog (2), Auto (3), boot (4)			nonE (0)		
0.31	Drive rated voltage	{11.33}	200 (0), 400 (1), 575 (2), 690 (3) V					
0.32	Drive rated current	{11.32}	0.00 to 9999.99A					
0.33	OL> Catch a spinning motor	{6.09}	0 to 3			0		
	VT> Rated rpm autotune	{5.16}		0 to 2			0	
0.34	User security code	{11.30}	0 to 999			0		
0.35	Serial comms mode	{11.24}	AnSI (0) rtu (1)			rtU (1)		
0.36	Serial comms baud rate	{11.25}	300 (0), 600 (1), 1200 (2), 2400 (3), 4800 (4), 9600 (5), 19200 (6), 38400 (7), 57600 (8) Modbus RTU only, 115200 (9) Modbus RTU only			19200 (6)		
0.37	Serial comms address	{11.23}	0 to 247			1		
0.38	Current loop P gain	{4.13}	0 to 30,000			All voltage ratings: 20	200V drive: 75 400V drive: 150 575V drive: 180 690V drive: 215	
0.39	Current loop I gain	{4.14}	0 to 30,000				All voltage ratings 40	200V drive: 1000 400V drive: 2000 575V drive: 2400 690V drive: 3000
0.40	Autotune	{5.12}	0 to 2	0 to 3		0		
0.41	Maximum switching frequency	{5.18}	3 (0), 4 (1), 6 (2), 8 (3), 12 (4), 16 (5) kHz			3 (0)		6 (2)
0.42	No. of motor poles	{5.11}	0 to 60 (Auto to 120 pole)			0 (Auto)		6 POLE (3)
0.43	OL & VT> Motor rated power factor	{5.10}	0.000 to 1.000			0.850		
	SV> Encoder phase angle	{3.25}			0.0 to 359.9°			0.0
0.44	Motor rated voltage	{5.09}	0 to AC_voltage_set_max V			200V drive: 230 400V drive: EUR> 400, USA> 460 575V drive: 575 690V drive: 690		
0.45	OL & VT> Motor rated full load speed (rpm)	{5.08}	0 to 180,000 rpm	0.00 to 40,000.00 rpm		EUR> 1,500 USA> 1,800	EUR> 1,450.00 USA> 1,770.00	
	SV> Motor thermal time constant	{4.15}			0.0 to 400.0			20.0
0.46	Motor rated current	{5.07}	0 to Rated_current_max A			Drive rated current [11.32]		
0.47	Rated frequency	{5.06}	0 to 3,000.0 Hz	0 to 1,250.0 Hz		EUR> 50.0 USA> 60.0		
0.48	Operating mode selector	{11.31}	OPEn LP (1), CL VEC1 (2), SErVO (3), rEGEn (4)			OPEn LP (1)	CL VEC1 (2)	SErVO (3)
0.49	Security status	{11.44}	L1 (0), L2 (1), Loc (2)					
0.50	Software version	{11.29}	1.00 to 99.99					

SMARTCARD

Drive reads all parameters from the SMARTCARD



Pr 0.30 = rEAD + ●

Programs all drive parameters to the SMARTCARD



Pr 0.30 = Prog + ●

Drive automatically writes to the SMARTCARD when a parameter save is performed



Pr 0.30 = Auto + ●

Boot



Pr 0.30 = boot + ●

Drive boots from the SMARTCARD on power up and automatically writes to the SMARTCARD when a parameter save is performed