

Send and receive data display area instructions

Send and receive data display area

[illegible]

Clear: empty to send and receive data display so data

Pause: pause in the sending and receiving display area shows that other data

Continue to: [continue to show to send and receive data](#)

Save: can send and receive data buffer data storage that can hold two format, excel or TXT text

☐ **Auto save** : After selecting, the software will automatically save the data in the transceiver cache area.

Display receive only: can send and receive data area show only accept data

Statistics: when display only accept data, CAN choose to be automatic refresh, this time data are real-time refresh, rather than increasing

Total: The capacity to receive data cache is the most volume. If the capacity of this data is exceeded, it will refresh data from scratch.

After selecting the transformation mode, click any line that needs to be converted in the receive and receive data buffer, and display the corresponding conversion data, such as the following

The data of the selected row is 16 hexadecimal display, and the following is displayed as unsigned 10 binary display.