

Agx Xavier开发套件 上电开机自启指导手册

瑞泰新时代（北京）科技有限公司

电话: +86 010-84284669 / 84280996 / 84278927

邮箱: info@realtimes.cn

网址: <http://www.realtimes.cn>

地址: 北京市朝阳区和平西街和平西苑 20 号楼 B 座 901





手册更新历史

文档版本	更新日期	更新内容	创建人
V1.0	2020-07	创建文档	项目部

RTIMES

本指南提供了 AGX Xavier 上电开机自启动指导说明

1、 硬件连接操作

3.5 Automation Header

The Jetson carrier board includes an 8-pin Header (J508) that makes accessible several critical system control signals.

Table 22. Automation Header Pin Descriptions

Pin #	Signal Name	Jetson Xavier Pin Name	Usage/Description	Type/Dir Default
1	GND	—	Ground	Ground
2	FORCE_RECOVERY*	FORCE_RECOVERY_N	Force Recovery Strap	Input
3	SYS_RST_IN*	—	System Reset – Connected to Reset Button on carrier board	Input
4	BUTTON_POWER_ON*	—	Power Button – Connected to Power Button on carrier board	Input
5	CCG4_LED	—	See note	Output
6	ACOK	—	AC (USB Type C or DC Jack) power OK	Input
7	CVB_STBY	—	Reserved	RSVD
8	SYSTEM_OC_N	SYSTEM_OC_N	System Overcurrent indicator	Input

Legend	Ground	Power	Reserved
--------	--------	-------	----------

Notes:

- Auto-Power-On is enabled when pins 5 & 6 are tied together
- In the Type/Dir column, Output is to Header. Input is from Header. Bidir is for Bidirectional signals.

将 J508 (8 引脚的排针) 的 5、6 脚进行短接。上电系统自动启动。