

## SMX<sup>®</sup> STMicro STM32746G-EVAL Board Support Notes IAR

January 12, 2019  
XiaoYi Chen

### Summary

The IAR STM32746G-EVAL and EVAL2 boards are built around a 32-bit STMicro STM32F746NG Cortex-M7 microcontroller. Cortex-M7 is an implementation of the ARM-M architecture, which is significantly different from the traditional ARM design (used by ARM7, 9, etc). **Please read the ARM-M section of the SMX Target Guide** for information about this architecture.

The BSP code consists of BSP\ARM\bsp.c and some other files in the directories BSP\ARM\STM32 and BSP\ARM\STM32\STM32F7xx. In BSPs for other processors, we keep bsp.c in the processor or board directory, but since the features it handles are all standard in the ARM-M core, we can share one file, bsp.c, for all ARM-M processors, even from different vendors. Sharing the file saves duplicating the code many times. The files in the STMicro subdirectory are from STMicro's firmware library. Only some of the files are used; add others to the App project, as needed. All changes we made are tagged "MDI:".

Notes:

1. There is a separate prefix file (.h) in the CFG directory for each board. For IAR, the one to use is selected in **iararm.h**.

Testing was done on these boards:

- STM32746G-EVAL Prototype. CPU ES32F746NGH6, 7BA2W VQ A, PHL 7B 443
- STM32746G-EVAL2. CPU STM32F746NGH6, 7BA3V VQ Z, PHL 3R 506 (see note below)
- STM32756G-EVAL2. CPU STM32F756NGH6, 7BA3U VQ Z, PHL 3R 506

**Problems** (may be also for other boards)

- We had trouble on the STM32746G-EVAL2 board using I-jet from the JTAG connector that made USB D flaky. Using the Trace port behind the LCD solved the problem. **We recommend covering the JTAG port with electrical tape and using the Trace port.**
- We had trouble on the STM32746G-EVAL2 board using I-jet or J-Link and with booting from ROM. We don't know if this was a defective board or if it had problems fixed on later boards. The 756 boards we received later do not have these problems.

2. Board selection in CFG\stm32746geval.h:

For EVAL (Rev A) uncomment #define USE\_STM32756G\_EVAL\_REVA.

For EVAL2 (Rev B), comment out this line. This is used in STMicro BSP code to select proper conditional code for each board.

3. All project files for this processor add the compiler switch **--no\_unaligned\_access** (see Extra Options tab in compiler settings) to Debug and Release build targets, to avoid processor faults on access to unaligned data in SDRAM. It tells the compiler not to generate unaligned data. The problem is caused because STMicro located SDRAM in the memory range for Device Memory, which requires 4-byte alignment. This switch has to be used in **all** project files for it to be effective. It is used for boards without SDRAM too, in case the project is cloned for another board that does have it.

### Jumper and Switch Settings:

This board has many solder bridges rather than jumpers. From the factory, the ones that are closed have a 0 ohm resistor. To open, remove it; to close just bridge the pads with solder.

- SW1 set to 0 to boot from Flash.
- Ethernet : JP6 1-2 for MII using external crystal X4 25 MHz and:  
EVAL/Rev A board: Solder bridge changes: SB5 closed (near CPU) and SB24 open. SB33 closed and SB22 open. Last 3 are on back of board.  
EVAL2/Rev B board: JP21 and JP22 2-3 (Ethernet). JP21 and JP22 are under the LCD, so release the white clip and tilt it up to access them.
- LEDs (on EVAL2/RevB board): JP23 and JP24 must be on 2-3 to select LD3 and LD1 rather than Camera and Potentiometer, respectively.
- Other jumpers are in the default positions or don't matter for our software.

### **IRQ Map**

<b>IRQ</b>	<b>Description</b>	<b>Interrupt Priority Level</b>	<b>Notes</b>
Int 15	SysTick	0x20 or 0x00	smx tick; all timing based on this
37	USART1	0xA0	Terminal output or serial data
49	SDIO Global	0x40	smxFS
59	SDIO DMA2 Stream3	0x20	smxFS
59	SDIO DMA2 Stream3	0x20	smxFS
61	Ethernet	0x40	smxNS
77	USB OTG HS	0x80	smxUSBD/smxUSBH

#### **Notes:**

1. SysTick has no IRQ number because it precedes the range of IRQs. IRQ0 is Int 16. SysTick does not appear in irq\_table[] and is hooked and configured specially, not using the usual BSP functions.
2. The STM32 processors support only 4 bits of priority levels (starting at the MSB), so there are only 16 priority levels: 0x00, 0x10, 0x20, ... 0xF0. Lower number is higher priority. Interrupts with the same priority level are prioritized by their IRQ number. The lower numbered IRQ has higher priority.
3. ISRs that use smx\_ISR\_ENTER/smx\_ISR\_EXIT should not be set to a lower value (higher priority) than SB\_ARMM\_BASEPRI\_VALUE (XBASE\barmm.h) because such level(s) are non-maskable and such ISRs must be maskable. These lower level(s) are reserved for special ISRs by using BASEPRI rather than PRIMASK to disable interrupts. SB\_ARMM\_DISABLE\_WITH\_BASEPRI in XBASE\barmm.h selects which method is used. See section Architectural Notes/ ISR Priority Level in the SMX Target Guide.
4. Interrupt priorities can be changed as desired. However, the priority of SysTick generally should be highest maskable level since all smx timing depends on it.

## Memory Map (Debug, Release, and ROM targets — Internal Flash, Internal SRAM)

Base Address	Size	Memory	Sections	Notes
0x00000000	1MB	Internal Flash	.intvec, .text, .rodata	Alias of 0x00200000 or 0x08000000 if boot switch SW1 at position 0.
0x00200000	1MB	Internal Flash (ITCM)	.intvec, .text, .rodata	Code and Read Only data. Faster bus.
0x08000000	1MB	Internal Flash (AXIM)	.intvec, .text, .rodata	Code and Read Only data. Slower bus.
0x20000000	64KB	Internal DTCM SRAM	SDAR, CSTACK, intvec	EVT, SDAR and System Stack, .intvec (EVT) copied here by startup code. See note about DTCM in Memory Configuration section.
0x20010000	240KB	Internal SRAM	.noinit, .bss, .data, ADAR, EMAC_BUFFER	Data and ADAR. smxNS frame buffers.
0x2004C000	16KB	Internal SRAM		unused
0x60000000	16MB	External NOR Flash		unused
0x64000000	2MB	External SRAM		unused
0xC0000000	32MB	External SDRAM	LCD Buffer	LCD Buffer

### Notes:

1. This uses the linker command file **stm32746g\_irom\_iram.icf** (on the Config tab of Linker settings) and no debug macro file (on the Setup tab of the Debugger settings). The checkbox **Use flash loader** must be checked (on the Download tab of the Debugger settings). The **Reset** type must be set to **Core** for J-Link (on the Setup tab of the J-Link/J-Trace settings) or **Normal** for ST-Link. Otherwise, execution will hang or fault in the startup code before main().  
**Note:** For the **746G-EVAL2 (Rev B)** board, as of IAR v7.40.7, only ST-Link works, not I-jet and J-Trace. For them, the download and verify may succeed, but stepping on the first instruction causes a fault. We only had one of these on loan, so we don't know if it is a bad board. Our 756 boards work fine with I-jet and J-Link.
2. **SB\_DEBUG\_IN\_ROM must be 1** in startup.c, if used for Debug and Release targets. It should be automatically set correctly.
3. Internal Flash ITCM and AXIM are the same physical memory but accessed via ITCM or AXIM interface, according to location addresses in .icf file.
4. Use the IAR Flash Loader to store the image file into flash. Please see section “Using IAR Flash Loader to Flash the Application” in this document.
5. This memory map comes from Table 5. Memory mapping vs. Boot mode/physical remap in STM32F7x6 Advanced ARM-based 32-bit MCUs Reference Manual.
6. External SRAM is initialized in SRAM\_Init() and External SDRAM is initialized in SDRAM\_Init() function. The driver code is supported by STMicroelectronics. We did not make External SRAM work yet.

## Memory Map (Debug and Release targets — External SDRAM)

Base Address	Size	Memory	Sections	Notes
0x00200000	1MB	Internal Flash (ITCM)		Unused. Faster bus.
0x08000000	1MB	Internal Flash (AXIM)		Unused. Slower bus.
0x20000000	64KB	Internal DTCM SRAM	SDAR, CSTACK, intvec	EVT, SDAR and System Stack, .intvec (EVT) copied here by startup code. See note about DTCM in Memory Configuration section.
0x20010000	240KB	Internal SRAM	EMAC_BUFFER	smxNS frame buffers.
0x2004C000	16KB	Internal SRAM		unused
0x60000000	16MB	External NOR Flash		unused
0x64000000	2MB	External SRAM		unused
0xC0000000	32MB	External SDRAM	.text, .rodata, .noinit, .bss, .data, ADAR, LCD Buffer	Code, Data, ADAR and LCD Buffer

### Notes:

1. This uses the linker command file **stm32746g\_xram.icf** (on the Config tab of Linker settings) and the debug macro file **stm32746g\_xram.mac** (on the Setup tab of the Debugger settings). The checkbox **Use flash loader** must be unchecked (on the Download tab of the Debugger settings), and for I-jet set **Reset** type to **Connect during reset (default)**. Also, `#define DATA_IN_ExtSDRAM` must be enabled in `CFG\stm32746geval.h`.  
For the **EVAL (Rev A)** board, this works for **I-jet** and **IAR v7.40.3** or later.  
For the **EVAL2 (Rev B)** board, this works for **I-jet** and **IAR v7.40.5** or later.
2. **SB\_DEBUG\_IN\_ROM** must be 0 in startup.c. It should be automatically set correctly.
3. Internal Flash ITCM and AXIM are the same physical memory but accessed via ITCM or AXIM interface, according to location addresses in .icf file.
4. This memory map comes from Table 5. Memory mapping vs. Boot mode/physical remap in STM32F7x6 Advanced ARM-based 32-bit MCUs Reference Manual.
5. The clock and External SDRAM are initialized in the .mac file.
6. MPU must be enabled for SDRAM; otherwise it crashes after downloading. Also, it is set bufferable, cacheable, and shareable. This is configured in the .mac file.
7. MPU-Plus cannot be supported for this build target, because SDRAM was put at address 0xC0000000 which is Device memory with XN (execute never) attribute. In order to run code from it, the MPU must have a slot mapping this area as executable, and it must always be enabled. However, code that changes the MPU entries (i.e. during init and task switches) temporarily disables it, resulting in a fault on the next instruction. `SMX_CFG_MPU` must be 0 for this build target.

## Memory Configuration

The memory maps are shown above. These are achieved with the linker command files (.icf) in APP\IAR.AM\STM32.

RAM usage is affected by settings in APP\acfg.h. If running from internal memories only, we define SB\_MIN\_RAM in bsp.h to reduce many settings. You may be able to reduce it some more. In particular, NUM\_STACKS has a big effect on RAM usage. As shipped, it is typically set to allow a few extra stacks beyond what the Protosystem/demos need, so you can add tasks. Use smxAware's stack display (text not GAT) to see how many of them are actually being used after free-running the application briefly. You may want to tune this down, especially if you choose to allocate bound stacks instead (stack\_size parameter of smx\_TaskCreate() != 0).

SDAR is put in DTCM SRAM (tightly coupled memory) for performance. This SRAM is not on the bus; it is connected only to the CPU, so there are limits on what can be put into it. In particular, the EVT and peripheral data buffers cannot be put into it. SDAR and ADAR can be located where desired. See dynamically allocated regions in the Memory chapter of the smx User's Guide.

## Peripherals Available on the STM32746G-EVAL Board

1. SysTick – Used to generate the smx system tick. See bspm.c in BSP\ARM.
2. USART #1 – Initialized to 115.2Kbps / no parity / 8 bits / 1stop bit. Used as the SMX information port. This includes Protosystem/demo output messages and SMX errors.
3. LED row – Four LEDs, LD1 to LD4 near bottom of board, below the LCD. Supported by our led.c. See LED\_task or LED\_LSR in app.c. On EVAL2/RevB board, JP23 and JP24 must be on 2-3 to select LD3 and LD1 rather than Camera and Potentiometer, respectively.
4. LCD Display: Supported for simple text display and PEG GUI.

lcd.c writes text strings. It is a simple mapping onto a few functions in STMicro LCD driver for this board. Demonstrated by lddemo.c. Set SB\_DISP\_DEMO to 0 in bsp.h to disable the demo.

PEG: LCD drivers are PEG\peg\source\screendrv\stm32f746\_16.cpp, l16scrn.cpp and PEG\peg\include\screendrv\stm32f746\_16.hpp, l16scrn.hpp.  
Touchscreen drivers are PEG\peg\source\touchdrv\stm32f746\_touch.cpp, ptouchdev.cpp and PEG\peg\include\touchdrv\stm32f746\_touch.hpp, ptouchdev.hpp

Note: PEG tested on EVAL (480x272) and EVAL2 (640x480) boards.

5. Ethernet – Supported by smxNS. Driver is XNS\drvsrc\arm\stm\stm32eth.c. See the Jumper and Switch Settings on page 1 of these notes.
6. USB Device – Supported by smxUSBBD. Driver is XUSBBD\DCD\udsyndwc.\*.
7. USB Host – Supported by smxUSBH, Driver is XUSBH\HCD\usyndwc.\*.
8. USB OTG – TBD
9. MicroSD card interface – Supported by smxFS. Driver is XFS\fdmsd\*.\*.
10. Accelerometer, ADC, audio, buttons, camera, CAN, CRY, DAC, DCMI, I2C, I2S, joystick, potentiometer, power management, RNG, RTC, SDIO, Smart Card, SPI, timers, watchdog are not supported.

## Clock (PLL) Configuration

The clock speed is controlled by the crystal and PLL configuration, which is initialized by `sb_ClocksInit()` in `bspm.c`, using functions in the STMMicro library.

<u>Crystal / CLKIN</u>	<u>SYSCLK (CPU)</u>	<u>HCLK (AHB)</u>	<u>PCLK1 (APB1)</u>	<u>PCLK2 (APB2)</u>	<u>PLL48 CLK</u>	<u>PLL12S</u>
25.000 MHz	200 MHz	200 MHz	50 MHz	100 MHz	48 MHz	N/A MHz

When running USB full speed (FS or HS controller) set `SB_USB_FS` to 1 in `bsp.h` to get:

<u>Crystal / CLKIN</u>	<u>SYSCLK (CPU)</u>	<u>HCLK (AHB)</u>	<u>PCLK1 (APB1)</u>	<u>PCLK2 (APB2)</u>	<u>PLL48 CLK</u>	<u>PLL12S</u>
25.000 MHz	192 MHz	192 MHz	48 MHz	96 MHz	48 MHz	N/A MHz

The second case is needed so PLL48 is 48 MHz, which is required when running the USB FS or HS controller at full speed.

## Timer Configuration

SysTick is used as the smx system tick, upon which all smx timing is based. The other timers are available for your use. Note that SysTick is part of the interrupt controller (NVIC), which is part of the ARM-M core, so it is documented in the section for the processor core.

## USART Configuration

USART #1 is used for console i/o, in polled mode. Messages written by the Protosystem and demos using `sb_ConWriteString()`, etc are displayed to an ANSI terminal connected to port “USART1” (CN8 – the DB9 connector closest to the LCD) on the board using a null modem cable. Initialization is done by `sb_PeripheralsInit()` in `bspm.c`. It is set to 115200-N-8-1.

## Ethernet Configuration (smxNS)

**Important:** The board requires some jumper and/or solder bridge changes to connect pins. See the Jumper and Switch Settings on page 1 of these notes.

The STM32 Ethernet controller uses DMA to transfer directly between the controller and the smxNS frame buffers. The DMA is coordinated using transmit and receive buffer descriptors. The controller is programmed to communicate with the PHY using MII, which is the default configuration on the evaluation board. The Ethernet controller initialization function assigns a number of alternate function signals to the Ethernet controller, so applications that bring in other subsystems should review this initialization code.

Notes:

- EXP\_IO1 pin can be set in Power Down Mode to avoid the impact of USB PHY and Ethernet PHY to get precise results for current consumption on JP2.
- PA8 (MII clock supported by MCO) is shared with LCD `BL_CTRL`, so do not initialize it in the EMAC driver.
- PH3 (MII\_COL) is shared with External SDRAM pin `SDNE0`, so do not initialize it in the EMAC driver.
- PI10 (RX\_ER) is shared with External SDRAM pin `D31`, so do not initialize it in the EMAC driver.

## LCD Configuration (PEG)

Configuration settings are made in WindowBuilder that appear in pconfig.hpp.

The location of the LCD display buffer is controlled by LCD\_BUFFER in the linker command file (.icf).

It was necessary to modify stm32f7xx\_hal\_i2c.c in the STMicro HAL to suspend the task in wait loops if a reasonable number of loops is exceeded. This is controlled by POLL\_LOOPS\_SUSP. See the note at the end of that file for more information.

## SDIO Configuration (smxFS SD/SDHC)

Polling mode and DMA mode are supported. The connector on the board is MicroSD so we could not test an MMC card.

## USB Device Configuration (smxUSB D)

There are two USB controllers in this processor, one for full speed and one for high speed. It is the Synopsys IP. On the board, OTG\_FS1 is connected to the FS controller. OTG\_HS and OTG\_FS2 are connected to the HS controller. OTG\_HS is connected to the external SMSC3300 ULPI transceiver, and OTG\_FS2 is connected to the built-in FS transceiver. We did not test OTG\_FS2 because it requires modifying the board hardware. Unfortunately, OTG\_FS1 shares pins with the UART, so it is necessary to disable SMX console I/O to use it. We recommend using OTG\_HS unless you are using both smxUSB D and smxUSBH, in which case one must use OTG\_HS and the other OTG\_FS1. Our driver doesn't support running both controllers in USB device mode simultaneously, but this can be supported in the future.

To use OTG\_HS, set SUD\_STM32F2XX\_USE\_HS to 1 in uport.h.

To use OTG\_FS1, set SUD\_STM32F2XX\_USE\_HS to 0, and set SB\_USB\_FS to 1 in bsp.h and change the PLL\_N setting accordingly in the debug .mac file (search for SB\_USB\_FS comment) so the PLL48 clock is correct. See section Clock (PLL) Configuration above. Also disable SMX console I/O by disabling SB\_CON\_IN and SB\_CON\_OUT to 0 in bcfg.h.

## USB Host Configuration (smxUSBH)

The same discussion applies as in the USB Device section above, but it is SU\_STM32F2XX\_USE\_HS in uport.h. Our host driver now supports running both controllers in USB host mode simultaneously (but it may not have been tested yet on this target). For this case, set SU\_SYNOPSIS to 2 in ucfg.h and SU\_STM32F2XX\_USE\_HS to 1 in uport.c. As mentioned for smxUSB D, you must set SB\_USB\_FS to 1 in bsp.h and change the PLL\_N setting accordingly in the debug .mac file (search for SB\_USB\_FS comment). Use ports OTG\_HS and OTG\_FS1, and you won't get terminal output because the FS port shares pins with the UART.

## USB OTG Configuration (smxUSBO)

TBD

## Debugging with IAR C-SPY

It is necessary to change the project settings to specify and configure it for the debug connection you are using. This is documented in the IAR EWARM User's Guide in Part 6: C-SPY Hardware Debugger Systems/ Hardware Specific Debugging. Also, see the documents about this linked by the IAR release

notes (readme.htm). In the table of documents at the bottom of the release notes there are links to IAR C-SPY driver notes files.

If necessary, a .mac file is provided in the project directory that the debugger runs to configure the board before downloading code. The project file is already set to point to this file.

Note: Breakpoints are limited to 6 when running in Flash, which is much better than traditional ARMs which support only 2. Still, this can make debugging more difficult than in RAM. The debugger will refuse to set more breakpoints, and a run to cursor might actually use the mode that traps after each assembly instruction, taking a long time to reach the destination.

Note: **We experience some problems debugging on this board.** Sometimes after stopping, execution does not resume properly. For example, fsdemo may stall awhile (and then report errors), but other demos continue running. Maybe an interrupt is missed. It seems to happen more when using I-jet than ST-Link and when using smxAware. More study is needed.

## Debugging with ST-Link

ST-Link is the debug connection built into the board via the large USB jack CN21. Select ST-Link in the project debug settings. See the previous section Debugging with IAR C-SPY.

## Debugging with J-Link

Note: J-Link would not work for the STM32746G-EVAL2 board we had on loan, and only ST-Link worked. It does work for the other boards we've used.

Select J-Link in the project debug settings. See the previous section Debugging with IAR C-SPY.

To support Cortex-M7 processors, the J-Link DLL file needs to be updated to V4.98b or later, and the J-Link firmware needs to be updated to the corresponding DLL version. Download the newest DLL from [www.segger.com](http://www.segger.com), and install it to IAR 7.40 or later. When the J-Link starts downloading the project image to the board, it will automatically detect new firmware is needed and open a dialog to prompt the user to download the firmware and update it automatically. See the previous section Debugging with IAR C-SPY.

## Debugging with I-jet

Note: I-jet would not work for the STM32746G-EVAL2 board we had on loan, and only ST-Link worked. It does work for the other boards we've used.

Select I-jet in the project debug settings. Leave the I-jet settings as default. See the previous section Debugging with IAR C-SPY.

## Boot and Startup Code

The same startup code is linked to the Protosystem for all build targets, so we don't rely on any boot code in flash to bring up the board. Summary of startup:

```
__iar_program_start -> __cmain -> __low_level_init -> main() -> smx_Go() -> smx_SchedRunTasks() -> ainit() -> tasks
```

\_\_iar\_program\_start is in the IAR run time library, DLIB, in cstartup\_M.c. It calls \_\_cmain in cmain.s, which calls \_\_low\_level\_init, which is our startup code in BSP\ARM\STM32\STM32F7xx\startup.c, and then it calls other init routines before calling main(). main() is in APP\main.c.



At startup, the main stack is used. `smx_Go()` changes to the dual-stack model so that tasks use the process stack pointer (PSP), and ISRs, LSRs, and the scheduler use the main stack pointer (MSP). There is a brief time during startup before the first task runs that both pointers are writing to the same area of memory, corrupting it, but that is ok because it is never used.

## **Using IAR Flash Loader to Flash the Application**

EWARM has a built-in flash loader for STM32 processors. It programs the internal flash on the chip. The ROM build target in the project file is already set up properly. See the EWARM User's Guide, Part 6: C-SPY Hardware Debugger Systems/ Hardware-Specific Debugging/ Using the Flash Loaders.

To download the app into flash, just press the Debug button as when debugging in RAM. The IDE automatically downloads the flash loader to RAM and starts it running to download and program the binary file into flash. The debugger comes up on the first instruction. You can run it in the debugger or you can power off the board, disconnect the JTAG unit, and power the board on. You can see it is running by the LED(s) blinking and terminal output.

## **Further Reading**

Refer to the release notes in the DOC directory and the ARM-M section of the SMX Target Guide.