

s115 migration document

Introduction to the s115 migration document

About the document

This document describes how to migrate to new versions of the s115 SoftDevice. The s115 release notes should be read in conjunction with this document.

For each version, we have the following sections:

- "Required changes" describes the changes that need to be done in the application when migrating from an older version of the SoftDevice.
- "New functionality" describes how to use new features and functionality offered by this version of the SoftDevice. **Note** : Not all new functionality may be covered; the release notes will contain a full list of new features and functionality.

Each section describes how to migrate to a given version from the previous version. If you are migrating to the current version from the previous version, follow the instructions in that section. To migrate between versions that are more than one version apart, follow the migration steps for all intermediate versions in order.

Example: To migrate from version 5.0.0 to version 5.2.0, first follow the instructions to migrate to 5.1.0 from 5.0.0, then follow the instructions to migrate to 5.2.0 from 5.1.0.

Copyright © Nordic Semiconductor ASA. All rights reserved.

Contents

Introduction to the s115 migration document	1
About the document	1
s115_9.0.0-3.prototype	3
Required changes	3
New functionality	3

s115_9.0.0-3.prototype

This section describes how to use the new features of s115_9.0.0-3.prototype when migrating from s115_9.0.0-2.prototype.

Required changes

New functionality