

[Submit a request](#)[Sign in](#)[SMRT Systems Help Center](#) > [General](#) > [Hardware](#)

Search our articles

## Honeywell Redundancy Scan Set-Up

**SMRT Support**

March 19, 2020 15:39

[Follow](#)

It's possible for a barcode scanner to read the wrong barcode number when scanning a heat seal barcode, especially if the barcode is faded or warped. In order to prevent barcodes from being read incorrectly, you can activate the *Redundancy* setting on your Honeywell scanners. This makes the scanner read the barcode a set number of times in order to make sure that each scan is identical before submitting the data. To turn this setting ON, print out this page and follow the three steps:

**Step 1:** Scan the *Redundancy* barcode below:



### Interleaved 2 of 5 Redundancy

**Step 2:** Scan the "3" barcode below:



**Step 3:** Scan the "Save" barcode below:



Once you scan the "Save" barcode, the *Redundancy* setting should successfully be programmed.

if using windows operating system / or above, the barcode below is required for the scanner to be used correctly.

Scan the *USB HID Bar Code Scanner* barcode below:



PAP131.

**USB HID Bar Code Scanner**

Was this article helpful?



0 out of 0 found this helpful



Have more questions? [Submit a request](#)