



[SMRT Systems Help Center](#) > [Learning Center](#) > [Troubleshooting](#)

Search

## Articles in this section



# EZ Press Heat Sealer



Ross Medina

2 years ago · Updated

Follow

SMRT recommends a temperature setting of 390 °F, and 9 seconds timer.

## To Change Time and Temperature

1. Turn off the press, wait 5 seconds and turn it back on while holding in the triangle key
2. Keep holding in the triangle key until the screen displays E244, then release the triangle key
3. Tap the triangle key 3 times to display the seconds screen – now tap the + or - key to increase or decrease the seconds. ( + plus key is 2nd button and – minus key is third button on the bottom)
4. Tap the triangle key one more time (4 times total) to display the temperature screen L 380, now tap the + or – key to increase or decrease the temperature
5. Turn the press off, wait 5 seconds and turn it back on. These will be the new default settings.

Help

## Resetting all Control Parameters back to Factory Settings

1. Turn the Power switch OFF and wait 5 seconds. Press and hold both the +key and – key IN while turning the Power switch ON. Continue to hold the +key and – key IN until the display shows FPR (Factory Parameter Reset)
2. Then release the +key and – key and turn the Power Switch OFF.

The next time you turn the Press ON, the Factory Parameters will be reset to their original out-of-box Factory settings.



---

Was this article helpful?

Yes

No

0 out of 0 found this helpful

---

Return to top ^

---

## Recently viewed articles

[Assembly Error - "Item Not On An Open Order"](#)

[Assisted Assembly](#)

[How To Change Due Dates](#)

[How To Take Deposits](#)

[Re-do](#)

## Related articles

[Assembly Error - Barcode "Is not valid" error](#)

[Re-do](#)

[Employee Levels](#)

[Order Not Closed](#)

[Customer.io Setup](#)

# Comments

0 comments



Be the first to write a comment.

SMRT Systems Help Center