

[Guides](#)[Current](#)[HID Joystick Support](#)

HID Joystick Support

HID joystick support is currently only available on F4 / F7 boards.

To enable it, set `usb_hid_cdc` to `on` in CLI, and reboot the flight controller. It will then be recognised as a HID joystick when plugged in via USB.

For Windows 7, a driver needs to be installed, it can be downloaded from [here](#).

Youtube

[▶ Joshua Bardwell](#)[▶ Ivan Efimov](#)

Community

[Discord](#)[IntoFPV](#)

Links

[Oscar Liang](#)[VitroidFPV](#)

Feeds

[RSS](#)[Atom](#)[JSON](#)

Copyright © 2025 All rights reserved Team Betaflight

Built with Docusaurus

made with ❤️ by [VitroidFPV](#) and [un!t](#)