



LM88AC

HARDWARE REFERENCE MANUAL

LM80C COLOR COMPUTER & LM80C 64K COLOR COMPUTER HARDWARE REFERENCE MANUAL

This release covers the
LM80C Color Computer
and
LM80C 64K Color Computer

Last revision on 31/12/2020

Copyright notices:

The names “LM80C”, “LM80C Color Computer”, and “LM80C BASIC”, the “rainbow LM80C” logo, the LM80C schematics, the LM80C sources, and this work belong to Leonardo Miliani, from here on the “owner”.

The “rainbow LM80C” logo and the “LM80C/LM80C Color Computer/LM80C 64K Color Computer” names can not be used in any work without explicit permission of the owner. You are allowed to use the “LM80C” name only in reference to or to describe the LM80C/LM80C 64K Color Computer.

The LM80C schematics and source codes are released under the GNU GPL License 3.0 and in the form of "as is", without any kind of warranty: you can use them at your own risk. You are free to use them for any non-commercial use: you are only asked to maintain the copyright notices, to include this advice and the note to the attribution of the original works to Leonardo Miliani, if you intend to re-distribute them. For any other use, please contact the owner.

Index

Copyright notices:.....	3
1. THE LM80C COLOR COMPUTER.....	5
1.1 Why this computer.....	5
1.2 LM80C: main features.....	5
1.3 LM80C 64K: main features.....	5
1.4 The 64K version: bank switching.....	6
1.5 System start-up.....	6
2. I/O PORTS.....	7
3. INTERRUPTS.....	8
4. RAM REGISTERS.....	9
4.1 REGISTERS FOR LM80C AS PER FIRMWARE REVISION 3.15.....	9
4.2 REGISTERS FOR LM80C 64K AS PER FIRMWARE REVISION 1.0.....	11
5. FLOATING POINT REPRESENTATION.....	20
6. HOW A BASIC PROGRAM IS STORED IN MEMORY.....	22
7. SERIAL CONFIGURATION.....	23
8. VDP SETTINGS.....	24
9. Z80 DAISY CHAIN INTERRUPT PRIORITY.....	25
10. STATUS LEDs.....	26
11. REFERENCES.....	27
12. USEFUL LINKS.....	28

1. THE LM80C COLOR COMPUTER

1.1 Why this computer

The LM80C Color Computer is a home-brew computer designed and programmed by me, Leonardo Miliani, an Italian retro-computer enthusiast, in an effort to have my own, old-style, 80s' computer. It is built upon the Z80, an 8-bit CPU developed in the '70s by Zilog. LM80C name stands for "L"eonardo "M"iliani (Z)"80" "C"olor. The "80" has the double meaning of Z80, to recall the CPU is built on, and 80s, to recall the years of my youth, when the 8-bit computers dominated the home computer market.

1.2 LM80C: main features

The LM80C might have been a good computer at that time. In fact, its features are as follow:

- CPU: Zilog Z80B@3.68 MHz
- RAM: 32 KB SRAM
- ROM: 32 KB EEPROM with built-in LM80C BASIC
- Video: TMS9918A with 16 KB VRAM, 256x192 pixels, 15 colors, and 32 sprites
- Audio: Yamaha YM2149F (or G.I. AY-3-8910) with 3 analog channels, 2x8-bit I/O ports (used to read the external keyboard)
- Serial I/O: 1xZ80 SIO, with serial line up to 57,600 bps
- Parallel I/O: 1xZ80 PIO
- Timer: 1xZ80 CTC

1.3 LM80C 64K: main features

The LM80C 64K is almost identical to its little brother. The main difference, as its name reveals, is the amount of RAM, expanded to 64 KB. Another difference is the ability to use 2x 16K banks for VRAM, allowing the VDP to keep 2 different video pages into memory:

- CPU: Zilog Z80B@3.68 MHz
- RAM: 64 KB SRAM
- ROM: 32 KB EEPROM with built-in LM80C BASIC
- Video: TMS9918A with 32 KB VRAM (splitted into 2x16 KB banks), 256x192 pixels, 15 colors and 32 sprites
- Audio: Yamaha YM2149F (or G.I. AY-3-8910) with 3 analog channels, 2x8-bit I/O ports (used to read the external keyboard)

- Serial I/O: 1xZ80 SIO, with serial line up to 57,600 bps
- Parallel I/O: 1xZ80 PIO
- Timer: 1xZ80 CTC

1.4 The 64K version: bank switching

The LM80C Color Computer version 2 has 64 KB of RAM and 32 KB of (EEP)ROM. Due to the 16-bit address bus limitations of the CPU, only 64 KB can be directly addressed. To go around this limit a sort of bank switching has been implemented.

ROM occupies the first 32 KB of the address space, from \$0000 to \$7FFF. The RAM is formed by 2x16 KB banks, lower and upper bank, or simply bank #0 and bank #1: bank #1 occupies the address space from \$8000 to \$FFFF while bank #0 occupies the same address space of the non-volatile memory but it's not enabled by default. When you power up the system or after a reset, the Z80 jumps to address \$0000, so the CPU have to find ROM memory at bank #0. Now comes in action the bank switching technique implemented: after the start, the CPU executes a little portion of code called "switcher", that copies the whole firmware from ROM bank #0 to RAM bank #1. Then, it disables the ROM in bank #0 and enables the underlying RAM chip, switching to a real 64 KB RAM memory. After this, it copies back the firmware from RAM bank #1 to RAM bank #0, so that the firmware goes back to occupy its original location.

Obviously, the entire RAM is available for user programs since he/she can overwrite the built-in firmware since it runs in a re-writeable memory.

1.5 System start-up

At startup the Z80 loads the address \$0000 into the PC (Program Counter) and start initializing the HW of the computer. After each peripheral has been set up, the control passes to the bank switcher, which moves the BASIC interpreter and the whole firmware from RAM to ROM, After this, the BASIC interpreter checks if this is a cold start (i.e. after a power-up): if this isn't such case, it asks the user if he/she wants to perform a cold or warm start: the first one initializes the working space like at boot, deleting every possible program still resident in RAM and clearing every variable, while the latter preserves both these data.

At the end of the startup process, the control is passed to the BASIC interpreter in direct mode: this means that the computer is able to execute commands as soon as they are entered.

2. I/O PORTS

Peripheral I/O chips have their I/O channels mapped at the following logical ports:

PIO:

- PIO data channel A: \$00
- PIO data channel B: \$01
- PIO control channel A: \$02
- PIO control channel B: \$03

CTC:

- CTC channel 0: \$10
- CTC channel 1: \$11
- CTC channel 2: \$12
- CTC channel 3: \$13

SIO:

- SIO data channel A: \$20
- SIO data channel B: \$21
- SIO control channel A: \$22
- SIO control channel B: \$23

VDP:

- VDP data port: \$30
- VDP control port: \$32

PSG:

- PSG register port: \$40
- PSG data port: \$42

The user can control these chips directly by reading/writing from/to the ports listed above.

3. INTERRUPTS

Several interrupt vectors are stored into ROM:

- \$0000 RESET: Z80 jumps here after a reset or at power-up
- \$0008 RST8: this restart calls a function that sends a char via serial
- \$000C INT vector for SIO RX_CHA_AVAILABLE interrupt signal
- \$000E INT vector for SIO SPEC_RX_CONDITION (special receive condition) interrupt signal
- \$0010 RST10: this restart jumps to a function that receives a char from the input buffer (serial and/or keyboard)
- \$0018 RST18: jumps to function that checks if a char is available in the input buffer
- \$0040 CTC CH0: jumps to CTC0IV (see below) - unused
- \$0042 CTC CH1: jumps to CTC1IV (see below) - unused
- \$0044 CTC CH2: jumps to CTC2IV (see below) - unused
- \$0046 CTC CH3: jumps to CTC3IV (see below) - used by system
- \$0066 NMI IRQ: jumps to NMIUSR (see below) - unused

4. RAM REGISTERS

The LM80C uses some RAM cells to store important information and data.⁽¹⁾ By manually writing into these locations the user can alter the functioning of the system, sometimes leading to crashes and/or non-predictable behaviors.

4.1 REGISTERS FOR LM80C AS PER FIRMWARE REVISION 3.15

805E	WRKSPC	(3)	BASIC Work space
8061	NMIUSR	(3)	NMI exit point routine
8064	USR	(3)	"USR (x)" jump
8067	OUTSUB	(1)	"out p,n"
8068	OTPORT	(2)	Port (p)
806A	DIVSUP	(1)	Division support routine
806B	DIV1	(4)	<- Values
806F	DIV2	(4)	<- to
8073	DIV3	(3)	<- be
8076	DIV4	(2)	<-inserted
8078	SEED	(35)	Random number seed
809B	LSTRND	(4)	Last random number
809F	INPSUB	(1)	INP A,(x) Routine
80A0	INPORT	(2)	PORT (x)
80A2	LWIDTH	(1)	Terminal width
80A3	COMMAN	(1)	Width for commas
80A4	NULFLG	(1)	Null after input byte flag
80A5	CTLOFG	(1)	Control "0" flag
80A6	CHKSUM	(2)	Array load/save check sum
80A8	NMIFLG	(1)	Flag for NMI break routine
80A9	BRKFLG	(1)	Break flag
80AA	RINPUT	(3)	Input reflection
80AD	STRSPC	(2)	Pointer to bottom (start) of string space
80AF	LINEAT	(2)	Current line number
80B1	HLPLN	(2)	Current line with errors
80B3	FNKEYS	(128)	default text of FN keys
8133	BASTXT	(3)	Pointer to start of BASIC program in memory
8136	BUFFER	(5)	Input buffer
813B	STACK	(85)	Initial stack
8190	CURPOS	(1)	Character position on line
8191	LCRFLG	(1)	Locate/Create flag for DIM statement
8192	TYPE	(1)	Data type flag
8193	DATFLG	(1)	Literal statement flag
8194	LSTRAM	(2)	Last available RAM location usable by BASIC
8196	TMSTPT	(2)	Temporary string pointer
8198	TMSTPL	(12)	Temporary string pool
81A4	TMPSTR	(4)	Temporary string
81A8	STRBOT	(2)	Bottom of string space
81AA	CUROPR	(2)	Current operator in EVAL
81AC	LOOPST	(2)	First statement of loop
81AE	DATLIN	(2)	Line of current DATA item
81B0	FORFLG	(1)	"FOR" loop flag

81B1	LSTBIN	(1)	Last byte entered
81B2	READFG	(1)	Read/Input flag
81B3	BRKLIN	(2)	Line of break
81B5	NXTOPR	(2)	Next operator in EVAL
81B7	ERRLIN	(2)	Line of error
81B9	CONTAD	(2)	Where to CONTInue
81BB	TMRcnt	(4)	TMR counter for 1/100 seconds
81BF	CTC0IV	(3)	CTC0 interrupt vector
81C2	CTC1IV	(3)	CTC1 interrupt vector
81C5	CTC2IV	(3)	CTC2 interrupt vector
81C8	CTC3IV	(3)	CTC3 interrupt vector
81CB	SCR_SIZE_W	(1)	screen width
81CC	SCR_SIZE_H	(1)	screen height
81CD	SCR_MODE	(1)	screen mode
81CF	SCR_NAM_TB	(2)	video name table address
81D1	SCR_CURS_X	(1)	cursor X
81D2	SCR_CURS_Y	(1)	cursor Y
81D3	SCR_CUR_NX	(1)	new cursor X position
81D4	SCR_CUR_NY	(1)	new cursor Y position
81D5	SCR_ORG_CHR	(1)	original char positioned under the cursor
81D6	CRSR_STATE	(1)	state of cursor
81D7	LSTCSRSTA	(1)	last cursor state
81D8	PRNTVIDEO	(1)	print on video buffer
81D9	CHR4VID	(1)	char for video buffer
81DA	FRGNDCLR	(1)	foreground color
81DB	BKGNDCLR	(1)	background color
81DC	TMPBFR1	(2)	word for general purposes use
81DE	TMPBFR2	(2)	word for general purposes use
81E0	TMPBFR3	(2)	word for general purposes use
81E2	TMPBFR4	(2)	word for general purposes use
81E4	VIDEOBUFF	(40)	temp. video buffer
820C	VIDTMP1	(2)	additional temp. video buffer
820E	VIDTMP2	(2)	additional temp. video buffer
8210	CHASNDDTN	(2)	sound Ch.A duration
8212	CHBSNDDTN	(2)	sound Ch.B duration
8214	CHCSNDDTN	(2)	sound Ch.C duration
8216	KBDNPT	(1)	temp. location for keyboard inputs
8217	KBTMP	(1)	temp. location used by keyboard scanner
8218	TMPKEYBFR	(1)	temp. location used for last key pressed
8219	LASTKEYPRSD	(1)	code of last key pressed
821A	CONTROLKEYS	(1)	flags for control keys
821B	SERIALS_EN	(1)	serial ports status
821C	SERABITS	(1)	serial port A data bits
821D	SERBBITS	(1)	serial port B data bits
821E	PROGND	(2)	End of program
8220	VAREND	(2)	End of variables
8222	ARREND	(2)	End of arrays
8224	NXTDAT	(2)	Next data item
8226	FNRGNM	(2)	Name of FN argument
8228	FNARG	(4)	FN argument value
822C	FPREG	(3)	Floating point register
822F	FPEXP	(1)	Floating point exponent
8230	SGNRES	(1)	Sign of result
8231	PBUFF	(13)	Number print buffer
823E	MULVAL	(3)	Multiplier
8241	PROGST	(100)	Start of program text area

4.2 REGISTERS FOR LM80C 64K AS PER FIRMWARE REVISION 1.01

515D	WRKSPC	(3)	BASIC Work space
5160	NMIUSR	(3)	NMI exit point routine
5163	USR	(3)	"USR (x)" jump
5166	OUTSUB	(1)	"out p,n"
5167	OTPORT	(2)	Port (p)
5168	DIVSUP	(1)	Division support routine
5169	DIV1	(4)	<- Values
516E	DIV2	(4)	<- to
5172	DIV3	(3)	<- be
5175	DIV4	(2)	<-inserted
5176	SEED	(35)	Random number seed
519A	LSTRND	(4)	Last random number
519E	INPSUB	(1)	#INP (x)" Routine
519F	INPORT	(2)	PORT (x)
51A1	LWIDTH	(1)	Terminal width
51A2	COMMAN	(1)	Width for commas
51A3	NULFLG	(1)	Null after input byte flag
51A4	CTLOFG	(1)	Control "0" flag
51A5	CHKSUM	(2)	Array load/save check sum
51A7	NMIFLG	(1)	Flag for NMI break routine
51A8	BRKFLG	(1)	Break flag
51A9	RINPUT	(3)	Input reflection
51AC	STRSPC	(2)	Pointer to bottom (start) of string space
51AE	LINEAT	(2)	Current line number
51B0	HLPLN	(2)	Current line with errors
51B2	KEYDEL	(1)	delay before key auto-repeat starts
51B3	AUTOKE	(1)	Delay for key auto-repeat
51B4	FNKEYS	(128)	default text of FN keys
5234	BASTXT	(3)	Pointer to start of BASIC program in memory
5235	BUFFER	(5)	Input buffer
523C	STACK	(85)	Initial stack
5291	CURPOS	(1)	Character position on line
5292	LCRFLG	(1)	Locate/Create flag for DIM statement
5293	TYPE	(1)	Data type flag
5294	DATFLG	(1)	Literal statement flag
5295	LSTRAM	(2)	Last available RAM location usable by BASIC
5297	TMSTPT	(2)	Temporary string pointer
5299	TMSTPL	(12)	Temporary string pool
52A5	TMPSTR	(4)	Temporary string
52A9	STRBOT	(2)	Bottom of string space
52AB	CUROPR	(2)	Current operator in EVAL
52AD	LOOPST	(2)	First statement of loop
52AF	DATLIN	(2)	Line of current DATA item
52B1	FORFLG	(1)	"FOR" loop flag
52B2	LSTBIN	(1)	Last byte entered
52B3	READFG	(1)	Read/Input flag
52B4	BRKLIN	(2)	Line of break
52B6	NXTOPR	(2)	Next operator in EVAL

52B8	ERRLIN	(2)	Line of error
52BA	CONTAD	(2)	Where to CONTInue
52BC	TMRcnt	(4)	TMR counter for 1/100 seconds
52C0	CTC0IV	(3)	CTC0 interrupt vector
52C3	CTC1IV	(3)	CTC1 interrupt vector
52C6	CTC2IV	(3)	CTC2 interrupt vector
52C9	CTC3IV	(3)	CTC3 interrupt vector
52CC	SCR_SIZE_W	(1)	screen width
52CD	SCR_SIZE_H	(1)	screen height
52CE	SCR_MODE	(1)	screen mode
52D0	SCR_NAM_TB	(2)	video name table address
52D2	SCR_CURS_X	(1)	cursor X
52D3	SCR_CURS_Y	(1)	cursor Y
52D4	SCR_CUR_NX	(1)	new cursor X position
52D6	SCR_CUR_NY	(1)	new cursor Y position
52D7	SCR_ORG_CHR	(1)	original char under the cursor
52D8	CRSR_STATE	(1)	state of cursor (1=on, 0=off)
52D9	LSTCSRSTA	(1)	last cursor state
52D0	PRNTVIDEO	(1)	print on video buffer
52DA	CHR4VID	(1)	char for video buffer
52DB	FRGNDCLR	(1)	foreground color
52DC	BKGNDCLR	(1)	background color
52DD	TMPBFR1	(2)	word for general purposes use
52DF	TMPBFR2	(2)	word for general purposes use
52E1	TMPBFR3	(2)	word for general purposes use
52E3	TMPBFR4	(2)	word for general purposes use
52E5	VIDEOBUFF	(40)	temp. video buffer
530D	VIDTMP1	(2)	temporary video word
530F	VIDTMP2	(2)	temporary video word
5311	CHASNDDTN	(2)	sound Ch.A duration (in 1/100s)
5313	CHBSNDDTN	(2)	sound Ch.B duration (in 1/100s)
5315	CHCSNDDTN	(2)	sound Ch.C duration (in 1/100s)
5317	KBDNPT	(1)	temp. location for keyboard inputs
5318	KBTMP	(1)	temp. location used by keyboard scanner
5319	TMPKEYBFR	(1)	temp buffer for last key pressed
531A	LASTKEYPRSD	(1)	last key code pressed
531B	STATUSKEY	(1)	status key, used for auto-repeat
531C	KEYTMR	(2)	timer used for auto-repeat key
531E	CONTROLKEYS	(1)	flags for control keys
531F	SERIALS_EN	(1)	serial ports status
5320	SERABITS	(1)	serial port A data bits
5321	SERBBITS	(1)	serial port B data bits
5322	DOS_EN	(1)	DOS enable/disable (1/0)
5323	PROGND	(2)	End of program
5325	VAREND	(2)	End of variables
5327	AREND	(2)	End of arrays
5329	NXTDAT	(2)	Next data item
532B	FNRGNM	(2)	Name of FN argument
532D	FNARG	(4)	FN argument value
5331	FPREG	(3)	Floating point register
5334	FPEXP	(1)	Floating point exponent
5335	SGNRES	(1)	Sign of result
5336	PBUFF	(13)	Number print buffer
5343	MULVAL	(3)	Multiplier
5346	PROGST	(100)	Start of program text area
53AA	STLOOK		Start of memory test

WRKSPC:	workspace. This is a jump to “Warm start” routine
USR:	user-defined function USR(X). Before to call it, locations USR+\$01 and USR+\$02 must be filled up with the address of the user routine. At startup, the default is a call to an “Illegal function call” error.
OUTSUB:	out sub-routine. Since the i8080 didn’t have the “OUT(c),r” instruction, this was a skeleton for such statement. Now it’s a sub-routine to write to a specific output port.
OTPORT:	output port “c” for the above routine.
DIVSUP:	skeleton routine used for division. Since there aren’t enough register to store dividend, divisor and quotient, the divisor is loaded into this routine, to leave registers free for dividend and quotient.
SEED:	seed for random number generator and table for floating point values used by RND function.
LSTRND:	last random number is stored (available by RND(0)).
INPSUB:	input sub-routine. Since the i8080 didn’t have the “IN r,(c)” instruction, this was a routine that read from an input port. Actually, just a sub-routine for “IN” statement.
INPORT:	input port “c” for the above routine.
NULLS:	nulls. Number of null chars printed after a carriage return. The original NASCOM BASIC had the command “NULL” to change this value, but now it can only be changed with a “POKE”.
LWIDTH:	terminal width, set by “WIDTH”.
COMMAN:	width of terminal for printing with commas. Since “WIDTH” does set LWIDTH but does NOT set COMMAN, the only way to get commas spacing work correctly is just using a POKE.
NULFLG:	null after input flag. Reminiscence of old terminal computers, where this command was used to set the number of null chars to send to teletype before printing any char.
CTLOFH:	flag for Control+”O”. When this flag is set, no output will be sent to the terminal.
LINESE:	lines counter. Initially loaded with the value of LINESE, it is decremented after every line. When it reaches zero, the BASIC interpreter stops waiting for a char from the keyboard.
LINESE:	lines number. Used for LINESE. It can be changed with a POKE.
CHKSUM:	checksum used for array load/save (NASCOM BASIC legacy).
NMIFLG:	Non-Maskable Interrupt flag. This is used to inform the BASIC that is has been interrupted by an NMI.
BRKFLG:	break flag, to let BASIC know that the break key was pressed.

RINPUT:	Reflection for “INPUT” routine. When an “INPUT” instruction is encountered, BASIC jumps to the input routine pointed by this jump. Default is jump to “TTYLIN”, aka get a line by character. This can be changed to “CRLIN” (output CR/LF and get a line), or “GETLIN” (no CR/LF, get a line).
STRSPC:	start of string space pointer, the area where BASIC stores strings. By default, it is set 100 bytes below the end of memory but this value can be changed by the “CLEAR n” statement.
LINEAT:	current line number. This pair of bytes contains the value of the current line being executed. A value is -1 means that BASIC is executing a statement in direct mode. A value of -2 means that the computer has been reset and it’s executing the routine to calculate the memory size or, in case it can not determine the amount of RAM, the “Memory size?” routine. If the user doesn’t input a number, -2 instructs the error routine that an error has occurred and that a cold start must be executed.
HLPLN:	help line. Current line that has raised an error during the execution of a BASIC program. This value is read by “HELP” statement, and reset after a program restart (“RUN”) or by another error in direct mode.
KEYDEL:	delay before the key auto-repeat starts repeating the pressed key.
AUTOKE:	Delay for key auto-repeat between two prints.
FNKEYS:	function keys. This area stores the text of function keys. 8 function keys are present and can be individually programmed with user defined statements, whose length can be up to 16 chars. Please refer to LM80C BASIC Reference Manual” to know the pre-configured texts.
BASTXT:	BASIC program text. Pointer to where the BASIC is stored in memory. Usually this reflects the contents of PROGST and both point to the BASIC program area, but it can be changed by the user if a program is loaded elsewhere into RAM.
BUFFER:	input buffer. 88 char buffer where the system stores all the input from the keyboard or the serial line.
STACK:	temporary stack used during boot of system.
CURPOS:	cursor position. This value keeps the cursor position through the current line and it is incremented every time a new char has been inserted. It is the value returned by “POS(x)” statement. A press on the “RETURN” key resets this value.
LCRFLG:	Locate/Create flag. Value used by the variable search routine to see if it’s in a “DIM” statement or not, so that it can determine if it has to locate or create the specified array.
TYPE:	type of data of the current expression. A zero value stands for a numeric type, while a non-zero value for a string.
DATFLG:	literal statement flag. It’s used by the BASIC to know if it’s pointing at a literal statement such as a quoted string, a “REM” or a “DATA” statement.

LSTRAM:	last available RAM pointer. Address of last location available to BASIC. It can be changed by “CLEAR n” statement.
TMSTPT:	temporary string pointer used to point a string into the temporary string pool.
TMSTPL:	temporary string pool. This pool contains 4 temporary strings that are created by string statements like “LEFT\$” and others.
TMPSTR:	temporary string. This is a temporary area where BASIC stores blocks of bytes that reference to the strings being constructed. Every string block consists of 4 bytes: the first byte stores the length of string; the second byte is not used; the last two bytes form the pointer to the location in memory where the string is stored.
STRBOT:	bottom of string space. This value points to the bottom of the string being used. Each time a new string is being formed, it is moved into the string area below this pointer that the pointer is decremented and moved below the new string. If there is not enough space for the new string, than a “garbage collector” is called to remove unused strings from the string space. If, after this cleaning, there is still not enough room, then an “Out of string space error” is raised.
CUROPR:	current operator address. Pointer to the current operator being evaluated in EVAL. This pointer is used to free the CPU register used to point to the current operator being analyzed and to avoid to store it into the stack, so that both can be used to simplify the evaluation of the operator.
LOOPST:	loop start address. Pointer to the first statement in the FOR loop being constructed. This address is later moved into the FOR block on the stack .
DATLIN:	data statement line number. This register contains the line number of the current DATA statement pointer. It’s used by DATSNR to report to the user the line where a DATA error has occurred.
FORFLG:	<p>“FOR”/”FN” flag. Flag to tell what GETVAR is expected to find:</p> <p>\$00: a variable or array element</p> <p>\$01: an array name</p> <p>\$64: a variable only</p> <p>\$80: an FN function</p>
LSTBIN:	last byte entered. Flag being set whenever any input is made into the BUFFER. The RETURN routine first checks this byte to see if a GOSUB was entered into direct mode, and if so checks this flag. If the flag is set, then this means that an INPUT statement has been encountered, and so after RETURN is executed, BUFFER contains garbage and the system returns into direct mode.
READFG:	read/input flag. This flag tells the READ/INPUT routine what’s the source of the data being read. If the flag is zero, then an INPUT is being executed, otherwise it’s a READ reading from a DATA statement.

BRKLIN:	break line pointer. Address of the line where a break occurred. This value is used by CONT to know where to continue the execution of the program.
NXTOPR:	next operator address. Pointer into the expression being evaluated by EVAL to know where the execution is in the string.
ERRLIN:	line number of break. This register contains the line number where a break occurred. Used by CONT to know the line number where to continue from.
CONTAD:	continue address. Address of the statement where CONT will continue.
TMRCNT:	timer counter. This is a 32-bit hundredths of a second counter used as a sys-tick timer to temporize events such as sound duration, pauses and other. Its value is incremented every 1/100 s and can be read by the TMR statement.
CTCxIV:	CTC interrupt vectors. Interrupt vectors that can be changed to point the CTC interrupts to specific interrupt service routines. CTC3IV is used by the kernel of the computer to temporize some jobs (see TMRCNT above).
SCR_SIZE_W:	screen width. This register stores the screen width of the current screen mode. See chap. 8 for more details.
SCR_SIZE_H:	screen height. This register stores the screen height of the current screen mode. See chap. 8 for more details.
SCR_MODE:	screen mode. Current screen mode. This value reflects the mode set by SCREEN statement.
SCR_NAM_TB:	screen name table address. VRAM address of the name table being used by the current screen mode. See chap. 8 for more details.
SCR_CURS_X:	current cursor X coordinate. Keeps the current horizontal coordinate of the cursor in a text mode (screen 0, 1, & 4).
SCR_CURS_Y:	current cursor Y coordinate. Keeps the current vertical coordinate of the cursor in a text mode (screen 0, 1, & 4).
SCR_CUR_NX:	new cursor X coordinate. Keeps the horizontal coordinate of the video cell that the cursor is going to occupy when being moved.
SCR_CUR_NY:	new cursor Y coordinate. Keeps the vertical coordinate of the video cell that the cursor is going to occupy when being moved.
SCR_ORG_CHR:	original char under the cursor. Register used to store the original char present in the video cell currently occupied by the cursor. It is used to restore the char during cursor flashing or when the cursor is moved into another location.
CRSR_STATE:	cursor state. Flag used to tell BASIC if the cursor is visible (1) or not (0).
LSTCSRSTA:	last cursor state. Flag used to store the current cursor state, i.e. when executing PRINT statements or when the cursor is moved around the screen.

PRNTVIDEO:	print on video buffer flag. Used to tell the BASIC if keys being pressed can be echoed on the screen or not. Usually, printing on video is off when in indirect mode (i.e. when a program is being executed).
CHR4VID:	char for video buffer. Temporary buffer that stores a char that must be printed on the screen.
FRGNDCLR:	foreground color. Foreground color set by SCREEN statement. The default value can also be changed with COLOR statement. Used to print chars on screen or to draw/plot figures/pixels on the graphic screen when no color is being specified.
BKGNDCLR:	background color. Background color set by SCREEN statement. The default value can also be changed with COLOR statement. Used for the background of the chars being printed on screen or to color the empty area of the graphic screen
TMPBFRx:	temporary buffer. 4 words used by the kernel and BASIC as temporary buffers.
VIDEOBUFF:	temporary video buffer. 40 RAM cells used by the kernel and BASIC for video scrolling in text modes and as temporary buffer.
VIDTMPx:	temporary video buffer. 2 additional buffers used by the firmware and BASIC.
CHASNDDTN:	channel A sound duration. Duration of the sound being generated by ch. A of the PSG, in hundredths of a second. This value is set by the SOUND statement and decremented by the kernel.
CHBSNDDTN:	channel B sound duration. Same as above, but for ch. B.
CHCSNDDTN:	channel C sound duration. Same as above, but for ch. C.
KBDNPT:	keyboard input. Temporary buffer to store the char being input through the keyboard.
KBTMP:	temporary keyboard scanner. Register used by the keyboard scanner routine to store the key row of the key matrix when a key is being pressed.
TMPKEYBFR:	last key pressed buffer. Temporary buffer used to store the code of the last key being pressed.
LASTKEYPRSD:	code of the last key pressed. Code of the last key being pressed.
STATUSKEY:	used by the key auto-repeat function. Stores the current state of the repeating (0 if no key is pressed, 1 if a key is being pressed for the first time, 2 if the key still continues to be pressed)
KEYTMR:	timer used by the key auto-repeat function to activate the auto-repeat function and the delay between 2 key prints.

CONTROLKEYS: flag for control keys. Flag used by the keyboard scanner to keep track of the control keys being pressed.

SERIALS_EN: serial lines enabled. Status of the serial lines. Bit 0 reflects the status of serial line 0, while bit 1 reflects the status of serial line 1: 0 means line OFF, 1 means line ON.

SERABITS: serial port A data bits. Register used to store the data configuration bits used to set the serial port A, used by the kernel.

SERBBITS: serial port B data bits. Register used to store the data configuration bits used to set the serial port B, used by the kernel.

DOS_EN: I/O DOS enabled/disabled (1/0). When the computer's logo is shown at boot, by pressing the SHIFT key the user can disable the I/O buffer used for DOS operations, to recover 512 bytes of free RAM.

PROGND: program end. Address of the byte after the end of the BASIC program text stored in RAM.

VAREND: variables end. Address of the byte after the last variable stored in RAM.

ARREND: arrays end. Address of the byte after the last array stored in RAM.

NXTDAT: next data item. Address of the next DATA item to be read by READ.

FNRGNM: FN argument name. Name of the argument of the current FN function. If an FN function calls another FN function, then this value is stored on the stack.

FNARG: FN function argument. Floating point value of the argument of the current FN function. If an FN function calls another FN function, then this value is stored on the stack together with its name.

FPREG: floating point register. Floating point value for the current value. These 3 bytes contains the mantissa.

FPEXP: floating point exponent. Floating point value for the current value. This byte contains the exponent. See chap. 5 for floating point representation in memory.

SGNRES: sign of the result. This register contains the sign of the result for multiplication. Both multiplicand and multiplier are tested and if their signs are different, then the product will be negative, otherwise it will be positive.

PBUFF: number print buffer. Temporary buffer used by NUMASC to store a floating point that has to be converted into ASCII for PRINT or STR\$ statements

MULVAL: multiplier. This 24-bit register contains the multiplier of a multiplication because there are not enough registers to store the multiplier, the multiplicand, and product at the same time.

PROGST: program start. This is the byte before the first line of a program and it MUST be zero to tell the execution driver that the next line is to be executed. See chap. 6 to see how a BASIC program is stored into RAM.

STLOOK: start of memory test. Address from which the memory test executed after a reset or when the system is powered up, start to look for the top of the RAM. This address is 100 bytes above the program text area so that the kernel can have at least some bytes to create the stack and store a very little program.

5. FLOATING POINT REPRESENTATION

Floating point numbers are represented in memory using the Microsoft Binary Format (MBF), introduced by Microsoft in its first Microsoft BASIC in 1975. It uses a 24-bit mantissa, of which 23 bits are used for the mantissa itself and 1 bit for its sign, and an 8-bit base-2 exponent, for a total of 32 bits (4 bytes). There is always a “1” bit implied to the left of the mantissa so that the exponent is encoded with a bias of 128, so that exponents from -127 to -1 are represented by values \$01~\$7F (1~127), while exponents 0~127 are represented by \$80~\$FF (128~255). Exponent set to zero is a special case, representing the whole number being zero.⁽¹⁾⁽²⁾

MBF representation:

```
m= mantissa bits
s=mantissa sign
x=exponent
```

Byte 1	Byte 2	Byte 3	Byte 4
smmmmmmmm	mmmmmmmmmm	mmmmmmmmmm	xxxxxxxxxx

Let's try to represent the 35.25 in MBF. Firstly, the number must be converted in binary format. To convert the integer part, divide the number repeatedly by 2, writing the remainder to the right, until the quotient becomes 0:

Div.	Quot.	Rem.
35/2 =	17	1
17/2 =	8	1
8/2 =	4	0
4/2 =	2	0
2/2 =	1	0
1/2 =	0	1

Now write the remainders from bottom to top. The results is the binary representation of the integer part of the number. 35 in base-2 representation is:

100011

To convert the fractional part, multiply it repeatedly by 2 until it becomes 0. Stop after a number of steps, if the fractional part does not become zero:

0.25 × 2 = 0.50 → 0	
0.50 × 2 = 1.00 → 1	← stop here, as the fract. Part is now 0.

From top to bottom, write the integer parts of the results to the fractional part of the base-2 number. So 0.25₁₀ becomes 0.01₂. Finally, the complete number is:

35.25 → 100011.01

Now, consider the base-2 exponent, so that the above is the same as:

```
100011.01 * 2^00000000
```

The binary point is moved to the left most position, so that now precedes the first “1”.

This is the actual situation:

```
.10001101
```

Since the point was moved left 6 times dividing the number by 2^6 , now we must add 6 to the exponent to re-multiply by 2^6 :

```
.10001101 * 2^00000110
```

Since the bit to the right of the point is always 1, we can use this bit to store the sign of the number: 0 for a positive number, and 1 for a negative number. So +35.25 is stored as:

```
.00001101 * 2^00000110
```

In 24 bits the above is:

```
.000011010000000000000000 * 2^00000110
```

Now, 128 is added to the exponent so that overflows and underflows can be detected easily. So the number actually is:

00001101	00000000	00000000	10000110	binary				
0	D	0	0	0	0	8	6	hex

The bytes of the mantissa are stored in reverse order. So, this gives the followings:

Decimal	Binary	Hexadecimal
+35.25	00001101 00000000 00000000 10000110	00 00 0D 86
-32.25	10001101 00000000 00000000 10000110	00 00 8D 86

Other examples:

Decimal	Binary	Hexadecimal
0	00000000 00000000 00000000 00000000	00 00 00 00
1	00000000 00000000 00000000 10000001	00 00 00 81
10	00100000 00000000 00001000 10000100	20 00 00 84
PI/2 (1.5708)	11011111 00001111 01001001 10000001	DB 0F 49 81

6. HOW A BASIC PROGRAM IS STORED IN MEMORY

A BASIC program is stored in memory following a specific scheme. The BASIC text area starts at the location PROGST (in the actual firmware revision this corresponds to address \$5346). This location must contain \$00. This is a special marker used by the interpreter to mark the beginning of the BASIC space. From the following 2 locations over, the BASIC program is stored line by line: each program line begins with a 2-byte address to the address of the next line in memory, followed by a word (2 bytes) containing the current line number, then the program line itself, and finally a zeros to mark the end of line. The text of the line is stored in a mixed format: BASIC statements are stored using their tokenized form (a particular form that uses a 1-byte code from \$80 to \$FF to represent each single statement) while the rest of the line is stored using ASCII codes. A couple of zeros used as pointers to the next line identify the end of the program.

An example is shown below. The following line:

```
10 FOR A=1 TO 10
```

is stored as:

5346	00	Marker for beginning of BASIC space
5347	56	Pointer to next line
5348	53	(\$5356 in little endian format (LSB/MSB))
5349	0A	Line number
534A	00	(\$000A = 10 in little endian format (LSB/MSB))
534B	81	Token for "FOR"
534C	20	ASCII code for "space" (\$20 = 32)
534D	41	ASCII code for "A" (\$41 = 65)
534E	C8	Token for "=" ("=" is interpreted as a STATEMENT)
534F	31	ASCII code for "1" (\$31 = 49)
5350	20	ASCII code for "space" (\$20 = 32)
5351	B7	Token for "TO"
5352	20	ASCII code for "space" (\$20 = 32)
5353	31	ASCII code for "1" (\$31 = 49)
5354	30	ASCII code for "0" (\$30 = 48)
5355	00	End of line
5356	00	Pointer to next line
5357	00	(\$0000 → end of program)

7. SERIAL CONFIGURATION

If you intend to connect the LM80C to a host computer through the serial port A, you have to use an FT232 module to adapt the RS232 serial lines of the LM80C to the USB port of modern systems. Moreover, to avoid serial issues during sending data to the LM80C, please configure the terminal emulator you are using (i.e. CoolTerm or TeraTherm) with these params:

PORT: choose the port your system has mounted the FT232 module to

BAUDRATE: 19,200/38,400 bps

DATA BITS: 8

PARITY: none (0)

STOP BITS: 1

FLOW CONTROL: CTS (optional, combine with TX delay)

SOFTWARE SUPPORT FOR FLOW CONTROL: yes

RTS AT STARTUP: on

HANDLE BS AND DEL CHARS: yes

HANDLE FF (FormFeed) CHAR: yes

USE TX DELAY: min. 5ms (increment it if you experience issues)

8. VDP SETTINGS

The VDP, aka Video Display Processor, is the video chip of the LM80C computer. It is a TMS9918A from Texas Instruments. It can visualize a video image of 256x192 pixels with 15 colors and 32 sprites. It has several graphics modes, each of them configured to store video datas in particular areas of the VRAM. These are the main settings for the modes supported by LM80C. Before to proceed, a little explanation of the meaning of different areas:

- pattern table: it's the area where the patterns that compose the chars are stored;
- name table: this is a sort of look-up table. This area maps what's is shown by the VDP in each cell of the video. The VDP reads the byte stored into a particular cell and then looks into the pattern table to find the data needed to draw the corresponding char;
- color table: some graphics modes store the color of a particular cell into this table.
- sprite pattern table: similarly to the pattern table, this area stores the data needed to draw the sprites;
- sprite attribute table: this area contains the info needed by the VDP to locate and color the sprites.

SCREEN MODE	SCREEN WIDTH	SCREEN HEIGHT	PATTERN TABLE	NAME TABLE	COLOR TABLE	SPRITE ATTRIBUTE TABLE	SPRITE PATTERN TABLE
Screen 0	40 cols.	24 rows	\$0000-\$07FF	\$0800-\$0BBF	----	----	----
Screen 1	32 cols.	24 rows	\$0000-\$07FF	\$1800-\$1AFF	\$2000-\$201F	\$1B00-\$1B7F	\$3800-\$3FFF
Screen 2	256 px.	192 px.	\$0000-\$17FF	\$1800-\$1AFF	\$2000-\$37FF	\$1B00-\$1B7F	\$3800-\$3FFF
Screen 3	64 blks.	48 blks.	\$0000-\$07FF	\$0800-\$0AFF	----	\$1B00-\$1B7F	\$3800-\$3FFF
Screen 4	32 cols.	24 rows	\$0000-\$07FF	\$1800-\$1FFF	\$3800-\$3AFF	\$1800-\$1FFF	\$3B00-\$3B7F

N.B: the addresses above are referred to Video RAM, so you must use the VPOKE and VPEEK statements to access it.

9. Z80 DAISY CHAIN INTERRUPT PRIORITY

Since the LM80C is set up to work in interrupt mode 2 (IM2), the Z80 CPU serves the interrupt signals following a priority schematic that is hard-wired in the computer itself. In IM2 interrupt signals with higher priority are served before others with lower priority. In LM80C computer:

- the highest priority periphery is the Z80 SIO, since data incoming over the serial must be collected as soon as they are available;
- then the Z80 CTC, also used for the system tick counter;
- lastly, the Z80 PIO that, at the moment, it's just used as on output periphery.

10. STATUS LEDs

Status LEDs are used by the operating system to communicate special conditions to the users. Their meaning is as follow:

0: Bank 0 selector: 0=RAM, 1=ROM	4: Serial 1 buffer overrun
1: VRAM bank # selector: 0=def., 1=alt.	5: Serial 2 buffer overrun
2: N.C.	7: Serial 1 line open
3: N.C.	8: Serial 2 line open

Please remember that LEDs #1 and #2 drive the bank switching mechanisms to switch between ROM and RAM in bank #0 of the main memory and between the two VRAM banks for the VDP, respectively. So, consider that you could get some unwanted side effects if you change them unintentionally.

11. REFERENCES

1. NASCOM ROM BASIC DIS-ASSEMBLED – PART I – BY CARL LLOYD-PARKER
2. https://en.wikipedia.org/wiki/Microsoft_Binary_Format

12. USEFUL LINKS

Project home page:

<https://www.leonardomiliani.com/en/lm80c/>

Github repository for source codes and schematics:

<https://github.com/leomil72/LM80C>

Hackaday page:

<https://hackaday.io/project/165246-lm80c-color-computer>

LM80C

Color Computer

Enjoy home-brewing computers

Leonardo Miliani