

Updating your firmware

Updating your MC6 MKII firmware

We are constantly updating the firmware to include new features and bug fixes.

The firmwares are available on our download page in our website. When a new firmware is released, we will send out an email to update users.

To update the firmware, you will need to use the Firmware Uploader software available in our Downloads page.

You will also need to download the new firmware. In our Downloads page, click on MC6 MKII Firmware. You will be redirected to our Github page, which is our repository where we store all our releases. Click into the firmware version you want to download. Under the Assets label, you can see the firmware ending with a .hex extension. Click on it to download.

Once the firmware and Firmware Uploader is downloaded, run the Firmware Uploader software and connect your MC6 MKII to your computer. Your device should appear in the Firmware Uploader.

Click on Upload. A pop-up box will appear. Select the firmware file that you downloaded and click Open.

The firmware should then begin uploading and should take only a couple of seconds. Once it is completed, your MC6 MKII will restart with the new firmware.

© 2019 Morningstar Engineering

Documentation built with MkDocs (<http://www.mkdocs.org/>).