

General Usage

Changing Banks

Step on Switches [A + B] together to bank down and Switches [B + C] to bank up. There are a total of 30 banks on the MC6.

Switch and Display Names

Activating Presets

Each switch corresponds to the display name closest to it. Pressing switch [A] activates Preset A, switch [B] activates Preset B and so forth.

If you have an external aux switch connected to the MC6, depending on how it is wired, it will invoke Presets G-L.

Mapping Actions to Midi Types

The MC6 MKII allows you to map actions taken on the switches to Midi Types and functions. For example, you can map a CC#1 message to a Press action, and a CC#2 message to a Release action. When the switch is pressed, a CC#1 message will be sent, and when the switch is released, a CC#2 messages will be sent. There is a list of actions available to you.

1. Press
2. Release
3. Long Press
4. Long Press Release
5. Double Tap
6. Double Tap Release
7. Long Double Tap
8. Long Double Tap Release
9. Release All

Dual Switch Functions

The MC6 makes use of dual switch combination to carry out certain functions.

Function	Switch
Bank Down	A+B
Bank Up	B+C
Edit Menu	D+F
Toggle Editor Mode	C+D
Toggle MIDI Thru	A+F

Besides this, you can also use dual switch presses to call the extra presets.

Preset Switch

G	D+E
H	E+F
I	A+D
J	B+E
K	C+F