

# Main Configuration Menu

To access the Controller Settings Menu, hold down **Switch D** before powering up the MC6. This menu allows you to edit the global settings for the device.

The Main Configuration Menu can also be accessed by going into the Edit Settings page (Switch D + F) and selecting **ConfigPg**.

Please note that the controller will restart after exiting the Main Configuration Menu.

The display will indicate that it is booting into the configuration page, and the menu below will be displayed:



D



E



F

M	i	d	i	C	h	n	l	R	e	s	e	t	P	g	(	1	/	2	)
E	x	p	l	n	p	t	S	w	S	e	n	s	(	E	x	i	t	)	

**MORNINGSTAR**

**MC6**

A



B



C



—— BANK DOWN ——

—— BANK UP ——



D



E



F

B	n	k	T	i	m	e	B	n	k	C	h	g	D	i	P	g	(	2	/	2	)
M	i	d	i	C	i	k	(	E	x	i	t	)									

**MORNINGSTAR**

**MC6**

A



B



C



—— BANK DOWN ——

—— BANK UP ——

## Factory Reset - Reset

To do a factory reset, hold down for 2 seconds. The MC6 will show that it is performing a factory reset. All user presets and settings will be reset to factory default when a reset is done.

## Set MIDI Channel - MidiCh

Set the MIDI receive channel for the MC6. The MC6 can receive and respond to messages from external midi controllers. Press Switch A or B to increase or decrease the MIDI channel respectively.

Press **(Save)** to save your settings and **(Exit)** to exit.

## Change Expression Input - Explnpt

Change Expression Input Type and select between **Aux Switch**, **Expression** or **Fixed Sw 1** Setting.

- Aux Switch: Use a stereo cable to connect to an external aux switch to control more presets. Aux Switch compatibility is described here ([../02-hardware-overview#using-external-aux-switches](#)).
- Expression: Connect an expression pedal via a stereo cable (Tip connected to wiper) to engage the expression preset. Expression Pedal compatibility is described here ([../02-hardware-overview#using-expression-pedals](#)).
- Fixed Sw 1: Similar to the aux switch, but the functions are hard-coded to control the Bank Up, Bank Down and Toggle Page functions without sacrificing any presets.

## Switch Sensitivity - SwSens

Set switch sensitivity. Choose from 1 (least sensitive) to 5 (most sensitive). Pressing Switch A+B together will select 2, while B+C will select 4.

By default, this is set to 3 and should be comfortable for most users. Depending on personal taste, you may adjust sensitivity to help you bank up/down (by stepping on 2 switches at once) more accurately. More sensitive means that the lag between the time when a message is sent out and when the switch is pressed it at its minimum.

## Change Page - Pg(1/2)

Access more options in the Main Configuration Menu by changing the page.

## Bank Display Time - BnkTime

This setting adjusts the amount of time the bank details will show when the bank is changed.

The value displayed is in milliseconds.

## Bank Change Time - BnkChgDelay

This setting adjusts the time it takes to load the next bank when the bank is changed.

The value displayed is in milliseconds.

## MIDI Clock - MidiClk

The MIDI clock setting toggles the persistent MIDI clock function ON and OFF. This setting is related to the MIDI Clock message under MIDI Types. If persistent MIDI is ON, the MIDI Clock message will continue sending a MIDI clock signal when engaged, even when engaging other presets or scrolling through banks. However, if persistent MIDI is OFF, the MIDI clock signals will shut off when an event (like a switch press or expression pedal move) is triggered.