

Reset emu

Resetting the EMU type

First we reset the FAN-interface then repeat the steps for resetting the SMU-interface

FAN-interface

- We will reset the FAN so we take the EMU ID “1”
- Then use the “config” command to enter config mode
- Then use the “interface emu 1” command to select the desired interface (FAN-interface)
- Then use the “reset” command then type “y” and press enter to reset the interface

```
WST68(config)#interface emu 1

WST68(config-if-fan-1)#reset
Are you sure to reset this EMU?(y/n) [n]:y
```

Check the status after the reset

Use command “display fan alarm” to check the alarm state of the fan, then use command “quit” to go back to config mode and check the EMU status with command “display emu 1”

<pre>Command: display fan alarm EMU ID: 1 ----- Alarm name Alarm state ----- Read temperature fault Normal Fan block Normal Temperature abnormal Normal Power fault Normal</pre>	<pre>WST68(config-if-fan-1)#quit WST68(config)#display emu 1 EMU ID: 1 ----- EMU name : H801FCBI EMU type : FAN Used or not : Used EMU state : normal Frame ID : 0 Subnode : 1 -----</pre>
--	--