

SMU-interface

- We will reset the SMU so we take the EMU ID “0”
- Use the “config” command to enter config mode
- Then use the “interface emu 0” command to select the EMU-interface

```
NRD44#config
NRD44(config)#interface emu 0
NRD44(config-if-smu-0)#
```

- Now use the “reset” command to reset the SMU

Check the EMU status

Now use command “quit” to go back to config mode

```
NRD44(config-if-smu-0)#quit
NRD44(config)#
```

Wait 30 seconds to 1 minute and use the command “display emu 0” to check the status of the SMU-interface

```
NRD44(config)#display emu 0

  EMU ID: 0
-----
  EMU name   : ETP4830
  EMU type   : SMU
  Used or not : Used
  EMU state   : normal
  Frame ID    : 0
  Subnode     : 0
```