

## Check Alarms

### 2. Alarm handling

#### 1. Check active alarms

- First enter enable mode use the “enable” command
- Use the command “Display alarm active all detail”
- Check the alarm number (in red circle)

```
NRD45>enable
NRD45#
```

```
NRD44#display alarm active all detail

ALARM 35890 FAULT WARNING 0x1541110b ENVIRONMENTAL 2025-06-18 12:19:50-03:00
ALARM NAME : The MDF is abnormal
SRVEFF : NSA
PARAMETERS : FrameID: 0 EMU ID: 0 Digital ID: 10 EMU Type: SMU
              Digital Name: Wiring
DESCRIPTION : The MDF is abnormal(digital parameter monitor)
CAUSE : The main distribution frame (MDF) is abnormal
ADVICE : Install the MDF again
--- END
```