

## SFP status check

- Login to the device (OLT)
- Go into config mode

Select the interface on which the SFP is:

- Command “interface gpon 0/5” (we will work on board 5)

```
ZUD0G(config)#interface gpon 0/5
```

Display the status of the specific SFP (we will work on SFP on port 10)

- Command “display port state 10” press enter two times

```
ZUD0G(config-if-gpon-0/5)# display port state 10  
{ <cr>||<K> }:
```

Read the relevant information you need. Press the space bar until you reach the end of the list.

```
-----  
Port Information  
-----  
F/S/P           0/5/10  
Port state      Online  
Last down cause LOS  
Last up time    2025-10-27 13:43:10-03:00  
Last down time  2025-10-27 13:42:30-03:00  
Port energy-saving flag No  
xPON MAC chipset state Normal  
Signal detect   Normal  
Available bandwidth(Kbps) 1102955  
Illegal rogue ONT Inexistent  
OTDR test status -  
Upstream bandwidth RTU -  
Downstream bandwidth RTU -  
Port RTU        -  
-----  
Optical Module State  
-----  
Optical Module status Online
```