

Bedankt voor de reminder.

Hierbij de stappen voor de emu config.

**Step 1:** Login to device through CLI.

**Step 2:** Run the following commands to go in to Config mode and view the EMU

- MA5600T: enable
- MA5600T: Config
- MA5600T(config): Display EMU 0 (the output below will be received)

```
Command:
      display emu
EMU parameter
```

ID	Type	State	ID	Type	State
0	SMU	normal	1	FAN	normal
2	-	-	3	-	-
4	-	-	5	-	-
6	-	-	7	-	-
8	-	-	9	-	-
10	-	-	11	-	-
12	-	-	13	-	-
14	-	-	15	-	-
16	-	-	17	-	-
18	-	-	19	-	-
20	-	-	21	-	-
22	-	-	23	-	-
24	-	-	25	-	-
26	-	-	27	-	-
28	-	-	29	-	-
30	-	-	31	-	-
32	-	-	33	-	-
34	-	-	35	-	-
36	-	-	37	-	-
38	-	-	39	-	-

**Step3:** Identify the which EMU is for the FAN and which EMU is for SMU (EMU 0 is for SMU and EMU 1 is for fan)

**Step 4:** Delete the EMU with the following commands

- MA5600T(config): emu del 0
- MA5600T(config): emu del 1

Step 5: run the following commands to add the EMU back in the OLT

- MA5600T(config): emu add 0 SMU 00
- MA5600T(config): emu add 1 FAN 0 0

**Step6:** Save the configuration by running the save command.