

Port resetting

6.1 Check port status

To see the status of a specific board and all the ports then use command:

“display board 0/9” display board 9 in frame 0 (we will be working on port 3 of this board)

CLI view

```
NRD25>display board 0/9

-----
Board Name       : H801SCUH
Board Status     : Standby normal
-----

-----
Power Status      Power-off cause      Power-off Time
-----
POWER-ON         -                      -
-----

-----
Port  Port Optic  Native  MDI   Speed   Duplex  Flow-  Active  Link
      Type Status  VLAN                (Mbps)
-----
0  GE   normal    1  -    auto_1000 auto_full off   active  online
1  GE   normal    1  -    auto      auto    off   deactive offline
2  GE   absence   1  -    auto      auto    off   active  offline
3  GE   normal    842 auto  auto    auto    off   active  offline
-----
```

GUI view



6.2 Reset the needed port

6.2.1 Enter config mode and navigate to the interface

First enter config mode then navigate to the interface from which you need to reset the port:

- Command “enable” then command “config”
- Command “interface scu 0/9” (the port is on SCUH board 9)

6.2.2 Resetting the port

6.2.2.1 Shutdown the port

Use the command “shutdown <port number>” - example “shutdown 3”

This will reset port 3 on board 9 of frame 0

CLI view

```
NRD25(config-if-scu-0/9)#shutdown 3
```

After resetting repeat 6.1 to check the board status and all its ports

CLI view

```
RD25(config-if-scu-0/9)#display board 0/9
```

```
-----
Board Name       : H801SCUH
Board Status     : Standby normal
-----

Power Status     Power-off cause           Power-off Time
-----
POWER-ON         -                         -
-----

Port  Port Optic Native MDI  Speed Duplex Flow- Active Link
     Type Status  VLAN      (Mbps)
-----
0  GE  normal    1  -   auto_1000 auto_full off  active online
1  GE  normal    1  -   auto      auto    off  deactive offline
2  GE  absence   1  -   auto      auto    off  active  offline
3  GE  normal    842 auto auto      auto    off  deactive offline
```

GUI view



6.2.2.1 Start the port

To re-enable the port run the following command “undo shutdown 3”

```
NRD25(config-if-scu-0/9)#undo shutdown 3
```

After enabling the port repeat 6.1 to check the board status and all its ports

CLI view

```
NRD25(config-if-scu-0/9)#undo sdisplay board 0/9
```

```
-----
Board Name       : H801SCUH
Board Status      : Standby normal
-----
```

```
-----
Power Status      Power-off cause      Power-off Time
-----
```

```
POWER-ON         -                     -
-----
```

Port	Port Type	Optic Status	Native VLAN	MDI	Speed (Mbps)	Duplex	Flow-Ctrl	Active State	Link
0	GE	normal	1	-	auto_1000	auto_full	off	active	online
1	GE	normal	1	-	auto	auto	off	deactive	offline
2	GE	absence	1	-	auto	auto	off	active	offline
3	GE	normal	842	auto	auto	auto	off	<u>active</u>	offline

GUI view

