

IP CORE MANUAL



AXI4-Stream Upsizer IP

px_axis_pdti_upsizer

PENTEK

Pentek, Inc.
One Park Way
Upper Saddle River, NJ 07458
(201) 818-5900
<http://www.pentek.com/>

Copyright © 2017

Manual Revision History

<u>Date</u>	<u>Version</u>	<u>Comments</u>
06/28/17	1.0	Initial Release

Legal Notices

The information disclosed to you hereunder (the “Materials”) is provided solely for the selection and use of Pentek products. To the maximum extent permitted by applicable law: (1) Materials are made available “AS IS” and with all faults, Pentek hereby DISCLAIMS ALL WARRANTIES AND CONDITIONS, EXPRESS, IMPLIED, OR STATUTORY, INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, OR FITNESS FOR ANY PARTICULAR PURPOSE; and (2) Pentek shall not be liable (whether in contract or tort, including negligence, or under any other theory of liability) for any loss or damage of any kind or nature related to, arising under, or in conjunction with, the Materials (including your use of Materials), including for any direct, indirect, special, incidental, or consequential loss or damage (including loss of data, profits, goodwill, or any type of loss or damage suffered as a result of any action brought by a third party) even if such damage and loss was reasonably foreseeable or Pentek had been advised of the possibility of the same. Pentek assumes no obligation to correct any error contained in the Materials or to notify you of updates to the Materials or to product specifications. You may not reproduce, modify, distribute, or publicly display the materials without prior written consent. Certain products are subject to the terms and conditions of Pentek’s limited warranty, please refer to Pentek’s Ordering and Warranty information which can be viewed at <http://www.pentek.com/contact/customerinfo.cfm>; IP cores may be subject to warranty and support terms contained in a license issued to you by Pentek. Pentek products are not designed or intended to be fail-safe or for use in any application requiring fail-safe performance; you assume sole risk and liability for the use of Pentek products in such critical applications.

Copyright

Copyright © 2017, Pentek, Inc. All Rights Reserved. Contents of this publication may not be reproduced in any form without written permission.

Trademarks

Pentek, Jade, and Navigator are trademarks or registered trademarks of Pentek, Inc.

ARM and AMBA are registered trademarks of ARM Limited. PCI, PCI Express, PCIe, and PCI-SIG are trademarks or registered trademarks of PCI-SIG. Xilinx, Kintex UltraScale, Vivado, and Platform Cable USB are registered trademarks of Xilinx Inc., of San Jose, CA.

Table of Contents

Page

IP Facts

Description.....	5
Features.....	5
Table 1-1: IP Facts Table.....	5

Chapter 1: Overview

1.1	Functional Description	7
	Figure 1-1: AXI4-Stream Upsizer Core Block Diagram.....	7
1.2	Applications.....	7
1.3	System Requirements	8
1.4	Licensing and Ordering Information	8
1.5	Contacting Technical Support	8
1.6	Documentation.....	8

Chapter 2: General Product Specifications

2.1	Standards	9
2.2	Performance.....	9
2.2.1	Maximum Frequencies	9
2.3	Resource Utilization	9
	Table 2-1: Resource Usage and Availability.....	9
2.4	Limitations and Unsupported Features.....	9
2.5	Generic Parameters.....	10
	Table 2-2: Generic Parameters	10

Chapter 3: Port Descriptions

3.1	AXI4-Stream Core Interfaces.....	11
3.1.1	Combined Sample Data/ Timestamp/ Information Streams (PDTI) Interface	11
	Table 3-1: Combined Sample Data/ Timestamp/ Information Streams	
	Interface Port Descriptions	11

Table of Contents

Page

Chapter 4: Designing with the Core

4.1	General Design Guidelines	15
4.2	Clocking	15
4.3	Resets	15
4.4	Interrupts	15
4.5	Interface Operation.....	15
4.6	Programming Sequence	15
4.7	Timing Diagrams	16

Chapter 5: Design Flow Steps

	Figure 5-1: AXI4-Stream Upsizer Core in Pentek IP Catalog.....	17
	Figure 5-2: AXI4-Stream Upsizer Core IP Symbol	18
5.2	User Parameters	18
5.3	Generating Output.....	18
5.4	Constraining the Core	19
5.5	Simulation	20
	Figure 5-3: AXI4-Stream Upsizer Core Test Bench Simulation Output.....	20
5.6	Synthesis and Implementation	20

IP Facts

Description

Pentek's Navigator™ AXI4-Stream Upsizer Core upsizes the number of samples-per-clock cycle in the input AXI4-Streams.

This core complies with the ARM® AMBA® AXI4 Specification and also provides a control/status register interface. This user manual defines the hardware interface, software interface, and parameterization options for the AXI4-Stream Upsizer Core.

Features

- Software programmable number of input and output samples-per-clock-cycle
- Software programmable number of bytes-per-sample

Table 1-1: IP Facts Table	
Core Specifics	
Supported Design Family ^a	Kintex® Ultrascale
Supported User Interfaces	AXI4-Stream
Resources	See Table 2-1
Provided with the Core	
Design Files	VHDL
Example Design	Not Provided
Test Bench	VHDL
Constraints File	Not Provided ^b
Simulation Model	VHDL
Supported S/W Driver	HAL Software Support
Tested Design Flows	
Design Entry	Vivado® Design Suite 2016.4 or later
Simulation	Vivado VSim
Synthesis	Vivado Synthesis
Support	
Provided by Pentek fpgasupport@pentek.com	

a.For a complete list of supported devices, see the [Vivado Design Suite Release Notes](#).

b.Clock constraints can be applied at the top level module of the user design.

This page is intentionally blank

Chapter 1: Overview


1.1 Functional Description

The AXI4-Stream Upsizer Core accepts a combined Sample Data/ Timestamp/ Information AXI4-Stream, which includes sample data, timestamp with a time-aligned copy of the timing events (gate, sync, PPS), and data information (see [Section 3.1](#)). This core upsizes the number of samples-per-clock-cycle in the input data streams to match the required number of output samples-per-clock-cycle defined by the user using the generic parameters (See [Section 2.5](#)).

The AXI4-Stream Upsizer Core uses the [Xilinx®](#) Width Converter IP block to implement the upsize operation on the input AXI4-Streams.

[Figure 1-1](#) is a top-level block diagram of the Pentek AXI4-Stream Upsizer Core. The modules within the block diagram are explained in the later sections of this manual.

Figure 1-1: AXI4-Stream Upsizer Core Block Diagram



- ❑ **AXI4-Stream Interface:** The AXI4-Stream Upsizer Core has two AXI4-Stream Interfaces. At the input, an AXI4-Stream Slave Interface is used to receive input AXI4-Streams and at the output an AXI4-Stream Master Interface is used to transfer AXI4-Streams through the output ports. For more details about the AXI4-Stream Interfaces please refer to [Section 3.1 AXI4-Stream Core Interfaces](#).

1.2 Applications

The AXI4-Stream Upsizer Core can be incorporated into any Kintex Ultrascale FPGA where the number of samples-per-clock-cycle in the input AXI4-Stream must be increased to a user-defined value.

1.3 System Requirements

For a list of system requirements, see the [Vivado Design Suite Release Notes](#).

1.4 Licensing and Ordering Information

This core is included with all Pentek Navigator FPGA Design Kits for Pentek Jade series board products. Contact Pentek for Licensing and Ordering Information (www.pentek.com).

1.5 Contacting Technical Support

Technical Support for Pentek's Navigator FPGA Design Kits is available via e-mail (fpgasupport@pentek.com) or by phone (201-818-5900 ext. 238, 9 am to 5 pm EST).

1.6 Documentation

This user manual is the main document for this IP core. The following documents provide supplemental material:

- 1) [Vivado Design Suite User Guide: Designing with IP](#)
- 2) [Vivado Design Suite User Guide: Programming and Debugging](#)
- 3) [ARM AMBA AXI4 Protocol Version 2.0 Specification](#)
<http://www.arm.com/products/system-ip/amba-specifications.php>

Chapter 2: General Product Specifications

2.1 Standards

The AXI4-Stream Upsizer Core has bus interface that complies with the [ARM AMBA AXI4-Stream Protocol Specification](#).

2.2 Performance

The performance of the AXI4-Stream Upsizer Core is limited only by the FPGA logic speed. The values presented in this section should be used as an estimation guideline. Actual performance can vary.

2.2.1 Maximum Frequencies

The AXI4-Stream Upsizer Core has an incoming clock signals, the AXI4-Stream clock that has a maximum frequency of 500 MHz on a Kintex Ultrascale -2 speed grade FPGA.

2.3 Resource Utilization

The resource utilization of the AXI4-Stream Upsizer Core is shown in [Table 2-1](#). Resources have been estimated for the Kintex Ultrascale XCKU060 -2 speed grade device. These values were generated using the Vivado Design Suite.

Table 2-1: Resource Usage and Availability	
Resource	# Used
LUTs	73
Flip-Flops	504

NOTE: Actual utilization may vary based on the user design in which the AXI4-Stream Upsizer Core is incorporated.

2.4 Limitations and Unsupported Features

This section is not applicable to this IP core.

2.5 Generic Parameters

The generic parameters of the AXI4-Stream Upsizer Core are described in [Table 2-2](#). These parameters can be set as required by the user application while customizing the core.

Table 2-2: Generic Parameters		
Port/Signal Name	Type	Description
bytes_per_sample	Integer	Bytes Per Sample: This parameter indicates the number of bytes-per-sample in the input data stream. It can take values 1, 2, and 4.
in_samples_per_cycle		Input Samples Per Cycle: This parameter indicates the number of samples present per-clock-cycle in the input data stream. It can take the values 1,2, and 4.
out_samples_per_cycle		Output Samples Per Cycle: This parameter indicates the number of samples-per-clock-cycle required in the output data stream. It can take the values 2,4, and 8. The number of output samples-per-clock-cycle must be greater than the number of input samples-per-clock-cycle.
has_tready	Boolean	Has Data Ready: When True, this parameter indicates that this core generates a ready output to the AXI Master in the user design transferring the input AXI4-Stream, and also accepts a data ready signal from an AXI Slave in the user design receiving the output data stream.

Chapter 3: Port Descriptions

This chapter provides details about the port descriptions for the following interface types:

- [AXI4-Stream Core Interfaces](#)

3.1 AXI4-Stream Core Interfaces

The AXI4-Stream Upsizer Core has the following AXI4-Stream Interfaces, used to receive and transfer data streams.

- Combined Sample Data/ Timestamp/ Information Stream (PDTI) Interface: This core implements two of these AXI4-Stream interfaces across the input and output to receive and transfer AXI4-Streams.

3.1.1 Combined Sample Data/ Timestamp/ Information Streams (PDTI) Interface

The Pentek Jade series board products have AXI4-Streams that follow a combined sample data/ Timestamp/ Information Stream format. This type of data stream combines sample data with its time-aligned timestamp and data information. There is an AXI4-Stream Slave Interface across the input to receive AXI4-Streams and an AXI4-Stream Master Interface across the output to transfer AXI4-Streams.

[Table 3-1](#) defines the ports in the AXI4-Stream Slave and Master Combined Sample Data/ Timestamp/ Information Stream Interfaces. See the [AMBA AXI4-Stream Specification](#) for more details on the operation of the AXI4-Stream Interface..

Table 3-1: Combined Sample Data/ Timestamp/ Information Streams Interface Port Descriptions			
Port	Direction	Width	Description
AXI4-Stream Slave Interface			
axis_aclk	Input	1	AXI4-Stream Clock
axis_aresetn			Reset: Active Low.
s_axis_pdti_tdata		depends on the generic parameters bytes_per_sample and in_samples_per_cycle	Input Data: This is the input data stream.

Table 3-1: Combined Sample Data/ Timestamp/ Information Streams Interface Port Descriptions (Continued)			
Port	Direction	Width	Description
AXI4-Stream Slave Interface (continued)			
s_axis_pdti_tvalid	Input	1	Input Data Valid: Asserted when data is valid on s_axis_pdti_tdata .
s_axis_pdti_tuser		128	Sideband Information: This is the user defined sideband information received alongside the data stream. tuser [63:0] - Timestamp[63:0] tuser [71:64] - Gate Positions tuser [79:72] - Sync Positions tuser [87:80] - PPS Positions tuser [92:88] - Samples per clock cycle tuser [94:93] - Data Format => 0 = 8-bit; 1 = 16-bit; 2 = 24-bit; 3 = 32-bit tuser [95] - Data Type => 0 = Real; 1 = I/Q tuser [103:96] - channel [7:0] tuser [127:104] - Reserved Note: The bits [103:96] define the channel number in the user design from where the data is being received.
s_axis_pdti_tready	Output	1	Output Data Ready: This signal is asserted by the AXI4-Stream Upsizer Core when it is ready to accept data from the user logic. This output can be enable by setting the generic parameter has_tready to True.
AXI4-Stream Master Interface			
m_axis_pdti_tdata	Output	depends on the generic parameters bytes_per_sample and out_sample_per_cycle	Output Data: This is the output data from the AXI4-Stream Upsizer Core.

Table 3-1: Combined Sample Data/ Timestamp/ Information Streams Interface Port Descriptions (Continued)			
Port	Direction	Width	Description
m_axis_pdti_tvalid	Output	1	Output Data Valid: Asserted when data is valid on m_axis_pdti_tdata .
m_axis_pdti_tuser		128	<p>Output Sideband Information: This is the user defined sideband information transmitted alongside the data stream.</p> <p>tuser [63:0] - Timestamp[63:0] tuser [71:64] - Gate Positions tuser [79:72] - Sync Positions tuser [87:80] - PPS Positions tuser [92:88] - Samples per clock cycle tuser [94:93] - Data Format => 0 = 8-bit; 1 = 16-bit; 2 = 24-bit; 3 = 32-bit</p> <p>tuser [95] - Data Type => 0 = Real; 1 = I/Q tuser [103:96] - channel [7:0] tuser [127:104] - Reserved</p> <p>Note: The bits [103:96] define the channel number in the user design from where the data is being received.</p>
m_axis_pdti_tready	Input	1	<p>Input Data Ready: This is an optional input ready signal to the core. When asserted, this signal indicates that the user logic is ready to accept data. Data is transferred across the interface when both m_axis_pdti_tvalid and m_axis_pdti_tready are High in the same cycle. If the user application deasserts the ready signal when m_axis_pdti_tvalid is High, the core maintains the data on the bus and keeps valid signal asserted until the user application has asserted the ready signal. This input signal to the core is enabled by setting the generic parameter has_tready to True. When this input is disabled the ready signal is set to 1 internally by the core.</p>

This page is intentionally blank

Chapter 4: Designing with the Core

This chapter includes guidelines and additional information to facilitate designing with the AXI4-Stream Upsizer Core.

4.1 General Design Guidelines

The AXI4-Stream Upsizer Core provides the required logic to generate an AXI4-Stream output that has the user-defined number of samples-per-clock-cycle.

4.2 Clocking

AXI4-Stream Clock: **axis_aclk**

This clock is used to clock all ports in the AXI4-Stream Upsizer Core.

4.3 Resets

Main reset: **axis_aresetn**

This is an active low reset synchronous with **s_axis_aclk**.

4.4 Interrupts

This section is not applicable to this IP core.

4.5 Interface Operation

Combined Sample Data/ Timestamp/ Information Streams (PDTI) Interfaces: This core implements two of these AXI4-Stream interfaces across the input and output to receive, and transfer AXI PDTI streams, and is associated with **axis_aclk**. For more details about this interface please refer to [Section 3.1.1](#).

4.6 Programming Sequence

This section is not applicable to this IP core.

4.7 Timing Diagrams


The timing diagrams for the AXI4-Stream Upsizer Core are obtained by running the simulation of the test bench of the core in Vivado VSim environment. For more details about the test bench, refer to [Section 5.5](#).

Chapter 5: Design Flow Steps

5.1 Pentek IP Catalog

This chapter describes customization and generation of the Pentek AXI4-Stream Upsizer Core. It also includes simulation, synthesis, and implementation steps that are specific to this IP core. This core can be generated from the Vivado IP Catalog when the Pentek IP Repository has been installed. It will appear in the IP Catalog list as **px_axis_pdti_upsizer_v1_0** as shown in [Figure 5-1](#).


Figure 5-1: AXI4-Stream Upsizer Core in Pentek IP Catalog



5.1 Pentek IP Catalog (continued)

When you select the **px_axis_pdti_upsizer_v1_0** core, a screen appears that shows the core's symbol and the core's parameters (see [Figure 5-2](#)). The core's symbol is the box on the left side.

Figure 5-2: AXI4-Stream Upsizer Core IP Symbol



5.2 User Parameters

The user parameters of this IP core are described in [Section 2.5](#) of this user manual.

5.3 Generating Output

For more details about generating and using IP in the Vivado Design Suite, refer to the [Vivado Design Suite User Guide - Designing with IP](#).

5.4 Constraining the Core

This section contains information about constraining the AXI4-Stream Upsizer Core in Vivado Design Suite.

Required Constraints

The XDC constraints are not provided with the AXI4-Stream Upsizer Core. Clock constraints can be applied in the top-level module of the user design.

Device, Package, and Speed Grade Selections

This IP works for the Kintex Ultrascale FPGAs.

Clock Frequencies

The AXI4-Stream clock (**axis_aclk**) has a maximum frequency of 500 MHz.

Clock Management

This section is not applicable for this IP core.

Clock Placement

This section is not applicable for this IP core.

Banking and Placement

This section is not applicable for this IP core.

Transceiver Placement

This section is not applicable for this IP core.

I/O Standard and Placement


This section is not applicable for this IP core.

5.5 Simulation

The AXI4-Stream Upsizer Core has a test bench which generates output waveforms using the Vivado VSim environment. The test bench is designed to run at 250 MHz AXI4-Stream clock frequency. The testbench is set to have input data with 2 bytes-per-sample, and generate 2 samples-per-cycle output data streams from single-sample-per-cycle input data streams.

The input data is generated by incrementing counter. When run, the simulation produces the results shown in [Figure 5-3](#).

Figure 5-3: AXI4-Stream Upsizer Core Test Bench Simulation Output



5.6 Synthesis and Implementation

For details about synthesis and implementation see the [Vivado Design Suite User Guide - Designing with IP](#).