

IP CORE MANUAL



Vector Delay IP

px_vctr_dly

PENTEK

Pentek, Inc.
One Park Way
Upper Saddle River, NJ 07458
(201) 818-5900
<http://www.pentek.com/>

Copyright © 2016

Manual Revision History

| <u>Date</u> | <u>Version</u> | <u>Comments</u> |
|--------------------|-----------------------|------------------------|
| 12/09/16 | 1.0 | Initial Release |

Legal Notices

The information disclosed to you hereunder (the “Materials”) is provided solely for the selection and use of Pentek products. To the maximum extent permitted by applicable law: (1) Materials are made available “AS IS” and with all faults, Pentek hereby DISCLAIMS ALL WARRANTIES AND CONDITIONS, EXPRESS, IMPLIED, OR STATUTORY, INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, OR FITNESS FOR ANY PARTICULAR PURPOSE; and (2) Pentek shall not be liable (whether in contract or tort, including negligence, or under any other theory of liability) for any loss or damage of any kind or nature related to, arising under, or in conjunction with, the Materials (including your use of Materials), including for any direct, indirect, special, incidental, or consequential loss or damage (including loss of data, profits, goodwill, or any type of loss or damage suffered as a result of any action brought by a third party) even if such damage and loss was reasonably foreseeable or Pentek had been advised of the possibility of the same. Pentek assumes no obligation to correct any error contained in the Materials or to notify you of updates to the Materials or to product specifications. You may not reproduce, modify, distribute, or publicly display the materials without prior written consent. Certain products are subject to the terms and conditions of Pentek’s limited warranty, please refer to Pentek’s Ordering and Warranty information which can be viewed at <http://www.pentek.com/contact/customerinfo.cfm>; IP cores may be subject to warranty and support terms contained in a license issued to you by Pentek. Pentek products are not designed or intended to be fail-safe or for use in any application requiring fail-safe performance; you assume sole risk and liability for the use of Pentek products in such critical applications.

Copyright

Copyright © 2016, Pentek, Inc. All Rights Reserved. Contents of this publication may not be reproduced in any form without written permission.

Trademarks

Pentek, Jade, and Navigator are trademarks or registered trademarks of Pentek, Inc.

ARM and AMBA are registered trademarks of ARM Limited. PCI, PCI Express, PCIe, and PCI-SIG are trademarks or registered trademarks of PCI-SIG. Xilinx, Kintex UltraScale, Vivado, and Platform Cable USB are registered trademarks of Xilinx Inc., of San Jose, CA.

Table of Contents

Page

IP Facts

| | |
|---------------------------------------|----------|
| Description..... | 5 |
| Features..... | 5 |
| Table 1-1: IP Facts Table..... | 5 |

Chapter 1: Overview

| | | |
|-----|---|----------|
| 1.1 | Functional Description | 7 |
| | Figure 1-1: Vector Delay Core Block Diagram..... | 7 |
| 1.2 | Applications..... | 7 |
| 1.3 | System Requirements | 7 |
| 1.4 | Licensing and Ordering Information | 7 |
| 1.5 | Contacting Technical Support | 8 |
| 1.6 | Documentation..... | 8 |

Chapter 2: General Product Specifications

| | | |
|-------|--|-----------|
| 2.1 | Standards | 9 |
| 2.2 | Performance..... | 9 |
| 2.2.1 | Maximum Frequencies | 9 |
| 2.3 | Resource Utilization | 9 |
| | Table 2-1: Pentek Vector Delay Core - Resource Usage and Availability | 9 |
| 2.4 | Limitations and Unsupported Features..... | 9 |
| 2.5 | Generic Parameters..... | 10 |
| | Table 2-2: Generic Parameters | 10 |

Chapter 3: Port Descriptions

| | | |
|-----|------------------------------------|-----------|
| 3.1 | I/O Signals | 11 |
| | Table 3-1: I/O Signals..... | 11 |

Chapter 4: Designing with the Core

| | | |
|-----|--------------------------------|----|
| 4.1 | General Design Guidelines..... | 13 |
| 4.2 | Clocking..... | 13 |
| 4.3 | Resets..... | 13 |
| 4.4 | Interrupts..... | 13 |

Table of Contents

 Page

Chapter 4: Designing with the Core (continued)

| | | |
|-----|----------------------------|----|
| 4.5 | Interface Operation..... | 13 |
| 4.6 | Programming Sequence | 13 |
| 4.7 | Timing Diagrams | 13 |

Chapter 5: Design Flow Steps

| | | |
|-----|--|-----------|
| | Figure 5-1: Vector Delay Core in Pentek IP Catalog..... | 15 |
| | Figure 5-2: Vector Delay Core IP Symbol..... | 16 |
| 5.2 | User Parameters | 16 |
| 5.3 | Generating Output..... | 16 |
| 5.4 | Constraining the Core | 17 |
| 5.5 | Simulation | 17 |
| 5.6 | Synthesis and Implementation | 17 |

IP Facts

Description

Pentek's Navigator™ Vector Delay Core is used to introduce user-defined delay to the input vector.

This user manual defines the hardware interface, software interface, and parameterization options for the Vector Delay Core.

Features

- User can introduce an input delay of up to 4096 clock cycles
- User-programmable width of input vector
- Supports clock enable and synchronous reset inputs

| Table 1-1: IP Facts Table | |
|---|--------------------------------------|
| Core Specifics | |
| Supported Design Family ^a | Kintex® Ultrascale |
| Supported User Interfaces | N/A |
| Resources | See Table 2-1 |
| Provided with the Core | |
| Design Files | VHDL |
| Example Design | Not Provided |
| Test Bench | Not Provided |
| Constraints File | Not Provided ^b |
| Simulation Model | N/A |
| Supported S/W Driver | N/A |
| Tested Design Flows | |
| Design Entry | Vivado® Design Suite 2016.3 or later |
| Simulation | Vivado VSim |
| Synthesis | Vivado Synthesis |
| Support | |
| Provided by Pentek fpgasupport@pentek.com | |

a.For a complete list of supported devices, see the [Vivado Design Suite Release Notes](#).

b.Clock constraints can be applied at the top level module of the user design.


This page is intentionally blank

Chapter 1: Overview

1.1 Functional Description

The Vector Delay Core generates an output vector from the input vector after introducing the required delay. The delay and width of the input vector can be defined by the user through the generic parameters as described in [Section 2.5](#). [Figure 1-1](#) is a top-level block diagram of the Pentek Vector Delay Core with input Vector A having a width of M bits and input Vector B having a width of N bits.

Figure 1-1: Vector Delay Core Block Diagram



1.2 Applications

The Vector Delay Core can be incorporated into any Kintex Ultrascale FPGA to introduce delay to the input vector.

1.3 System Requirements

For a list of system requirements, see the [Vivado Design Suite Release Notes](#).

1.4 Licensing and Ordering Information

This core is included with all Pentek Navigator FPGA Design Kits for Pentek Jade series board products. Contact Pentek for Licensing and Ordering Information (www.pentek.com).

1.5 Contacting Technical Support

Technical Support for Pentek's Navigator FPGA Design Kits is available via e-mail (fpgasupport@pentek.com) or by phone (201-818-5900 ext. 238, 9 am to 5 pm EST).

1.6 Documentation

This user manual is the main document for this IP core. The following documents provide supplemental material:

- 1) [*Vivado Design Suite User Guide: Designing with IP*](#)
- 2) [*Vivado Design Suite User Guide: Programming and Debugging*](#)

Chapter 2: General Product Specifications

2.1 Standards

This section is not applicable to this IP core.

2.2 Performance

The performance of the Vector Delay Core is limited only by the FPGA logic speed. The values presented in this section should be used as an estimation guideline, actual performance can vary.

2.2.1 Maximum Frequencies

The Vector Delay Core has a maximum operating frequency of 700 MHz on a Kintex Ultrascale -2 speed grade FPGA.

2.3 Resource Utilization

The resource utilization for the Vector Delay Core is shown in [Table 2-1](#). Resources have been estimated for the Kintex Ultrascale XCKU060 -2 speed grade device. These values were generated using Vivado Design Suite.

| Table 2-1: Pentek Vector Delay Core - Resource Usage and Availability | |
|---|--------|
| Resource | # Used |
| LUTs | 16 |
| Flip-Flops | 64 |
| Memory LUTs | 16 |

NOTE: Actual utilization may vary based on the user design in which the Vector Delay Core is incorporated.

2.4 Limitations and Unsupported Features

This section is not applicable to this IP core.

2.5 Generic Parameters

The generic parameters of the Vector Delay Core are described in [Table 2-2](#). These parameters can be set as required by the user application while customizing the core.

| Table 2-2: Generic Parameters | | |
|-------------------------------|---------|---|
| Port/Signal Name | Type | Description |
| width | Integer | Vector Width: This parameter defines the width of the input vector to the core. It can range from 1 to 1024 bits. |
| delay | | Delay: This parameter defines the delay to be introduced to the input of the core. It can range from 1 to 4096 clock cycles. |
| has_ce | Boolean | Has Clock Enable: This parameter indicates if there is a clock enable input to the core. |
| has_rst | | Has Synchronous Reset: This parameter indicates if there is a synchronous reset input to the core. |

Chapter 3: Port Descriptions

This chapter provides details about the port descriptions for the following interface types:

- [I/O Signals](#)

3.1 I/O Signals

The I/O port/signal descriptions of the top level module of the Vector Delay Core are discussed in [Table 3-1](#).

| Table 3-1: I/O Signals | | | |
|------------------------|------------------|-----------|---|
| Port/ Signal Name | Type | Direction | Description |
| din[width-1:0] | std_logic_vector | Input | Input Vector: This is the input vector to the core. |
| clk | std_logic | | Clock: This is clock input to the core. |
| rst_n | | | Synchronous Reset: This is the synchronous reset input to the core when the generic parameter has_rst is set to True. Active Low. |
| ce | | | Clock Enable: This is the clock enable input to the core when the generic parameter has_ce is set to True. |
| dout[width-1:0] | std_logic_vector | Output | Output Vector: This is the output vector of the core. |

This page is intentionally blank

Chapter 4: Designing with the Core

This chapter includes guidelines and additional information to facilitate designing with the Vector Delay Core.

4.1 General Design Guidelines

The Vector Delay Core can generate an output vector from the input vector after adding the required delay. The user can customize the core to introduce the required delay by defining the generic parameters are described in [Section 2.5](#).

4.2 Clocking

Main Clock: **clk**

This input clock signal is used to clock all the ports in the Vector Delay Core.

4.3 Resets

Optional Synchronous Reset Input:

This is an active low reset input synchronous with the main clock (**clk**) signal.

4.4 Interrupts

This section is not applicable to this IP core.

4.5 Interface Operation

This section is not applicable to this IP core.

4.6 Programming Sequence

This section is not applicable to this IP core.

4.7 Timing Diagrams

This section is not applicable to this IP core.


This page is intentionally blank

Chapter 5: Design Flow Steps

5.1 Pentek IP Catalog

This chapter describes customization and generation of the Pentek Vector Delay Core. It also includes simulation, synthesis, and implementation steps that are specific to this IP core. This core can be generated from the Vivado IP Catalog when the Pentek IP Repository has been installed. It will appear in the IP Catalog list as **px_vctr_dly_v1_0** as shown in [Figure 5-1](#).


Figure 5-1: Vector Delay Core in Pentek IP Catalog



5.1 Pentek IP Catalog (continued)

When you select the **px_vctr_dly_v1_0** core, a screen appears that shows the core's symbol and the core's parameters (see [Figure 5-2](#)). The core's symbol is the box on the left side.

Figure 5-2: Vector Delay Core IP Symbol



5.2 User Parameters

The user parameters of this core are described in [Section 2.5](#) of this user manual.

5.3 Generating Output

For more details about generating and using IP in the Vivado Design Suite, refer to the [Vivado Design Suite User Guide - Designing with IP](#).

5.4 Constraining the Core

This section contains information about constraining the Vector Delay Core in Vivado Design Suite.

Required Constraints

This section is not applicable to this IP core.

Device, Package, and Speed Grade Selections

This IP works for the Kintex Ultrascale FPGAs.

Clock Frequencies

The maximum input clock frequency (**clk**) for this IP core is 700 MHz.

Clock Management

This section is not applicable for this IP core.

Clock Placement

This section is not applicable for this IP core.

Banking and Placement

This section is not applicable for this IP core.

Transceiver Placement

This section is not applicable for this IP core.

I/O Standard and Placement

This section is not applicable for this IP core.

5.5 Simulation

This section is not applicable to this IP core.

5.6 Synthesis and Implementation

For details about synthesis and implementation see the [Vivado Design Suite User Guide - Designing with IP](#).

This page is intentionally blank